Washing Machine

۲

User manual

WW**CGC*****/WW1*DG*****/WW1*DE*

SAMSUNG

۲

۲

Contents

Safety information	4
What you need to know about the safety instructions	4
Important safety symbols	4
Important safety precautions	5
Critical installation warnings	6
Installation cautions	8
Critical usage warnings	8
Usage cautions	9
Critical cleaning warnings	12
Instructions about the WEEE	13
Ecodesign	13
Installation	14
What's included	14
Installation requirements	16
Step-by-step installation	18
Before you start	28
Initial settings	28
Laundry guidelines	28
Detergent recommendation	32 33
Detergent drawer guidelines	55
Operations	36
Control panel	36
Simple steps to start	38
Cycle overview	39
Settings	43
Special features	44
SmartThings	45
Open Source Announcement	46
Maintenance	47
DRUM CLEAN / DRUM CLEAN+	47
Emergency drain	48
Cleaning	49
Recovery from freezing	52
Care against an extended time of disuse	52
J	52

۲

2 English —

۲

۲

Troubleshooting	53
Checkpoints	53
Information codes	57
Specifications	59
Fabric care chart	59
Protecting the environment	61
Spare parts guarantee	61
Specification sheet	62
EPREL information	64
Indicative information (According to EU 2019/2023)	64
Contact information	66
OUESTIONS OR COMMENTS?	66

۲

۲

۲

Safety information

Congratulations on your new Samsung washing machine. This manual contains important information on the installation, use and care of your appliance. Please take some time to read this manual to take full advantage of your washing machine's many benefits and features.

()

What you need to know about the safety instructions

Please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance. Please store the manual in a safe location close to the appliance for future reference. Use this appliance only for its intended purpose as described in this instruction manual.

Warnings and Important Safety Instructions in this manual do not cover all possible conditions and situations that may occur. It is your responsibility to use common sense, caution and care when installing, maintaining and operating your washing machine.

Because the following operating instructions cover various models, the characteristics of your washing machine may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service centre or find help and information online at www.samsung.com.

Important safety symbols

What the icons and signs in this user manual mean:

(�)

Hazards or unsafe practices that may result in severe personal injury, death and/or property damage.

Hazards or unsafe practices that may result in personal injury and/or property damage.

NOTE

Indicates that a risk of personal injury or material damage exists.

III Read the instructions

These warning signs are here to prevent injury to yourself and others.

Please follow them explicitly.

After reading this manual, store it in a safe place for future reference.

Read all instructions before using the appliance.

As with any equipment that uses electricity and moving parts, potential hazards exist. To safely operate this appliance, familiarize yourself with its operation and exercise care when using it.

Important safety precautions

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

۲

- This appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2. For use in Europe: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **3.** Children should be supervised to ensure that they do not play with the appliance.
- **4.** If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 5. The new hose-sets supplied with the appliance are to be used and old hose-sets should not be reused.

()

Safety information

- **6.** For appliances with ventilation openings in the base, a carpet must not obstruct the openings.
- 7. For use in Europe: Children of less than 3 years should be kept away unless continuously supervised.
- 8. CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- **9.** This appliance is intended to be used in household only and it is not intended to be used such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - areas for communal use in blocks of flats or in launderettes.

Critical installation warnings

()

The installation of this appliance must be performed by a qualified technician or service company.

• Failure to do so may result in electric shock, fire, an explosion, problems with the appliance, or injury.

The appliance is heavy, therefore take care when lifting it.

Plug the power cord firmly into a wall socket that meets local electrical specifications. Use the socket for this appliance only, and do not use an extension cord.

- Sharing a wall socket with other appliances using a power strip or extending the power cord may result in electric shock or fire.
- Ensure that the power voltage, frequency, and current are the same as those of the product specifications. Failure to do so may result in electric shock or fire.
- 6 English

Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis.

۲

- Unplug the power plug and clean it with a dry cloth.
- Failure to do so may result in electric shock or fire.

Plug the power plug into the wall socket so that the cord is running towards the floor.

If you plug the power plug into the socket in the opposite direction, the electric wires within the cable
may be damaged and this may result in electric shock or fire.

Keep all packaging materials out of the reach of children as these may be dangerous.

• If a child places a bag over its head, it may suffocate.

When the appliance, power plug or power cord is damaged, contact your nearest service centre.

This appliance must be properly grounded.

Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.

- This may result in electric shock, fire, an explosion, or problems with the appliance.
- Never plug the power cord into a socket that is not grounded correctly and make sure that it is in
 accordance with local and national regulations.

Do not install this appliance near a heater or any inflammable material.

Do not install this appliance in a humid, oily or dusty location, or in a location exposed to direct sunlight or water (rain drops).

Do not install this appliance in a location exposed to low temperatures.

• Frost may cause the tubes to burst.

Do not install this appliance in a location where gas may leak.

• This may result in electric shock or fire.

Do not use an electric transformer.

• This may result in electric shock or fire.

Do not use a damaged power plug, damaged power cord, or loose wall socket.

• This may result in electric shock or fire.

Do not pull or excessively bend the power cord.

Do not twist or tie the power cord.

Do not hook the power cord over a metal object, place a heavy object on the power cord, insert the power cord between objects, or push the power cord into the space behind the appliance.

• This may result in electric shock or fire.

Do not pull the power cord when unplugging the power plug.

- Unplug the power plug by holding the plug.
- Failure to do so may result in electric shock or fire.

This appliance should be positioned so that the power plug, the water supply taps, and the drain pipes are accessible.

(�)

 (\bullet)

Safety information

Following the repair by a non-authorized service provider, self-repair or non-professional repair of the product, Samsung is not liable for any damage to the product, any injury or any other product safety issue caused by any attempt to repair the product which does not carefully follow these repair and maintenance instructions. Any damage to the product caused by an attempt to repair the product by any person other than a Samsung certified service provider will not be covered by the warranty.

Installation cautions

This appliance should be positioned in such a way that the power plug is easily accessible.

• Failure to do so may result in electric shock or fire due to electric leakage.

Install your appliance on a solid, level floor that can support its weight.

• Failure to do so may result in abnormal vibrations, movement, noise, or problems with the appliance.

Critical usage warnings

(�)

If the appliance is flooded, turn off the water & power supplies immediately and contact your nearest service centre.

- Do not touch the power plug with wet hands.
- Failure to do so may result in electric shock.

If the appliance generates a strange noise, a burning smell, or smoke, unplug the power cord immediately and contact your nearest service centre.

• Failure to do so may result in electric shock or fire.

In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power plug. Do not touch the appliance or power cord.

- Do not use a ventilating fan.
- A spark may result in an explosion or fire.

Remove the washing machine door lever before disposing the appliance.

• If trapped inside the appliance, children may suffocate to death.

Make sure to remove the packaging (sponge, styrofoam) attached to the bottom of the washing machine before using it.

Do not wash items contaminated with gasoline, kerosene, benzene, paint thinner, alcohol or other inflammable or explosive substances.

• This may result in electric shock, fire, or an explosion.

Do not open the washing machine door by force while it is operating (high-temperature washing/drying/ spinning).

()

- Water flowing out of the washing machine may result in burns or cause the floor to be slippery. This may result in injury.
- Opening the door by force may result in damage to the appliance or injury.

Do not touch the power plug with wet hands.

• This may result in electric shock.

Do not turn the appliance off by unplugging the power cord while an operation is in progress.

• Plugging the power cord into the wall socket again may cause a spark and result in electric shock or fire.

Do not let children climb in or onto the appliance.

• This may result in electric shock, burns or injury.

Do not put your hand under the washing machine.

• You may injure your hand on rotating or sharp (metal or plastic, etc.) parts.

Do not unplug the appliance by pulling the power cord. Always grip the plug firmly and pull it straight out of the outlet.

• Damage to the power cord may cause a short-circuit, fire and/or electric shock.

Do not attempt to repair, disassemble, or modify the appliance yourself.

- Do not use a fuse (such as copper, steel wire, etc.) other than a standard fuse.
- When the appliance needs to be repaired or reinstalled, contact your nearest service centre.
- Failure to do so may result in electric shock, fire, problems with the appliance, or injury.

If the water supply hose comes loose from the water tap and floods the appliance, unplug the power cord.

• Failure to do so may result in electric shock or fire.

Unplug the power cord when the appliance is not being used for long periods of time or during a thunder or lightning storm.

• Failure to do so may result in electric shock or fire.

If any foreign substance enters into the appliance, unplug the power cord and contact your nearest Samsung Customer Service.

• This may result in electric shock or fire.

Do not let children (or pets) play in or on your washing machine. The washing machine door does not open easily from the inside and children may be seriously injured if trapped inside.

Usage cautions

When the washing machine is contaminated by a foreign substance such as detergent, dirt, food waste, etc., unplug the power cord and clean the washing machine using a damp, soft cloth.

• Failure to do so may result in discolouration, deformation, damage, or rust.

(�)

Safety information

The front glass may be broken by a strong impact. Take care when using the washing machine.

• If the glass is broken, it may result in injury.

Open the water tap slowly after a long period of non-use, water supply failure, or when reconnecting the water supply hose.

()

• The air pressure in the water supply hose or the water pipe may damage a part of the appliance or result in a water leak.

If a draining error occurs during an operation, check if there is a draining problem.

 If the washing machine is used when it is flooded because of a draining problem, it may result in electric shock or fire.

Insert the laundry into the washing machine completely so that the laundry does not get caught in the door.

• If laundry gets caught in the door, it may result in damage to the laundry or the washing machine, or result in a water leak.

Turn the water supply off when the washing machine is not being used.

• Ensure that the screws on the water supply hose connector are properly tightened.

Ensure that the rubber seal and front door glass are not contaminated by a foreign substance (e.g. waste, thread, hair, etc.).

• If a foreign substance is caught in the door or the door is not completely closed, it may cause a water leak.

Open the water tap and check if the water supply hose connector is firmly tightened and that there is no water leak before using the appliance.

• If the screws on the water supply hose connector are loose, it may result in a water leak.

The appliance you have purchased is designed for domestic use only.

Using the appliance for business purposes qualifies as an appliance misuse. In this case, the appliance will not be covered by the standard warranty provided by Samsung and no responsibility can be attributed to Samsung for malfunctions or damages resulting from such misuse.

Do not stand on the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.

• This may result in electric shock, fire, problems with the appliance, or injury.

Do not spray volatile material such as insecticide onto the surface of the appliance.

 As well as being harmful to humans, this may result in electric shock, fire or problems with the appliance.

Do not place objects that generate electromagnetic fields near the washing machine.

• This may result in injury due to a malfunction.

Water drained during a high-temperature wash or drying cycle is hot. Do not touch the water.

• This may result in burns or injury.

10 English

()

Draining time may vary depending on the water temperature. If the water temperature is too high, the draining process starts after the water cools down.

۲

Do not wash, spin, or dry water-proof seats, mats, or clothing (*) unless your appliance has a special cycle for washing these items.

(*): Woollen bedding, rain covers, fishing vests, ski pants, sleeping bags, diaper covers, sweat suits, and bicycle, motor cycle and car covers, etc.

- Do not wash thick or hard mats even if the washing machine mark is on the care label. This may result in injury or damage to the washing machine, walls, floor, or clothing due to abnormal vibrations.
- Do not wash throw rugs or doormats with rubber backing. The rubber backing may come off and stick to inside the drum, and this may result in malfunction such as a drainage error.

Do not operate the washing machine when the detergent drawer is removed.

• This may result in electric shock or injury due to a water leak.

Do not touch the insides of the drum during or just after drying as it is hot.

• This may result in burns.

The door glass becomes hot during washing and drying. Therefore, do not touch the door glass.

Also, do not allow children to play around the washing machine or touch the door glass.

• This may result in burns.

(�)

Do not insert your hand into the detergent drawer.

• This may result in injury as your hand may be caught by the detergent input device.

Remove the liquid detergent quide (applicable models only) when using powdered detergent.

• If not, water may leak through the front of the detergent drawer.

Do not place any objects (such as shoes, food waste, animals) other than laundry into the washing machine.

• This may result in damage to the washing machine, or injury and death in the case of pets due to the abnormal vibrations.

Do not press the buttons using sharp objects such as pins, knifes, fingernails, etc.

• This may result in electric shock or injury.

Do not wash laundry contaminated by oils, creams or lotions usually found in skincare shops or massage clinics.

• This may cause the rubber seal to become deformed and result in a water leak.

Do not leave metal objects such as safety pins, hair pins or bleach in the drum for long periods of time.

- This may cause the drum to rust.
- If rust starts appearing on the surface of the drum, apply a (neutral) cleansing agent to the surface and use a sponge to clean it. Never use a metal brush.

Do not use dry cleaning detergent directly and do not wash, rinse, or spin laundry contaminated by dry cleaning detergent.

This may result in spontaneous combustion or ignition due to the heat from the oxidation of the oil.

English 11

Safety information

Do not use water from water cooling/heating devices.

• This may result in problems with the washing machine.

Do not use natural hand-washing soap for the washing machine.

 If it hardens and accumulates inside the washing machine, it may result in problems with the appliance, discolouration, rust, or bad odours.

Place socks and brassieres in a washing net and wash them with the other laundry.

Do not wash large laundry items such as bedding in the washing net.

• Failure to do so may result in injury due to abnormal vibrations.

Do not use hardened detergent.

• If it accumulates inside the washing machine, it may result in a water leak.

Make sure that the pockets of all the clothing items to be washed are empty.

 Hard, sharp objects such as coins, safety pins, nails, screws, or stones can cause extensive damage to the appliance.

Do not wash clothing with large buckles, buttons or other heavy metal objects.

Sort the laundry by colour on the basis of its colorfastness and select the recommended cycle, water temperature and additional functions.

• This may result in discolouration or fabric damage.

Take care that children's fingers are not caught in the door when you close it.

Failure to do so may result in injury.

To prevent odours and mould, leave the door open after a wash cycle to allow the drum to dry.

To prevent limescale build up, leave the detergent drawer open after a wash cycle and dry inside it.

Critical cleaning warnings

(�)

Do not clean the appliance by spraying water directly onto it.

Do not use a strong acidic cleaning agent.

Do not use benzene, thinner or alcohol to clean the appliance.

• This may result in discolouration, deformation, damage, electric shock or fire.

Before cleaning or performing maintenance, unplug the appliance from the wall socket.

• Failure to do so may result in electric shock or fire.

12 English

Instructions about the WEEE



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

For information on Samsung's environmental commitments and product regulatory obligations, e.g. REACH, visit our sustainability page available via www.samsung.com

Product disposal in France



Ecodesign

(�)

For detailed instructions on installation and cleaning of the washing machine and ecodesign information (according to (EU)2019/2023), visit the Samsung website (http://www.samsung.com), go to Support > Support home, and then enter the model name.


Installation

Follow these instructions carefully to ensure proper installation of the washing machine and to prevent accidents when doing laundry.

۲

What's included

Make sure all the parts are included in the product package. If you have a problem with the washing machine or the parts, contact a local Samsung customer centre or the retailer.



14 English

10 Power plug


۲

12 Levelling feet

()

۲

11 Drain hose



۲

NOTE

۲

- Spanner: For removing the shipping bolts and levelling the washing machine.
- Bolt caps: For covering the holes after removing the shipping bolts. The provided number of bolt caps depends on the model.
- Hose guide: For hanging the drain hose in the drainpipe or wash-basin.
- Cold/Hot water hose: For supplying water to the washing machine. (Hot water hoses is for applicable models only.)
- Liquid detergent guide: Insert it in the detergent compartment to use liquid detergent. (applicable models only)

()

• Check valve: Only supplied to some models.

Accessories (not supplied)

- Stacking kit: SKK-5E*
 - Staking kit is required to stack a dryer on a washing machine.

English 15

۲

2024-06-17 6:47:30

Installation

Installation requirements

Electrical supply and grounding

• Use an individual branch circuit specific to the washing machine.

To ensure proper grounding, the washing machine comes with a power cord featuring a three-prong grounding plug for use in a properly installed and grounded outlet.

Check with a qualified electrician or service person if you are not sure about the grounding. Do not modify the provided plug. If it does not fit the outlet, call a qualified electrician to install a proper outlet.

()

- Do NOT use an extension cord.
- Use only the power cord that comes with the washing machine.
- Do NOT connect the ground wire to plastic plumbing, gas lines, or hot water pipes.
- Improperly connected grounding conductors may cause electric shock.

Water supply

 $(\mathbf{\Phi})$

A proper water pressure for this washing machine is between 50 kPa and 1000 kPa. Water pressure less than 50 kPa may cause the water valve not to close completely. Or, it may take longer to fill the drum, causing the washing machine to turn off. Water taps must be within 120 cm from the rear of the washing machine so that the provided inlet hoses reach the washing machine.

To reduce the risk of leaks:

- Make sure water taps are easily accessible.
- Turn off the taps when the washing machine is not in use.
- Check for any leaks at the water inlet hose fittings on a regular basis.

Before using the washing machine for the first time, check all connections at the water valve and taps for any leaks.

Drain

Samsung recommends a standpipe in height of 60-90 cm. The drain hose must be connected through the hose clip to the standpipe, and the standpipe must fully cover the drain hose.

Flooring

For best performance, the washing machine must be installed on a solid floor. Wood floors may need to be reinforced to minimise vibration and/or unbalanced loads. Carpeting and soft tile surfaces are not a good resistance to vibrations and may cause the washing machine to move slightly during the spin cycle.

()

Do NOT install the washing machine on a platform or a poorly supported structure.

Water temperature

Do not install the washing machine in areas where water may freeze as the washing machine always retains some water in its water valves, pumps, and/or hoses. Frozen water left in the connection parts may cause damage to belts, the pump, and other components of the washing machine.

Alcove or closet installation

 (\blacklozenge)

Minimum clearance for stable operation:

Sides	25 mm
Тор	25 mm
Rear	50 mm
Front	550 mm

If both the washing machine and a dryer are installed in the same location, the front of the alcove or closet must have at least a 550 mm unobstructed air opening. Your washing machine alone does not require a specific air opening.

6.47.30

2024-06-17

Installation

Step-by-step installation

STEP 1 Select a location

Location requirements:

- Solid, level surface without carpeting or flooring that may obstruct ventilation
- Away from direct sunlight
- Adequate room for ventilation and wiring
- The ambient temperature is always higher than the freezing point (0 °C)
- Away from a heat source

STEP 2 Remove the shipping bolts

Unpack the product package and remove all shipping bolts.

NOTE


()

Number of shipping bolts may differ depending on the model.

<u>∕</u>∧ WARNING

- Packaging materials can be dangerous to children. Dispose all packaging material (plastic bags, polystyrene, etc.) out of children's reach.
- To avoid injury, cover the holes with bolt caps after removing the shipping bolts. Do not move the washing machine without the shipping bolts in place. Assemble the shipping bolts before moving the washing machine to another location. Keep the shipping bolts in a safe place for future use.

۲



- 1. Locate the shipping bolts (marked with circle in the figure) on the rear side of the washing machine.
- 2. Using the supplied spanner, loosen all the shipping bolts by turning them counterclockwise.


NOTE

۲

You must keep the shipping bolts for future use.

18 English


(�)



3. Insert the **bolt caps (B)** to the holes (marked with circle in the figure).


۲

STEP 3 Adjust the levelling feet



- 1. Gently slide the washing machine into position. Excessive force may damage the levelling feet.
- 2. Level the washing machine by manually adjusting the levelling feet.
- **3.** When levelling is complete, tighten the nuts using the spanner.

 $(\mathbf{0})$




۲

۲

2024-06-17 6:47:31

Installation



۲

When installing the product make sure the levelling feet is not pressing the power cord.

۲


Make sure all the levelling feet are seating on the floor surface to avoid the washing machine from moving or generating noise due to vibration Then, check if the washing machine is not rocking. If the washing machine is not rocking, tighten the nuts.

۲

STEP 4 Connect the water hose


The provided water hose may differ depending on the model. Please follow the instruction according to the provided water hose.

Connecting to a threaded water tap



1. Connect the water hose to the water tap, and then turn the connector clockwise as shown.

- 2. Connect the other end of the water hose to the inlet valve on the back of the washing machine. Turn the hose clockwise to tighten.



3. Open the water tap and check if there are any leaks around the connection areas. If there are water leaks, repeat the steps above.


()

If there is a water leak, stop operating the washing machine and disconnect from the electrical supply. Then, contact a local Samsung service centre in case of a leak from the water hose, or contact a plumbing technician in case of a leak from the water tap. Otherwise, this may cause electric shock.


Installation

Do not stretch the water hose by force. If the hose is too short, replace the hose with a longer, highpressure hose.


Connecting to a non-threaded water tap




1. Remove the adaptor (A) from the water hose (B).



2. Use a Phillips screwdriver to loosen four screws on the adaptor.



3. Hold the adaptor and turn **part (C)** in the arrow direction to loosen it by 5 mm (*).




- **4.** Insert the adaptor onto the water tap, and then tighten the screws while lifting the adaptor.
- 5. Turn part (C) in the arrow direction to tighten it.

22 English

()

۲



 While pulling down part (D) on the water hose, connect the water hose to the adaptor. Then, release part (D). The hose fits into the adaptor with a clicking sound.

7. To complete connecting the water hose, see 2 and 3 on the "Connecting to a threaded water tap" section.

NOTE

()


• After connecting the water hose to the adaptor, check if it is connected properly by pulling the water hose downwards.

۲

• Use a popular type of water taps. If the tap is square-shaped or too big, remove the spacer ring before inserting the tap into the adaptor.

4

For models with an additional hot water inlet:




- 1. Connect the red end of the hot water hose to the hot water inlet on the back of the machine.
- **2.** Connect the other end of the hot water hose to the hot water tap.

(�)

Installation


Check valve (applicable models only)



Before connecting the water hose to a water tap, connect the supplied check valve to the water tap and then connect the water hose.

۲

Aqua hose (applicable models only)



The aqua hose alerts users of a risk of water leaks. It senses the water flow and turns red on the centre **indicator (A)** in case of a leak.

NOTE


۲


The end of the aqua stop hose must be fitted to the water tap and not the machine.

()


STEP 5 Position the drain hose

The drain hose can be positioned in three ways:





The drain hose must be placed at a height of between 60 cm and 90 cm (*) from the floor. To keep the spout of the drain hose bent, use the supplied **plastic hose guide** (A). Secure the guide to the wall using a hook to ensure stable drainage.



In a drain pipe


The drain pipe should be between 60 cm and 90 cm high (*). It is advisable to use a 65 cm high vertical pipe.

- To ensure the drain hose stays in position, use the plastic hose quide provided (see the figure).
- To prevent the siphoning of water flow during drainage, make sure to insert the drain hose 15 cm in the drain pipe.
- To prevent the drain hose from moving around, secure the hose guide to the wall.

Drain standpipe requirements:

- Minimum diameter of 5 cm
- Minimum carry-away capacity of 60 litres per minute

Installation



In a sink drain pipe branch


The drain pipe branch mush be above the sink siphone so that the end of the hose is at least 60 cm above the ground.

(*):60 cm

۲

Remove the lid on the sink drain pipe branch before connecting the drain pipe to it.

Do not put the drain hose in places of stagnant water or ponding. The water may flow back to the washing machine.




۲

۲

STEP 6 Power on

Plug the power cord into a wall socket that is correctly rated, grounded, and protected by a fuse or circuit breaker. Then, press **Power** to turn on the washing machine.

۲



NOTE

Door latch (lever) (A) is originally designed to be loose a little, because it may make the door latch be inserted into the door more easily.

NOTE

۲

If the door is locked during installation, plug the power cord, and turn on the power. The door will unlock.

()

Before you start

NOTE

Before doing your laundry for the first time, you must run a complete wash cycle without any items in the drum.

 $(\mathbf{0})$

Initial settings

Run Calibration (recommended)

Calibration ensures accurate weight detection by the washing machine. Make sure the drum is empty before running Calibration.

- 1. Power off, and then power on the washing machine.
- 2. Hold down Temp. I and Delay End i simultaneously for 3 seconds to enter Calibration mode. The "Cb" message appears.
- 3. Press Start/Pause to run the Calibration cycle.
- **4.** The drum will rotate for about 3 minutes. (The direction of the drum rotation may differ depending on the model.)
- 5. When the cycle is complete, "0" appears on the display and the washing machine will turn off automatically.
- 6. The washing machine is now ready for use.

Laundry guidelines

STEP 1 Sort

Sort the laundry according to these criteria:

- Care Label: Sort the laundry into cottons, mixed fibres, synthetics, silks, wools, and rayon.
- Colour: Separate whites from colours.
- Size: Mixing different sized items together in the drum improves the washing performance.
- Sensitivity: Wash delicate items separately using an Easy Iron option for pure, new woollen items, curtains, and silk items. Check the labels on the items.

NOTE

Make sure to check the care label on the clothing, and sort them accordingly before starting the wash.

STEP 2 Empty pockets

Empty all the pockets of your laundry items

• Metal objects such as coins, pins, and buckles on clothing may damage other laundry items as well as the drum.

()

Turn clothing with buttons and embroideries inside out

- If pants or jacket zippers are open while washing, the drum may be damaged. Zippers should be closed and fixed with a string.
- Clothing with long strings may become entangled with other clothes. Make sure to tie the strings before starting the wash.

STEP 3 Use a laundry net

- Brassieres (water washable) must be placed in a laundry net. Metal parts of the brassieres may break through and tear other laundry items.
- Small, light clothing such as socks, gloves, stockings, and handkerchiefs may become caught around the door. Place them inside a fine laundry net.
- Do not wash the laundry net by itself without other laundry. This may cause abnormal vibrations that could move the washing machine and result in injury.

(�)

STEP 4 Prewash (if necessary)

Select the Prewash option for the selected cycle if the laundry is heavily soiled. When selecting the Prewash option, make sure to put powder-type detergent into the main wash compartment.

STEP 5 Determine the load capacity

Do not overload the washing machine. Overloading may cause the washing machine to not wash properly. For the load capacity for the type of clothing, see page **39**.

NOTE

When washing bedding or bedding covers, the wash time may be lengthened or the spin efficiency may be reduced. For bedding or bedding covers, the recommended maximum spin cycle speed is 800 rpm, and the load capacity is 2.0 kg or less.

Unbalanced laundry may reduce the spinning performance.

Before you start

STEP 6 Apply a proper detergent type

The type of detergent depends on the type of fabric (cotton, synthetic, delicate items, wool), colour, wash temperature, and degree of soiling. Always use "low suds" laundry detergent, which is designed for automatic washing machines.

۲

NOTE

- Follow the detergent manufacturer's recommendations based on the weight of the laundry, the degree of soiling, and the hardness of the water in your local area. If you are not sure about the water hardness, contact a local water authority.
- Do not use detergent that tends to be hardened or solidified. This detergent may remain after the rinse cycle, blocking the drain outlet.

⚠ CAUTION

()


When washing wool using the **WOOL** (a) or **WOOL/DELICATES** cycle, use only a neutral liquid detergent. If used with the **WOOL** (b) or **WOOL/DELICATES** cycle, powder detergent may remain on the laundry and discolour the laundry.

(�)


Laundry capsules

To get the best results from using laundry capsules, please follow these instructions.

۲



1. Put the capsule in the bottom of the empty drum towards the rear.



2. Put the laundry in the drum on top of the capsule.

۲

For cycles using cold water or cycles that complete in less than one hour, it is recommended to use a liquid detergent. Otherwise, the capsule may not dissolve completely.

۲

Before you start

Detergent recommendation

The recommendations apply to the temperature ranges given in the cycle chart.

	Recommended	Liquid detergent only
-	Not recommended	Powder detergent only

۲


Detergent				
Cycle	Universal	Delicates and woollens	Specialist	Temp. (°C)
ECO 40-60	•	-	-	40-60
COTTON	•	-	-	Cold-90
SYNTHETICS	•	-	-	Cold-60
HYGIENE STEAM	•	-	-	Cold-90
QUICK WASH 15'		-	-	Cold-40
MIXED LOAD (WW**CGC***** models only)	•	_	-	Cold-40
SUPER SPEED (WW**DG5***** models only)	•	_	_	Cold-40
LESS MICROFIBER	•	-	-	Cold-40
INTENSE COLD	•	-	-	Cold-Cold
COLOURS	•	_	_	Cold-40
WOOL/DELICATES	_		_	Cold-40
BEDDING	•	-	-	Cold-40

۲

۲

Detergent drawer guidelines


The washing machine provides a three-compartment dispenser: the left compartment for the main wash, the centre for fabric softeners, and the right for the preliminary wash.



- 1. **I Prewash compartment**: Apply prewash detergent or starch.
- 2. I Main-wash compartment: Apply main-wash detergent, water softener, soaking detergent, bleach, and/or stain removers.
- 3. Softener compartment: Apply additives such as fabric softener. Do not exceed the max line (A).

NOTE

The actual appearance of the softener guide may differ with the model.




()

- Do not open the detergent drawer while the washing machine is operating.
- Do not use the following types of detergent:
 - Tablet or capsule types
 - Ball or net types
- To prevent the compartment clogging, concentrated or highly-enriched agents (fabric softener or detergent) must be diluted with water before being applied.
- When Delay End is selected, do not apply detergent directly into the drum. Otherwise, this may discolour the laundry. Use the detergent drawer when Delay End is selected.
- Do not use any cleaning agents for cleaning the drum. Chemical residue in the drum deteriorates the washing performance.

4

• Be careful not to spill fabric softener on the worktop or the control panel.

Before you start




To apply washing agents to the detergent drawer

1. Slide open the detergent drawer.

۲


 Apply laundry detergent to the **1** main-wash compartment as instructed or recommended by the manufacturer. To use liquid detergent, see page 35. Do not exceed the max line (A) when adding detergent.

 Apply fabric softener to the Softener compartment. Do not exceed the max line (A). Softener is dispensed into the wash during the final rinse.



۲


۲



- If you want to prewash, apply prewash detergent to the **1** prewash compartment as instructed or recommended by the manufacturer.
- 5. Close the detergent drawer.



- Do not apply powder detergent to the liquid detergent guide.
- Concentrated fabric softener must be diluted with water before applied.
- Do not apply main-wash detergent to the S softener compartment.



To use liquid detergent (applicable models only)

First insert the provided liquid detergent guide in the **1 main-wash compartment**. Then, apply liquid detergent to the guide below the marked **max line (A)**.

NOTE

- Do not exceed the max line (A) in the liquid detergent guide when you apply liquid detergent.
- Insert the liquid detergent guide only after you remove the detergent drawer from the washing machine by pressing **release lever (A)**.
- After a wash, some liquid detergent may remain in the detergent drawer.

- Do not use the Prewash function when you use liquid detergent.
- Remove the liquid detergent guide when you use powder detergent.

English 35


()

()

Operations

Control panel


WW**CGC*****



۲

WW**DG5****

۲



01 Cycle Selector	Turn the dial to select a cycle.	
	The display shows current cycle information and estimated time remaining, or an information code when a problem occurs.	
02 Display	NOTE	
	The actual washing time may differ from the estimated time initially displayed on the control panel upon cycle selection.	
03 Delay End 🕒	 Delay End lets you set the end time of the current cycle. Based on your settings, the start time of the cycle will be determined by the machine's internal logic. For example, this setting is useful for programming your machine to finish a wash at the time you normally return home from work. Press to choose a preset unit of hours. 	
04 Temp. 🌡	Press to change the water temperature for the current cycle.	

۲

05 Spin (9)	 Press to change the spinning speed for the current cycle. Rinse Hold (No indicator): The final rinse process is suspended so that the laundry remains in the water. To unload the laundry, run a drain or spin process. To use the Rinse Hold option, press Spin ⁽⁽⁾) repeatedly until all the Spin option indicators turn off. No Spin ^(Q): The drum does not spin after the final drain process. To use the No Spin option, press Spin ⁽⁽⁾) repeatedly until the option indicator (^(Q)) turns on.
06 Extra Rinse ₩	Press this button to add additional rinse cycles.
07 Prewash 닌/	This will add a preliminary washing cycle before the main wash cycle.
08 Intensive 🏠	 For badly soiled laundry. The operation time for each cycle is longer than normal. Sound Sound Sound
09 Easy Iron 노골	 Press to prepare your laundry so that it can be easily ironed by reducing the wrinkles during the spin cycle. Easy Iron is only available for the following wash cycles: ECO 40-60, COTTON, SYNTHETICS, HYGIENE STEAM, MIXED LOAD, SUPER SPEED, INTENSE COLD, COLOURS, BEDDING
10 Bubble Soak ම	 Press to activate/deactivate the Bubble Soak function. This function helps remove a wide variety of stubborn stains. Bubble Soak is only available for the following wash cycles: COTTON, SYNTHETICS, HYGIENE STEAM, MIXED LOAD, SUPER SPEED, BEDDING
11 Smart Control 🔒	 Press to activate or deactivate the Smart Control function. Tap and hold to enter pairing mode to connect to the SmartThings app. When the Smart Control function is activated, you can control your washing machine remotely using the SmartThings app on your smartphone or tablet (Android or iOS).
12 Power	Press to turn on/off the washing machine.
13 Start/Pause	Press to start or stop operation.

۲

۲


۲

۲

2024-06-17 6:47:36

Operations

Simple steps to start



۲

- 1. Press Power to turn on the washing machine.
- 2. Turn the Cycle Selector to select a cycle.
- 3. Change the cycle settings (Temp. §, and Spin (3)) as necessary.
- 4. To add an option, press the corresponding button.
- 5. Press Start/Pause.

To change the cycle during operation

- 1. Press Start/Pause to stop operation.
- 2. Select a different cycle.
- 3. Press Start/Pause again to start the new cycle.

Add Garments

۲

To add laundry after the wash starts, use **Start/Pause**.

- 1. Tap and hold Start/Pause to stop the wash cycle.
- 2. Open the door and add the laundry into the drum.
- 3. Close the door, and then tap and hold Start/Pause again to resume the wash cycle.

()

Cycle overview

Standard cycles

Cycle	Description	Max load (kg)
ECO 40-60	 For cleaning normally soiled cotton items which are declared to be washable at 40 °C or 60 °C, together in the same cycle. This cycle is used to assess the compliance with the EU Ecodesign legislation. This cycle is set as a default. 	Max
COTTON	 For cottons, bed linens, table linens, underwear, towels, or shirts. The washing time and the rinse count are automatically adjusted according to the load. For cleaning lightly soiled cotton items at a nominal temperature of 20 °C. 	Max
SYNTHETICS	• For fabrics that are made of polyester(diolen, trevira), polyamide (perlon, nylon), or the like.	4.0
HYGIENE STEAM	 Cotton and linen fabric which have been in direct contact with the skin, e.g. underwear. For optimum hygiene results select a temperature of 60 °C or above. Steam cycles feature allergy care and bacteria elimination (sterilize). 	4.0
RINSE+SPIN	 Featuring an additional rinse process after applying fabric softener to the laundry. 	Max
DRUM CLEAN (WW**CGC***** models only)	 Cleans the drum by removing dirt and bacteria from it. Perform once every 40 washes with no detergent or bleach applied. Notification message appears after every 40 washes. Make sure the drum is empty. Do not use any cleaning agents for cleaning the drum. 	-

۲

۲

_

۲

Operations

Cycle	Description	Max load (kg)
DRUM CLEAN+ (WW**DG5***** models only)	 Cleans the drum by removing dirt and bacteria from it. Cleans the rubber door gasket by removing dirt from the gasket. Perform once every 40 washes with no detergent or bleach applied. Notification message appears after every 40 washes. Make sure the drum is empty. Do not use any cleaning agents for cleaning the drum. 	-
DOWNLOADED	 Select to choose from more cycles available on the SmartThings app on your smartphone. 	-
QUICK WASH 15'	 For lightly soiled items in less than 2.0 kg that you want to wash quickly. Use less than 20 g of detergent. Using more than 20 g of detergent may leave detergent residue. For liquid detergent, use a maximum of 20 ml of liquid detergent. 	2.0
MIXED LOAD (WW**CGC***** models only)	For mixed load consisting of cotton and synthetic.	4.0
SUPER SPEED (WW**DG5***** models only)	 Fast completion for everyday items such as underwear and shirts. The cycle time will differ depending on the water supply conditions, load, and type of laundry. 	5.0
LESS MICROFIBER	• Use this cycle to reduce the amount of microfibers generated during washing synthetic clothes.	2.0
INTENSE COLD	Low temperature ecobubble cycle helps reduce power consumption.	4.0
COLOURS	• Featuring additional rinses and reduced spinning to ensure that the laundry is washed gently and rinsed thoroughly.	4.0

۲

۲

Cycle	Description	Max load (kg)
WOOL/DELICATES	 Specific for machine-washable wool and delicates fabrics such as sheer fabrics, bras, lingerie (silk), and other handwash-only fabrics. The WOOL/DELICATES cycle features gentle cradling and soaking to protect fibres from shrinkage/ distortion. A neutral detergent and liquid detergent is recommended. 	2.0
BEDDING	For bed spreads, bed sheets, bedding covers, etc.For best results, wash only 1 type of bedding.	2.0

۲

NOTE

()

• Loading the household washing machine or the household washer-dryer up to the capacity indicated by the manufacturer for the respective programmes will contribute to energy and water savings.

• The noise and remaining moisture content are influenced by the spinning speed: the higher the spinning speed in the spinning phase, the higher the noise and the lower the remaining moisture content.

• The most efficient cycle in terms of energy consumption are generally those that perform at lower temperatures and longer duration.

۲

()

2024-06-17 6:47:36

Operations

Options

	Option	Description
((r·	Wi-Fi	• This icon indicates that the washing machine is connected to Wi-Fi.
甌	DRUM CLEAN reminder	 This icon indicates that you should clean the drum using the DRUM CLEAN cycle. After every 40 cycles, this icon appears for an hour and then turns off automatically. The icon will appear for 5 more cycles, turn off, and then will not appear for another 40 cycles.
Ð	Child Lock	 This icon indicates that Child Lock is on. For more information on Child Lock, see page 43.
G	Door Lock	 This icon indicates the door is locked and cannot be opened. The door locks automatically during a cycle and this indicator turns on. You can open the door when this icon disappears.

۲

Delay End 🕒

()

You can set the washing machine to finish your wash automatically at a later time, choosing a delay of between 1 to 24 hours (in 1 hour increments). The hour displayed indicates the time the wash will finish.

- 1. Select a cycle. Then change the cycle settings if necessary.
- 2. Press Delay End () repeatedly until a desired end time is set.
- 3. Press Start/Pause.

The corresponding indicator turns on with the clock running.

4. To cancel the **Delay End** (), restart the washing machine by pressing **Power**.

Real-life case

You want to finish a two-hour cycle 3 hours later from now. For this, you add the Delay End option to the current cycle with the 3-hour setting, and press **Start/Pause** at 2:00 p.m. Then, what happens? The washing machine starts operating at 3:00 p.m., and ends at 5:00 p.m. Provided below is the time line for this example.



42 English

(�)

Settings

Child Lock 🔂

To prevent accidents by children, Child Lock locks all buttons except for **Power**.

- To set the Child Lock function, hold down **Temp. 1** and **Spin O** simultaneously for 3 seconds.
- To release the Child Lock function, hold down **Temp.** $\[b]$ and **Spin** $\[o]$ simultaneously for 3 seconds.

۲

NOTE

۲

- In the Child Lock state, you must first release the Child Lock if you want to add detergent or laundry.
- Your setting will be kept even after restarting the machine.

Operations

Special features

Smart Control (applicable models only)

You can connect to the SmartThings app and control your washing machine remotely.

Connecting your washing machine

- 1. Download and open the SmartThings app on your smartphone or tablet (Android & iOS).
- 2. Tap Power to turn on the washing machine.
- **3.** Tap and hold **Smart Control 1**.
 - **a.** The washing machine enters AP mode and connects to your smartphone or tablet.
 - **b.** Tap **Smart Control ()** to authenticate your washing machine.
 - c. Once the authentication process is complete, your washing machine is successfully connected to the app.
 - You can use various features available in the SmartThings app.

NOTE

 $(\mathbf{\Phi})$

- If your washing machine fails to connect with the SmartThings app, try again.
- Check your router if you experience any Internet connection problem after connecting your washing machine with the SmartThings app.
- If the Wi-Fi is off, tap and hold **Temp.** 🌡 and **Smart Control** 🗊 simultaneously for 3 seconds to turn it on.
- Turning the washing machine's Wi-Fi on allows you connect to the washing machine via SmartThings app on your smartphone or tablet, regardless of the power status of the washing machine. However, the washing machine appears offline on the SmartThings app if the washing machine's Wi-Fi is off.
- Close the door before starting the Smart Control function.
- If you use your washing machine for a while without connecting it to the SmartThings app, a pop-up message about Smart Control will show for 3 seconds.
- If the washing machine's Wi-Fi is not connected to an AP (access point), the Wi-Fi will turn off when you turn of the power.

Stay Connect

Set up the Stay Connect function in your SmartThings app to keep Smart Control turned on at the end of a cycle. Your washing machine stays connected to the app so you can send additional instructions, whether you are at home or away.

- 1. If you turn on the Stay Connect function on the SmartThings app, the washing machine will stay in standby power saving mode after completing a cycle.
 - The Stay Connect function will remain active for up to 24 Hours if the door remains closed.
- 2. When the Stay Connect function is active, the Smart Control, Door Lock, and Wi-Fi icons are illuminated on your washing machine display.

()

3. You can conveniently control your washing machine, adding rinse, spin or dry cycles using the SmartThings app.

NOTE

 The washing machine switches to standby power saving mode when operation is paused even if the machine is not connected to the SmartThings app.

()

• In some circumstances, only the Door Lock icon may be illuminated.

SmartThings

Wi-Fi connection

On your smartphone or tablet, go to **Settings** and turn on the wireless connection and select an AP (Access Point).

• This appliance supports the Wi-Fi 2.4 GHz protocols.

Download

On an app market (Google Play Store, Apple App Store, Samsung Galaxy Apps), find the SmartThings app with a search term of "SmartThings". Download and install the app on your device.

NOTE

The app is subject to change without notice for improved performance.

Log in

(�)

You must first log into SmartThings with your Samsung account. To create a new Samsung account, follow the instructions on the app. You don't need a separate app to create your account.

NOTE

If you have a Samsung account, use the account to log in. A registered Samsung smartphone or tablet user automatically logs in.

To register your appliance to SmartThings

- 1. Make sure your smartphone or tablet is connected to a wireless network. If not, go to **Settings** and turn on the wireless connection and select an AP (Access Point).
- 2. Open SmartThings on your smartphone or tablet.
- 3. If a message of "A new device is found.", select Add.
- If no message appears, select + and select your appliance in a list of devices available. If your appliance
 is not listed, select Device Type > Specific Device Model, and then add your appliance manually.
- 5. Register your appliance to the SmartThings app as follows.
 - a. Add your appliance to SmartThings. Make sure your appliance is connected to SmartThings.
 - b. When registration is complete, your appliance appears on your smartphone or tablet.

Operations

Open Source Announcement

The software included in this product contains open source software. You may obtain the complete corresponding source code for a period of three years after the last shipment of this product by contacting our support team via http://opensource.samsung.com (Please use the "Inquiry" menu.)

It is also possible to obtain the complete corresponding source code in a physical medium such as a CD-ROM; a minimal charge will be required.

The following URL http://opensource.samsung.com/opensource/SMART_AT_051/seq/0 leads to the open source license information as related to this product. This offer is valid to anyone in receipt of this information.



NOTE

()

- When Wi-Fi is activated, the energy consumption increases in comparison to the values specified in the indicative information.
- Hereby, Samsung declares that this radio equipment is in compliance with Directive 2014/53/EU and with the relevant statutory requirements in the UK. The full text of the EU declaration of conformity and the UK declaration of conformity is available at the following internet address: The official Declaration of conformity may be found at http://www.samsung.com, go to Support > Support home and enter the model name. Wi-Fi max transmitter power : 20 dBm at 2.412 GHz – 2.472 GHz

46 English

Maintenance

Keep the washing machine clean to prevent deteriorated performance and to preserve its life cycle.

DRUM CLEAN / DRUM CLEAN+

Perform this cycle regularly to clean the drum by removing bacteria from it. This cycle heats the water between 60 °C and 70 °C, and it also removes accumulated dirt from the rubber door gasket.

- 1. Press Power to turn on the washing machine.
- 2. Turn the Cycle Selector to select DRUM CLEAN / DRUM CLEAN+.
- 3. Press and hold Start/Pause.

NOTE

()

- The water temperature for DRUM CLEAN / DRUM CLEAN+ is set to 70 °C, which cannot be changed.
- It is recommended to run the DRUM CLEAN / DRUM CLEAN+ cycle once every 40 washes.
- To prevent limescale, add the proper amount of detergent according to your local water hardness or add a water softener additive together with the detergent.

DRUM CLEAN / DRUM CLEAN+ reminder

Depending on the model, the DRUM CLEAN / DRUM CLEAN+ reminder is either an icon or an LED.

For icons, the icon lights up on the control panel.

For LEDs, the LED lights up next to **DRUM CLEAN / DRUM CLEAN+**, or on the option area of the control panel.

- The DRUM CLEAN / DRUM CLEAN+ reminder blinks on the control panel once every 40 washes. It is advisable to perform DRUM CLEAN / DRUM CLEAN+ regularly.
- When you first see this reminder blinking, you can ignore the reminder for 6 consecutive washes. From the 7th wash, the reminder no longer appears. However, it appears again on the second 40th wash.
- Even after the last process is terminated, the "0" message may remain.
- Even if "O" does not disappear, the machine operates normally.
- It is recommended to run the cycle regularly for hygienic purposes.

Maintenance


Emergency drain

In case of a power failure, drain the water inside the drum before taking out the laundry.



- 1. Power off and unplug the washing machine from the electrical outlet.
- 2. Open the filter cover (A).
 - TYPE 1: Gently press the top area of the **filter cover (A)** to open.
 - TYPE 2: Push down the latch of the **filter cover (A)** to open.

3. Put an empty, spacious container around the cover, and stretch the emergency drain tube to the container while holding the **tube cap (B)**.



- 4. Open the tube cap and let water in the **emergency** drain tube (C) flow into the container.
- 5. When done, close the tube cap, and reinsert the tube. Then, close the filter cover.

NOTE

Use a spacious container because the water in the drum may be more than expected.



48 English

۲

()

Cleaning


Surface of the washing machine


Use a soft cloth with a nonabrasive household detergent. Do not spray water onto the washing machine.

 (\blacklozenge)

Mesh filter

Clean the mesh filter of the water hose once or twice a year.





- 1. Turn off the washing machine, and unplug the power cord.
- 2. Close the water tap.
- **3.** Loosen and disconnect the water hose from the back of the washing machine. Cover the hose with a cloth to prevent water from gushing out.
- **4.** Use pliers to pull out the mesh filter from the inlet valve.
- 5. Submerge the mesh filter deeply in water so that the threaded connector is also submerged.
- 6. Dry the mesh filter completely in the shade.
- 7. Reinsert the mesh filter into the inlet valve, and reconnect the water hose to the inlet valve.
- 8. Open the water tap.

 (\mathbf{r})

NOTE


()


If the mesh filter is clogged, an information code of "4C" appears on the screen.

Maintenance

Debris filter

It is advisable to clean the debris filter every 2 months to prevent its clogging. A clogged debris filter may reduce the bubble effect.





- 1. Turn off the washing machine, and unplug the power cord.
- 2. Drain the remaining water inside the drum. See the "Emergency drain" section.
- 3. Open the filter cover.
 - TYPE 1: Gently press the top area of the **filter cover** to open.
 - TYPE 2: Push down the latch of the **filter cover** to open.
- **4.** Turn the debris filter knob to the left, and drain off the remaining water.
- Clean the debris filter using soft brushes. Make sure the drain pump propeller inside the filter is unclogged.
- **6.** Reinsert the debris filter, and turn the filter knob to the right.

NOTE

- Some debris filters feature a safety knob that is designed to prevent accidents by children. To open the safety knob of the debris filter, push in and turn it anticlockwise. The spring mechanism of the safety knob helps open the filter.
- To close the safety knob of the debris filter, turn it clockwise. The spring makes a rattling sound, which is normal.

NOTE

()


If the debris filter is clogged, an information code of "5C" appears on the screen.

- Make sure the filter knob is closed properly after cleaning the filter. Otherwise, this may cause a leak.
- Make sure the filter is inserted properly after cleaning it. Otherwise, this may cause an operational failure or a leak.

50 English


()

Detergent drawer




- 1. While holding down the **release lever (A)** on the inner of the drawer, slide open the drawer.
- **2.** Remove the release lever and the liquid detergent guide from the drawer.

۲



3. Clean the drawer components in flowing water using a soft brush.



- 4. Clean the drawer recess using a bottle brush to remove detergent residues and limescale on the drawer recess.
- 5. Reinsert the release lever and the liquid detergent guide to the drawer.
- 6. Slide the drawer inward to close it.

NOTE

۲

To remove remaining detergent, perform the **RINSE+SPIN** cycle with the drum being empty.

 $(\mathbf{0})$

Maintenance

Recovery from freezing

The washing machine may freeze when it drops below 0 °C.

- 1. Turn off the washing machine, and unplug the power cord.
- 2. Pour warm water over the water tap to loosen the water hose.
- 3. Disconnect the water hose, and soak it in warm water.
- 4. Pour warm water into the drum and leave it for about 10 minutes.
- 5. Reconnect the water hose to the water tap.

NOTE

()

If the washing machine still doesn't operate normally, repeat the above steps until it operates normally.

 $(\mathbf{\Phi})$

Care against an extended time of disuse

Avoid leaving the washing machine unused for an extended time. If this is the case, drain the washing machine and unplug the power cord.

- 1. Turn the Cycle Selector to select a RINSE+SPIN.
- 2. Empty the drum, and press Start/Pause.
- 3. When the cycle is complete, close the water tap and disconnect the water hose.
- 4. Turn off the washing machine, and unplug the power cord.
- 5. Open the door to let air circulate through the drum.

()

Troubleshooting

Checkpoints

If you encounter a problem with the washing machine, first check the table below and try the suggestions.

۲

Problem	Action
Does not start.	 Make sure the washing machine is plugged in. Make sure the door is properly closed. Make sure the water taps are open. Make sure to press or tap Start/Pause to start the washing machine. Make sure Child Lock is not activated. Before the washing machine starts to fill, it will make a series of clicking noises to check the door lock and does a quick drain. Check the fuse or reset the circuit breaker.
Water supply is insufficient, or no water is supplied.	 Fully open the water tap. Make sure the door is properly closed. Make sure the water supply hose is not frozen. Make sure the water supply hose is not kinked or clogged. Make sure there is sufficient water pressure.
After a cycle, detergent remains in the detergent drawer.	 Make sure the washing machine is running with sufficient water pressure. Make sure the detergent is added to the centre of the detergent drawer. Make sure the rinse cap is inserted properly. If using granular detergent, make sure the detergent selector is in the upper position. Remove the rinse cap and clean the detergent drawer.
Excessive vibrations or makes noise.	 Make sure the washing machine is installed on a level, solid floor that is not slippery. If the floor is not level, use the levelling feet to adjust the height of the washing machine. Make sure the shipping bolts are removed. Make sure the washing machine is not contacting any other object. Make sure the laundry load is balanced. The motor can cause noise during normal operation. Overalls or metal-decorated clothes can cause noise while being washed. This is normal. Metal objects such as coins can cause noise. After washing, remove these objects from the drum or filter case.

۲

۲

Troubleshooting

Problem	Action
Does not drain and/ or spin.	 Make sure the drain hose is straightened all the way to the drain system. If you encounter a drain restriction, call for service. Make sure the debris filter is not clogged. Close the door and press or tap Start/Pause. For your safety, the washing machine will not tumble or spin unless the door is closed. Make sure the drain hose is not frozen or clogged. Make sure the drain hose is connected to a drain system that is not clogged. If the washing machine is not supplied with sufficient power, the washing machine temporarily will not drain or spin. As soon as the washing machine regains sufficient power, it will operate normally. Spinning does not work. Make sure the washing machine is on a flat, stable surface. Redistribute the load. If only one item of clothing needs washing, such as a bathrobe or pair of jeans, the final spin result might be unsatisfactory, and an "Ub" check message will be shown in the display.
The door does not open.	 Press or tap Start/Pause to stop the washing machine. It may take a few moments for the door lock mechanism to disengage. The door will not open until 3 minutes after the washing machine has stopped or the power turned off. Make sure all the water in the drum is drained. The door may not open if water remains in the drum. Drain the drum and open the door manually. Make sure the door lock light is off. The door lock light turns off after the washing machine has drained.
Excessive suds.	 Make sure you use the recommended types of detergent as appropriate. Use high efficiency (HE) detergent to prevent oversudsing. Reduce the detergent amount for soft water, small loads, or lightly soiled loads. Non-HE detergent is not recommended.
Cannot apply additional detergent.	Make sure the remaining amount of detergent and fabric softener is not over the limit.

۲

۲

Problem	Action
Stops.	 Plug the power cord into a live electrical outlet. Check the fuse or reset the circuit breaker. Close the door and press the Start/Pause button to start the washing machine. For your safety, the washing machine will not tumble or spin unless the door is closed. Before the washing machine starts to fill, it will make a series of clicking noises to check the door lock and does a quick drain. There may be a pause or soak period in the cycle. Wait briefly and the washing machine may start. Make sure the mesh filter of the water supply hose at the water taps are not clogged. Periodically clean the mesh filter. If the washing machine is not supplied with sufficient power, the washing machine temporarily will not drain or spin. As soon as the washing machine regains sufficient power, it will operate normally.
Fills with the wrong water temperature.	 Fully open both taps. Make sure the temperature selection is correct. Make sure the hoses are connected to the correct taps. Flush water lines. Make sure the water heater is set to supply a minimum 120 °F (49 °C) hot water at the tap. Also, check the water heater capacity and recovery rate. Disconnect the hoses and clean the mesh filter. The mesh filter may be clogged. While the washing machine fills, the water temperature may change as the automatic temperature control feature checks incoming water temperature. This is normal. While the washing machine fills, you may notice just hot and/or just cold water going through the dispenser when cold or warm temperatures are selected. This is a normal function of the automatic temperature.
Load is wet at the end of a cycle.	 Use the High or Extra High spin speed. Use high efficiency (HE) detergent to reduce oversudsing. Load is too small. Small loads (one or two items) may become unbalanced and not spin completely. Make sure the drain hose is not kinked or clogged.

۲

۲

۲

Troubleshooting

Problem	Action
Leaks water.	 Make sure the door is properly closed. Make sure all hose connections are tight. Make sure the end of the drain hose is correctly inserted and secured to the drain system. Avoid overloading. Use high efficiency (HE) detergent to prevent oversudsing. Check if there is something stuck between the door and the diaphragm. If there is something stuck between the door and the diaphragm, it may cause a leak or damage to the diaphragm.
Has odours.	 Excessive suds collect in recesses and can cause foul odours. Run cleansing cycles to sanitize periodically. Clean the door seal (diaphragm). Dry the washing machine interior after a cycle has finished.
No bubbles are seen (Bubble models only).	Overloading may screen bubbles.Severely contaminated laundry may not generate bubbles.
Increased time of washing	• The actual washing time may differ from the estimated time initially displayed on the control panel upon cycle selection.

۲

• If a problem persists, contact a service center. The number of the service center is on the label attached to the product.

• Samsung is not liable for any damage to the product, any injury, or any other product safety issue caused by a repair which does not follow the instructions in these Repair Guides. Any damage to the product caused by an attempted repair (by anyone other than a Samsung certified service provider) will also not be covered by the warranty.

۲

(�)

Information codes

If the washing machine fails to operate, you may see an information code on the screen. Check the table below and try the suggestions.

۲

Code	Action
4C	 Water is not supplied. Make sure the water taps are open. Make sure the water hoses are not clogged. Make sure the water taps are not frozen. Make sure the washing machine is running with sufficient water pressure. Make sure that the cold water tap and the hot water tap are properly connected. Clean the mesh filter as it may be clogged. When the "4C" message appears, the machine drains water for 3 minutes. In the meantime, the power button will be disabled.
4C2	• Make sure the cold water supply hose is firmly connected to the cold water tap. If it is connected to the hot water tap, the laundry may be deformed with some cycles.
5C	 Water is not draining. Make sure the drain hose is not frozen or clogged. Make sure the drain hose is positioned correctly, depending on the connection type. Clean the debris filter as it may be clogged. Make sure the drain hose is straightened all the way to the drain system. If the information code remains, contact a customer service centre.
dC	Operating the washing machine with the door open.Make sure the door is properly closed.Make sure laundry is not caught in the door.
OC	 Water is overflowed. Restart after spinning. If the information code remains on the display, contact a local Samsung service centre.
LC, LC1	 Check the drain hose. Make sure the end of the drain hose is not placed on the floor. Make sure the drain hose is not clogged. If the information code remains, contact a customer service centre.
3C	Check the motor for operation.Try restarting the cycle.If the information code remains, contact a customer service centre.

۲

۲

۲

2024-06-17 6:47:38

Troubleshooting

Code	Action
UC	The electronic control needs to be checked.Check if power is supplied properly.If the information code remains, contact a customer service centre.
	Low voltage detected.Check if the power cord is plugged in.If the information code remains, contact a customer service centre.
НС	High temperature heating check.If the information code remains, contact a customer service centre.
1C	The Water Level sensor is not working properly.Try power off and restarting the cycle.If the information code remains, contact a customer service centre.
AC	Check communications between main and sub PBAs.Try power off and restarting the cycle.If the information code remains, contact a customer service centre.
0	 The machine does not turn off automatically after the last spinning process, and the "0" message remains. The machine operates normally without running the DRUM CLEAN cycle. However, it is recommended to run the cycle for hygienic purposes.
Ub	 Spinning does not work. Make sure laundry is spread out evenly. Make sure the washing machine is on a flat, stable surface. Redistribute the load. If only one item of clothing needs washing, such as a bathrobe or pair of jeans, the final spin result might be unsatisfactory, and an "Ub" check message will be shown in the display.

۲

If any information code keeps appearing on the screen, contact a local Samsung service centre.

۲

۲

Specifications

Fabric care chart

The following symbols provide garment care direction. The Clothing care labels include symbols for drying, bleaching, drying and ironing, or dry cleaning when necessary. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to maximize garment life and reduce laundering problems.

Washing

۲

95	95 °C normal wash.
60	60 °C normal wash.
60	60 °C mild wash.
40	40 °C normal wash.
40	40 °C mild wash.
40	40 °C very mild wash.
30	30 °C normal wash.
30	30 °C mild wash.
30	30 °C very mild wash.
K M	Hand wash.
\boxtimes	Do not wash.

Bleaching

۲

\triangle	Any bleach allowed.			
	Only oxygen bleach allowed.			
\bowtie	Do not bleach.			

Drying

$\overline{\mathbf{O}}$	Tumble drying / normal temperture / maximum exhaust temperatue 80 °C.			
$\overline{\mathbf{O}}$	Tumble drying / lower temperature / maximum exhaust temperature 60 °C.			
\boxtimes	Do not tumble dry			
	Line drying.			
	Drip line drying.			
\Box	Flat drying.			
	Drip flat drying.			
	Line drying in the shade.			
	Drip line drying in the shade.			
	Flat drying in the shade.			
E	Drip flat drying in the shade.			

NOTE

- The dots indicate the drying level of the dryer.
- The lines indicate the type and place of the drying.

NOTE

The numbers in the wash tub specify the maximum washing temperatures in degrees celsius which must not be exceeded.

()

Specifications

Ironing

	Iron at maximum sole plate temperature of 200 °C.			
	Iron at maximum sole plate temperature of 150 °C.			
Ā	Iron at maximum sole plate temperature of 110 °C. Caution when using steam irons (work without steam).			
\mathbb{X}	Do not iron.			

NOTE

۲

The dots indicate the temperature ranges for ironing (regulator, steam, travel irons and ironing machines).

Professional care

P	Professional dry-cleaning in perchloroethylene and/or hydrocarbons (heavy benzines) with normal process.			
<u>P</u>	Professional dry-cleaning in perchloroethylene and/or hydrocarbons (heavy benzines) with gentle process.			
F	Professional dry-cleaning in hydrocarbons (heavy benzines) with normal process.			
<u>(F)</u>	Professional dry-cleaning in hydrocarbons (heavy benzines) with gentle process.			
\bigotimes	Do not dry-clean.			
W	Professional wet-cleaning.			
<u>()</u>	Mild professional wet-cleaning.			

	Very mild professional wet-cleaning.
X	Do not wet-clean.

NOTE

۲

۲

- The letters in a circle indicate the solvents (P, F) used in dry cleaning or wet cleaning (W).
- Generally, the line under the symbol indicates a milder treatment (e.g. gentle cycle for easycare items). The double line indicates care levels with particularly gentle treatment.

()

Protecting the environment

 This appliance is manufactured from recyclable materials. If you decide to dispose of it, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the lid so that animals and small children cannot get trapped inside the appliance.

۲

- Do not exceed the detergent quantities recommended in the detergent manufacturers' instructions.
- Use stain removal products and bleaches before the wash cycle only when necessary.
- Save water and electricity by only washing full loads (the exact amount depends upon the program used).

Spare parts guarantee

We guarantee that the following spare parts will be available to professional repairers and end-users for a minimum period of 10 years after placing the last unit of the model on the market.


- Door, door hinges and seals, other seals, door locking assembly, and plastic peripherals such as detergent dispensers.
- Listed parts can be purchased at below website.
 - http://www.samsung.com/support

()

Specifications

Specification sheet

"*" Asterisk(s) means variant model and can be varied (0-9) or (A-Z).



۲

	Туре	Front loading washing machine			
Model name			WW9*CGC**** WW8*CGC****		
	A (W	A (Width)		600 mm	
	B (He	eight)	850 mm		
Dimensions	Dimensions C (Depth)		550	mm	
	D		630 mm		
	E	E		1080 mm	
Water pressure			50-1000 kPa		
Net weight			65.0 kg		
Maximum load capacity Washing and spinning		9.0 kg	8.0 kg		
Power consumption	Washing and heatingAC 220-240 V / 50 Hz		1900-2300 W		
Spin revolutions			1400	RPM	

۲

۲

	Туре	Front loading washing machine		
Model name			WW1*DG*****	
	Model hame	WW1*DE*		
	A (W	idth)	600 mm	
	B (Height)		850 mm	
Dimensions	C (Depth)		600 mm	
	D		640 mm	
	E		1090 mm	
Water pressure			50-1000 kPa	
Net weight			72.0 kg	
Maximum lo	bad capacity	acity Washing and spinning 11.0 kg		
Power consumption	Washing and heatingAC 220-240 V / 50 Hz		1900-2300 W	
Spin revolutions			1400 RPM	

۲

NOTE

۲

- The design and specifications are subject to change without notice for quality improvement purposes.
- The dimensions stated here may differ slightly from the actual measurements depending on the measuring method.

۲

Specifications

EPREL information

To access energy labelling information about this product on the European Product Registry for Energy Labelling (EPREL), go to https://eprel.ec.europa.eu/qr/***** where ***** is the product's EPREL registration number. You can find the registration number on the rating label of your product.

۲

Indicative information (According to EU 2019/2023)

Model	Cycles	Capacity (kg)	Program Time (HH:MM)	Energy Consumption (kWh/Cycle)	Water Consumption (L/cycle)	Maximum Temperature (°C)	Remaining Moisture Content (%)	Spinning Speed (RPM)
		11	4:00	0.930	93.8	33	53.9	1400
	ECO 40-60	5.5	3:00	0.490	59.4	27	53.9	1400
		3	2:40	0.234	31.4	23	53.9	1400
	COTTON 20°C	11	3:59	0.336	132.0	20	50.0	1400
WW1*DG*****	COTTON 60°C	11	2:32	1.390	132.0	60	50.0	1400
WW1*DE*	COTTON 60°C + Bubble Soak	11	3:02	2.170	147.0	60	50.0	1400
	SYNTHETICS 40°C	4	2:59	0.735	58.0	40	33.0	1200
	QUICK WASH 15' Cold	2	0:15	0.015	41.0	15	105.0	800
		9	3:48	0.690	71.0	28	53.9	1400
	ECO 40-60	4.5	2:54	0.465	47.0	28	53.9	1400
		2.5	2:44	0.222	34.6	23	53.9	1400
	COTTON 20°C	9	3:19	0.357	117.0	20	53.0	1400
	COTTON 60°C	9	2:25	1.504	134.0	55	53.0	1400
WW9*CGC*****	COTTON 60°C + Bubble Soak	9	2:55	2.099	134.0	60	53.0	1400
	SYNTHETICS 40°C	4	2:59	0.819	61.4	40	33.0	1200
	QUICK WASH 15' Cold	2	0:15	0.015	43.0	15	105.0	800
		8	3:38	0.734	65.0	30	53.9	1400
	ECO 40-60	4	2:48	0.432	45.0	27	53.9	1400
		2	2:16	0.223	31.0	23	53.9	1400
	COTTON 20°C	8	3:19	0.339	104.0	20	53.0	1400
	COTTON 60°C	8	2:25	1.659	127.0	55	53.0	1400
WW8*CGC*****	COTTON 60°C + Bubble Soak	8	2:55	2.192	127.0	60	53.0	1400
	SYNTHETICS 40°C	4	2:59	0.819	61.4	40	33.0	1200
	QUICK WASH 15' Cold	2	0:15	0.015	43.0	15	105.0	800

۲

• The values given for programmes other than the ECO 40-60 programme and the wash and dry cycle are indicative only.

۲

• The time values stated here may differ from the actual values due to the influence of the water pressure/hardness/temperature, type/amount/soiling level of the laundry, type/amount of the detergent used, power supply, and the selected additional functions.

()

Contact information

QUESTIONS OR COMMENTS?

COUNTRY	CALL	OR VISIT US ONLINE AT		
UK	0333 000 0333	www.samsung.com/uk/support		
IRELAND (EIRE)	0818 717100	www.samsung.com/ie/support		
GERMANY	06196 77 555 77	www.samsung.com/de/support		
FRANCE	01 48 63 00 00	www.samsung.com/fr/support		
SPAIN	91 175 00 15	www.samsung.com/es/support		
PORTUGAL	210 608 098 Chamada para a rede fixa nacional Dias úteis das 9h às 20h	www.samsung.com/pt/support		
LUXEMBURG	261 03 710	www.samsung.com/be_fr/support		
NETHERLANDS	088 90 90 100	www.samsung.com/nl/support		
BELGIUM	02-201-24-18	www.samsung.com/be/support (Dutch) www.samsung.com/be_fr/support (French)		
NORWAY	21 62 90 99	www.samsung.com/no/support		
DENMARK	70 70 19 70	www.samsung.com/dk/support		
FINLAND	030-622 75 15	www.samsung.com/fi/support		
SWEDEN	0771-400 300	www.samsung.com/se/support		
AUSTRIA	0800 72 67 864 (0800-SAMSUNG)	www.samsung.com/at/support		
SWITZERLAND	0800 726 786	www.samsung.com/ch/support (German) www.samsung.com/ch_fr/support (French)		
HUNGARY	0680SAMSUNG (0680-726-7864)	www.samsung.com/hu/support		
CZECH	800 - SAMSUNG (800-726786)	www.samsung.com/cz/support		
SLOVAKIA	0800 - SAMSUNG (0800-726 786)	www.samsung.com/sk/support		
CROATIA	072 726 786	www.samsung.com/hr/support		
BOSNIA	055 233 999	www.samsung.com/ba/support		
North Macedonia	023 207 777	www.samsung.com/mk/support		
MONTENEGRO	020 405 888	www.samsung.com/support		
SLOVENIA	080 697 267 (brezplačna številka)	www.samsung.com/si/support		
SERBIA	011 321 6899	www.samsung.com/rs/support		

۲

66 English –

۲

۲

COUNTRY	CALL	OR VISIT US ONLINE AT
Kosovo	038 40 30 90	www.samsung.com/support
ALBANIA	045 620 202	www.samsung.com/al/support
BULGARIA	0800 111 31 - Безплатен за всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 до 18:00 - Понеделник до Петък	www.samsung.com/bg/support
ROMANIA	0800872678 - Apel gratuit *8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PM	www.samsung.com/ro/support
ITALIA	800-SAMSUNG (800.7267864)	www.samsung.com/it/support
CYPRUS	8009 4000 only from landline, toll free	
GREECE	80111-SAMSUNG (80111 726 7864) from mobile and land line (+30) 210 6897691 from mobile and land line	www.samsung.com/gr/support
POLAND	801-172-678* * (opłata według taryfy operatora)	http://www.samsung.com/pl/support/
LITHUANIA	8-800-77777	www.samsung.com/lt/support
LATVIA	8000-7267	www.samsung.com/lv/support
ESTONIA	800-7267	www.samsung.com/ee/support

۲

— English **67**

۲

۲

SAMSUNG



۲

۲

۲