





TS4-A-M Installation Quick Start Guide


1



2



3




Note: When installing TS4-A or TS4-A-Duo, connect the input cables to the PV module before connecting the TS4-A output cables in series.

If disconnecting TS4-A or TS4-A-Duo, disconnect the TS4-A output cables from the string before disconnecting the input cables from the PV module.

Removable clips

Mounting holes (M8)



For installation with frameless modules, remove metal clips and bolt TS4-A to rail.



support.tigoenergy.com



support@tigoenergy.com



International: 00800.2255.8446

Americas: +1.408.402.0802



Manual

TS4-A-M: Monitoring

The TS4-A-M is the advanced add-on solution that brings smart module functionality to standard PV modules, including module-level monitoring.

Maximum power: 500W

Maximum voltage: 90V_{DC}

Maximum current: 15A_{DC}

Maximum string voltage 1000V/1500V
depending on connectors.

Use ANSI/NFPA 70 wiring methods.

Modules must not be installed in readily accessible locations. (Canada only)

Connectors from different manufacturers cannot be mated with each other.

TAP and CCA are required for module-level monitoring.



- ① PV Module -
- ② String -
- ③ String +
- ④ PV Module +

Class II double insulation

High Voltage
DANGER

IMPORTANT NOTICE

Electricity will be supplied to the Tigo TS4-A output cables immediately when connected to a PV module exposed to sunlight. Use care when handling.

注意事项

当连接的组件暴露在阳光下时电力将会从Tigo TS4-A输出端输出。请小心处理。

ATTENTION!

Une fois connecté au panneau photovoltaïque exposé au soleil, les boîtiers Tigo TS4-A laisseront passer le courant. Soyez vigilant.

WICHTIGER HINWEIS

Bei Verbindung der Tigo TS4-A mit einem aktiven PV-modul steht der Ausgang unmittelbar unter Spannung. Bitte Vorsicht im Umgang.

AVVISO IMPORTANTE

Prestare la massima attenzione: i cavi di uscita dei Tigo TS4-A sono già alimentati con energia elettrica quando vengono collegati a un modulo fotovoltaico esposto alla luce del sole.

안전을 위한 주의사항

햇빛에 노출된 태양전지 모듈에 연결하면 Tigo TS4-A 출력 케이블에 즉시 전기가 흐르게 됩니다. 취급 시 주의하십시오.

重要事項

日射下の太陽光モジュールを接続すると同時に、タイゴTS4-Aの出力 ケーブルにも電気が流れますので、取扱いには十分ご注意ください。

¡PRECAUCION!

Al momento de conectar los cables de salida los Tigo TS4-A a un módulo fotovoltaico expuesto al sol, se iniciará la corriente eléctrica. Tenga cuidado en su manejo.