

QUICK NOTES

TMM4 PLUS MULTI-PURPOSESTRETCHER-CHAIR



1. SIDE RAIL - LOWERING/RAISING



Lowering the Side Rail Grasp the top of the side rail and push slightly inward while pulling out the Red release tab at the bottom of the rail.

Stowing the Side Rail

Lower the rail into the down position.



Raising the Side Rail

Lift the side rail until it is in the up position. The Red release tab will engage (lock) automatically.

WNOTICE

After raising, pull on side rail to ensure it is securely locked.

2. BACK SECTION QUICK RELEASE



Location

The (Red) quick release lever is located under the seat on the patient's right side.

Activating the Quick Release

Pull the Red lever out towards the side rail. When weight is applied, the back section will drop until the lever is released.



Intended for EMERGENCY purposes ONLY.

3. CASTER BRAKE OPERATION



Brake Mode

Activate the braking system by pressing down on the red end of either brake pedal.



This mode prevents all four casters from swiveling and all four wheels from spinning.



Neutral Mode

Activate the neutral mode by placing either brake pedal into a horizontal orientation.



This mode allows all four casters to swivel and all four wheels to spin freely.

Steer Mode

Activate the steer-locking system by pressing down on the green end of either brake pedal.



This mode locks front right caster parallel to the base but allows the other three casters to swivel and all four wheels to spin freely.

4. BATTERY PACK ("B" OPTION) INSTALLATION AND REMOVAL



Battery Pack Removal Grasp the battery pack's integrated handle and lift up until locks disengage then pull the battery away from the mounting bracket.



Installing the Battery Pack

Place the two circular pins located on the back of the battery pack into the square openings on the battery mounting bracket. Once the pins are aligned, slide the battery pack down until the pins lock into place.



To maintain an optimum charge, Winco recommends charging your battery every 2-3 days.

5. PUSH BAR OPERATION




Lowering the Push Bar Grasp the push bar handle while pulling out the Red release knob and lower the push bar.

Raising the Push Bar

Lift up on the push bar handle until the Red release knob engages (locks).

6. AUTO-EXTENDING FOOTREST



Storing the Footrest

Lift the end of the footrest until it engages in the stored, upright position. The footrest should be stored in this position when not being used.

Lowering the Footrest

Push down on the footrest to lower for use.



7. EIGHT BUTTON PENDANT

Pendant Storage

To prevent damage, the pendant may be stored at various locations on the chair when not in use.

Pendant is NOT INTENDED FOR PATIENT USE.



Back Adjustment

The first row of buttons controls the angle of the back section. Press the left button to raise the chair back. Press the right button to lower the chair back.

Leg Adjustment

The second row of buttons controls the angle of the leg section. Press the left button to raise the leg section. Press the right button to lower the leg section.

Seat Height Adjustment

The third row of buttons controls the seat height. Press the left button to raise the seat. Press the right button to lower the seat.

Auto-Contour Adjustment

The fourth row of buttons controls the simultaneous actuation of the leg and back sections. Press the left button to place the chair in a stretcher position. Press the right button to place the unit into the chair position.

AWARNING

PATIENT MUST ENTER / EXIT FROM THE SIDE WITH THEIR BODY WEIGHT CENTERED OVER SEAT SECTION.

PATIENT INGRESS / EGRESS SHOULD ALWAYS BE MADE WITH THE UNIT IN AN UPRIGHT-CHAIR POSITION WITH CASTERS LOCKED.



For additional assistance, please contact us at:

800-237-3377 | 352-854-2929 5516 SW 1st Lane, Ocala, FL 34474 WincoMfg.com