


# TOLSEN

**HYDRAULIC  
TROLLEY JACK**



BUY ON

[www.cablematic.com](http://www.cablematic.com)

## SAFETY

Always follow safety precautions when installing and operating this jack. Keep all decals on the unit clean and visible. Before proceeding ensure that you fully understand and comprehend the full contents of this manual. Failure to operate this equipment as directed may cause injury or death. The distributor is not responsible for any damages or injury caused by improper use or neglect.



### THIS IS A LIFTING DEVICE ONLY!

- This jack is designed only for lifting part of the total vehicle.
- Do not move or dolly the vehicle while on the jack.
- The vehicle must be supported after lifting immediately by appropriately rated jack stands.
- NEVER go under a vehicle that is not supported with appropriately rated jack stands.
- Use wheel chocks or other blocking device on opposing wheels before using jack stands.

### ⚠ WARNING!

#### Always use Jack Stands!

**DO NOT USE** wood blocks or any other non-approved load sustaining devices. The manufacturer only warrants loads to be sustained by jack stands that meet current ASME standards.

**DO NOT USE** wood blocks or any other non-approved lifting devices for a means of lifting with the jack and/or load being raised. Failure to heed these warnings may cause injury or death.

## SAFETY MARKINGS

### ⚠ WARNING!

1. Study, understand, and follow all instructions before operating this device.
2. Do not exceed rated capacity.
3. Use only on hard, level surfaces, with less than 3 degrees of slope.
4. Lifting device only. Immediately after lifting, support the vehicle with appropriate means.
5. Do not move or dolly the vehicle while on the jack.
6. Lift only on areas of the vehicle as specified by the vehicle manufacturer.
7. No alterations shall be made to this product.
8. Only attachments and/or adapters supplied by the manufacturer shall be used.
9. Do not get under or allow anyone under the vehicle until it has been supported by jack stands.
10. Center load on saddle prior to lifting.
11. Use wheel chocks or other blocking device on opposing wheels before using jack.
12. Never use on a lawn mower or lawn tractor.
13. Do not use this jack for any use other than the manufacturer specified usage.
14. Failure to heed these markings may result in personal injury and/or property damage.

BUY ON

[www.cablematic.com](http://www.cablematic.com)

## GENERAL SAFETY INSTRUCTIONS

### Always Use Jack Stands

After lifting the vehicle always support the load with appropriately rated vehicle Jacks stands before working on the vehicle.

### Do Not Overload Jack

Do not overload this jack beyond its rated capacity. Overloading this jack beyond its rated capacity can cause damage to or failure of the jack.

### Always Use on Hard Level Surfaces

This jack is designed only for use on hard level surfaces capable of sustaining the load. Use on unstable or other possible loss of load.

### Chock and Block (Stabilize)

Apply parking brake in vehicle before operating jack.

A chock is a wedge for steadying an object and holding it motionless, or for preventing the movement of a wheel. Chock the wheel opposite the end being lifted.

When you block a load, you secure and support a load that is being lifted. The block(s) or stabilizer(s) should have a weight capacity that is greater than the weight of the load which is being lifted.

### Center Load on Jack Saddle

Center load on jack saddle before lifting vehicle.

Off-center loads and loads lifted when the jack is not level can cause loss of load or damage to the jack.

Do not raise or lower the vehicle unless tools, materials and people are clear.

When the lift is being lowered, make sure there are no tools or equipment left under or around the jack before lowering.

### Always lower the jack slowly.

### DO NOT USE THE JACK TO SUPPORT OR STABILIZE A LOAD.

Using the jack to support or stabilize a load may result in unexpected movement and result in serious injury, being crushed and death. Always securely chock and block (stabilize) the load to be lifted. Never place any part of the body under a raised load without properly chocking and supporting the load.

### Never use the jack on curved or tubular vehicle

Bumpers, this will result in the vehicle slipping off the jack and falling, causing serious injury or death. Use a bumper lift to lift most vehicles with curved bumpers or plastic bumpers.

### Wear safety glasses and heavy-duty work gloves during use.

### Do not adjust the safety valve.

### Do not move or dolly vehicle while jack is in use.

Stay alert. Use caution and common sense when operating jack. Do not use a jack when tired, incoherent, dizzy, under the use of drugs or alcohol.

### Training

Read this manual before use. Do not allow anyone who has not read this manual, and/or does not understand the requirements, to use the jack.

### Spectators

Do not allow bystanders around the jack or under the load supported only by the jack. -Do not allow anyone in the vehicle while the jack is in use. Keep all bystanders away from vehicle when in use.

### Inspection

Inspect the jack carefully before each use. Ensure the jack is not damaged, excessively worn, or missing parts. -Do not use the jack unless it is properly lubricated. -Using a jack that is not in good clean working condition or properly lubricated may cause serious injury.

### Additional Notes:

**Do not modify the jack in any way.** Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the jack was designed.

**Always check for damaged or worn out parts before using the jack.** Broken parts will affect the equipment operation. Replace or repair damaged or worn parts immediately.

When jack is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.

## BEFORE USE

1. Before using this product, read the owner's manual completely and familiarize yourself thoroughly with the product and the hazards associated with its improper use.
2. Perform the air purge procedure. (See previous instructions for system purge procedure.)
3. Check and that the pump operates smoothly before putting into service.
4. Inspect before each use. Do not use if bent, broken or cracked components are noted.

### RAISING THE JACK

1. Block the vehicle's wheels for lifting stability. Secure the load to prevent inadvertent shifting and movement.
2. Position the jack near desired lift point.
3. Set the Parking Brake in the vehicle.
4. Refer to the vehicle manufacturer owner's manual to locate approved lifting points on the vehicle. Position the jack so that the saddle is centered and will contact the load lifting point firmly.
5. Assemble the handle, ensure that spring clips align with slots.
6. Close the release valve by turning it clockwise until it is firmly closed.

## OPERATING INSTRUCTIONS

**▲ IMPORTANT:** Before attempting to raise a vehicle, check vehicle service manual for recommended lifting surfaces.

**▲ CAUTION:** Keep hands or feet away from the hinge mechanism of the jack.

1. To raise load: Close release valve tightly (by turning handle clockwise) **DO NOT OVERTIGHTEN**. Position jack under load so that saddle will contact load firmly and load is centered so it cannot slip. Operate jack handle until saddle approaches the load. Once again check to see that saddle is correctly positioned. Raise load to desired height. Place jack stands of appropriate capacity under the vehicle. **DO NOT CRAWL UNDER VEHICLE WHILE LIFTING VEHICLE OR PLACING OR REMOVING JACK STANDS!** Place jack stands at vehicle manufacturer's recommended lift areas that provide stable support for the raised vehicle.
2. To lower load: Open release valve **VERY SLOWLY** (by turning handle counterclockwise). When release valve is opened, saddle and load will be lowered. Lower the vehicle slowly so as not to shock load the jack stands. Once repairs are completed, raise vehicle enough to remove jack stands. Lower vehicle very slowly.

**▲ CAUTION:** Keep hands or feet away from the hinge mechanism of the jack.

BUY ON

[www.cablematic.com](http://www.cablematic.com)

## MAINTENANCE INSTRUCTIONS

If you use and maintain your equipment properly, it will give you many years of service. Follow the maintenance instructions carefully to keep your equipment in good working condition. Never perform any maintenance on the equipment while it is under a load.

### Inspection

You should inspect the product for damage, wear, broken or missing parts (e.g.: pins) and that all components function before each use. Follow lubrication and storage instructions for optimum product performance.

### Binding

If the product binds while under a load, use equipment with equal or a larger load capacity to lower the load safely to the ground. After un-binding; clean, lubricate and test that equipment is working properly. Rusty components, dirt, or worn parts can be causes of binding. Clean and lubricate the equipment as indicated in the lubrication section. Test the equipment by lifting without a load. If the binding continues contact Customer Service.

### Cleaning

If the moving parts of the equipment are obstructed, use cleaning solvent or another good degreaser to clean the equipment. Remove any existing rust, with a penetrating lubricant.

### Lubrication

This equipment will not operate safely without proper lubrication. Using the equipment without proper lubrication will result in poor performance and damage to the equipment. Some parts in this equipment are not self-lubricating inspect the equipment before use and lubricate when necessary. After cleaning, lubricate the equipment using light penetrating oil, lubricating spray.

- Use a good lubricant on all moving parts.
- For light duty use lubrication once a month.
- For heavy and constant use lubrication recommended every week.
- **NEVER USE SANDPAPER OR ABRASIVE MATERIAL ON THESE SURFACES!**

### Rust Prevention:

Check rams and pump plungers on the power unit assemblies daily for any signs of rust or corrosion. Without a load lift the equipment as high as it goes and look under and behind the lifting points. If signs of rust are visible clean as needed.

### Grease Fittings

Some models contain grease fittings the will regularly need to be greased and lubricated.

### How the Jack Operates

With release valve closed, an upward stroke of the jack handle draws oil from the reservoir tank into the plunger cavity. Hydraulic pressure holds the valve closed, which keeps the oil in the plunger cavity. A downward stroke of the jack handle releases oil into the cylinder, which forces the ram out. This raises the saddle. When the ram reaches maximum extension, oil is bypassed back into the reservoir to prevent an over extended ram stroke and possible damage to the jack. Opening the release valve allows oil to flow back into reservoir. This releases hydraulic pressure on the ram, which results in lowering the saddle.

### Storing the Jack

1. Lower the Lifting Arm.
2. Place the handle in the upright position.
3. Store in a dry location, recommended indoors.

Note: If the jack is stored outdoors, be sure to lubricate all parts before and after use to ensure the jack stays in good working condition. Always store jack in the fully retracted position when stored in outdoor or caustic environments that can cause corrosion and/or rust.

**IMPORTANT:**

When adding or replacing oil, always use a quality hydraulic oil. DO NOT use brake fluid, transmission fluid, alcohol, glycerine, detergent motor oil, or dirty oil as improper fluid can cause serious internal damage to jack. To add oil: With saddle fully lowered and jack on level ground, remove filler plug. Oil should be filled to level of oil filler plug hole. If low, add oil as needed. Maintenance and Inspection: The owner and/or user must maintain and inspect the jack in accordance with the manufacturer's instructions.




Fig. 1

**TROUBLESHOOTING**

JACK WILL NOT LIFT LOAD	JACK WILL NOT HOLD LOAD	JACK WILL NOT LOWER	POOR JACK LIFTING	WILL NOT LIFT TO FULL EXTENSION	CAUSES AND SOLUTIONS
X	X		X		Release valve is not completely closed (Turn handle clockwise).
X					Weight Capacity Exceeded.
X			X		Air is in the hydraulics. Purge air from system.
X	X		X	X	Low oil level. Add oil as required.
		X			Oil reservoir is overfilled. Drain excessive oil. Lubricate moving parts.
		X			Jack is binding or foreign obstruction
X	X		X		Power unit malfunctioning. Replace the power unit.

Safe Operating Temperature is between 40°F – 105°F (4°C - 41°C)


**65462 PART LIST & EXPLODING VIEW**

Item	Description	QTY
1	Carrying handle	1
2	Nut	4
3	Flat washer	4
4	Side member, right	1
5	Radius link	2
6	Retaining ring	4
7	Washer	1
8	Saddle-A	1
9	Cover plate	1
10	Cap	1
11	Spindle side member	1
12	Handle	1
13	Anchor bolt	2
14	Nut	2
15	Spring washer	2
16	Spacer front wheel	2
17	Front wheel	2

Item	Description	QTY
18	Pin, mount saddle	1
19	Retaining ring	2
20	Mount, saddle	1
21	Spindle, front wheel	1
22	Retaining ring	2
23	Lifting arm	1
24	Cross head pin	1
25	Caster wheel	2
26	Fork, caster wheel	4
27	Spindle, caster wheel	2
28	Slewing bearing	2
29	Bolt, caster wheel	2
30	Steel ball, bearing	2
31	Lock washer	2
32	Nut	2
33	Side member, left	1
34	Return spring	1
35	Hydraulic unit assembly	1


BUY ON

[www.cablematic.com](http://www.cablematic.com)



Item	Description	QTY
P01	Piston rod	1
P02	Piston head	1
P03	Back-up ring	1
P04	O-ring seal	1
P05	Cylinder ram	1
P06	Washer	1
P07	Screer filler body	1
P08	Steel ball	1
P09	Body hydraulic unit	1
P10	Steel ball	2
P11	O-ring seal	2
P12	Release valve	1
P13	Screen washer pump	1
P14	Cylinder pump	1
P15	Overload valve adjusting screw	1
P16	Spring	1

Item	Description	QTY
P17	Spring guid overload valve	1
P18	Steel ball	1
P19	Top nut	1
P20	O-ring seal	1
P21	Fiber washer oil chamber	1
P22	Oil chamber	1
P23	Filler plug	1
P24	Fiber washer oil chamber	1
P25	O-ring seal	1
P26	O-ring seal	1
P27	Back-up ring	1
P28	Piston	1
P29	Link piston	1
P30	Connector pin	1
P31	Connector pin	1
P32	Handle sleeve	1
P33	Set pin	2



BUY ON  
[www.cablematic.com](http://www.cablematic.com)

BUY ON

[www.cablematic.com](http://www.cablematic.com)

Item	Description	QTY
P01	Piston rod	1
P02	Piston head	1
P03	Back-up ring	1
P04	O-ring seal	1
P05	Cylinder ram	1
P06	Washer	1
P07	Screer filler body	1
P08	Steel ball	1
P09	Body hydraulic unit	1
P10	Steel ball	2
P11	O-ring seal	2
P12	Release valve	1
P13	Screen washer pump	1
P14	Cylinder pump	1
P15	Overload valve adjusting screw	1
P16	O-ring seal	1

Item	Description	QTY
P17	Spring	1
P18	Spring guid overload valve	1
P19	Steel ball	1
P20	Top nut	1
P21	O-ring seal	1
P22	Fiber washer oil chamber	1
P23	Oil chamber	1
P24	Filler plug	1
P25	Fiber washer oil chamber	1
P26	Back-up ring	1
P27	Piston	1
P28	Link piston	1
P29	Connector pin	1
P30	Connector pin	1
P31	Handle sleeve	1
P32	Set pin	2

