



# BEAMS ACTIVE PHOTOELECTRIC DETECTOR WITH DIGITAL FREQUENCY CONVERSION INSTALLATION GUIDE



BUY ON  
[www.cablematic.com](http://www.cablematic.com)



# Model:

**Three Beam-50 (Outdoor 50m, Indoor 150m)**


**Three Beam-100 (Outdoor 100m, Indoor 300m)**

**Three Beam-150 (Outdoor 150m, Indoor 450m)**


**Three Beam-200 (Outdoor 200m, Indoor 600m)**

**Three Beam-250 (Outdoor 250m, Indoor 750m)**


## I. Part Name



➔ Housing





Signal strength receiving indicator. In the diagram, after adjustment of the beam, the level 5 shall light up. Otherwise, adjust again. It is strongly recommended that it should be adjusted to the point until level 7 or higher lights up.





- Power transmit indicator
- LEVEL: Indicators turns on when the beam align presents. Specific alignment accuracy refer to signal strength receiving indicator.

- ALARM: The indicator turns on when alarm presents.
- GOOD: The green indicator turns on when the beam aligns with the receiver. If fails to align, the indicator will OFF.




## II Precautions for setting



Multi sensors may be used for long-distance guarding. Please install according to the below diagram to avoid interference between beams.




● Adjustable angle: horizontal  $\pm 90^\circ$   
vertical  $\pm 10^\circ$




Style	Guarding distance	Beam spread diameter
50	50m	1.5m
100	100m	3.0m
150	150m	4.5m
200	200m	6.0m
250	250m	7.5m

### III Setting procedure


1. Remove the cover






3. Put the cable through the hole for wiring.



4. Fix the main body onto the wall




5. Connect the cable to the wire terminal.




6. Put on the cover after adjusting the response time of the beam.

### ● Installation of fixed bracket


1. Drill a hole on the bracket and extend out the cable from it.




2. Remove the cover.



3. Fasten the base-plate to the bracket.



(Back-to-back installation guiding diagram)



Wiring distance between transmitter and receiver





wire size	distance	voltage	
		DC13.8V	DC24V
0.5mm <sup>2</sup> (φ0.8)		300m	300m
0.75mm <sup>2</sup> (φ1.0)		400m	800m
1.25mm <sup>2</sup> (φ1.2)		700m	1400m
2.0mm <sup>2</sup> (φ1.6)		1000m	2000m

# IVBeam alignment

## Visual test method

1. Remove the cover and connect power.
2. Adjust the beam frequency of transmitter and receiver to the same channel.
3. Observe the collimation effect at a distance of 5cm from the viewfinder. Adjust the upper / lower angle regulation screw and horizontal adjustment wheel in order that the image of opposite detector falls into the central part of the viewing hole.
4. Adjust the vertical adjustment screw and the horizontal

angle adjusting wheel, the signal strength indicator will light up step by step, adjust until level 5 or higher indicator lights up. If not, adjust it again.




Multimeter selects DC 10V


## Voltage test method

1. Insert the test pen into the test hole (please note the +,- polarity)
2. First adjust the horizontal angle until the test hole voltage output maximize. Then adjust the vertical angle by the same way.

## VBeam response time adjustment



Please see the diagram to adjust the response time of the receiver. Usually, the time set shall be less than the time when the intruder crosses the guarding area.




High speed:1

Fast running(6.9m/s):2

Fast walking(1.2m/s):3

Normal walking(0.7m/s):4

Slow walking(0.4m/s):5



## VIPhysical test

Walking test is required after the setting, physical test in accordance to below diagram.

	State	Signal
Transmitter	Transmitting	The 2 indicators of green LED light up
Receiver	Guarding	GOOD LEVEL indicators light up
	In alarm	The red ALARM indicator light up

## VII. Trouble checking


Fault	Cause	Solution
The LED of the transmitter doesn't light up	Power failure (open circuit, short-circuit, etc.)	Check the power wiring
The LED of the receiver doesn't light up	Power failure (open circuit, short-circuit, etc.)	Check the power wiring
The LED of the receiver doesn't light up when the light is blocked	<ol style="list-style-type: none"> <li>1.By reflecting, or light from other sources enter the receiver</li> <li>2.Both beams are not blocked at the same time</li> <li>3.Response time is set too short</li> </ol>	<ol style="list-style-type: none"> <li>1.Remove the reflecting object or change the direction of beam</li> <li>2. Block both beams at the same time</li> <li>3.Prolong the response time</li> </ol>
The receiver alarm indicator ON after the beam is blocked, but there is NO alarm signal output	<ol style="list-style-type: none"> <li>1.Broken circuit or short-circuit of the wiring</li> <li>2.Poor contact</li> </ol>	<ol style="list-style-type: none"> <li>1.Check the wiring and contact</li> <li>2.Connect the cable</li> </ol>
The alarm indicator of the receiver is constantly ON.	<ol style="list-style-type: none"> <li>1.The beam doesn't match closely</li> <li>2.There is obstacle presents between the transmitter and the receiver</li> <li>3.The cover is polluted.</li> </ol>	<ol style="list-style-type: none"> <li>1.Re-adjust the beam</li> <li>2.Remove the obstacle</li> <li>3.Clear the cover</li> </ol>
Intermittent alarm signal output	<ol style="list-style-type: none"> <li>1.Improper wiring</li> <li>2.The supply voltage does not reach 13V or higher</li> <li>3.The potential obstacle appears to block the beams due to the effect of wind and rain</li> <li>4.The installation base unstable</li> <li>5:The beam coincidence accuracy is inadequate</li> <li>6.Beams blocked by other moving objects</li> <li>7.Response time too short</li> <li>8.Level 5 LED does not light up before the cover is put on</li> </ol>	<ol style="list-style-type: none"> <li>1.Check the wiring</li> <li>2.Check the supply power</li> <li>3.Remove the obstacle or change the location</li> <li>4.Select a site with a stable base</li> <li>5.Re-adjust the optical axis</li> <li>6.Adjust the shade time or change the install location</li> <li>7.Re-adjust the response time</li> <li>8.Re-adjust the optical axis, and make the signal reception reaches its top.</li> </ol>

## VIII Technical parameters:

Model	50	100	150	200	250	
Alert distance	Outdoor	50m	100m	150m	200m	250m
	Indoor	150m	300m	450m	600m	750m
No. of beams	3 beams					
Detection mode	3 beams blocked simultaneous					
Optical source	Infrared digital pulse beam					
Response speed	50 ~ 700msec adjustable					
Alarm output	Relay contact output: NO. NC contact rating: AC/DC30V 0.5Amax					
Power supply	DC13.8 ~ 24V AC11 ~ 18V P ≥ 15W					
Power consumption	70mAmax	80mAmax	90mAmax	100mAmax		
Operation temperature & humidity	-25℃~55℃ 5%~95%RH(relative humidity)					
Dimensions	Refer to its diagram					
Tamper output	Contact output: NC contact rating DC24V 0.5Amax					
Optical axis adjustment(H)	± 180° ( ± 90° )					
Optical axis adjustment(V)	20° ( ± 10° )					
Viewfinder	Detachable					
Protection against dew, frost	Calefaction housing (optional)					
Material	PC resin					
Gross	1450g					

# IX. Recommended installation guide & physical appearance and dimension

Recommended installation



Installation bracket

T-shaped bracket  
 T-100  
 100 x 120mm  
  
 T-200  
 200 x 120mm

I-shaped bracket  
 I-100  
 100mm  
  
 I-200  
 200mm

L-shaped bracket  
 80 x 75mm



Physical appearance & dimension

