

## HUAEN NOTE COUNTER FOR H-5388 QUICK START GUIDE



### 1. Key introduction

**RESTART:** Used to start counting operation in the following cases. To resume counting after an error is cleared. To clear the displayed counted number. Press to start counting.

**MG:** Press "MG" key , the MG light on, the magnetic function open

**UV:** Press "UV" key , the UV light on, the ultraviolet function open

**ADD:** In order to turn on bank note addition, press "ADD" key until the add lights on. To turn the adding off, press "ADD" once again

**BATCH:** Press "BATCH" key to show 100/50/20/10

**+** : Under batch function , press "+" key can add batch no.

**-** : Under batch function , press "-" key can minus batch no.

### 2. Quick&Easy Operation

1. **Voice** : Press "+" key long time until machine show Y01, the voice on, press "+" or "-" key to shot time to show Y00 , voice off .

Let the machine run or press "RESTART" key to save the change

2. **Fake note counting:** Press "-" key long time until machine show U01 , fake note counting , press "+" or "-" key to shot time to show U00 , fake note not counting.

Let the machine run or press "RESTART" key to save the change

3. **UV setting:** Press "UV" key long time until machine show A05 , press "+" or "-" key to shot time to change setting from 0-10.

Let the machine run or press "RESTART" key to save the change

4. **MG setting:** Press "MG" key long time until machine show b05, press "+" or "-" key to shot time to change setting from 0-10.

Let the machine run or press "RESTART" key to save the change

### 3. Factory setting

Press "MG" key then power on the machine show 9999999 , factory setting success .

### 4. Sensitivity setting

Press "ADD" key at the same time until machine show H-01, press "BATCH" & "ADD" to shift from each setting, then press "UV" or "MG" key to set time to change parameter. Press "RESTART" to exit

Code reference:

CODE	Terms	Original	Instruction
H-01	VOICE	1	0 : OFF , 1 : ON
H-02	FAKE NOTE COUNTING	1	0 : OFF , 1 : ON
H-03	PIECE COMPARE	1	0 : ON , 1 : OFF
H-04	Frag note test	1	0 : ON , 1 : OFF
H-05	Slope compensation	1	0 : OFF , 1 : GENERAL , 2:High-supply
H-06	LCD standby	3	0-10 , 0:ON
H-13	Single counting tube opto repair time	10	The greater and the longer repair time
H-E	DOUBLE NOTE	0(0-10)	0:OFF , The greater No. The higher sensitivity, error code :d
H-C	Chain note	3	0:off , The greater No. The higher sensitivity error code:C
H-A	UV	6	The small No. The higher sensitivity error code:A
HB1	Ruble MG	5	The greater No. The higher sensitivity error code:b

### 5. Error code

CODE	REASON	CODE	REASON
A	UV	FE1	Start sensor
b	MG	FE2	Left IR
C	Chain note	FE3	Right IR
D	Size	FE6	Clear
E	Double note	FE7	Disc code
F	Slope	FE9	Magnetic
H	Half note	FEA	UV light