



EurotestAT
MI 3101
Short instructions
Version 4.1, HW5, Code no. 20 751 321

Distributor:

Manufacturer:

METREL d.d.
Ljubljanska cesta 77
1354 Horjul
Slovenia

web site: <http://www.metrel.si>

e-mail: metrel@metrel.si




Mark on your equipment certifies that this equipment meets the requirements of the EU (European Union) concerning safety and interference causing equipment regulations

© 2006..2010 METREL


No part of this publication may be reproduced or utilized in any form or by any means without permission in writing from METREL.

1. Safety and operational considerations

1.1. Warnings

- **This document cannot be a substitute for the Instruction manual!**
- **Before using EurotestAT instrument read the Instruction manual carefully, otherwise use of the instrument may be dangerous for the operator, for the instrument or for equipment under test!**
- ** Symbol on the instrument means »Read the Instruction manual with special care«. The symbol requires an action!**
- **If the test equipment is used in a manner not specified in Instruction manual the protection provided by the equipment may be impaired!**
- **Do not use the instrument and accessories if any damage is noticed!**
- **In case a fuse has blown follow the instructions in Instruction manual to replace it!**
- **Consider all generally known precautions in order to avoid risk of electric shock while dealing with hazardous voltages!**
- **Do not use the instrument in supply systems with voltages higher than 550 V!**
- **Service intervention or adjustment and calibration procedure is allowed to be carried out only by a competent authorized person!**
- **Use only standard or optional test accessories supplied by your distributor!**
- **Consider that older and some of new optional test accessories compatible with this instrument meet over voltage category CAT III / 300 V! It means that maximum allowed voltage between test terminals and ground is 300 V!**
- **Instrument contains rechargeable NiCd or NiMh batteries. The batteries should only be replaced with the same type as defined on the battery placement label or in Instruction manual. Do not use standard batteries while power supply adapter is connected, otherwise they may explode!**
- **Hazardous voltages exist inside the instrument. Disconnect all test leads, remove the power supply cable and switch off the instrument before removing battery compartment cover.**

1.2. Batteries

- ❑  When battery cells have to be replaced or before opening battery/fuse compartment cover, disconnect any measuring accessory connected to the instrument and power off the instrument, hazardous voltage inside!
- ❑ Insert cells correctly, otherwise the instrument will not operate and the batteries could be discharged.
- ❑ If the instrument is not used for a long period of time remove all batteries from the battery compartment.
- ❑ Alkaline or rechargeable Ni-Cd or Ni-MH batteries (size AA) can be used. The operating hours are given for cells with normal capacity of 2100 mAh.
- ❑ Do not recharge alkaline batteries!

The batteries are charged whenever the power supply adapter is connected to the instrument. In-built protection circuits control the charging procedure and assure maximal battery lifetime. Power supply socket polarity is shown in figure below.



Power supply socket polarity





Note:

- ❑ Use only power supply adapter delivered from manufacturer or distributor of the test equipment to avoid possible fire or electric shock!

1.3. Communication

There are two communication interfaces available on the instrument: USB and RS 232.

How to select interface port on the instrument:

- ❑ Select the  menu and then the  option.
- ❑ With the keys ↑ / ↓ select communication port ( or ).
- ❑ Press the TEST key to confirm selected port.

How to transfer stored data:

- ❑ Select appropriate communication interface (USB / RS 232).
- ❑ Power on the PC and the instrument.
- ❑ Run the program Eurolink.
- ❑ The PC and the instrument automatically recognize each other.
- ❑ Use the program for: downloading data, clearing storage, modifying user data, preparing reports and exporting for spreadsheet.

Note:


- ❑ Only one interface port of the instrument can be active at the same time.
- ❑ USB drivers should be installed on PC before using the USB interface. Refer to USB installation instructions available on installation CD.

Communication transfer speed:

RS 232 115200 baud

USB 256000 baud

2. Instrument front panel



Legend:

- 1 Switches the instrument power on or off.
- 2 Accesses help menus.
- 3 Adds new memory location/ Confirmation of name entered in edit mode.
- 4 Enters memory editing mode/ Deletes character on the left in edit mode.
- 5 Memory handling.
- 6 Exits selected and displayed option.
- 7 Jumps between display windows (TAB).
- 8 Cursor keypad with TEST key.
- 9 Changes backlight level and contrast.
- 10 ... 320 x 240 dots matrix display with backlight.

3. Auto sequence

- | | |
|---|--|
| <p>1 Set function</p> <ul style="list-style-type: none"> <input type="checkbox"/> Select Auto sequence in Main menu. <input type="checkbox"/> Use cursors ← / → to select appropriate test sequence. | <p>2 Set parameters and limits</p> <ul style="list-style-type: none"> ↓ / ↑ ... Select auto sequence step or parameter. ← / → ... Select test function or parameter value. TAB Enters test function parameters setup menu. F1..... Name / description or pause / comment menus. |
|---|--|

- 3 Building auto sequence procedure**
- Select auto sequence in the main menu.
 - Press the TEST key.
 - Select auto sequence number (← / →).
 - Edit name and description if necessary (F1).
 - Repeat until finished (maximum 6 steps):
 - ◆ Select auto sequence step (↓ / ↑).
 - ◆ Select auto sequence function (← / →).
 - ◆ Select auto sequence test parameters of the function (TAB).
 - ◆ Set / reset pause flag **||** and select or enter comment if necessary (F1).
 - Name (or rename) the auto sequence (F1).
 - Save prepared auto sequence (F2).

- 4 Running auto sequence**
- Select auto sequence in the main menu.
 - Select correct auto sequence (← / →).
 - Connect the instrument to tested object.
 - Press TEST key.
 - The sequence will pause at the functions marked with pause flag **||**.
 - ◆ Press the TAB key to toggle between comments menu and auto sequence main menu.
 - ◆ Press the TEST key to continue with the auto sequence.
 - ◆ Press the F1 key to skip the target function or the ESC key to skip the remaining functions and finish the auto sequence.
 - The sequence will stop when invalid condition of test terminals is detected. It will:
 - ◆ Continue after correct condition is restored.
 - ◆ Skip the target function by pressing the F1 key or the remaining functions and finish the auto sequence by pressing the ESC key.
 - Results of a finished auto sequence can be viewed and stored.

5 View results

Particular test results

- The key ↓ into sequence field.
 - ◆ Press TEST key to display result of selected function.
 - ◆ Press TEST or ESC key.
 - ◆ The key ↓ (or ↑) for next function.
 - ◆ Repeat this part for all results.
- The key ↑ or the ESC key to exit view.

Displayed results:

- CONTINUITY** Measurement is finished and has failed.
- INSULATION** Measurement is finished and has passed.
- VOLTAGE** Measurement is finished. No comparison limit was applied.
- Z-LINE** Measurement is not performed yet (during test) or was skipped.
- Overall PASS result is reported if all performed tests passed.
- Overall FAIL result is reported if one or more performed tests failed.

4. Measurements

4.1. Inspections

1 Set function

- Select Single test in Main menu.
- Use cursors ← / → to find and choose the **VISUAL** function.
- Use cursors ↓ / ↑ to select appropriate item.

2 Set parameters
Item.....Inspection schedules.

3 Visual inspection procedure

- Select Schedule type.
- Press TEST key to start inspection.
- Browse through items line by line and apply appropriate flags.
- Press TEST or ESC key to stop inspection.
- Store the result (optional).

4 View results

FULL SCHEDULE 11:34

- (v) Electrical separation
- Prevention of mutual detrimental influence**
- a. Proximity of non-electrical services and other influences
- b. Segregation of Band I and Band II circuits of Band II insulation used
- c. Segregation of safety circuits
- Identification**
- Presence of diagrams, instructions, circuits charts and similar information
- Presence of danger notices and other warning notices
- Labelling of protective devices, switches and terminals

CLEAR ALL

FULL SCHEDULE DOMESTIC SCHEDULE

FULL SCHEDULE 11:36

SCHEDULE OF ITEMS INSPECTED

Methods of protection against electric shock

- a. Protection against both direct and indirect contact
- (i) SELV
- (ii) Limitation of discharge of energy
- b. Protection against direct contact:
- (i) Insulation of live parts
- (ii) Barriers of enclosures
- (iii) Obstacles
- (iv) Placing out of reach
- (v) PELV
- (vi) Presence of RCD for supplementary protection

CLEAR ALL

FULL SCHEDULE DOMESTIC SCHEDULE

DOMESTIC SCHEDULE 11:36

SCHEDULE OF ITEMS INSPECTED

Methods of protection against electric shock

- Insulation of live parts, and barriers of enclosures
- Presence of RCD(s) for supplementary protection against direct contact and/or protection against indirect contact
- Presence of earthing conductors and circuit protective conductors
- Presence of main equipotential bonding conductors
- Presence of supplementary equipotential bonding conductors
- Class II fixed equipment
- SELV

CLEAR ALL

FULL SCHEDULE DOMESTIC SCHEDULE

FUNCTIONAL INSPECTION 11:36

SCHEDULE OF ITEMS TESTED

- Functional testing of assemblies

CLEAR ALL

FUNCTIONAL INSPECTION


Markings:

- Inspection was not performed
- Inspection passed.
- Inspection failed.
- Inspection was performed in limited extent.
- Inspection was not applicable.

4.2. Insulation resistance

- ① **Set function**
 - ❑ Select Single test in Main menu.
 - ❑ Use cursors \leftarrow / \rightarrow to find and choose the **INSULATION** function.
- ② **Set parameters and limits**

TESTTest configuration.
U_{iso}Test voltage.
Limit.....Minimum insulation resistance.



- ④ **Insulation resistance measuring procedure**
 - ❑ **Disconnect** tested installation from mains supply (and discharge tested insulation).
 - ❑ **Connect** test cable to the instrument and tested item.
 - ❑ Press the **TEST** key for measurement (keep pressing for continuous measurement).
 - ❑ After the measurement is finished **store** the result (optional).

⑤ **View results**

INSULATION: ALL 11:18

R_{In}: **7.05 MΩ** U_m 516V
 R_{Ipe}: **20.1 MΩ** U_m 516V
 R_{npe}: **27.1 MΩ** U_m 517V

TEST: ALL
 U_{iso}: 500V
 Limit: OFF

VOLTAGE INSULATION CONTINUITY

INSULATION: L2-L3 12:27

R₂₃: **42.0 MΩ** ✓
 U_m 1050V

TEST: L2-L3
 U_{iso}: 1000V
 Limit: ON

POLARITY INSULATION Z-LINE Z-LOC

INSULATION: L-PE 10:46

R_{Ipe}: **40.5 MΩ**
 U_m 517V

TEST: L-PE
 U_{iso}: 500V
 Limit: OFF

INSULATION CONTINUITY Z-LINE

INSULATION: ALL 3ph 12:25

R₁₂: **8.15 MΩ** U_m 1050V
 R₁₃: **11.25 MΩ** U_m 1050V
 R₂₃: **7.94 MΩ** U_m 1050V

TEST: ALL 3ph
 U_{iso}: 1000V
 Limit: ON

POLARITY INSULATION Z-LINE Z-LOC

Displayed results:



- R_{In}** Insulation resistance between L (+) and N (-).
- R_{Ipe}** Insulation resistance between L (+) and PE (-).
- R_{npe}** Insulation resistance between N (+) and PE (-).
- U_m** Test voltage(s) – actual value(s).

Displayed results:



- R₁₂** Insulation resistance between L1 (+) and L2 (-).
- R₁₃** Insulation resistance between L1 (+) and L3 (-).
- R₂₃** Insulation resistance between L2 (+) and L3 (-).
- U_m** Test voltage(s) – actual value(s).

4.2.1. General resistance measurement

- | | |
|---|---|
| <p>1 Set function</p> <ul style="list-style-type: none"> <input type="checkbox"/> Select Single test in Main menu. <input type="checkbox"/> Use cursors ← / → to find and choose the CONTINUITY function. <input type="checkbox"/> Use cursors ↓ / ↑ to select sub-function General. | <p>2 Set parameters and limits</p> <p>TEST Resistance measurement sub-function.
 Current.. Test current (200 mA, 7 mA).
 Limit..... Maximum resistance.</p> |
|---|---|

<p>3 Test circuit for General 200 mA measurement</p> <p><small>MPEC...Main Potential Equilizing Collector PCC...Protection Conductor Collector</small></p>  <p style="text-align: center;">Connection of universal test cable plus optional extension lead</p>	<p>Test circuit for continuous resistance measurement (General 7 mA)</p>  <p style="text-align: center;">Universal test cable application</p>
---	--

- | | |
|--|---|
| <p>4 Measurement procedure</p> <ul style="list-style-type: none"> <input type="checkbox"/> Connect test cable to the instrument. <input type="checkbox"/> Compensate test leads resistance (if necessary). <input type="checkbox"/> Disconnect tested installation from mains supply (recommended). <input type="checkbox"/> Connect test leads to the tested PE wiring. <input type="checkbox"/> Press the TEST key for measurement. <input type="checkbox"/> After the measurement is finished store the result (optional). | <ul style="list-style-type: none"> <input type="checkbox"/> Connect test cable to the instrument. <input type="checkbox"/> Compensate test leads resistance (if necessary). <input type="checkbox"/> Disconnect tested object from mains supply (recommended). <input type="checkbox"/> Connect test leads to the tested object. <input type="checkbox"/> Press the TEST key for continuous measurement. <input type="checkbox"/> Press the TEST key to stop measurement. <input type="checkbox"/> After the measurement is finished store the result (optional). |
|--|---|

<p>5 View results</p> 	<p>Displayed results:</p> <p>R Main R200mA resistance (average of R+ and R- results), R+ ...R200mA sub-resistance with positive voltage at N terminal, R- ...R200mA sub-resistance with positive voltage at PE terminal.</p>	 <p>Displayed result: R....Resistance</p>
--	---	--

4.2.2. Continuity of star circuit connections, R1+R2, R2

1 Set function

- Select Single test in Main menu.
- Use cursors \leftarrow / \rightarrow to find and choose the **CONTINUITY** function.
- Use cursors \downarrow / \uparrow to select sub-function (R2, R1+R2).

2 Set parameters and limits

TEST Resistance measurement sub-function.
Cable..... Applied test cable (plug cable, universal).
Limit Maximum resistance.

3 Test circuit for Star R2 measurement

Connection of universal test cable

Test circuit for Star R1+R2 measurement

Plug cable and universal test cable application

4 Measurement procedure

- Connect** test cable to the instrument.
- Compensate** test leads resistance (if necessary).
- Disconnect** from mains supply and discharge tested installation.
- Connect** test cable to the tested wiring.
- Press the **TEST** key for measurement.
- Apply** manual PASS/FAIL (optional).
- After the measurement is finished **store** the result (optional).

5 View results

Displayed results:

R2..... Main R2 resistance (average of R+ and R-results),

R1+R2..... Main R1+R2 resistance (average of R+ and R-results),


R+..... Sub-resistance with positive voltage at N terminal,

R-..... Sub-resistance with positive voltage at PE terminal.

4.2.3. Compensation of test leads resistance

- ① **Set function**
- Select appropriate **CONTINUITY** function in Single test.
 - Press **F1** for compensating procedure.

- ② **Set parameters and limits**



- ④ **Measurement procedure**
- Connect test cable to the instrument.
 - Short** test leads intended for current earth bond resistance measurement.
 - Press the **TEST** key for compensating the test leads resistance.

⑤ **View results**

Displayed results:

....Resistance of the test leads is compensated.

.....Resistance of the test leads is not compensated.

4.3.1. Continuity in ring final circuits, R1+RN, R1+R2


① Set function

- Select Single test in Main menu.
- Use cursors \leftarrow / \rightarrow to find and choose the **RING CONT.** function.
- Use cursors \downarrow / \uparrow to select sub-function (R1+RN, R1+R2).


② Set parameters and limits

- TEST**..... Resistance measurement sub-function.
Cable..... Applied test cable (plug cable, universal).

③ Step 1 – test circuit



Step 2 – cross connections and verification of wall sockets



④ Measurement procedure


Step 1:

- Connect** test cable to the instrument.
- Disconnect** tested installation from mains supply.
- Compensate** test leads resistance (if necessary).
- Press the **TEST** key for measurements.
- Perform measurement between both ends of phase conductor.
- Commit result to r1.
- Perform measurement between both ends of neutral conductor.
- Commit result to rN.
- Perform measurement between both ends of PE conductor.
- Commit result to r2.

Step 2:


- Cross-connect** conductors of tested ring circuit.
- Press the **TEST** key for measurements on socket.
- Commit result.
- Perform measurement on next socket.
- Commit result. It will be committed only if it is higher than the previous one.
- Repeat last two steps on all sockets of the circuit.
- Press** the **F2** key to apply manual pass/fail of the result (optional).
- Press the **ESC** key to exit the measurement.
- After the measurement is finished **store** the result (optional).

5 View results



Displayed results:


r1..... line conductor resistance,
rN..... neutral conductor resistance,
r2..... protective conductor resistance,
(r1+r2)/4..... reference value for L-PE,
(r1+rN)/4..... reference value for L-N,
(R1+R2)max... worst socket resistance L-PE,
(R1+RN)max.. worst socket resistance L-N,



4.3.2. Continuity in ring final circuits, Auto

- ① **Set function**
- Select Single test in Main menu.
 - Use cursors ← / → to find and choose the **RING CONT.** function.
 - Use cursors ↓ / ↑ to select sub-function Auto.

- ② **Set parameters and limits**
- TEST.....Auto



- ④ **Measurement procedure**
- Step 1:
- Connect** Ring adapter to the instrument.
 - Disconnect** tested installation from mains supply.
 - Connect** Ring adapter to the tested installation.
 - Compensate** test leads resistance (if necessary).
 - Press the **TEST** key for measurements.
 - Perform measurements of r1, rN, and r2.
 - Commit results (F1 key) to r1, rN, and r2.
- Step 2:
- Disconnect** Ring adapter from the instrument.
 - Connect** plug cable or test cable to the instrument.
 - Press the **TEST** key for measurements.
 - Perform a measurement on socket.
 - The resistance R1+R2 slightly increases with length if cross section of PE conductor is smaller than of line conductor.
 - Commit results.
 - Perform measurement on next socket.
 - Commit results again. The results will be committed only if they are higher than the previous.
 - Repeat last two steps on all sockets of the circuit.
 - Press the F2** key to apply manual pass/fail of the result (optional).
 - Press the **ESC** key to exit the measurement.
 - After the measurement is finished **store** the result (optional).

⑤ **View results**

RING CONT. 14:00

r1: 0.15Ω (r1+N)/4= 0.07Ω

rN: 0.15Ω (r1+r2)/4= 0.07Ω

r2: 0.14Ω

(R1+R2)max: 0.16Ω 35.5Ω

(R1+R2)max: 0.14Ω 21.9Ω

F1 COMMIT

F2 [X]

TEST: Auto

VOLTAGE CONTINUITY RING CONT. PO

Displayed results:

- r1.....line conductor resistance,
- rN.....neutral conductor resistance,
- r2.....protective conductor resistance,
- (r1+r2)/4.....reference value for L-PE,
- (r1+rN)/4.....reference value for L-N,
- (R1+R2)max.....worst socket resistance L-PE,
- (R1+RN)max.....worst socket resistance L-N,

4.4. Polarity

① **Set function**

- Select Single test in Main menu.
- Use cursors ← / → to find and choose the **POLARITY** function.


② **Set parameters and limits**

No parameters in the function.

④ **Measurement procedure**

- Connect** test cable to the instrument.
- Compensate** test leads resistance (if necessary).
- Connect** test cable to the measured object.
- Press the **TEST** key for continuous measurement.
- Press the **TEST** key to stop measurement.
- Press** the **F2** key to apply manual pass/fail of the result (optional).
- After the measurement is finished, **store** the result (optional).

⑤ **View results**



Displayed result:
RResistance.

4.5. Testing RCDs


1 Set function

- Select Single test in Main menu.
- Use cursors \leftarrow / \rightarrow to find and choose the **RCD** function.
- Use cursors \downarrow / \uparrow to select sub-function (Contact voltage, Trip-out time, Trip-out current, Fault loop impedance, RCD autotest).

2 Set parameters and limits

TEST..... RCD sub-function test.


I_{Δn}..... Rated RCD residual current sensitivity I_{Δn}.

type..... RCD type [G, S], test current waveform plus starting polarity 

MUL..... Actual test current relative to rated I_{Δn}.

U_{lim}..... Conventional touch voltage limit.

3 Circuits for testing RCD



Connecting plug cable and universal test cable

4 Measurement procedure


Measurement procedure for Contact voltage, Fault loop impedance, Trip-out time and Trip-out current:

- Connect** test cable to the instrument.
- Connect** test leads to the tested object.
- Press the **TEST** key.
- After the measurement is finished **store** the result (optional).

Measurement procedure for RCD Autotest:

- Connect** test cable to the instrument.
- Connect** test leads to the tested object
- Press the **TEST** key.
- Test **t1** with I_{Δn}, 0°.
- Re-activate** RCD.
- Test **t2** with I_{Δn}, 180°.
- Re-activate** RCD.
- Test **t3** with 5×I_{Δn}, 0°.
- Re-activate** RCD.
- Test **t4** with 5×I_{Δn}, 180°.
- Re-activate** RCD.
- Test **t5** with ½×I_{Δn}, 0°; test **t6** with ½×I_{Δn}, 180°.
- After the measurement is finished **store** the result (optional).

5 View results




Displayed results:

- Uc** Contact voltage for rated I_{Δn},
- RI**..... Fault loop resistance,
- t**..... Trip-out time,
- I**..... Trip-out current,
- Uci**... Contact voltage at trip-out current,
- RMAX**.Limit earth fault loop resistance value acc. to BS 7671.

4.6. Fault loop impedance and prospective fault current

- ① **Set function**
- Select Single test in Main menu.
 - Use cursors \leftarrow / \rightarrow to find and choose the **Z-LOOP** function.
 - The F1 enables / disables Zmax function.

- ② **Set parameters and limits**
- FUSE Type** Selection of fuse type [---, BS88, BS3036, BS1361, BS1362, B, C, D].
- FUSE I** Rated current of selected fuse.
- FUSE T** Maximum breaking time of selected fuse.
- Z lim** Maximum fault loop impedance for selected fuse.



- ④ **Measurement procedure**
- Connect** test cable to the instrument.
 - Connect** test leads to the tested object.
 - Press the **TEST** key.
 - After the measurement is finished **store** the result (optional).

⑤ **View results**

--	--	--

Displayed results:

Z Fault loop impedance / maximum fault loop impedance in Zmax function,

Isc Prospective fault current,



R Resistive part of loop impedance,

XL Reactive part of loop impedance,

Uc Contact voltage.

4.7. Line impedance / prospective short-circuit current and Voltage drop

<p>① Set function</p> <ul style="list-style-type: none"> ❑ Select Single test in Main menu. ❑ Use cursors ← / → to find and choose the ██████ function. ❑ Use cursors ↑ / ↓ to find and choose the Z / ΔU sub-function. 	<p>② Set parameters and limits</p> <p>FUSE Type.....Selection of fuse type [---, BS88, BS3036, BS1361, BS1362, B, C, D].</p> <p>FUSE I.....Rated current of selected fuse.</p> <p>FUSE T.....Maximum breaking time of selected fuse.</p> <p>Z lim.....Maximum line impedance for selected fuse.</p> <p>Limit.....Maximum voltage drop.</p>
---	--



4 Measurement procedure

Line impedance

- Connect** test cable to the instrument.
- Connect** test leads to the tested object.
- Press the **TEST** key.
- After the measurement is finished **store** the result (optional).

Voltage drop




Step 1

- Connect** test cable to the instrument.
- Connect** the test leads to the origin of electrical installation.
- Press the **F1** key to perform the measurement of Zref.

Step 2


- Connect** test cable or plug cable to the instrument.
- Connect** the test leads to the tested points.
- Press the **TEST** key to perform the measurement.
- After the measurement is finished **store** the result (optional).

5 View results

Line impedance	Voltage drop
  <p>Displayed results:</p> <p>Z..... Line impedance, Isc..... Prospective short-circuit current, R..... Resistive part of line impedance, XL..... Reactive part of line impedance.</p>	 <p>Displayed results:</p> <p>ΔU..... Voltage drop, Isc..... Prospective short-circuit current, Z..... Line impedance at measured point, Zref..... Reference impedance.</p>

4.8. Voltage, frequency and phase sequence

- ① **Set function**
- Select Single test in Main menu.
 - Use cursors \leftarrow / \rightarrow to find and choose the **VOLTAGE** function.



- ③ **Measurement procedure**
- Connect test cable to the instrument.
 - Connect test leads to the tested object.
 - Store current measurement result (optional).

④ **View results**

Displayed results for single phase system:

- U_{l-n}**..... Voltage between phase and neutral conductors.
- U_{l-pe}**..... Voltage between phase and protective conductors.
- U_{n-pe}**..... Voltage between neutral and protective conductors.

Displayed results for three-phase phase system:

- U₁₋₂**..... Voltage between phases L1 and L2.
- U₁₋₃**..... Voltage between phases L1 and L3.
- U₂₋₃**..... Voltage between phases L2 and L3.
- 1.2.3** Correct connection.
- 2.3.1** Invalid connection.

4.9. Resistance to earth

1 Set function

- Select Single test in Main menu.
- Use cursors \leftarrow / \rightarrow to find and choose the **EARTH** function.
- Use cursors \downarrow / \uparrow to select test sub-function.

2 Set parameters and limits

Test..... Selection of test principle [3-wire, specific earth resistance ρ]

Limit Maximum resistance [OFF, 1 Ω ÷ 5 k Ω , 20 Ω (two clamps)]

For ρ only:
Distance ... Distance between probes [0.1 m ÷ 30.0 m] or [1 ft ÷ 100 ft].

3 Circuits for measuring resistance to earth

The first diagram shows 'Resistance to earth measurement – PE grounding' with a meter connected to points H, S, and E. Distances are marked as $>5d$ and d . The second diagram shows 'Resistance to earth measurement – lightning protection' with a meter connected to points H, S, and E, and additional points RE1, RE2, RE3, RE4. Distances are marked as $>5d$ and d . The third diagram shows 'Specific earth resistance measurement with ρ -adaptor' with a meter connected to points E, ES, S, and H. Distances between E, ES, and S are marked as a , and the depth of the probe is marked as $a/20$ max.

4 Measurement procedure

- Connect** test cable / ρ adaptor to the instrument.
- Disconnect** tested object from mains supply.
- Connect** test leads / ρ adaptor to the tested object.
- Press the **TEST** key.
- After the measurement is finished **store** the result (optional).

5 View results

The first screenshot shows 'EARTH: 3-WIRE' with a result of **R: 2.98 Ω** . It also displays $R_c: 0.1 k\Omega$ and $R_p: 2.8 k\Omega$. The second screenshot shows 'EARTH: ρ ' with a result of **$\rho: 1.01 k\Omega m$** . It also displays $R_c: 0.1 k\Omega$ and $R_p: 0.0 k\Omega$, and a distance of **15.7 m**.


Displayed results for earth resistance measurement:

- R**..... Earth resistance.
- ρ** Specific earth resistance.
- R_c** Resistance of S probe.
- R_p** Resistance of H probe.

4.10. Varistor test

- ① **Set function**
- Select Single test in Main menu.
 - Use cursors \leftarrow / \rightarrow to find and choose the **VARISTOR TEST** function.

- ② **Set parameters and limits**
- Lo limit** Minimum DC threshold voltage [50 V ÷ 1000 V].
- Hi limit** Minimum DC threshold voltage [50 V ÷ 1000 V].



- ④ **Measurement procedure**
- Disconnect mains supply and consumers from tested overvoltage device.
 - Connect** test cable to the instrument and tested item.
 - Press the **TEST** key for measurement.
 - After the measurement is finished wait until tested item is discharged.
 - Store** the result (optional).

⑤ **View results**

Displayed results for varistor test:

U.....Measured threshold voltage at It (1 mA).

Uac.....Rated AC voltage.

4.11. PE test terminal

① **Measurement procedure**

- ❑ **Connect** test cable to the instrument.
- ❑ **Connect** test leads to the tested object.
- ❑ Touch PE test probe (the **TEST** key) for at least one second.
- ❑ If PE terminal is connected to phase voltage the warning message is displayed, instrument buzzer is activated and further measurements are disabled.

② **Examples for intention of PE test terminal**

*Reversed phase and protection conductors!
THE MOST DANGEROUS SITUATION!*

Reversed L and PE conductors (application of plug cable)

*Reversed phase and protection conductors!
MOST DANGEROUS SITUATION!*


Reversed L and PE conductors (application of universal test cable)

4.12. Locator


① Measurement procedure

- ❑ Select the **LOCATOR** function in MISC menu.
- ❑ **Connect** test cable to the instrument.
- ❑ **Connect** test leads to the tested object.
- ❑ Press the **TEST** key.
- ❑ Trace lines with receiver (in IND mode) or receiver plus its optional accessory.
- ❑ After tracing is finished press the **TEST** key again to stop generation of test signal.

② Typical applications for tracing electrical installation



Tracing wires under walls and in cabinets




Locating individual fuses


5. Maintenance

5.1. Replacing fuses

- F1
M 0.315 A / 250 V, 20x5 mm
This fuse protects internal circuitry of low-value resistance function if test probes are connected to the mains supply voltage by mistake.
- F2, F3
F 4 A / 500 V, 32x6.3 mm
General input protection fuses of test terminals L/L1 and N/L2.

Warnings:

-  Disconnect any measuring accessory and power off the instrument before opening battery/fuse compartment cover, hazardous voltage inside!
- Replace blown fuse with original type only, otherwise the instrument may be damaged and/or operator's safety impaired!



Battery and fuse compartment

Legend:

- 1Fuse F1.
- 2Fuse F2.
- 3Fuse F3.
- 4Serial number label.
- 5Batteries or accus (size AA).
- 6Battery holder.

