

FLUKE®

566/568

Infrared Thermometers

Getting Started

PN 2812159
August 2007

© 2007 Fluke Corporation. All rights reserved. Printed in China.
All product names are trademarks of their respective companies.

LIMITED WARRANTY AND LIMITATION OF LIABILITY

This Fluke product will be free from defects in material and workmanship for two years from the date of purchase. This warranty does not cover fuses, disposable batteries, or damage from accident, neglect, misuse, alteration, contamination, or abnormal conditions of operation or handling. Resellers are not authorized to extend any other warranty on Fluke's behalf. To obtain service during the warranty period, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that Service Center with a description of the problem.

THIS WARRANTY IS YOUR ONLY REMEDY. NO OTHER WARRANTIES, SUCH AS FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSED OR IMPLIED. FLUKE IS NOT LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, ARISING FROM ANY CAUSE OR THEORY. Since some states or countries do not allow the exclusion or limitation of an implied warranty or of incidental or consequential damages, this limitation of liability may not apply to you.

Fluke Corporation
P.O. Box 9090
Everett, WA 98206-9090
U.S.A.
11/99

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands

Table of Contents

Title	Page
Introduction.....	1
Using the Thermometer.....	3
Connecting the Type K Thermocouple, USB Cable (568 Only), and Changing Batteries	3
Menu Overview	3
Specifications Summary.....	5

566/568
Infrared Thermometers

List of Tables

Table	Title	Page
1.	Top-Level Menu Description	4

List of Figures

Figure	Title	Page
1.	Laser Safety Markings.....	2
2.	Thermocouple and USB Connection and Changing Batteries.....	3
3.	Menu Navigation	4

Infrared Thermometers


Introduction

The 566 and 568 Infrared Thermometers (“the thermometers”) are for non-contact temperature measurement. These thermometers determine an object’s surface temperature by measuring the amount of infrared energy radiated by the object’s surface. The thermometers also support contact-temperature measurement via K-type thermocouple. See the Users Manual CD for complete operating instructions.

Safety Information

Warning

A Warning identifies conditions and actions that pose hazards to the user. To avoid personal injury, follow these guidelines:


- ** Do not point laser directly at eye or indirectly off reflective surfaces.**
- **Replace the batteries as soon as the low-battery indicator appears.**
- **Do not use the thermometer if it operates abnormally. Protection may be impaired. When in doubt, have the thermometer serviced.**
- **Do not operate the thermometer around explosive gas, vapor, or dust.**
- **Do not connect the optional external probe to live electrical circuits.**

- To avoid a burn hazard or fire, know that reflective objects may be much hotter than the indicated temperature reading.
 - Do not leave the thermometer on or near objects of high temperature.
 - Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous laser radiation exposure.

⚠ Caution

To avoid damaging the thermometer or the equipment under test, protect them from the following:

- EMF (electro-magnetic fields) from arc welders, induction heaters, etc.
- Static electricity
- Thermal shock (caused by large or abrupt ambient temperature changes- for highest accuracy, allow 30 minutes for thermometer to stabilize before use).




ewm08b.eps

Figure 1. Laser Safety Markings

Using the Thermometer

To take a temperature reading, point the Thermometer at the desired object and pull the trigger. You can use the laser pointer to help aim the Thermometer. You may also insert the K-type thermocouple probe for contact measurement.

Connecting the K-Type Thermocouple, USB Cable (568 Only), and Changing Batteries




ewm04.eps

Figure 2. Thermocouple and USB Connection and Changing Batteries

Menu Overview

There are many settings that can be easily changed by using the menu. Table 1 is a top-level description. Selecting the **Menu** button advances the menu to the next level. Figure 3 shows the LCD and menu interface. The Users Manual explains the menus in full detail.



ewm01a.eps

Figure 3. Menu Navigation

Table 1. Top-Level Menu Description

Level	Left Softkey	Description	Center Softkey	Right Softkey	Description
1	Save	Save reading to memory	Menu	Light	Turn on bright backlight
2	Mem	Review / delete memories	Menu	ϵ	Set emissivity
3	MnMx	Enables Min/Max	Menu	Avg	Enable Avg/Diff
4	°F/°C	Toggle between C and F	Menu	Alarm	Set and enable alarms
5	🔒 (Lock)	Lock the thermometer on	Menu	Laser	Toggle the laser on/off
6	Setup	<ul style="list-style-type: none"> - Turn off backlight - Change Time/Date - Change Language 	Menu		

Specifications Summary

See Users Manual on CD for full specifications.

Feature	566	568
IR Temperature Range	-40 °C to 650 °C (-40 °F to 1202 °F)	-40 °C to 800 °C (-40 °F to 1472 °F)
Accuracy above 0 °C (32 °F)	> 0 °C: $\pm 1\%$ or $\pm 1.0\text{ °C}$ (> 32 °F: $\pm 1\%$ or $\pm 2\text{ °F}$), whichever is greater	
K T/C Temperature Range	-270 °C to 1372 °C (-454 °F to 2501 °F)	
K T/C Input Accuracy	-270 °C to -40 °C: $\pm(1\text{ °C} + 0.2\text{ °/1 °C})$ (-454 °F to -40 °F: $\pm(2\text{ °F} + 0.2\text{ °/1 °F})$) -40 °C to 1372 °C: $\pm 1\%$ or 1 °C (-40 °F to 2501 °F: $\pm 1\%$ or 2 °F), whichever is greater	
Distance:Spot (90 % energy)	30:1	50:1
Laser sighting	Offset single laser < 1 mW	
Minimum spot size	19 mm	19 mm
Emissivity	Digitally adjustable from 0.10 to 1.00 by 0.01	
Data storage	20 points	99 points
Communication	None	USB 2.0
Operating Altitude	3000 meters above mean sea level	
Storage Altitude	12,000 meters above mean sea level	
Relative Humidity	10 % to 90 % RH non-condensing up to 30 °C (86 °F)	
Operating Temperature	0 °C to 50 °C (32 °F to 122 °F)	
Storage Temperature	-20 °C to 60 °C (-4 °F to 140 °F)	
Power	2 AA /LR6 Batteries	2 AA /LR6 Batteries or USB connection when used with a PC
Battery Life	12 hours with laser and backlight on; 100 hours with laser and backlight off, at 100 % duty cycle (continuously on)	

566/568*Getting Started*

Feature	K-Type Thermocouple Probe (Bead Type)
Measurement Range	-40 °C to 260 °C (-40 °F to 500 °F)
Accuracy above 0 °C (32 °F)	±1.1 °C (±2.0 °F)