

TRANSPORT CANADA TYPE APPROVAL No H-102

REGISTRATION No

SERIAL No

Indes on Technis

LA REU



ΒY

DATE 13 DEC. 1998





IT IS THE OPERATOR'S RESPONSIBILITY TO MAINTAIN THIS MANUAL IN A CURRENT IN ACCORDANCE WITH THE LIST OF EFFECTIVE PAGES.

THIS ROTORCRAFT FLIGHT MANUAL IS APPROVED FOR CANADIAN REGISTERED AIRCRAFT IN ACCORDANCE WITH THE CANADIAN AIRWORTHINESS MANUAL. THE TRANSPORT CANADA FLIGHT MANUAL CONSISTS OF ALL UNCODED AND CODED C PAGES MARKED "DGAC APPROVED".

THIS DOCUMENT SHALL BE CARRIED IN AIRCRAFT AT ALL TIMES.



EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : JUNE 1997



TITLE



LIST OF CONDITIONAL REVISIONS (CR) EFFECTIVE PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following pink pages except those cancelled when the conditions are complied with.

CAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

PAGE	DATE	REMARKS / EFFECTIVITY
	1	
	.1	
	PAGE	PAGE DATE



DGAC APPROVED REVISION 3 A



LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) EFFECTIVE PAGES

The manual contains the following additional yellow pages.

No	PAGE	DATE	No	PAGE	DATE	
						•



ITR 5D

Replace page A1 by the following : LIST OF APPLICABLE CONDITIONAL REVISIONS (RC) PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following pink pages except those canceled when the conditions are complied with.

CAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

No	PAGE	DATE	APPLICABLE BEFORE CONDITION IS MET :
RC 1	2 - 5	SEPT.99	SB N°32-001 (Skid blades landing gear) and Mod. N° A 00075 (installation of tail skid)
RC 1	5 - 7	NOV.00	SB N°32-001 (Skid blades landing gear) and Mod. N° A 00075 (installation of tail skid)
RC 1	5 - 8	NOV.00	SB N°32-001 (Skid blades landing gear) and Mod. N° A 00075 (installation of tail skid)
RC 2	2 - 1	SEPT.99	SB N°34-001 (Cabin adaptation for night VFR)
RC 2	2 - 14	SEPT.99	SB N°34-001 (Cabin adaptation for night VFR)
RC 2	2 - 15	SEPT.99	SB N°34-001 (Cabin adaptation for night VFR)
RC 3	4 - 5	SEPT.99	SB N°76-002 (Engine controls)
RC 3	4 - 6	SEPT.99	SB N°76-002 (Engine controls)
RC 4	2 - 10	JULY 00	SB N°28-007 (Use of JP 4 and JET B)
RC 4	2 - 18	JULY 00	SB N°28-007 (Use of JP 4 and JET B)
l			

DGAC APPROVED REVISION 5D A1





LIST OF APPLICABLE CONDITIONAL REVISIONS (RC) PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following pink pages except those canceled when the conditions are complied with.

CAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

No	PAGE	DATE	APPLICABLE BEFORE CONDITION IS MET :
	2 - 5	SEPT.99	SB N°32-001 (Skid blades landing gear) and Mod. N° A 00075 (installation of tail skid)
RC 1	5 - 7	NOV.00	SB N°32-001 (Skid blades landing gear) and Mod. N° A 00075 (installation of tail skid)
	5 - 8	NOV.00	SB N°32-001 (Skid blades landing gear) and Mod. N° A 00075 (installation of tail skid)
	2 - 1	SEPT.99	SB N°34-001 (Cabin adaptation for night VFR)
RC 2	2 - 14	SEPT.99	SB N°34-001 (Cabin adaptation for night VFR)
	2 - 15	SEPT.99	SB N°34-001 (Cabin adaptation for night VFR)
PC 3	4 - 5	OCT.01	SB N°76-002 (Engine controls)
KC J	4 - 6	SEPT.99	SB N°76-002 (Engine controls)
DC 4	2 - 10	JULY 01	SB N°28-007 (Use of JP 4 and JET B)
KU 4	2 - 18	JULY 00	SB N°28-007 (Use of JP 4 and JET B)

DGAC APPROVED REVISION 5 **A1**



LIST OF APPLICABLE CONDITIONAL REVISIONS (RC) PAGES (CONT'D)

	PAGE	DATE	APPLICABLE BEFORE CONDITION IS MET:
RC 5	3 – 20	OCT 01	SB N° 21.008 (P2 TEMP warning light)
<i>.</i>			
		а.,	
	an a		
	·		
	· · · · ·		
	1		ς



LIST OF VALID CONDITIONAL REVISIONS (RC) PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following conditional revisions printed on pink pages after the last indicated date.

CAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

			Embodim	ent of SB	VALID	TTC A	
DATE	NAME	SB N°	Yes	No	RC N°	VISA	
	K	32-001 and A 00075	X		RC 1	JKelly 4272	4
		34-001			RC 2		
		76-002			RC 3		

eurocopter

EC120 B

EXAMPLE OF A LIST OF VALID CONDITIONAL REVISIONS (RC) PAGES

This page must not be included in Flight Manual.

Suppose SB 34-001 and SB 76-002 are embodied-

The corresponding RC are crossed-out by the user and removed from the Flight Manual.

IAME	SB NA	Yes	No No	VALID RC N°	VISA
SER	\$2-001 and A 00075	\mathbf{r}	Х	RC 1	0
USER	34-001	\times		RC 2	0
see	76-002	×		RC 3	0
	JAME SER JSER	IAME SB N ^a SER 32-001 and A 00075 JSEE 34-001 JSEE 76-002	IAME SB N SER 32-001 and A 08075 JSER 34-001 × JSER 76-002 ×	IAME SB N Ves No SER $32-001$ and X A 00075 JSER $34-001$ X JSER $76-002$ X	IAMESB NVesNoVALID RC N°SER $32-001$ and A 08075XRC 1JSER $34-001$ XRC 2JSER $76-002$ XRC 3

REVISION 4



LIST OF VALID CONDITIONAL REVISIONS (RC) PAGES (CONT'D)

			Embodin	nent of SB	VALID	1/10 4	
DATE	NAME	SB N°	Yes	No	RC N°	VISA	
	10. 10						
1							
					1		
					- N .		
	1					-	

...

REVISION 4

B2



LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) EFFECTIVE PAGES

ITR 5C

The manual contains the following additional yellow pages.

					[
No	PAGE	DATE	No	PAGE	DATE
5 A	C	FEB 00			
5 A	4 - 6	FEB 00			
5 B	С	JUN 00			
5 B	2-11	JUN 00		• •	
5 C	A1	JUL 00			
5 C	С	JUL 00			
5 C	1 - 3	JUL 00		·	
5 C	2 - 10	JUL 00			
5 C	2 - 11	JUL 00			
5 C	2 - 18	JUL 00			

DGAC APPROVED REVISION 5C С





LIST OF INTERMEDIATE TEMPORARY REVISIONS **(ITR) EFFECTIVE PAGES**

ITR 5D

The manual contains the following additional yellow pages :

Г	Nº	PACE	DATE	Π	Nº	PACE	DATE
ŀ	-11 			H	17	IAU	DAIE
	<u> SA</u>	4 - 0	FEV UU				
	5 C	1-3	JUL 00				
	5 C	2 - 10	JUL 00				
	5 C	2 - 11	JUL 00				
	5 C	2 - 18	JUL 00				
		RR 5C supersedes RR 5	3				
	5 D	A 1	NOV 00				
	5 D	С	NOV 00				
	5 D	2 - 5	NOV 00				
	5 D	2 - 13	NOV 00				
	5 D	2 - 19	NOV 00				
	5 D	5 - 7	NOV 00				
	5 D	5 - 8	NOV 00				
	5 D	5 - 9	NOV 00				
	5 D	5 - 11	NOV 00				
		· · ·					

DGAC APPROVED **REVISION 5D**

С



LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) EFFECTIVE PAGES

The manual contains the following additional yellow pages.

No	PAGE	DATE	No	PAGE	DATE
•					
					•

DGAC APPROVED REVISION 4 С



LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) REQUIRING NO APPROVAL

The manual contains the following additional yellow pages.

No	PAGE	DATE	No	PAGE	DATE
.::*.:					
•					
• •	ана стана стана Стана стана стан Стана стана стан				
•					

REVISION 4



ITR 5A

LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) REQUIRING NO APPROVAL

The manual contains the following additional yellow pages.

	No	PAGE	DATE	No	PAGE	DATE
ſ	5A	10 - 8	NOV 99			
	5A	10 - 9	NOV 99			
	5A	10 - 10	NOV 99			
	5A	10 - 11	NOV 99	-		
•		:				





LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) REQUIRING NO APPROVAL

The manual contains the following yellow pages.

No	PAGE	DATE	No	PAGE	DATE
6 a	5 - 18	FEB 02			
6 b	8-9	JULY 02			
6 b	8 – 24A	JULY 02			
6 c	D	JULY 02			
6 c	8 - 28	JULY 02			
		×			
			2 2		

REVISION 6c



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
Title A1 A2 C E F G M i iii iii iii v v v vi	0 5 4 5 5 5 5 5 0 0 0 0 4 4 4 4 5 5 5 5	added	2-7 2-8 2-9 2-10 2-10A 2-10B 2-11 2-12 2-13 2-13A 2-13B 2-14 2-15 2-16 2-17 2-18 2-19	5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	added added added added
1-1 1-2	5 0		2-20	3	
1-3	5			SECTION 3	
1-4	5		3-i	0	
1-5	3		3-ii	3	
1-6	5		3-1	5	
	SECTION 2		3-2	3	
2:	5		3-3	5	
2-1			3-4	5	
2-1	5		3-5	U	
2-1	5		3-0	5	
2-3	5		3-/		
2-4	5		3-0	5	
2-5	5		3-10	4	
2-6	4		3-11	4	



DGAC APPROVED REVISION 5 Ē



LIST OF APPROVED EFFECTIVE PAGES (CONT'D)

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
3-12 3-13 3-14 3-15 3-16 3-17 3-18 3-19 3-20 3-21 4-i 4-i 4-i 4-i 4-2 4-3 4-3A 4-3A 4-3A 4-3B 4-4 4-5 4-6 4-7 4-8 4-9 4-10 4-11 4-12	5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	blank	5-1A 5-1B 5-2 5-3 5-4 5-5 5-6 5-7 5-8 5-9 5-10 5-11 5-12	4 5 4 5 5 5 5 5 5 5 5 5 5	added
5-1 5-ii 5-1	5 5 5	added			

DGAC APPROVED REVISION 5

F



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL	0	JUNE 1997
REVISION	1	SEPTEMBER 1997
REVISION	2	MARCH 1998
REVISION	3	JANUARY 1999
REVISION	4	SEPTEMBER 1999
REVISION	5	NOVEMBER 2001

NORMAL REVISION 5 DATE: 21 NOV 2001 **APPROVED BY : DGAC**







RECORD OF APPROVED REVISIONS

Rev.	Date	Inse	rted	Rev.	Date	Inse	rted
No	Approved	Date	Initials	No	Approved	Date	Initials
5	21NOU 01	FEBCOLUZ	JDK				
			<u> </u>				
				i			
						·	
							<u> </u>



REVISION 4

.

.



LIST OF EFFECTIVE PAGES REQUIRING NO APPROVAL

PAGE	REV No	REMARKS		PAGE	REV No	REMARKS
R1	4	······································		6 12	0	
ם בם רם	4			6-13		
	4			0-14	5	
	4		ŀ	0-15	4	
	5				SECTION 7	
	5			7-i	3	
J	5			7-ii	1	
				7-iii	3	
	4			7-1	5	
IN	5			7-2	5	
	SECTION 5			7-3	5	
5-13	5	added		7-4	3	
5-14	5	added		7-5	3	
5-15	5	added		7-6	1	
5-16	5	added		7-7	3	
5-17	5	added		7-8	1	
5-18	5	added		7-9	1	
	SECTION (7-10	1	
	SECTION 6			7-11	5	~
6-i	0			7-12	5	
6-ii	0			7-13	5	
6-1	0			7-14	5	
6-2	4			7-15	1	
6-3	5			7-16	5	
6-4	5			7-17	1	4
6-5	0			7-18	5	
6-6	0			7-19	5	
6-7	0			7-20	1	
6-8	5	ļ		7-21	4	
6-9	5			7-22	5	
6-10	5			7-23	1	blank
6-11	5		{	7-24	1	
6-12	0					



REVISION 5

I



LIST OF EFFECTIVE PAGES REQUIRING NO APPROVAL (CONT'D)

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
7-25	3		8-19	5	
7-26	2		8-20	2	
7-2/	2		8-21	2	
7-28	5		8-22		
7 20	2		8-23	2	
7-30	2		0-24	5	
7-32	3		8 26	5	
7 32			0-20	5	
7-33	1		 0-27	5	
7-34	5		8-20	5	
·	SECTION 8	·	8-30	5	
8-i	2		8-30	5	
8-ii	2		8-37	5	
8-1	5		8-33	5	
8-2	5		0.55	5	
8-3	5			SECTION 10	
8-4	2		10-i	5	
8-5	2		10-ii	5	added
8-6	2		10-1	2	
8-7	5		10-2	2	
8-8	5		10-3	2	
8-9	2		10-4	2	
8-10	2		10-5	2	
8-11	2		10-6	2	
8-12	2		10-7	2	
8-13	2		10-8	5	added
8-14	2		10-9	5	added
8-15	2		10-10	2	added
8-16	3		10-11	2	added
8-17	2		10-12		added
8-18	2		10-13	2	added
	1 .	1	1	1	





LOG OF NORMAL REVISIONS REQUIRING NO APPROVAL

ORIGINAL	0	JUNE 1997
REVISION	1	JANUARY 1998
REVISION	2	JULY 1998
REVISION	3	FEBRUARY 1999
REVISION	4	SEPTEMBER 1999
REVISION	5	NOVEMBER 2001



REVISION 5



RECORD OF REVISIONS REQUIRING NO APPROVAL

Rev.	Date	Inserted		Rev.	Date	Inse	Inserted		
No		Date	Initials	No		Date	Initials		
				<u> </u>					
				<u> </u>					
				 					
			ļ		×				
				ļ					
					-				
<u>-</u>									



REVISION 4



CUSTOMIZATION

A/C : EC 120B - S/N :

LIST OF ADDITIONAL APPROVED PAGES

PAGE	REV N°	REMARKS	PAGE	REV N°	REMARKS



CUSTOMIZATION

A/C : EC 120B - S/N :

LIST OF ADDITIONAL APPROVED PAGES

PAGE	REV N°	REMARKS	PAGE	REV N°	REMARKS



REVISION 5



Э

6

7

8

10

11

MAIN TABLE OF CONTENTS

GENERAL

LIMITATIONS

EMERGENCY PROCEDURES

NORMAL PROCEDURES

PERFORMANCE DATA (APPROVED PART / NON APPROVED PART)

WEIGHT AND BALANCE

SYSTEMS DESCRIPTION

HANDLING, SERVICING, MAINTENANCE

FLIGHT MANUAL SUPPLEMENTS (SPECIAL OPERATIONS / OPTIONAL EQUIPMENT)

OPERATIONAL TIPS

APPENDIX





DGAC APPROVED ORIGINAL ISSUE i



ORGANIZATION OF THE MANUAL

1 GENERAL

To achieve the required degree of safety, this manual must be used in conjunction with the relevant regulations covering aircraft operation, such as aerial navigation laws in the operator's country. It is essential for the crew to become familiar with the contents of this manual, special certification requirements and any information specific to customized configurations, and to check all revisions and related requirements.

2 PAGE NUMBERING

The numbering of pages within each section consists of the section number or designation, a dash and the consecutive number of the page beginning with "1"; e.g. for SECTION 3: 3-1, 3-2, etc.

Figures are likewise numbered consecutively by section, such as Fig. 3-1, Fig. 3-2, etc.

Exceptions :

- The numbering of the TABLE OF CONTENTS pages preceding each section in this manual consists of the section number, a dash and the consecutive roman numeral (lower case) of the page, beginning with "i"; e.g. for SECTION 3: 3-i, 3-ii, etc.
- The page numbers of the FLIGHT MANUAL SUPPLEMENTS (FMS) and APPENDICES consist of the section number, a dash, the number of the SUPPLEMENT/APPENDIX, a dash and the consecutive number of the page; e.g. for FMS 9-17: 9-17-1, 9-17-2, etc.
- Figures within a FMS and APPENDIX are numbered consecutively, such as Fig. 1, Fig. 2, etc.

The number of a blank page within a page block is printed on the preceding or following page by using dual page numbering; e.g. 3-9/(3-10 blank) or (3-9 blank)/3-10.





If, at a later date, pages have to be added to the initial printing, the new pages may carry the number of the preceding page plus a letter suffix; e.g. 2-6A, 2-6B, etc.

3 FLIGHT MANUAL SUPPLEMENTS (FMS)

Information concerning optional equipment systems and operational procedures is covered by FMS.

Each FMS is self-contained and corresponds in its general arrangement to the basic FLIGHT MANUAL, but only additional information or different data will be the subject of an FMS.

Each FMS, although complete in nature, shall therefore be used in conjunction with the basic FLIGHT MANUAL.

A LOG OF SUPPLEMENTS is provided in SUPPLEMENT 9.0 as an index listing the current supplements.

The manufacturer retains the right to convert optional equipment to standard equipment at any time as a product improvement program. FLM coverage of the converted optional equipment, however, will remain as an FMS in SECTION 9 and also as an optional equipment item entry in the EQUIPMENT LIST.

4 REVISION SERVICE

This manual is kept up-to-date by normal revisions and intermediate temporary revisions.

4.1 **REVISIONS**

Normal revisions are issued periodically. They are printed on white paper and incorporated into the manual in accordance with a "CHANGE INSTRUCTIONS" sheet which does not need to be inserted in the manual. Revisions are numbered consecutively beginning with the No. 1.



DGAC APPROVED ORIGINAL ISSUE iii



4.2 INTERMEDIATE TEMPORARY REVISIONS (ITR)

ITRs are provided to transmit information between revisions. They are printed on yellow paper and are accompanied by an updated list of intermediate temporary revision effective pages.

The modified page is filed in the manual facing the existing page which is to be kept.

ITRs are identified by the number of the next normal revision and a letter suffix in normal alphabetical order. Several ITRs may be issued between two normal revisions. All ITRs are canceled when the normal revision bearing the same number is issued. If certain ITR provisions remain after the subsequent normal revision, they are confirmed by a new ITR with another identification code.

4.3 CONDITIONAL REVISIONS (RC)

The revised manual is issued on white pages and corresponds to the latest recommended standard.

The conditional revisions, corresponding to the previous standard, are issued on pink pages.

The list of pink pages corresponding to the modification <u>applicable</u> to the helicopter is given on white pages A1/A2 and/or 9-0-A1/9-0-A2.

This list of pink pages is subjected to approval and is updated by EUROCOPTER.

The list of <u>valid</u> conditional revisions that must remain in the FLM because the corresponding modification or SB has not been embodied to the aircraft, is given on pink pages B1/B2 and/or 9-0-B1/9-0-B2. This list of conditional revisions is not subjected to approval and must be updated by the user.

The conditional revisions must not be removed from the FLM until the modification or SB has been embodied to the aircraft.

When the user embodies/removes a modification or SB, the corresponding pages of the conditional revision (pink pages) must be removed from/incorporated in FLM. The list of valid conditional revisions (pages B1/B2 and/or 9-0-B1/9-0-B2) must be up-dated accordingly and validated by a visa.



eurocopter

FLIGHT MANUAL EC120 B

From the present revision onward, at the delivery of the aircraft, the list of the valid modifications or SBs will be specified by EUROCOPTER on the pink pages B1/B2 and /or 9-0-B1/9-0-B2, according to the configuration of the aircraft delivered. The valid conditional revisions are those validated by the visas.

NOTE

The RC are unaffected by normal and intermediate temporary revisions or by customization.

4.4 IDENTIFYING REVISED MATERIAL

Changes (except as noted below) to the text and tables (including new material on added pages) are indicated by a vertical line in the outer margin.

Change symbols will not be shown for :

- Introductory material.
- Blank space resulting from the deletion of text, or an illustration or a part of an illustration, or table.
- Correction of minor inaccuracies, such as spelling, punctuation, relocation of material, etc., unless such correction changes the meaning of instructive information and procedures.

Changes to illustrations may be indicated by a miniature pointing hand. A vertical line next to changed text and call-outs on illustrations may be used in lieu of a pointing hand. Shading and screening may be used for diagrams and schematics to highlight the area containing the changed information. Extensively changed presentations may be indicated by a screen border around the affected area.





4.5 "ERRATUM" PROCEDURE

In the case of minor errors (typing errors, bad printing) likely to affect the understanding of the text, the "ERRATUM" procedure is used to make quick corrections between revisions.

In this case, the pages affected by the procedure are re-issued completely and the page number is underlined for identification.

These pages are summarized on an accompanying sheet which is not identified.

5 CUSTOMIZATION OF MANUAL (PRINTED ON GREEN PAPER)

Special features of a particular aircraft may justify the incorporation, on certain pages, of information differing from that of the basic manual and Supplements. These pages, printed on green paper, are filed in the manual over the corresponding white pages.

The information contained in the green pages supersedes or supplements the information covered by the relevant white page. No white page is deleted.





SECTION 1 GENERAL

1-1
1-2
1-3
1 - 3
1 - 3
1 - 3
1 - 3
1 - 3
1 - 4
1 - 6
1 - 6
1 - 6

LIST OF FIGURES

Page

FIGURE 1-1 : THREE-VIEW DRAWING		2
---------------------------------	--	---





DGAC APPROVED ORIGINAL ISSUE



1.1 TERMINOLOGY

- Unless otherwise specified in the text, altitudes are pressure-altitudes.
- Warnings, Cautions and Notes are used throughout this manual to emphasize important and critical instructions and are used as follows:

WARNING

AN OPERATING PROCEDURE, PRACTICE, ETC., WHICH, IF NOT CORRECTLY FOLLOWED, COULD RESULT IN PERSONAL INJURY OR LOSS OF LIFE.



An operating procedure, practice, etc., which, if not strictly observed, could result in damage to, or destruction of equipment.

NOTE

An operating procedure, condition, etc., which is essential to highlight.

USE OF PROCEDURAL WORDS

The concept of procedural word usage and intended meaning which has been adhered to in preparing this manual is as follows:

- "Shall" has been used only when application of a procedure is mandatory.
- "Should" has been used only when application of a procedure is recommended.
- "May" and "need not" have been used only when application of a procedure is optional.
- "Will" has been used only to indicate future event or action, never to indicate a mandatory procedure.





1.2 MAIN AIRCRAFT DIMENSIONS



NOTE

The values which vary according to weight are given at the maximum weight.

Figure 1-1 : three-view drawing



1.3 DESCRIPTIVE DATA

1.3.1 ENGINE

- Number - Manufacturer	:	1 TURBOMECA	- Power with engine t (ISA, at sea level):	or	que limit
- Model - Type	:	ARRIUS 2F	. Takeoff	:	322 kW (432 SHP)
			. Max. continuous	:	322 kW (432 SHP)
			- Power without engin	le	torque limit
			(ISA at sea level):		-
			. Takeoff	:	376 kw (504 SHP)
			. Max continuous	:	335 kw (449 SHP)
122 DOTOD					

1.3.2 ROTOR

- Type	: SPHERIFLEX	- Diameter	: 10 m
			(32.81 ft)
- Number of blades	: 3	- Nominal rotor speed	: 406 rpm

1.3.3 TAIL ROTOR

- Type	: FENESTRON	- Number of blades	: 8
- Diameter	: 0.75 m (2.46 ft)	- Nominal tail rotor spe	ed:4567 rpm

1.3.4 FUEL

- Total capacity	: 410.5 liters		- Usable fuel : 406 liters
	(326.3 kg)		(323 kg)
	108.5 US gal)	-	(107.3 US gal)

1.3.5 OIL

- MGB oil capacity including filter	: 41	- Engine oil capacity : 2.5 l min. (0.66 US gal)
- TGB oil capacity	: 0.2 1	: 4.6 l max. (1.22 US gal)



DGAC APPROVED REVISION 5 1-3



1.4 SYMBOLS AND ABBREVIATIONS

DESIGNATION	SYMBOL OR
SPEEDS	ADDREVIATION
Calibrated airspeed	CAS
Indicated airspeed	IAS
True airspeed	TAS
Never exceed speed	Vne
Best rate of climb speed	Vie
Rate of climb	R/C
METEOROLOGY	
International standard atmosphere	TC A
Outside air temperature	
Outside air renssure	DAT n
Relative air density	p T
Wind velocity	o Vw
	v w
<u>ALTITUDE / HEIGHT</u>	
Geometric altitude	H
Pressure altitude	Нр
Density altitude	Нσ
Radio altimeter height	HRA
Height	h
POWER / ENGINE PARAMETERS	
Maximum continuous power	МСР
Maximum takeoff power (5 min.)	MTOP
Power	PWR
Engine power check	EPC
Rotor speed	NR
Engine generator speed	Ng
Engine generator deviation indication	ΔNg
Free turbine speed	Nſ
Torque	Tq
Power turbine inlet temperature	T4
First limitation indicator	FLI



à

.


DESIGNATION	SYMBOL OR
	ABBREVIATION
HOVER / TAKEOFF / LANDING	
Hover in ground effect	HIGE
Hover out of ground effect	HOGE
WEIGHT AND BALANCE	
Center of gravity	CG
Empty weight	EW
Equipped empty weight	EEW
Operating empty weight	OEW
Useful load	UL
Payload	P/L
All-up weight	AUW
Maximum takeoff weight	MTOW
MISCELLANEOUS	
Automatic direction finder	ADF
Automatic flight control system	AFCS
Ancillary system unit	ASU
Battery contactor	BATC
Cockpit circuit breaker panel	CCBP
Caution and warning panel	CWP
Direct current	DC
Emergency locator transmitter	ELT
Electrical master box	EMB
Engine	ENG
Equivalent	≅
Essential contactor	ESSC
External power line contactor	EPLC
External power unit	EPU
Hall effect sensors	HECS
Generator line contactor	GLC
Global positioning system	GPS
High load contactor	HLC
Horizontal situation indicator	HSI
Height-Velocity	HV



DGAC APPROVED REVISION 3 1 - 5



DESIGNATION	SYMBOL OR ABBREVIATION
MISCELLANEOUS (cont'd)	
Intercommunication system	ICS
Light and ancillary control unit	LACU
Main gear box	MGB
Radio magnetic indicator	RMI
Shed bus contactor	SBC
Starting contactor	SC
To be defined	TBD
Tail gear box	TGB
Vehicle and engine management display	VEMD
Flight-related check	VLV

1.5 CONVERSION FACTORS

1.5.1 METRIC UNITS TO ANGLO-SAXON UNITS

1 cm	= 0.3937 in	cm - centimeter
1 m	= 3.2808 ft	m - meter
1 km	= 0.5400 NM	km - kilometer
11	= 0.2642 US gal	l - liter
11	= 0.2200 UK gal	l - liter
l kg	= 2.2046 lb	kg - kilogram
1 bar	= 14.5040 psi	bar - bar

1.5.2 ANGLO-SAXON UNITS TO METRIC UNITS

l in	= 2.5400 cm	in - inch
1 ft	= 0.3048 m	ft - foot
1 NM	= 1.8520 km	NM - nautical mile
1 US gal	= 3.7850 1	US gal - US gallon
1 UK gal	= 4.5460 1	UK gal - UK gallon
1 lb	= 0.4536 kg	lb - pound
1 psi	= 0.0689 bar	psi - pound per square inch
1.013 Hpa	= 29.92 in.hg	in.hg-inches of mercury



.



SECTION 2 LIMITATIONS

Page

2.1 GENERAL
2.1.1 TYPE OF OPERATION
2.1.2 OCCUPANTS
2.1.3 INSTRUMENT MARKINGS 2-1
2.2 WEIGHT AND BALANCE LIMITATIONS
2.2.1 WEIGHT LIMITATION 2-2
2.2.2 LONGITUDINAL CG
2.2.3 LATERAL CG
2.3 FLIGHT ENVELOPE LIMITATIONS
2.3.1 AIRSPEED LIMITATIONS
2.3.2 ALTITUDE LIMITATION
2.3.3 TEMPERATURE LIMITATION
2.3.4 LANDING AND STOPPING LIMITATIONS ON SLOPE
2.3.5 MANEUVERING LIMITATIONS 2-5
2.4 VEHICLE LIMITATIONS
2.4.1 MAIN ROTOR LIMITATIONS 2-6
2.4.2 FIRST LIMITATION INSTRUMENT 2-7
2.4.3 MAIN TRANSMISSION LIMITATIONS 2-7
2.4.4 ENGINE LIMITATIONS 2-8
2.4.5 GENERATOR LOAD LIMITATIONS 2-10
2.4.6 BATTERY TEMPERATURE LIMITATION 2-10
2.5 MISCELLANEOUS LIMITATIONS 2-10
2.5.1 FUEL
2.5.2 APPROVED LUBRICANTS 2-14
2.5.3 ANTICRASH SYSTEM ON REAR SEATS
2.5.4 BAGGAGE COMPARTMENT LOAD LIMITATIONS 2-13
2.5.5 CABIN COMPARTMENT LOAD LIMITATIONS 2-15
2.5.6 MANDATORY MINIMUM EQUIPMENT 2-13A
2.5.7 OPTIONAL EQUIPMENT 2-13A
2.6 PLACARDS



DGAC APPROVED REVISION 5

2 - i



LIST OF FIGURES

FIGURE 2-1 : LONGITUDINAL CG CHART	2-2
FIGURE 2-2 : LATERAL CG CHART	2-3

DGAC APPROVED ORIGINAL ISSUE

ì



RC 2

Replace the paragraph 2.1 by the following paragraph :

2.1 GENERAL

The helicopter is approved in compliance with JAR part 27 issue 1. The helicopter shall be operated in compliance with the limitations of this section.

2.1.1 TYPE OF OPERATION

The helicopter is approved to operate by day in VFR. The following are forbidden :

- Night flight

- Flight in freezing rain.

- Flight in icing conditions. - Aerobatics maneuvers. (visible moisture and temperatures conducive to producing ice).

2.1.2 OCCUPANTS

The helicopter in its basic configuration is approved as a 5-seat rotorcraft.

Minimum crew

: One pilot in right or left seat.

2.1.3 INSTRUMENT MARKINGS

Limitations are marked on instruments with the following color code:

: Safety limit or takeoff limitation Red : Vne. power off Red with white hatching : Caution range or takeoff Yellow or amber or reserved rating range NV.EC120.0095.01 : Normal operating range Green : Equipment operating limit White mark ∇ : Transient limit Red triangle

<u>CAUTION</u> THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATION SB Nº 34.001 HAS BEEN EMBODIED TO THE AIRCRAFT.

DGAC APPROVED SEPTEMBER 99



2.1 GENERAL

The helicopter is approved in compliance with JAR part 27 issue 1. The helicopter shall be operated in compliance with the limitations of this section.

2.1.1 TYPE OF OPERATION

The helicopter is approved to operate :

- by day in VFR.
- by night in VFR, when the equipment required by operational regulations are installed and serviceable.

The following are forbidden:

- Aerobatic maneuvers
- Flight in freezing rain.
- Flight in icing conditions (visible moisture and temperatures conducive to producing ice).

2.1.2 OCCUPANTS

- Minimum flight crew: One pilot in right or left seat.
- Maximum number of seats: 5

(including flight crew)

2.1.3 INSTRUMENT MARKINGS

Limitations are marked on instruments with the following color code:



DGAC APPROVED **REVISION 5**

2 - 1



- : Caution range or takeoff
- rating range : Normal operating range
- : Equipment operating limit
- : Transient limit







On the VEMD, related numerical value of parameters underlined : - in yellow when the parameter is in caution or takeoff range, - in red when at or above safety limit or maximum takeoff power. Moreover, to enforce safety, red underlining flashes.

2.2 WEIGHT AND BALANCE LIMITATIONS

2.2.1 WEIGHT LIMITATION

Maximum permissible weight in flight : 1715 kg (3780 lb) Maximum permissible weight for IGE, takeoff and landing : 1715 kg (3780 lb). Minimum permissible weight in flight : 1035 kg (2284 lb).



2.2.2 LONGITUDINAL CG



NOTE

The datum is located 4 m forward of the main rotor head center line.



ł

2.2.3 LATERAL CG

Maximum left CG	
Maximum right CG	

: 0.09 m (3.54 in) : 0.08 m (3.15 in)





NOTE

The datum is located in the plane of symmetry of the helicopter.



2.3 FLIGHT ENVELOPE LIMITATIONS

2.3.1 AIRSPEED LIMITATIONS

• Doors closed



• Doors open

The Vne to be taken into account is the lowest value given either on the drawing hereafter (adapted to the doors configuration) or in the above « doors closed » paragraph.





-			
ŗ	DO		
Ŀ	ĸc	1	
ᄂ		-	

Replace the paragraph 2.3.2 by the following paragraph :

2.3.2 ALTITUDE LIMITATION

Maximum operating altitude in flight	Hp =	20 000 ft
Maximum operating altitude for HIGE, takeoff		
and landing	Hp =	2 000 ft



CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATIONS N° A 00075 AND SB N° 32.001 HAVE BEEN EMBODIED TO THE AIRCRAFT.

DGAC APPROVED SEPTEMBER 99 2 - 5



2.3.2 ALTITUDE LIMITATION

• Maximum operating altitude in flight

Hp = 20000 ft

2.3.3 TEMPERATURE LIMITATION

Minimum temperature Maximum temperature : - 30°C : ISA + 35°C limited to + 50°C

NOTE

The use at $-40^{\circ}C \le OAT \le -30^{\circ}C$ forms the subject of the supplement 9 - 4 (see SECTION 9).

2.3.4 LANDING AND ROTOR STOPPING LIMITATIONS ON SLOPE

-	Nose up	10°
~	Nose down	-6°
-	Sideways:	8°

2.3.5 MANEUVERING LIMITATIONS

Maximum load factor is determined by the servo-control reversibility limit. This phenomenon is smooth and presents no danger.

Maximum load factor is a combination of TAS / Ho / Weight.

This servocontrol reversibility limit may be reached in a turn or in a pull-up or when maneuvering near VNE. In this case reduce collective pitch and airspeed.





2.4 VEHICLE LIMITATIONS

2.4.1 MAIN ROTOR LIMITATIONS

It is prohibited to use the rotor brake prior to engine shutdown. Minimum time between two consecutive brakings : 5 min.







2.4.2 FIRST LIMITATION INSTRUMENT



NOTE

The values (Ng = 100%, T4 = 680°C, Tq = 90%) are given as examples.

Use of P2 air bleeds is forbidden above the maximum continuous rating (Ng or T4).

2.4.3 MAIN TRANSMISSION LIMITATIONS

• TORQUE LIMITATIONS



NOTE

In hover flight, maximum takeoff torque has no time limit.





2.4.4 ENGINE LIMITATIONS

• STARTER LIMITATIONS Starter shall not be energized more than 3 consecutive times. After the 3rd attempt wait 30 minutes.

• Nf LIMITATIONS



Ng LIMITATIONS



Ng 63 % : Minimum stabilized speed Δ Ng = -1,5 % Max. continuous rating

- (Ng = 99,5 %, Hp = 0, ISA)
- : Δ Ng = -1,5 % à 0 % Takeoff power rating range
- : Δ Ng = 0 % Maximum takeoff rating (Ng = 101 %, Hp = 0, ISA)
- : ΔNg = +2.6% Max. transient rating (5 s) (Ng = 103,6 %, Hp = 0, ISA)





OIL TEMPERATURE LIMITATIONS



-10 °C to +10 °C Caution range

110 °C Maximum temperature

Minimum oil temperature before power application : $0^{\circ}C$ (Oil 3 cSt) or $10^{\circ}C$ (Oil 5 cSt)

• OIL PRESSURE LIMITATIONS



AV .EC120 .0013 .02



2.4.5 GENERATOR LOAD LIMITATIONS

Maximum continuous	: 150 A
Maximum transient	: 240 A (2 min.)

2.4.6 BATTERY TEMPERATURE LIMITATION

Caution temperature	: 60 °C
Maximum temperature	: 75 °C

2.5 MISCELLANEOUS LIMITATIONS

2.5.1 APPROVED FUEL

• NORMAL FUELS

USE FOR: $-30^{\circ}C \le OAT \le +50^{\circ}C$					
Type of fuel	NATO		Anti-ice additive		
-	code	FRANCE	USA	UK	included
Kerosene - 50 (AVTUR-FSII) JP8)	F 34	AIR 3405 F 34	MIL-T-83133 (JP8)	D.ENG. RD 2453	Yes
Kerosene - 50 (AVTUR) (JP1)	F 35	AIR 3405 F 35	ASTM-D- 1655 JET A1	D.ENG.RD 2494	No
Kerosene	-	-	ASTM-D- 1655 JET A	-	No
Hight flash point (JP5) (AVCAT)	F 43	AIR 3404 F 43	_	D.ENG. RD 2498	No
Hight flash point (JP5) (AVCAT SII)	F 44	AIR 3404 F 44	MIL-T-5624 (JP5)	D.ENG.RD 2452	Yes



٠

ł.

Ł

• REPLACEMENT FUELS

USE FOR:	USE FOR: $-30^{\circ}C \le OAT \le +30^{\circ}C$ AND FOR Hp ≤ 9842 ft (3000 m) ONLY						
Type of fuel	NATO code	Specifications		Anti-ice additive included			
		FRANCE	USA	UK			
Wide cut (AVTAG FSII) (JP 4)	F 40	AIR 3407	MIL-T-5624 (JP 4)	D.ENG. RD 2454	Yes		
Wide cut	_		ASTM-D-1655 (JET B)		No		

NOTE 1

The use of an anti-icing additive is compulsory for $OAT \le +0^{\circ}C$ and for all approved fuels.

NOTE 2

All specifications are effective at latest issue or amendment for all approved fuels.



DGAC APPROVED REVISION 5 2 - 10A(10B blank)



.



.

REVISION 5

.



- ADDITIVES
- Anti-ice additive : If the fuel does not contain a freezing inhibitor and if the OAT is below or equal to 0°C, the use of an anti-icing additive is compulsory. The additive shall comply with French specification AIR 3652 (equivalent to : MIL-I 27686, D-ENG-RD 2451,S 748, PHILLIPS PFA/55 MB).
 - NOTE

Concentration shall be between 0.10 % and 0.15 % by volume.

Anti-static additive : SHELL ASA 3, maximum concentration 0.0001 % by volume.

• FUEL GAUGE



NOTE

10 = 406 litres (323 kg) (107.3 US gal) = usable fuel quantity.

The unusable fuel quantity is reached when zero is indicated on the fuel gauge.



2.5.2 APPROVED LUBRICANTS

• ENGINE LUBRICANTS

	NORMAL USE (- 30°C ≤ OAT ≤ + 50°C)					
Oil trme	NATO Specification App	Approved oil grades				
On type	Code	FRENCH	USA	UK		
Synthetic 5 cSt at 98.9° C	0.156	-	MIL-L-23699	-	AEROSHELL OIL/500/560 CASTROL/5000/AEROJET 5 ELF TURBOJET II ESSO TURBO OIL/II/2380/2197 MOBIL JET OIL/II/254/291 TURBONYCOIL 600	

· .	OTHER OILS (- $30^{\circ}C \le OAT \le + 30^{\circ}C$)						
Oil toma	NATO		Specification	1	Approved oil grades		
Оптуре	code	FRENCH	USA	UK	1		
Synthetic	0.148	-	MIL-L-7808	-	ESSO TURBO OIL 2389 MOBIL OIL AVREX 256 TURBONYCOIL 160		
3 to 3.5 cSt at 98.9° C	0.150	AIR 3514	-	-	ELF JET SYNTHETIC OIL 15 TOTAL AERO TURBINE 312 TURBONYCOIL 13B		
Synthetic 3.9 cSt at 98.9° C	-		-	DEF STAN 91-94	AEROSHELL TURBINE OIL 390		

NOTE 1

When the oil specification or grade differs from the approved one, the engine manufacturer's approval shall be obtained before using this oil.

NOTE 2

In the event of a change in oil grade or specification, the oil system shall be flushed as prescribed in TURBOMECA Maintenance Manual.

NOTE 3

All specifications are effective at latest issue or amendment.



• MAIN GEARBOX LUBRICANTS

		NORM	AL USE (- 25°C	≤ OAT ≤	(+50°C)
	NATO		Spécifications		
On type	Code	FRANCE	USA	UK	Approved lubricants
Mineral	0.155	AIR 3525	MIL-L-6086		ESSO GEAR OIL MEDIUM NYCOLUBE 3525 TOTAL AEROGEAR 823

THE « SHELL » TRADEMARK IS PROHIBITED

COLD WEATHER USE ($-30^{\circ}C \le OAT \le +0^{\circ}C$)						
Oilterne	NATO		Specifications			
On type	vpe Code F	FRANCE	USA	UK	Approved lubricants	
Synthétic	0.148	AIR 3513	MIL-L-7808		ESSO TURBO OIL 2389 MOBIL OIL AVREX 256 TURBONYCOIL 160	
	0.150	AIR 3514			ELF JET SYNTHETIC OIL 15 TOTAL AERO TURBINE 312 TURBONYCOIL 13B	

- TAIL GEARBOX LUBRICANTS Same as MGB.
- SERVO CONTROL LUBRICANT

Hydraulic fluid NATO H 537 or MIL-H-83282

2.5.3 ANTICRASH SYSTEM ON REAR SEATS

When the rear seats are unoccupied, check that unused safety belts are not fastened and the button on the shoulder straps is not visible.

2.5.4 BAGGAGE COMPARTMENT LOAD LIMITATIONS

Maximum unit load : 300 k

: 300 kg/m2 (62.5 pounds/sq feet)

2.5.5 CABIN COMPARTMENT LOAD LIMITATIONS

Maximum unit load : 300 kg/m2 (62.5 pounds/sq feet)





2.5.6 MANDATORY MINIMUM EQUIPMENT

A minimum of two adequate radio / ICS audio headsets shall be onboard the helicopter, one worn by the pilot at the controls and one in stand-by to monitor the audio warnings delivered through the ICS system.

2.5.7 OPTIONAL EQUIPMENT

When optional equipment is installed, refer to supplements (SECTION 9) for additional limitations, procedures and performance data.



2-13A(13B blank)



DGAC APPROVED REVISION 5 2 – 13B



2.6 PLACARDS

		atit
V.N.E. F		
HP (ft)	Vi (kts)	
0	150	
2 000	144	
4 000	138	
6 000	132	
8 000	126	
10 000	120	
12 000	114	
14 000	108	
16 000	102	
18 000	96	
20 000	90	
* V.N.E. PO LESS 3	WER OFF : 30 kts	

Location : Inside cabin, on center post, above standby compass.

MV.EC120.0094.00

RC 2



Replace the VNE placard by the following:

V.N.E.	POWER ON		
↓ HP			
0	150		
1000	147		
2000	144		
3000	141		
4000	138		
5000	135		
6000	132		
7000	129		
8000	126		
9000	123		
10000	120		
11000	117		
12000	114		
13000	111		
14000	108		
15000	105		
16000	102		
17000	99		
18000	96		
19000	93		
20000	90		
*V.N.E POWER OFF :			
LESS 30 KTS			

Location : Inside cabin, instrument panel RH side.

CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATION SB N° 34.001 HAS BEEN EMBODIED TO THE AIRCRAFT.









THE HELICOPTER IS APPROVED TO OPERATE BY DAY IN VFR. THE MARKINGS AND FLACARDS INSTALLED ON THIS HELICOPTER CONTAIN OPERATING LIMITATIONS WHICH MUST BE COMPLIED WITH WHEN OPERATING THIS ROTORCRAFT. OTHER OPERATING LIMITATIONS WHICH MUST BE COMPLIED WITH WHEN OPERATING THIS ROTORCRAFT ARE CONTAINED IN THE ROTORCRAFT FLIGHT MANUAL. THE "AIRWORTHINESS LIMITATIONS" SECTION OF THE ROTORCRAFT MAINTENANCE MANUAL MUST BE COMPLIED WITH.

Location : Inside cabin, aft of overhead control quadrant.



PULL UP TO OPEN PUSH DOWN TO LOCK

Location : Inside RH door

Placard :

Placard :



Location : Inside LH door

CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATION SB N° 34.001 HAS BEEN EMBODIED TO THE AIRCRAFT.

DGAC APPROVED SEPTEMBER 99



Placard :

THE HELICOPTER IS APPROVED TO OPERATE BY DAY AND NIGHT IN VFR. THE MARKINGS AND FLACARDS INSTALLED ON THIS HELICOPTER CONTAIN OPERATING LIMITATIONS WHICH MUST BE COMPLIED WITH WHEN OPERATING THIS ROTORCRAFT. OTHER OPERATING LIMITATIONS WHICH MUST BE COMPLIED WITH WHEN OPERATING THIS ROTORCRAFT ARE CONTAINED IN THE ROTORCRAFT FLIGHT MANUAL. THE "AIRWORTHINESS LIMITATIONS" SECTION OF THE ROTORCRAFT MAINTENANCE MANUAL MUST BE COMPLIED WITH.

Location : Inside cabin, aft of overhead control quadrant.

Placard :



Location : Inside RH door

Placard :



Location : Inside LH door



Location : Sliding door, inside LH side.



Location : Inside cabin, door bottom, in front of door jettisoning handle

Placard :

DO NOT STOW ANYTHING UNDER ALL THE SEATS

Location : - RH forward seat, at bottom RH side; - LH forward seat, at bottom LH side ; Bench seat, LH side.

AV.EC120.0060.00





A/C SERI/	AL N°:	
WEIGHT	:	
C. OF G.	:	
DATE	:	

Location : Console RH side.

Placard :



Location : Console LH side, cargo hold, RH side.

WV.EC120.0061.00

Placard :



Location : Inside cabin, on center post, under standby compass.



Placard :





Location : LH filler neck, LH side. Placard :

Placard :

CARBURANT	JP1-JP4-JP5-JP8 JET A1-JET A - JET B
FUEL: F34-F	35-F40-F43-F44
CAPACITE /	CAPACITY :
108,5	U.S. GALLONS
90,4	IMP. GALLONS
410,5	LITRES / LITERS
326,3	KG

Location : RH of filler neck, LH side.

MV.EC120.0065.01

Placard :



Location : RH of engine oil filler cap.



RC 4



Replace Fuel placard by the following :

CARBURANT : JP1-JP5-JP8 JET A1-JET A FUEL : F34-F35-F43-F44 CAPACITE / CAPACITY : 109,9 U.S. GALLONS 91,6 IMP. GALLONS 416 LITRES / LITERS 324 KG

NOTE

The total fuel capacities to be taken into account are those shown in page 1 - 3.

CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE FLIGHT MANUAL UNTIL MODIFICATION SB N° 28 007 HAS BEEN EMBODIED TO THE AIRCRAFT.





Location : Near TGB and MGB filler neck RH side.

Placard :

Placard :





Location : Inside cabin, on console lateral side

Placard :



Location : Inside cabin, near reading light.









Location : LH side of aircraft, above grounding point.

Placard (If fitted)



Location : RH side, on ground power receptacle cover.





Page

SECTION 3

EMERGENCY PROCEDURES

		5
3.1 GENERAL	3 -	- 1
3.1.1 AUDIO WARNINGS	3 -	- 1
3.2 ENGINE FLAME-OUT	3.	- 2
3.2.1 CRUISE FLIGHT	3.	. 2
3.2.2 HOVER-IGE	3.	- 3
3.2.3 HOVER-OGE	.3.	- 4
3.3 ENGINE GOVERNOR FAILURE	3.	- 4
3.3.1 NR DROP	3.	. 4
3.3.2 NR INCREASE.	.3	- 5
3.4 TAIL ROTOR CONTROL FAILURE	.3.	- 6
3.4.1 HOVER-IGE	.3.	- 6
3.4.2 HOVER-OGE	.3.	- 6
3.4.3 IN CRUISE FLIGHT	.3.	- 6
3.5 SMOKE IN THE COCKPIT/CARGO	.3	- 7
3.5.1 SOURCE NOT IDENTIFIED	.3.	- 7
3.5.2 SOURCE IDENTIFIED	.3.	- 7
3.6 VEMD FAILURE	.3.	- 8
3.6.1 VEMD SCREEN FAILURE	.3.	- 8
3.6.2 CAUTION MESSAGES ON VEMD	.3.	- 8
3.6.3 ABNORMAL NR/Nf INDICATION	3 -	10
3.6.4 ABNORMAL ENGINE PARAMETER INDICATION	3 -	10
3.7 CAUTION AND WARNING PANEL	3 -	12
3.7.1 ENGINE EMERGENCY	3 -	12
3.7.2 TRANSMISSION EMERGENCY	3 -	14
3.7.3 HYDRAULIC EMERGENCY	3 -	15
3.7.4 ELECTRICAL EMERGENCY	3 -	16
3.7.5 FUEL EMERGENCY	3 -	18
3.7.6 MISCELLANEOUS	3 -	20



DGAC APPROVED ORIGINAL ISSUE



	Page	
3.8 VARIOUS FAILURES AND INCIDENTS NOT INDICATED ON		
THE CWP	3 - 21	•







3.1 GENERAL

Emergency procedures describe the actions that the pilot must take relative to the various possible failures that can occur.

Meanwhile, depending on the many variable external environment, such as the type of terrain flown over, the pilot may have to adapt to the situation according to his experience.

To help the pilot in his decision process, four recommendations are used :

. LAND IMMEDIATELY

Self explanatory.

· LAND AS SOON AS POSSIBLE

Emergency conditions are urgent and require landing at the nearest landing site at which a safe landing can be made.

. LAND AS SOON AS PRACTICABLE

Emergency conditions are less urgent and in the pilot's judgement, he may proceed to the nearest airfield where he can expect appropriate assistance. CONTINUE FLIGHT

Continue flight as planned. Repair at the destination according to the maintenance manual.

NOTE

Immediate actions that the pilot shall take are written in bold characters.

3.1.1 AUDIO WARNINGS

On the LACU, a pushbutton is used to activate the audio warning. When pressed in, the HORN light on the warning panel goes out.

NOTE

The pilot at the controls shall wear an adequate radio / ICS audio headset to monitor the audio warnings delivered through the ICS system.

• GONG

A gong is generated each time a red warning appears on the warning panel.



DGAC APPROVED REVISION 5 3-1


Collective pitch......INCREASE to maintain NR in green arc

Apply applicable procedure according to the situation.

3.2 ENGINE FLAME-OUT

3.2.1 CRUISE FLIGHT

AUTOROTATION PROCEDURE OVER LAND

1. Collective pitch REDUCE

to maintain NR in green arc.

- 2. IAS...... Vy
- 3. Twist Grip...... SHUT OFF position

4. Maneuver the aircraft into the wind on final approach.

- At height \cong 70 ft
- 5. Cyclic FLARE
- At 20 25 ft and at constant attitude

6. Collective pitch..... GRADUALLY INCREASE to reduce the rate of descent and forward speed.

7. Cyclic FORWARD slightly

to adopt landing attitude.

8. Pedal ADJUST

to cancel any side-slip tendency.



9. Collective pitch INCREASE

to cushion touch-down.

- After touch-down
- 10. Cyclic, collective, pedal...... ADJUST

to control ground run.

- Once the aircraft has stopped
- 11. Collective pitch FULLY DOWN
- 12. Rotor brake..... APPLY below 150 rpm.

AUTOROTATION PROCEDURE OVER WATER

Apply same procedure as over land, except items 10, 11 and 12, but maneuver to head the aircraft equally between the wind and wave direction on final approach. Ditch with minimum forward and vertical speed. Then apply following check list for items 10, 11 and 12.

- <u>At touch-down</u>
- 10. Collective pitch MAINTAIN
- 11. Door emergency handles......PULL-UP
- 12. Rotor brake...... APPLY Evacuate aircraft once the rotor has stopped.

RELIGHTING

When Ng is less than 10%, according to available height and cause of flame-out, try to relight using starting procedure. At least 1000 ft are necessary to complete restarting procedure after flame-out.

3.2.2 HOVER-IGE

1. Collective	MAINTAIN
2. Pedals	CONTROL YAW
3. Collective	INCREASE as needed to cushion
	touch-down.





3.2.3 HOVER-OGE

- 1. Collective pitch FULLY DOWN
- When NR stops decreasing

2. CyclicFORWARD

to gain airspeed according to available height.

3. Autorotation procedure APPLY



SAFE AUTOROTATIVE LANDING CAN NOT BE WARRANTED IN CASE OF A FAILURE IN HOGE BELOW THE TOP POINT OF THE HV DIAGRAM (REFER TO SECTION 5).

3.3 ENGINE GOVERNOR FAILURE

Engine governor failure leads either to NR drop, or to NR increase.

3.3.1 NR DROP

 IN CRUISE FLIGHT Simultaneously to maintain NR in green arc: 1. Collective......REDUCE 2. Twist grip CHECK in Flight Position 1 YES NO Autorotation Procedure APPLY 1. Twist grip..... FLIGHT POSITION 2. Collective INCREASE When $Ng \ge 70\%$ HOVER-IGE LAND IMMEDIATELY 1. Collective MAINTAIN 2. YawCONTROL 3. Collective INCREASE to cushion touch-down



• HOVER-OGE

Simultaneously



Autorotation Procedure...... APPLY

Twist grip....FLIGHT POSITION
 Collective....INCREASE When Ng ≥ 70%

3.3.2 NR INCREASE

Simultaneously to maintain NR in green arc : 1. CollectiveINCREASE 2. Twist GripSLIGHTLY REDUCE LAND AS SOON AS POSSIBLE

NOTE

During flight, the pilot shall control NR using the twist grip.

APPROACH AND LANDING

Initiate a shallow approach at Vy.

On final approach reduce speed slowly and adjust collective pitch to set torque at around 30%.

Reduce forward speed and increase collective to cushion landing at low speed (ground speed below 10 kt).

After touch down, reduce throttle before lowering collective pitch.





3.4 TAIL ROTOR CONTROL FAILURE

Symptom : the helicopter will yaw to the left with a rotational speed depending on the amount of power and the forward speed set at the time of the failure.

3.4.1 HOVER-IGE

LAND IMMEDIATELY

- 1. Twist GripIDLE STOP POSITION
- 2. Collective INCREASE to cushion touch-down

3.4.2 HOVER-OGE

Simultaneously

1. Collective	REDUCE depending on available
	height
2. Cyclic	FORWARD to gain speed
-3. Cyclic	
	control yaw

LAND AS SOON AS POSSIBLE Carry out an autorotative landing

3.4.3 IN CRUISE FLIGHT

LAND AS SOON AS POSSIBLE APPROACH AND LANDING

Carry out an autorotative landing.

۴.



3.5 SMOKE IN THE COCKPIT/CARGO

3.5.1 SOURCE NOT IDENTIFIED

Heating, Demisting OFF

smoke cleared



CONTINUE FLIGHT depending on weather conditions

- Battery.....OFF
 GeneratorOFF
 Ventilate the cabin When smoke clears
- All Consumers OFF
- 1. Battery.....ON check DC voltage

NO

2. GeneratorON check DC voltage

If all is normal

All ConsumersON one by one to identify the failed system; then keep it off.

CAUTION

When battery and generator are off line the VEMD goes out and only the analog NR remains. Apply both screen failure procedure (§ VEMD SCREEN FAILURE - SECTION 3).

3.5.2 SOURCE IDENTIFIED

- 1. Corresponding system...... OFF
- 2. Ventilate the cabin





3.6 VEMD FAILURE

3.6.1 VEMD SCREEN FAILURE

• Failure of one screen

Failed Screen.....OFF.

Read all information on the other screen.

All information is available using the SCROLL pushbutton either on the VEMD or on the collective pitch lever.

• Failure of both screens

Can be a single failure when battery and DC generator are in "OFF" position (fire and smoke detection procedure).

Set maximum power to establish level straight flight with the following law :

IAS kt = 100 kt at sea level - (2 kt / 1000 ft)

For landing carry out a no hover landing.

3.6.2 CAUTION MESSAGES ON VEMD

When a parameter is off line, the parameter value is not displayed on the VEMD upper screen and the parameter scale symbology is displayed in yellow. Caution messages are self explanatory and the pilot shall comply with the action requested. If no light is lit on the caution and warning panel, no other action is required from the pilot.

•	LANE 1 (or 2) FAILED > PRESS OFF 1 (or 2)	•	Self explanatory
•	VEH PARAM OVER LIMIT	:	Vehicle parameter over limit
	ENG PARAM OVER LIMIT	:	Engine parameter over limit

These messages appear when a parameter usually displayed on this page reaches a limitation, as the relevant (vehicle or engine) pages are not displayed.

- SCROLL: DEPRESS to reach the relevant page and check the

parameter.



- CROSS TALK FAILED
- BRT CNTRL FAILED
- FLI FAILED ---> CHECK PARAM
- : Self explanatory
- : Brightness control has failed
- : One parameter (Ng, T4, torque) is not consistent
- Parameter consistancy: CHECKED
- Relevant procedures in § ABNORMAL ENGINE PARAMETER INDICATION (SECTION 3): APPLY
- GENE PARAM OVER LIMIT
 BAT PARAM OVER LIMIT
 Battery parameter over limit
 Battery parameter over limit

These messages appear when the relevant parameter is not displayed on the vehicle page and when a limitation is reached.



LACU pushbutton: ACTUATE

BAT.T

: This message appears when battery temperature is off line.



3.6.3 ABNORMAL NR/Nf INDICATION

• NR Indication Failure

Maintain the torque above 20%.

LAND AS SOON AS PRACTICABLE

• Nf Indication Failure

CONTINUE FLIGHT Avoid abrupt collective reduction.

NOTE

Failure of the NR/Nf indicator DC power supply switches off the Nf indication and the digital NR indication.

After the failure of the Nf indicator, the FLI is replaced by the 3 data symbology (Ng/ Δ Ng, t4 and torque) and a failure message is displayed.

3.6.4 ABNORMAL ENGINE PARAMETER INDICATION



LAND AS SOON AS PRACTICABLE

LAND AS SOON AS POSSIBLE

Loss of OAT, Ng, Torque or t4 parameters

When a parameter is off line, the parameter value is not displayed on the VEMD upper screen and the parameter scale symbology (if applicable) is displayed in yellow.

The FLI is replaced by the 3-data symbology (Ng/ Δ Ng, t4 and torque) and a failure message is displayed.

CONTINUE FLIGHT



- OAT Indicator Failure

OAT : appears in lower right corner of upper screen when OAT is off line with ΔNg gauge in yellow.

Respect the maximum Ng values given below :

- Maximum tacke off power (MTOP) Ng = 100 %
- Maximum continuous power (MCP) Ng = 98.5 %

- Ng Indicator Failure

Respect the maximum t4 values below :

- OAT > - 10° C t4 limited to 760° C

- OAT < - 10° C t4 limited to 750°C

NOTE

t4 limitations displayed are starting limitations

- Torquemeter Failure

Respect the Ng given in the following table :



t4 Indicator Failure

Respect Ng and torque limitations. Do not try to start the engine.





3.7 CAUTION AND WARNING PANEL

3.7.1 ENGINE EMERGENCY

WARNING PANEL	CORRECTIVE ACTIONS		
ENG FIRE	 At start-up : Twist gripSHUT-OFF position Emergency fuel shut-off handleAFT Booster pumpOFF 		
Fire in engine bay	 4. Crank pushbutton		
	• Hover, Takeoff, Final :		
•	LAND IMMEDIATELY		
	Carry out a no hover powered landing then, after landing, apply same procedure as above.		
	• In Flight :		
	LAND IMMEDIATELY		
	 Collective pitch		



WARNING PANEL	CORRECTIVE ACTIONS		
ENG P	Oil pressureCHEC	K NORMAL ↓	
Engine oil pressure	1. Autorotation Procedure APPLY	LAND AS SOON AS PRACTICABLE	
< 1,7 bar.	LAND IMMEDIATELY		
TWT GRIP	Twist grip	INCREASE to flight position	
Twist grip outside flight position			
ENG CHIP Metal particles in engine oil circuit.	LAND AS SOON AS POSSIBLE Execute a minimum power approach landing and be prepared in case of an engine flame-out.		



3.7.2 TRANSMISSION EMERGENCY





,

WARNING PANEL	CORRECTIVE ACTIONS		
HYDR	NOTE Pressure in accumulator allows enough time to secure the flight.		
	On ground : LOCK LOCK LYD switch (on Collective lever) OFF		
Hydraulic	CAUTRION		
< 20 bar	If not locked, the collective pitch will pull up when HYD switch is in "OFF" position.		
	• <u>In flight</u> : Simultaneously		
	1. Collective		
	2. CyclicSET IAS at Vy		
	3. HYD switch (on Collective lever) OFF.		
	To counter effort		
	4. CyclicPUSH FORWARD 5. CollectiveADJUST		
	CAUHON		
	If HYD switch is not switched off on the collective lever, collective pitch may increase.		
	NOTE Efforts in anoma with anomal		
	Approach ·		
	perform a shallow approach and terminate to a hover landing		
	• In hover :		
	Landing possible :		
	LAND AS SOON AS POSSIBLE		
Normal landing.			
	WHEN ON THE GROUND SHUT DOWN THE ENGINE.		
	THEN LOCK THE COLLECTIVE PITCH.		



3.7.4 ELECTRICAL EMERGENCY







DGAC APPROVED REVISION 5

3 - 17













3.7.6 MISCELLANEOUS



RC 5

eurocopter

Replace the table by the following:







3.8 VARIOUS FAILURES AND INCIDENTS NOT INDICATED ON THE CWP

· Flight control hardover or servojam.

Hardover is manifested by uncommanded movements of one or two flight controls.

Servojam is manifested by a higher than normal force to move the control.

- 2. HYD switch OFF (on collective lever)
- 3. IAS Vy

LAND AS SOON AS POSSIBLE





.

•

SECTION 4

NORMAL PROCEDURES

1

4.1 GENERAL	4 - 1
4.1.1 OPERATING LIMITATIONS	4 - 1
4.1.2 FLIGHT PLANNING	4 - 1
4.1.3 TAKEOFF AND LANDING DATA	4 - 1
4.1.4 WEIGHT AND BALANCE DATA	4 - 1
4.2 PREFLIGHT CHECK	4 - 2
4.2.1 EXTERIOR CHECK	4 - 2
4.2.2 INTERIOR CHECK	4 - 4A
4.2.3 TURNAROUND CHECK	4 - 3A
4.3 START UP	4 - 4
4.3.1 ENGINE PRESTART CHECK	4 - 4
4.3.2 ENGINE STARTING	4 - 5
4.3.3 RUN-UP CHECK	4 - 6
4.4 TAKEOFF	4 - 8
4.4.1 BEFORE TAKEOFF CHECK	4 - 8
4.4.2 TAKEOFF CHECK AND PROCEDURE	4 - 8
4.5 CLIMB	4 - 9
4.6 CRUISE	4 - 9
4.7 APPROACH AND LANDING	4 - 9
4.7.1 APPROACH	4 - 9
4.7.2 LANDING	4 - 9
4.8 ENGINE AND ROTOR SHUTDOWN	4 - 10
4.9 EXTREME WEATHER OPERATIONS	4 - 11
4.9.1 HIGH WIND OPERATION (WIND ABOVE 30 KT)	4 - 11
4.9.2 COLD WEATHER OPERATION	4 - 12





LIST OF FIGURES

Page

FIGURE 4-1 : SEQUENCE OF CHECKS	4	-	2	
FIGURE 4-2 : TAKEOFF PROCEDURE	4	-	8	



÷

.



4.1 GENERAL

This section contains instructions and procedures for operating the helicopter from the planning stage, through actual flight conditions, to securing the helicopter after landing.

Normal and standard conditions are assumed in these procedures. Pertinent data in other sections is referenced when applicable.

The instructions and procedures contained herein are written for the purpose of standardization and are not applicable to all situations.

4.1.1 OPERATING LIMITATIONS

For minimum and maximum limits, refer to SECTION 2.

Each time an operating limitation is exceeded, an appropriate entry shall be made in the logbook (helicopter, engine, etc.). The entry shall state which limit was exceeded, the duration of time, the extreme value attained, and any additional information essential in determining the maintenance action required.

4.1.2 FLIGHT PLANNING

Each flight should be planned adequately to ensure safe operations and to provide the pilot with the data to be used during flight.

Flight planning must comply with helicopter limitations and performances (Refer to SECTIONS 2, 5, 6 and 9).

4.1.3 TAKEOFF AND LANDING DATA

Refer to SECTION 2 - LIMITATIONS and SECTION 5 - PERFORMANCE DATA.

4.1.4 WEIGHT AND BALANCE DATA

Ascertain proper weight and balance of the helicopter as follows :

- Consult SECTION 6 WEIGHT AND BALANCE.
- Ascertain weight of fuel, oil, payload, etc.
- Compute takeoff and anticipated landing gross weights.
- Check helicopter centre of gravity (CG) locations.
- Check that the weight and CG limitations in SECTION 2 are not exceeded.



4 - 1



4.2 PREFLIGHT CHECK

- Make sure that the Flight-Related Checks (VLV) after the last flight of the previous day or before the first flight of the day have been performed either by a pilot suitably trained to perform VLV and referring to present Flight Manual (see SECTION 8) or by a qualified mechanic complying with the Aircraft Maintenance Manual.
- Check that the aircraft area is clean and unobstructed.
- Carry out the following checks :

4.2.1 EXTERIOR CHECK



Figure 4-1 : Sequence of Checks

Station 1

- Pitot tube	Cover removed - check condition.
- Landing gear (crossmembers,	
skids, wear resistant plates)	Secure - visual check.
- Engine air intake	Clear (water, snow, foreign matter)
Station 2	
- Doors	Closed.
- Fuel tank and system	Filler plug closed.
- MGB cowl	MGB and engine oil levels. Cowl
	closed.
- All lower and upper fairing	
panels	Closed.





- Main rotor head Visual inspection, rotor head, sleeves, spherical thrust bearing, adapters, bonding braids. - Hydraulic unit/system Check hydraulic reservoir fluid level. - Main rotor blades Secure, visual inspection from ground. - Static port..... Clear. - Exhaust pipe..... Condition - Cover removed. - Rear door cargo compartment..... Check for snow in the tail boom -Closed. - Tail boom Condition, condition of antennas. Station 3 - Stabilizer General condition. - Tail rotor blades No impact. - Tail rotor hub fairing No rotation (paint marks). Station 4 - TGB..... Oil level. - Stabilizer General condition. - Tail boom Condition, condition of antennas. Station 5 - Static port..... Clear. - Starboard cargo door Door opening action. No loose objects. Electrical panel. Closing, latching. - Landing gear (crossmembers, skids, wear resistant plates) Secure, visual inspection. - All lower fairing panels Closed. - EPU door..... Closed. deck. Deck wiped clean. Cowl closed.



I



4.2.2 INTERIOR CHECK

- CabinClean.
- Blanking plate of pedal unit.....Installed (if single pilot

configuration).

- Fire extinguisher.....Fitted and checked.
- Breakers.....All set.
- Objects carried.....Stowed.
- FreightStowed.
- Door jettison.....Checked, lockwired.

4.2.3 TURNAROUND CHECK

- Overall aspectcondition, cleanliness.
- Engine / MGBoil level.
- Main and tail rotor bladescondition. (from ground)
- Loadssecured.
- All doors and cowlingslocked.

NOTE 1

If the aircraft is to be parked some time between flights, temporary picketing is recommended by fitting blanks, covers, and blade socks. In this case, perform a complete exterior check.

NOTE 2

Perform a complete exterior check if the aircraft is to be parked under snow precipitations.





.



4.3 START UP

4.3.1 ENGINE PRESTART CHECK

- Seats and control pedals ADJUSTED.

- Seat belts FASTENED.

NOTE 1

Copilot seat belts shall be fastened in all cases.

NOTA 2

When the rear seats are unoccupied, check that the unused safety belts are not fastened and the button on the shoulder straps is not visible.

NOTE 3

Check that, when flying with doors opern there are no loose objects in the cabin, and the belts of unoccupied rear seats are stowed between the backrest foam and the backrest.

	** .*		•
1		domosoftem or	0.1.1
	пеянио	nennisinno	211
	LIQUULLE,	COMPANY	

- conditioner.....OFF.
- 2. Rotor brake.....FORWARD.
- 3. Fuel shut-off lever FORWARD. LOCKWIRED.
- 4. Battery and Generator ON.
- 5. Light test..... COMPLETE.
- 6. Engine fire test COMPLETE.
- 7. Warning panel remaining

		OTTO.
1	1 abto	1 'HH4
1	12 HUN	 CILL
-		

• With battery power.....

GENE	PITO	т	ENG
FUEL	НО	RN	MGB
TWT G	RIP	HY	'DR

illuminated

• With EPU power	Same lights as above +	BALL
	illuminated	
8. VEMD	Engine page DISPLAYED	•

9. Control pedals Freedom of travel, then NEUTRAL.

- 10.Collective pitch LOCKED.
- 11.Twist grip SHUT OFF position.
- 12.Hydraulic switch (both

collective levers) ON.







Replace the paragraph 4.3.2 by the following paragraph :

4.3.2 ENGINE STARTING

- 1. Booster pump ON FUEL P goes out
- 2. Anticollision light..... ON
- <u>After 30 s</u>
- 3. Starter DEPRESS
- 4. Twist grip GROUND IDLE position

NOTE

If remaining T4 is above 150°C wait until 10% Ng before actuating twist grip.

- 5. Twist grip MONITOR T4
 - depending upon T4 rate of increase.
- When Ng = 50%
- 6. Starter RELEASED
- 7. Twist grip FLIGHT POSITION

Maintain Tq < 40%

Check that ENG P, HYDR and MGB P lights go out on the warning panel.

• When NR \geq 350 rpm.

Switch ON the aural warning and check that HORN light goes out on the warning panel.

• When Twist Grip is in flight position.

Check that NR indication is in the lower part of the green arc and that TWT GRIP light is out.

CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATION SB N° 76.002 HAS BEEN EMBODIED TO THE AIRCRAFT.

DGAC APPROVED OCTOBER 2001



4 - 5



4.3.2 ENGINE STARTING

- 1. Booster pump ON FUEL P goes out
- 2. Anticollision light ON
- <u>After 30 s</u>
- 3. Twist grip on START position
- 4. Starter DEPRESS
- 5. Twist grip MONITOR T4 depending upon T4 rate of increase.

• When Ng = 50%

- 6. Starter RELEASED
- 7. Twist grip FLIGHT POSITION
 - Maintain Tq < 40%

Check that	ENG P,	HYDR and	MGB P light	s go out on the
warning pane	el.			-

• When $NR \ge 350$ rpm.

Switch ON the aural warning and check that HORN light goes out on the warning panel.

• When Twist Grip is in flight position.

Check that NR indication is in the lower part of the green arc and that TWT GRIP light is out.

NOTE

↓ At Ng > 60 % the VEMD upper screen automatically switches to FLI display.

• If EPU is used :

EPU DISCONNECTED

Check that GENE and BATT are not illuminated on the caution and warning panel.





NOTE

- In case of an aborted start, keep the starter button depressed, set twist grip to shut off position, release the starter button, then switch off the booster pump and the generator.
- In case of t4 higher than 200°C or aborted start due to excessively high T4, check the battery voltage :
 - Normal voltage :
 - Crank (LACU pushbutton) during 10 s.
 - Apply Normal start procedure.
 - Voltage under 15 Vdc when starting : No start possible.

4.3.3 RUN-UP CHECK

1. Pitot heat.....ON.

PITOT goes out

- 2. Booster pump.....OFF.
- 3. Check :
- . No warning light illuminated.
- . Electrical system voltage and current.
- . Engine oil pressure.
- 4. All necessary systemsON. TESTED

(Radio, radio navigation, lights, windshield wiper* etc.).

NOTE

Do not use the wiper on a dry windshield or in light rain.

* Optional





Replace the paragraph 4.3.2 by the following paragraph (cont'd):

NOTE

At Ng > 60 % the VEMD upper screen automatically switches to FLI display.

• If EPU is used :

EPU......DISCONNECTED Check that <u>GENE</u> and <u>BATT</u> are not illuminated on the warning panel.

NOTE 1

- In case of an aborted start, keep the starter button depressed, set twist grip to shut off position, release the starter button, then switch off the booster pump and the generator.
- In case of aborted start due to excessively high T4, check the battery voltage :
 - Normal voltage : Try to restart, wait until Ng = 10 % before actuating twist grip, then gradually increase the fuel flow without Ng drop.
 - Voltage under 15 Vdc when starting : No start possible.

NOTE 2

After a failed start or if T4 is higher than 200°C, crank the engine before actuating the starter button, then control T4 with twist grip.

CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATION SB N° 76.002 HAS BEEN EMBODIED TO THE AIRCRAFT.





- Hydraulic accumulator test :
- 1. Collective pitch LOCKED.
- 2. Hydraulic LACU pushbutton...... OFF.

comes on

- . Move the cyclic stick 2 or 3 times along both axes separately
- \pm 10 % of total travel (\pm 2.5 cm). Check hydraulic assistance for absence of control load.
- 3. Hydraulic LACU pushbutton...... ON.

HYDR goes out

CAUTION

If not locked, the collective pitch will increase when HYD switch is in "OFF" position.

- Hydraulic shut-off test :
- 1. Collective pitch LOCKED.
 - 2. Hydraulic collective switch OFF.

Comes on.

Control loads are immediately felt.

3. Hydraulic collective switch ON.

HYDR goes out immediately.

4.4 TAKEOFF

4.4.1 BEFORE TAKEOFF CHECK

- 1. Doors.....CLOSED.
- 2. Collective, cyclic friction locks......AS REQUIRED.
- 3. Landing light.....AS REQUIRED
- 4. Pressures and temperatures.....NORMAL RANGE.
- 6. Collective pitch.....UNLOCKED.

NOTE

Adjust collective and cyclic friction locks so that friction forces are felt by the pilot when moving the flight controls.

4.4.2 TAKEOFF CHECK AND PROCEDURE

CAUMON

- Use of P2 air bleeds are forbidden above the maximum continuous rating (Ng or T4)
- Gradually increase collective pitch to hover at 5 ft. Check engine and mechanical control instruments, no warning light.
- Increase airspeed with the HIGE power until IAS = 40 kt, then begin to climb so as to clear 20 ft at IAS = 65 kt.

MV.EC120.0017.02



Figure 4-2 : Takeoff Procedure

CAUTION

For safe operation, takeoff path should comply with HV diagram (refer to SECTION 5)

Iroconter



4.5 CLIMB

Above 100 ft (30 m) select Maximum Continuous Power and optimum climbing speed of (Vy): IAS = 65 kt (120 km/h) - 1 kt per 1000 ft.

4.6 CRUISE

Fast cruise is obtained by the first limitation reached corresponding to the beginning of the FLI amber area :

Corresponding mechanical limit Tq or Ng are pointed out with underlined numerical value.

Economic cruise : set Tq to 10% less than MCP Tq. Reduce indicated airspeed in turbulence.

4.7 APPROACH AND LANDING

4.7.1 APPROACH

- Perform approach at a minimum rate of descent and at \cong Vy.

- At approximately 100 ft, reduce airspeed down to HIGE at 5 ft.
- · Approach check :
- 1. Landing light.....AS REQUIRED.
- 2. All parameters.....CHECK.

4.7.2 LANDING

- In hover, gradually reduce collective pitch until touch-down, then fully reduce collective pitch.



Use of P2 air bleeds are forbidden above the maximum continuous rating (Ng or T4)


4.8 ENGINE AND ROTOR SHUTDOWN

- 1. Cyclic stick NEUTRAL
- 2. Collective pitch LOCK
- 3. Pitot, Horn, Landing light OFF
- 4. Twist grip GROUND IDLE position

63 % \leq Ng \leq 68 %, wait 30 s. for temperature stabilization.

5. Generator and all systems OFF

6. Twist grip SHUT OFF position

Cancel the idle stop by briefly pressing the starter button.

- For NR \leq 150 rpm
- 7. Rotor brake APPLY
- 8. Anticollision light..... OFF

• BEFORE LEAVING HELICOPTER

- VEMD CHECK flight report page information.
- Ng and Nf cycles written in white characters and above 0.
- Switch off the battery.

- Pitot, intake, exhaust covers, blade socks as required.



4.9 EXTREME WEATHER OPERATIONS 4.9.1 HIGH WIND OPERATION (WIND ABOVE 30 KT)

- Parking
 - Park the helicopter head into the wind. Maintain rotor brake applied with one blade at 12 o'clock. Keep blade socks until start up.
- For wind above 50 kt the helicopter must be tied down.
- Start up
- When the rotor begins to turn, push the cyclic stick slightly forward and accelerate the engine as soon as possible until NR = 320 rpm within T4 limitation.
- Then carry out the normal procedure.

NOTE

Start up and shut down have been demonstrated up to 55 kt of wind from all directions.



ł



4.9.2 COLD WEATHER OPERATION

NOTE

Use of 3 cSt synthetic oil is recommended for low temperature operation.

• Operation in Snow

- Clean the helicopter before takeoff ; blades, rotor head, windshield ...
- Do not stay in HIGE with snow recirculation.
- Replace the turnaround check by a complete exterior check.



.

SECTION 5

PERFORMANCE DATA (APPROVED PART / NON APPROVED PART)

Page

5.1 INTRODUCTION	5 - 1
5.2 STARTING AND STOPPING THE ROTOR ENVELOPE	
5.3 ENGINE CHECK PROCEDURE	
5.3.1 BEFORE TAKEOFF	
5.3.2 IN FLIGHT	5 - 1A
5.3.3 MANUAL ENGINE POWER CHECK	5 - 1B
5.4 AIR DATA SYSTEM CALIBRATION	
5.5 HEIGHT - VELOCITY DIAGRAM	5 - 6
5.6 HOVER IN GROUND EFFECT	5 - 8
5.7 HOVER OUT OF GROUND EFFECT	5 - 9
5.8 CORRECTED WEIGHT	5 - 10
5.9 RATE OF CLIMB	
5.10 GLIDE DISTANCE IN AUTOROTATION	
5.11 NOISE LEVEL	



LIST OF FIGURES

Page

FIGURE 5 - 1a : ENGINE POWER CHECK
FIGURE 5 - 1b : ENGINE POWER CHECK 5 - 3
FIGURE 5 - 2 : T4 CHECK
FIGURE 5 - 3 : AIR DATA SYSTEM CALIBRATION
FIGURE 5 - 4 : HEIGHT - VELOCITY DIAGRAM
FIGURE 5 - 5 : HOVER IN GROUND EFFECT 5 - 8
FIGURE 5 - 6 : HOVER OUT OF GROUND EFFECT 5 - 9
FIGURE 5 - 7 : CORRECTED WEIGHT 5 - 10
FIGURE 5 - 8 : RATE OF CLIMB
FIGURE 5 - 9 : TAS/CAS IN RECOMMENDED CRUISE 5 - 13
FIGURE 5 - 10 : FUEL CONSUMPTION-ENDURANCE IN
RECOMMENDED CRUISE 5 - 14
FIGURE 5 - 11 : RANGE IN RECOMMENDED CRUISE 5 - 15
FIGURE 5 - 12 : TAS/CAS IN FAST CRUISE 5 - 16
FIGURE 5 - 13 : FUEL CONSUMPTION-RANGE IN FAST
CRUISE 5 - 17
FIGURE 5 - 14 : ENDURANCE IN CRUISE AT MINIMUM HOURLY
FUEL CONSUMPTION 5 - 18



.

.



5.1 INTRODUCTION

The following performance curves apply to the basic version of the aircraft. Refer to SECTION 9 when optional equipment is fitted.

NOTE

Values obtained on VEMD PERFORMANCE and ENGINE POWER CHECK pages can be checked with the ENGINE POWER CHECK, T4 CHECK, HOVER IN GROUND EFFECT, and HOVER OUT OF GROUND EFFECT curves.

For AUW over 1680 kg, the performances have to be checked manually with the figures 5-5, 5-6 and 5-7.

CAUTION

Pilot shall limit the flight envelope and weight displayed on VEMD PERFORMANCE pages to the relevant limitations of SECTION 2.

5.2 STARTING AND STOPPING THE ROTOR ENVELOPE

Maximum wind velocity from any direction for starting and stopping the rotor is 55 kt

5.3 ENGINE CHECK PROCEDURE

5.3.1 BEFORE TAKEOFF

In HIGE at 5ft and before initiating forward flight, pull the collective pitch lever slightly to ensure that the Ng can increase by at least 1%.



5.3.2 IN FLIGHT

Perform a VEMD engine check (Pressure Altitude - Hp - less than 12000 ft (3657 m) and heater and demister OFF).

Apply to the "TRQ MARGIN" given by the VEMD, the correction factor of the following table :

Pressure altitude (ft)	0	1000	2000	3000	4000	5000
TRQ (%)	+1.7	+1.3	+1	+0.7	+0.4	0

Example :

OAT	= 20	°C	Hp	= 1000 ft
Ng	= 98.7	%	NR.	= 411 tr/min
TORQUE	= 9 7	%		

"TRQ MARGIN" Real	æ	+ 2.3	%
"TRQ (%) Correction	=	+ 1.3	%
"TRO MARGIN" (VEMD)	=	+1	%



5.3.3 MANUAL ENGINE POWER CHECK

In stabilized level flight at the maximum Ng displayed, note the following parameters : torque, Ng, NR, Hp, OAT and T4. Read the figures ENGINE POWER CHECK and T4 CHECK in the direction indicated by the arrows. Engine power check is OK if point "P" is located in the area marked "CORRECT". T4 check is OK if point "T" is located in the area marked "CORRECT".





Figure 5 - 1a

DGAC APPROVED REVISION 4

.

.





Figure 5 - 1b

DGAC APPROVED REVISION 4







Figure 5 - 2

DGAC APPROVED REVISION 5

.

eurocopter

FLIGHT MANUAL EC120 B

5.4 AIR DATA SYSTEM CALIBRATION

.-



DGAC APPROVED **REVISION 4**

5 - 5

:



5.5 HEIGHT - VELOCITY DIAGRAM

The avoidance zone is defined by 4 points : A, B, C, D.

- Point A : low hover point

Point A is at 6 ft (1.80 m) skid height at zero airspeed.

- Point B

Point B is defined by :

- . a variable height (18 ft \leq height \leq 24 ft) depending on the altitude and on the aircraf weight as determined by line (C),
- . a variable airspeed (50 kt \leq IAS \leq 60 kt) depending on the altitude and on the aircraft weight as determined by line (C).

- Point C

Point C is defined by :

- . a constant height of 50 ft (15 m),
- . a variable airspeed (50 kt \leq IAS \leq 60 kt) depending on the altitude and on the aircraft weight as determined by line (C).

- Point D

Point D is defined by :

- . a variable height (500 ft \leq height \leq 800 ft) depending on the altitude and on the aircraf weight as determined by line (D),
- . a constant zero airspeed.







Figure 5 - 4



5.6 HOVER IN GROUND EFFECT



Figure 5 - 5





Replace figure 5-5 by the following :







DGAC APPROVED NOVEMBER 00





5.7 HOVER OUT OF GROUND EFFECT



Figure 5 - 6



| 5.8 CORRECTED WEIGHT



Figure 5 - 7

DGAC APPROVED REVISION 4

.

.



۰.

5.9 RATE OF CLIMB



DGAC APPROVED REVISION 5



5.10 GLIDE DISTANCE IN AUTOROTATION

The distance flown in autorotation is : 0.7 Nm (1300 m)/1000 ft at Vy and NR $\cong 410 \text{ rpm}$

5.11 NOISE LEVEL

Noise characteristics defined by chapter 11 and appendix 4 of the ICAO annex 16 are as follows :

Measurement	Noise Level	ICAO Noise Limits
Reference Point	SEL (dBA)	SEL (dBA)
Overflight (at Max. gross weight)	78.7	85.4







MANUFACTURER'S DATA REVISION 5





Figure 5 - 10

MANUFACTURER'S DATA REVISION 5



STABILIZED LEVEL FLIGHT

CONDITIONS

FLIGHT MANUAL EC120 B

RANGE IN RECOMMENDED CRUISE



Figure 5 - 11

MANUFACTURER'S DATA REVISION 5





Figure 5 - 12

MANUFACTURER'S DATA REVISION 5

.

,



CONDITIONS STABILIZED LEVEL FLIGHT FUEL CONSUMPTION RANGE IN FAST CRUISE 110 110 100 100 200 90 90 80 80 EV. 29298.CHISOZPCRAP.00 EV.29298.CHISOVPCRAP.00 70 150 60 -40 -30 -20 -10 0 10 20 30 40 50 0.2 0.3 0.4 0.5 0.6 0.7 (kg/km) OAT (°C) 0.6 0.8 i 1.2 0.4 1.4 (kg/NM) 1.5 I 2 2.5 CONS./SPEED (Ib/NM) з 1000 E- 500 E(nm) 800 400 RANGE (km) 600 100 300 80 400 500 000 EV.29288.DISTCRAP.00 80 40 200 EXAMPLE : OAT = +15°C TAS = 236 km/h (127 kt) => RANGE = 395 NM Hp = 2000 ft FUEL = 100% Figure 5 - 13

MANUFACTURER'S DATA REVISION 5



Figure 5 - 14

_rocopter



SECTION 6

WEIGHT AND BALANCE

Page

6.1 GENERAL	. 6 - 1
6.2 WEIGHT AND BALANCE	. 6 - 1
6.2.1 WEIGHT - STANDARD DEFINITIONS	. 6-1
6.2.2 CENTER OF GRAVITY CONVENTIONAL TERMS	. 6-2
6.3 WEIGHING	. 6-3
6.4 LONGITUDINAL CG LOCATION	. 6-3
6.4.1 CALCULATING CG	. 6-3
6.4.2 LOADING DATA	. 6 - 5
6.4.3 CG CHARTS	. 6-9
6.5 LATERAL CG	6 - 12
6.5.1 CREW AND PASSENGERS	6 - 12
6.5.2 DETERMINATION OF LATERAL CG LOCATION	6 - 14
6.6 WEIGHT AND MOMENT OF EQUIPMENT ITEMS	6 - 15





MANUFACTURER'S DATA ORIGINAL ISSUE 6 - i



LIST OF FIGURES

Page

FIGURE 6 - 1 : BASIC DATUM PLANES	6 - 2
FIGURE 6 - 2 : LONGITUDINAL LOCATION OF SEATS	6-5
FIGURE 6 - 3 : LONGITUDINAL LOCATION OF LOADS	6-6
FIGURE 6 - 4 : LONGITUDINAL LOCATION OF FUEL	6 - 8
FIGURE 6 - 5 : CENTER OF GRAVITY 6 - 10	/ 6 - 11
FIGURE 6 - 6 : LATERAL LOCATION OF SEATS AND	
LOADS	. 6 - 12



MANUFACTURER'S DATA ORIGINAL ISSUE



6.1 GENERAL

The purpose of this section is to provide data for use when evaluating a proposed loading configuration or calculating the weight and center of gravity of an aircraft in service.

6.2 WEIGHT AND BALANCE

6.2.1 Weight - Standard Definitions

• Empty Weight (EW)

This corresponds to the sum of the permanent assemblies and equipment:

- The vehicle and its power plant.
- Equipment common to all missions.
- Lubricants and hydraulic fluids.
- Unusable fuel.

EW then, is constant for a given aircraft.

• Equipped Empty Weight (EEW)

This is the sum of :

- Empty weight (EW)
- Specific operational or mission equipment.

EEW varies according to the proposed mission.

• All-up Weight (AUW)

This is the sum of :

- Equipped empty weight (EEW)
- Crew
- Payload
- Usable fuel
- Maximum Weight

Weight is limited on takeoff and landing. See limitations (SECTION 2).



6.2.2 Center of Gravity Conventional Terms

- The center of gravity is defined by dimensions measured perpendicular to the three basic datum planes. These planes are as follows :
 - A horizontal plane parallel to the cabin floor datum, the Z datum plane, located 3.47 m (136.6 in) above this datum.
 - A vertical plane perpendicular to the cabin floor datum. This Y datum plane is the aircraft plane of symmetry. Dimensions to the left (port) are negative, dimensions to the right (starboard) are positive.
 - A vertical plane perpendicular to the two mentioned above, situated 4.00 m (157.5 in) forward of the center of the main rotor. This is the X datum plane, from which the longitudinal reference stations and CG positions are measured.



Figure 6 - 1 : Basic datum planes

• CG location limits are never to be exceeded. See Limitations (SECTION 2).





- A CG location which is correct on takeoff may vary during the mission, due to the reduction in load and therefore exceed acceptable limits.
 - Longitudinal CG must be monitored more closely.
 - Lateral CG need be considered only in very asymmetrical loading configurations.



6.3 WEIGHING

Weighing is the only reliable way of obtaining :

- Equipped empty weight (EEW).
- Aircraft center of gravity (CG) location.

The aircraft must be weighed :

- On leaving the works.
- · Following any major modification.

6.4 LONGITUDINAL CG LOCATION

6.4.1 Calculating CG

• Procedure

The distance from the aircraft center of gravity to the datum plane is obtained using the formula :

 $\frac{\text{Sum of moments}}{\text{Sum of weights}} = CG \text{ in flight order.}$





- Example : Analysis for a passenger transport mission
 - Before takeoff
 - 1) Determine the maximum permissible takeoff weight.
 - 2) Note the equipped empty weight and the moment.
 - 3) Refer to the tables given below to determine loading conditions; totalize weights and moments.
 - 4) Calculate the CG location.
 - Example: Kg m.Kg EEW 970 4103.1 160 376.0 Crew Passengers Cargo 40 164 Fuel 300 1227.0 5870.1 TOTAL 1470
 - 5) Check that CG falls within permissible limits.

 $CG = \frac{5870.1}{1470} = 3.993 \text{ m}$

Longitudinal CG is within the permissible limits.

- In flight or on landing

The aircraft will normally keep within its weight and balance diagram regardless of fuel consumption.



6.4.2 Loading data

• Crew and passengers



Figure 6 - 2 : Longitudinal location of seats

	METRIC UNITS			
WEIGHT	MOMENT : m.kg			
kg	(A)	(B)		
60	141.00	195.00		
80	188.00	260.00		
100	235.00	325.00		
120	282.00	390.00		
140	329.00	455.00		
160	376.00	520.00		
180	423.00	585.00		
200	470.00	650.00		
220	517.00	715.00		
240		780.00		
260		845.00		
280		910.00		
300		975.00		
320		1 040.00		
330		1 072.50		



MANUFACTURER'S DATA ORIGINAL ISSUE

	r
--	---



	ANGLO-SAXON UNITS			
WEIGHT	MOMENT : in.lb			
lb	(A)	(B)		
100	9 250	12 790		
150	13 875	19 185		
200	18 500	25 580		
250	23 125	31 975		
300	27 750	38 370		
350	32 375	44 765		
400	37 000	51 160		
450	41 625	57 555		
485	44 863	62 032		
500		63 950		
550		70 345		
600		76 740		
650		83 135		
700		89 530		
730		93 367		

• Freight and baggage transport



Figure 6 - 3 : Longitudinal location of loads



MANUFACTURER'S DATA ORIGINAL ISSUE



	METRIC UNITS					
WEIGHT	MOMENT : m.kg					
kg	(A)	(A) (B) (C) (D)				
10	23,50	31,00	41,00	47,50		
20	47,00	62,00	82,00	95,00		
50	117,50	155,00	205,00	237,50		
70	164,50	217,00	287,00			
80	188,00	248,00	328,00			
100	235,00	310,00	410,00			
120	282,00	372,00	492,00			
150	352,50	465,00	615,00			
200		620,00	820,00			
250		775,00	1 025,00			
300		930,00	1 230,00			
320		992,00	1 312,00			

	ANGLO-SAXON UNITS					
WEIGHT	MOMENT : in.lb					
lb	(A)	(B)	(C)	(D)		
50	4 625	6 100	8 070	9 350		
100	9 250	12 200	16 140	18 700		
110	10 175	13 420	17 754	20 570		
150	13 875	18 300	24 210			
200	18 500	24 400	32 280			
250	23 125	30 500	40 350			
300	27 750	36 600	48 420			
330	30 525	40 260	53 262			
350		42 700	56 490			
400		48 800	64 560			
450		54 900	72 630			
500		61 000	80 700			
550		67 100	88 770			
600		73 200	96 840			
650		79 300	104 910			
700		85 400	112 980			



MANUFACTURER'S DATA ORIGINAL ISSUE



• Fuel



Figure 6 - 4 : Longitudinal location of fuel

NOTE

Fuel specific gravity : 0.795

METRIC UNITS								
Liter	kg	m. kg	1. kg Liter		kg	m.kg		
25.16	20	81.80	22	26.42	180	736.20		
50.31	40	163.60	25	51.57	200	818.00		
75.47	60	245.40	27	6.73	220	899.80		
100.63	80	327.20	30	01.89	240	981.60		
125.79	100	409.00	32	27.04	260	1063.40		
150.94	120	490.80	35	2.20	280	1145.20		
176.10	140	572.60	37	7.36	300	1227.00		
201.26	160	654.40	40)6.00	323	1321.07		

ANGLO-SAXON UNITS								
US gal	UK gal	lb	in.lb	US gal	UK gal	lb	in.lb	
7.54	6.28	50	8050	67.84	56.54	450	72450	
15.08	12.56	100	16100	75.38	62.82	500	80500	
22.61	18.85	150	24150	82.92	69.10	550	88550	
30.15	25.13	200	32200	90.45	75.39	600	96600	
37.69	31.41	250	40250	97.99	81.67	650	104650	
45.23	37.69	300	48300	105.53	87.95	700	112700	
53.76	44.98	350	56350	107.30	89.40	711.5	114551	
60.30	50.26	400	64400					



MANUFACTURER'S DATA REVISION 5


6.4.3 CG Charts

The following charts (metric and anglo-saxon units) are used to easily determine the aircraft center-of-gravity. When the point obtained is close to the limits, it should be confirmed by calculations.

Example (SEE chart 6.5) :	Item on
	chart
- The weighing operation locates the (CG
at 4.23 m (166.5 in) for an EEW of	: 970 kg (2138 lb) : ①
- 2 front seats used	: 160 kg (353 lb) : (2)
- 1 rear seat used	: 80 kg (176 lb): ③
- Freight in the rear seat	:100 kg (220 lb): ④
- Freight in the hold with a rear CG	: 90 kg (198 lb): (5)
- Fuel	: 300 kg (661 lb): 6

The longitudinal CG is within the permissible limits.

These charts are designed so that the variations in fuel weight and freight in the hold (SEE figure 6.3; item C at 4,10 m (161.4 in)) make the CG move along a vertical line :

- The total weight is 1700 kg (3748 lb) with a center of gravity at 3.925 m

(154.5 in). During the flight, after consuming 200 kg (441 lb) of fuel

(SEE item O), the center of gravity will be 3.903 m (153.6 in).

The weight and CG limits are given in LIMITATIONS (SEE SECTION 2) and may be modified by the Supplements corresponding to the optional items fitted.

FLIGHT MANUAL EC120 B



Figure 6-5 : Center of gravity

MANUFACTURER'S DATA REVISION 5

rocopter





Figure 6 - 5 : Center of gravity (cont'd)

MANUFACTURER'S DATA REVISION 5

6 - 11



6.5 LATERAL CG

The tables below give the lateral CG positions for different weights and their moments with respect to the Y plane (positive dimensions on the right, negative dimensions on the left).

6.5.1 Crew and passengers





METRIC UNITS						
WEIGHT		MOMENT : m.kg				
kg	A +	A -	B+	В-	C +	C -
50	18.00	- 18.00	25.00	- 25.00	19.00	- 19.00
60	21.60	- 21.60	30.00	- 30.00	22.80	- 22.80
70	25.20	- 25.20	35.00	- 35.00	26.60	- 26.60
80	28.80	- 28.80	40.00	- 40.00	30.40	- 30.40
90	32.40	- 32.40	45.00	- 45.00	34.20	- 34.20
100	36.00	- 36.00	50.00	- 50.00	38.00	- 38.00
110	39.60	- 39.60	55.00	- 55.00	41.80	- 41.80
120	43.20	- 43.20	60.00	- 60.00	45.60	- 45.60
130	46.80	- 46.80	65.00	- 65.00	49.40	- 49.40
140	50.40	- 50.40	70.00	- 70.00	53.20	- 53.20
150	54.00	- 54.00	75.00	- 75.00	57.00	- 57.00



MANUFACTURER'S DATA ORIGINAL ISSUE



ANGLO-SAXON UNITS						
WEIGHT		MOMENT : in.lb				
lb	A +	A - 1	B+	B -	C +	C-
50	71	- 71	99	- 99	75	- 75
100	142	- 142	197	- 197	150	- 150
150	213	- 213	296	- 296	225	- 225
200	284	- 284	394	- 394	300	- 300
250	355	- 355	493	- 493	375	- 375
300	426	- 426	591	- 591	450	- 450
330	469	- 469	650	- 650	495	- 495

MANUFACTURER'S DATA ORIGINAL ISSUE 6 - 13



6.5.2 Determination of lateral CG location

The computation method is the same as that used for determining the longitudinal CG location (§ CALCULATING CG - SECTION 6).

Add weights and moments to the aircraft empty weight and moment referring to preceding pages.

Lateral CG location values during the mission shall fall within the permissible limits.

	Kg	m.Kg
EEW	970	9.70
Pilot	80	28.80
Copilot	80	-28.80
Right passenger	80	40.00
Right cargo	150	57.00
Fuel	250	0.00
TOTAL	1610	106.7
Lateral C.G.		
location		

Example during hoisting operation

Lateral CG = $\frac{106.7}{1610}$ = 0.0662 m

This value falls within the permissible limits. (Longitudinal CG = 3.993 m)

MANUFACTURER'S DATA REVISION 5 eurocopter

6.6 WEIGHT AND MOMENT OF EQUIPMENT ITEMS

The following list covers the equipment items. It gives the approximate weight and moment of the removable components.

DESCRIPTION	WEIGHT		MOMENT		
	kg	lb	m.kg	in.lb	
Aircraft tool kit	TBD	TBD	TBD	TBD	١.
Cabin fire extinguisher	2.01	4.43	4.82	418.59	
RH front large door	11.10	24.47	27.75	2407.95	
LH front door	8.90	19.62	20.47	1776.24	
RH rear fixed panel	3.50	7.72	11.55	1002.23	
LH rear sliding door	10.40	22.93	33.28	2887.81	
Dual control	5.34	11.77	10.63	922.10	
Front seat	12.10	26.68	30.25	2624.88	
Three place seat rear (complete with armrests)	30.80	67.90	104.72	9086.87.	
First aid kit	TBD	TBD	TBD	TBD	
LH side main flight controls	TBD	TBD	TBD	TBD	



FLIGHT MANUAL EC120B

SECTION 7

SYSTEM DESCRIPTION

Page

7.1 INSTRUMENT PANEL AND CONSOLE	
7.2 FLIGHT INSTRUMENTS AND COMPUTERS	
7.2.1 CENTRAL COMPUTERS	7-2
7.2.2 CENTRAL WARNING SYSTEM	7-4
7.2.3 VEHICLE AND ENGINE MANAGEMENT DISPLAY	7-5
7.3 ENGINE SYSTEM	7-15
7.3.1 GENERAL	7-15
7.3.2 ENGINE OIL SYSTEM	7-15
7.4 FUEL SYSTEM	7-16
7.4.1 GENERAL	7-16
7.4.2 FUEL TANKS	
7.4.3 FUEL SUPPLY SYSTEM AND REGULATION	
7.4.4 CONTROLS AND MONITORING	7-17
7.5 TRANSMISSION SYSTEM	
7.5.1 ROTORS	7-18
7.5.2 TRANSMISSION	
7.6 FLIGHT CONTROL GRIPS	
7.6.1 COLLECTIVE LEVER GRIP	7-21
7.6.2 CYCLIC STICK GRIP	
7.7 HYDRAULIC SYSTEM	
7.7.1 GENERAL	7-24
7.7.2 HYDRAULIC COMPACT UNIT	7-26
7.8 ELECTRICAL SYSTEM	
7.8.1 GENERAL	7-27
7.8.2 DESCRIPTION OF ELECTRICAL SYSTEM	
7.8.3 ELECTRICAL DISTRIBUTION	7-28







0

7.9 LIGHTING SYSTEM	
7.9.1 INTERIOR LIGHTING	7-30
7.9.2 EXTERIOR LIGHTING	7-31
7.10 CABIN VENTILATION / HEATING AND DEMISTING	7-32
7.10.1 AIR GENERATION	
7.10.2 CONTROLS AND MONITORING	7-33
7.11 PITOT-STATIC SYSTEM	

LIST OF FIGURES

FIGURE 7 - 1 : INSTRUMENT PANEL AND CONSOLE	7-1
FIGURE 7 - 2 : CENTRAL COMPUTERS	7-3
FIGURE 7 - 3 : CENTRAL WARNING SYSTEM	7-4
FIGURE 7 - 4 : VEMD CONTROL	7-6
FIGURE 7 - 5 : MANAGEMENT OF PAGES IN NORMAL DISPLAY	
MODE	7-8
FIGURE 7 - 6 : MANAGEMENT OF PAGES IN DEGRADED DISPLAY	Y
MODE	7-9
FIGURE 7 - 7 : FLI PAGE	
FIGURE 7 - 8 : ENGINE PAGE	7-10
FIGURE 7 - 9 : VEHICLE PAGE	7-11
FIGURE 7 - 10 : FIRST PAGE OF THE EPC	7-11
FIGURE 7 - 11 : SECOND PAGE OF THE EPC	7-12
FIGURE 7 - 12 : PERFORMANCE PAGE	7-13
FIGURE 7 - 13 : FLIGHT REPORT PAGE	7-14
FIGURE 7 - 14 : ENGINE VIEW	7-15
FIGURE 7 - 15 : FUEL SYSTEM	7-17
FIGURE 7 - 16 : MAIN GEAR BOX	7-19
FIGURE 7 - 17 : TAIL GEAR BOX	7-20
FIGURE 7 - 18 : COLLECTIVE LEVER GRIP	7-21
FIGURE 7 - 19 : CYCLIC STICK GRIP	7-22









Page

FIGURE 7 - 20 : HYDRAULIC SYSTEM	
FIGURE 7 - 21 : HYDRAULIC COMPACT UNIT	7-26
FIGURE 7 - 22 : ELECTRICAL SYSTEM	
FIGURE 7 - 23 : DC DISTRIBUTION	
GENERAL DESCRIPTION	
FIGURE 7 - 24 : CARGO COMPARTMENT CIRCUIT	
BREAKER PANEL	
FIGURE 7 - 25 : CCBP	
FIGURE 7 - 26 : NR/NF INDICATOR AND LIGHTING	
POTENTIOMETER	
FIGURE 7 - 27 : AIR GENERATION	
FIGURE 7 - 28 : PITOT-STATIC SYSTEM	



7.1 INSTRUMENT PANEL AND CONSOLE



Figure 7 - 1 : Instrument panel and console



MANUFACTURER'S DATA REVISION 5



7.2 FLIGHT INSTRUMENTS AND COMPUTERS 7.2.1 CENTRAL COMPUTERS

• General

The central computers perform the ancillary service functions of the helicopter. They include two subassemblies :

- the ancillary systems unit (ASU) (1),
- the lighting and ancillary control unit (LACU) (2).

The ASU manages all the aural alarms, some visual warnings, and the processing of specific electrical signals.

The LACU includes all the electrical indicating and control components of the main systems and lighting systems.

Characteristics

The ASU and the LACU are both supplied with a dual 28 V DC power supply, and are protected by circuit breakers.

• Description

The ASU (1) performs the following functions :

- management of the

ENG FIRE

warning light,

- generation of the aural max. and min. NR alarms,
- management of aural "gong" alarms, due to red alarms and maximum takeoff rating,
- generation of the FLIGHT/GROUND signal for the VEMD,
- time delay for maintaining the electro-magnetic pointer of the twist grip after releasing the starter button,

- management of the



caution light,





The front panel of the LACU (2) includes :

- A lighting selector : OFF/DAY/NIGHT. In the DAY position, lighting is at nominal brightness. In the NIGHT position, the VEMD lighting, NR/NF indicator lighting and warning lights are dimmed.
- Two potentiometers for adjusting the brightness of the instrument panel, console and standby compass lighting, which are active when the selector is in the DAY or NIGHT position.

- Control and monitoring pushbuttons.



A

A.COL

GEN

ELECT

LIGHT

PITOT

POS.

FIRE TEST

HORN.

MV.EC120.0123.02





2

FLIGHT MANUAL EC120B



7.2.2 CENTRAL WARNING SYSTEM

• Description

Visual indicators are provided by a caution and warning panel which comprises the following components :

- 6 red warning lights for alarms which require immediate action,
- 18 amber caution lights for alarms requiring action which can be deferred.

Aural alarms are generated via the intercommunications system. The aural warning is activated by pushing in the HORN pushbutton on the Lighting and Ancillary Control Unit (LACU). In this case, the HORN light extinguishes on the caution and warning panel.



Figure 7 - 3 : Central warning system



• Characteristics

The central warning system is supplied by a dual 28 V DC power supply and is protected by circuit breakers.

7.2.3 VEHICLE AND ENGINE MANAGEMENT DISPLAY

• General

The system, which comprises the VEMD multi-function screen, provides a display of engine and vehicle parameters. The VEMD is located in the center of the instrument panel and comprises :

- two calculating modules : LINE 1 and LINE 2,
- one "screen" module which comprises two screens and control pushbuttons.
- Characteristics

The VEMD is supplied with a dual 28 V DC power supply and is protected by circuit breakers.

• Operating modes

Three operating modes are accessible :

- "FLIGHT" mode : by default, this constitutes the main operating mode of the equipment. It contains the ENGINE, VEHICLE, FLI, FLIGHT REPORT, ENGINE POWER CHECK and PERFORMANCE pages.
- Access to "CONFIG" mode :
 - 1. Switch Battery OFF.
 - 2. Maintain [SELECT] and [ENTER] depressed, while switching battery ON.
 - 3. Maintain until message "RELEASE KEY" appears on two screens.
- Access to "MAINT" mode :

same procedure as "CONFIG" mode except item 2, replace by following :

.maintain [SCROLL] and [RESET] depressed, while switching battery ON.



MANUFACTURER'S DATA REVISION 3

FLIGHT MANUAL EC120B



VEMD controls



- OFF1 (2) pushbuttons:
 Energize or cut the processing module 1 (2) and the upper (lower) screen.
- 2 SCROLL pushbutton:
 - . Commute the page
- 3 RESET pushbutton:
 - . Return to nominal display configuration.
- 4 SELECT pushbutton:
 - . Select the data field

- 5 +/- pushbuttons:
 - . Increase/decrease the numerical value of the selected data.
- 6 ENTER pushbutton: . Validate the selected data.
- 7 BRT +/- pushbuttons:
 - . Screen brightness control
- Figure 7 4 : VEMD control









• Operation

The VEMD is switched on when the "BAT" switch is set to "ON".

The equipment performs an initialization test which checks correct operation of each of the two lines. During the test, the following message is displayed :

"TEST IN PROGRESS"

If the test is faulty, the following is displayed :

'LANE1 FAILED"	Or	"LANE 2 FAILED"
"PRESS OFF1"		"PRESS OFF2"

The line concerned can be cut by pressing the associated pushbutton (OFF1 or OFF2). This validates the initialization tests and switches the remaining line to operating mode.

If the test is correct, the VEMD automatically goes to operating mode.

• FLIGHT mode

The flight mode is displayed by default, when no other mode is selected. The "SCROLL" pushbutton is used to scroll the pages as shown on the following diagrams (Fig. 7.5 and Fig. 7.6).



FLIGHT MANUAL EC120B



- Management of pages in normal mode



Figure 7 - 5 : Management of pages in normal display mode

- \rightarrow Automatic change-over at end of phase.
- ---> Page selected manually by pressing "SCROLL".

MANUFACTURER'S DATA REVISION 1



7 - 8





Management of pages in degraded mode.

Figure 7 - 6 : Management of pages in degraded display mode

- \rightarrow Automatic change-over at end of phase.
- ---> Page selected manually by pressing "SCROLL".





- The FIRST LIMITATION INDICATOR (FLI) page

Figure 7 - 7 : FLI page (Values given as an example) Fuel gauge with auxilary tank installed (optional)

NOTE

If one of the parameters on the FLI page becomes invalid, the ENGINE page is displayed automatically ; the parameters can then be read on independent indicators.



The ENGINE page

Figure 7 - 8 : ENGINE page



- The VEHICLE page



Figure 7 - 9 : VEHICLE page

The fuel flowmeter (Optional) delivers an instantaneous fuel consumption and the VEMD computes the remaining endurance as a function of the remaining fuel quantity.

- The ENGINE POWER CHECK (EPC) page

The first page displays the conditions of compliance, where applicable, when the EPC is requested, in order to obtain a correct engine power check. The check is broken down into three phases :

- * a value stabilization phase,
- * a more restrictive stabilization phase,
- * a margin stabilization phase.



Figure 7 - 10 : First page of the EPC



The second page displays the result of the EPC according to 6 parameters (Ng, Nf, T4, Zp, Tq, OAT) and the positive or negative differences in T4 and torque.

NG 99.4 %	NF 412 RPM
T4 795 °C	Zp 2300 Ft
TRQ 96.9 %	OAT + 25.1 °C
T4 MARGIN	TRQ MARGIN
- 34 °C	+ 2.9 %
GOOD	BAD

م م م م م

Figure 7 - 11 : Second page of the EPC

- The PERFORMANCE page

This page is used to calculate aircraft weight and performance in the form of takeoff weights, in and out of ground effect.

The following parameters must be set :

- the equipped empty weight of the aircraft
- the weight of the crew
- the weight of the payload
- the sling load if installed (optional)

Fuel and external parameters Zp and OAT are taken into account automatically.



For mission planning purposes, Zp and OAT can be modified.

When Zp is modified, the OAT decreases in accordance with the standard atmosphere law. When the page is changed or another parameter is selected, the VEMD takes into account the actual Zp and OAT values. To set or modify the parameters, apply the following procedure :



Use of +/- Keys

		Weight	Zp	OAT	
	Press > 5s	±100 kg (200 lb)	± 500 ft (150 m)	±5°C (10°F)	
	Press < 5s	±2 kg (4 lb)	± 100 ft (30 m)	±1°C (2°F)	

	PERFORMANCE			
	E.E.W	970 кg		n an
	CREW	160 к _я		
WN EC120 20037 102	PAY LOAD	1 30 Kg	Zp	8500 E
	USABLE FUEL	300 kg	OAT	+10 °c
	1993년 1월 20일 - 1993년 1월 20일 1993년 1월 20일 - 1993년 1993년 1월 20일 - 1993년		IGE	• 1610 кg
	A.U.W	1560 Kg	OGE	1540 Kg
	MV .EC120.0037.02	E.E.W CREW PAY LOAD USABLE FUEL	PERFORM E.E.W 970 kg CREW 160 kg PAY LOAD 130 kg USABLE FUEL 300 kg Stress 4.U.W	PERFORMANCE E.E.W 970 Kg CREW 160 Kg PAY LOAD 130 Kg VAY LOAD 130 Kg OAT IGE A.U.W 1560 Kg OGE



NOTE

When the IGE and OGE values are less than the aircraft all-up weight, they are displayed in yellow.





- The FLIGHT REPORT page

The purpose of this page is to provide the crew with a synthetic report of the last flight performed. The end of flight report automatically replaces the "VEHICLE" page when the VEMD detects the engine "shutdown" state.



Figure 7 - 13 : FLIGHT REPORT page

- 1 Flight number, which is incremented automatically.
- 2 Flight time
- 3 Compressor cycles / Total cycles
- 4 Free turbine cycles / Total cycles
- 5 Message area (in yellow) if a discrepancy is detected during the flight.

If a message appears, refer to the "MAINTENANCE" mode in the systems description manual.

To exit this page, press the "RESET" key.



MV.EC120.0041.00

7.3 ENGINE SYSTEM

7.3.1 GENERAL

The engine is located in a separate fireproof compartment after the MGB and above the LH rear cargo compartment. The TURBOMECA ARRIUS 2F engine is a free-wheel turbo shaft type engine with a single stage centrifugal compressor, an annular reverse flow combustion chamber and a single gas generator turbine.



MAGNETIC CHIP DETECTOR PLUGS

Figure 7 - 14 : Engine view

7.3.2 ENGINE OIL SYSTEM

The engine oil system is divided into two systems :

- an external system installed in both the MGB and engine compartments. It includes two coolers crossed in parallel by the oil and a thermostatic valve which bypasses the coolers for low temperature starting. The hoses installed in the engine compartment are fireproof.
- an internal system integrated into the engine. It includes a tank, pressure and scavenge pumps, a filter and electrical magnetic chip detector plugs.



MANUFACTURER'S DATA REVISION 1



7.4 FUEL SYSTEM

7.4.1 GENERAL

The fuel system comprises two tanks with crashworthy elastomer bladders, a supply system, refueling equipment and a monitoring system. The connections are anti-crash treated.

7.4.2 FUEL TANKS

The upper tank is located above the cargo compartment and feeds the lower tank by gravity. The lower tank is located below the cargo compartment floor. The engine is supplied from this tank.

Both tanks are equipped with a mounting plate and a fuel level transmitter.

As soon as the upper tank is dried, the indicated fuel quantity is approximately 145 kg (1801 - 48 US gal). According to the fuel flow, this value reaches 120 kg (1501 - 40 US gal) due to the fuel lines between the two tanks after about 15 minutes flight.

The lower tank also includes a starting pump, a quick fuel drain valve and a decanting sump with a sediment drain valve. A venting device on the RH side and a filler on the LH side are fitted to the upper tank.

7.4.3 FUEL SUPPLY SYSTEM AND REGULATION

The fuel is sucked up through the filter by the high pressure pump. The fuel flow is regulated in the metering valve according to the power required in normal flight mode. The principle is to govern a constant Nf regardless of the power required from the engine, by controlling Ng: For starting, the twist grip opens the metering valve, regulators supply the fuel necessary for lighting up Ng \approx 15 % under starter generator effect. The twist grip is then moved forward to its flight position. The fuel is then distributed to the injectors.





7.4.4 CONTROLS AND MONITORING



Figure 7 - 15 : Fuel system

MANUFACTURER'S DATA REVISION 1



7.5 TRANSMISSION SYSTEM 7.5.1 ROTORS

• MAIN ROTOR

The main rotor is fully articulated and includes three blades. It rotates clockwise when viewed from above at a nominal speed of 406 rpm. Flapping, lead-lag and pitch hinges are provided by a spherical elastomeric bearing. An elastomeric lead-lag damper links each blade to the hub.

TAIL ROTOR

The tail rotor is shrouded (FENESTRON), and is housed in the vertical fin; it comprises eight blades.

The blades rotate clockwise when viewed from the LH side of the aircraft.

7.5.2 TRANSMISSION

The transmission system consists of:

- Engine / MGB coupling,
- Main gear box (MGB),
- Tail rotor drive shaft,
- Tail gear box (TGB).

ENGINE / MGB COUPLING

The engine / MGB coupling transmits the engine power to the MBG. It consists of :

- A coupling shaft with a triangular flange at each end.
- Two flexible couplings at each end of the shaft.
- An antifail system in case of flexible couplings failure.
- A fixed housing bolted to the engine on one side and attached to the input casing on the other side.



- MGB
 - It transmits the power from the engine to the main rotor with a speed reduction.
 - It drives the tail rotor drive.
 - It drives and supports the hydraulic compact unit, the MGB lubricating pump, the rotor brake and the oil cooler fan.
 - It supports the servocontrols and suspension bar attachment fittings.

It includes its own lubricating system, monitoring systems and access for maintenance.

The lubricating pump sucks the oil up from the MGB sump through a strainer and delivers it through a filter. The oil returns to the sump by gravity.



Figure 7 - 16 : Main gear box





• TAIL ROTOR DRIVE SHAFT AND TGB

The tail rotor drive shaft is composed of two shafts, a front shaft which is shorter, and a rear shaft.

The TGB is fitted to the rear end of the tail boom and it comprises power and control modules contained in one housing.

The TGB is splash-lubricated and comprises a visual oil level

indicator and a chip detection device (amber «GB CHIP» caution light).



Figure 7 - 17 : Tail gear box

MANUFACTURER'S DATA REVISION 1



7.6.2 CYCLIC STICK GRIP



- 1 Radio frequency selection switch
- 2 Four-way mirror switch *
- 3 Cargo release pushbutton *
- 4 AFCS release pushbutton *
- 5 Camera pushbutton *
- 6 ICS switch

* OPTIONAL



MANUFACTURER'S DATA REVISION 5

7 - 22 (7 - 23 Blank)



FLIGHT MANUAL EC120B

MANUFACTURER'S DATA REVISION 1

7 - 23



7.7 HYDRAULIC SYSTEM

7.7.1 GENERAL

The hydraulic system reduces the pilot's workload by providing hydraulic assistance to actuate the main rotor controls. It comprises two separate assemblies :

- a hydraulic compact unit, supported and driven by the MGB, which generates the hydraulic power, pressure and flowrate.
- a distribution system which comprises flexible pressure and return hoses, supplying the three servo-controls.
- Normal operation

At start-up, hydraulic pressure is nil and the red "HYDR" warning light (9) is lit on the caution and warning panel. When the pressure in the system is between 20 and 30 bar (290 psi and 435 psi) the warning light (9) must go out.

When the pushbutton (6) is released, and the switches (7) are in the off position, the electro-valves (4) and (8) are not energized and are open.

The hydraulic pump (2) operates when the rotor is spinning.

The regulating valve (1) regulates the pressure to between 37 and 40 bar. The hydraulic warning light (9) is out.

The servo-controls are supplied normally.

The nitrogen in the accumulators (3) is compressed by the hydraulic fluid. The pressure of the nitrogen P1 equalizes with the pressure of the hydraulic fluid P2 (Detail A). The accumulator (3) is ready to release its energy (expansion of gas) in case of a pressure drop.





MANUFACTURER'S DATA REVISION 1

7 - 24





Figure 7 - 20 : Hydraulic system

MANUFACTURER'S DATA REVISION 3 

7.7.2 HYDRAULIC COMPACT UNIT



Figure 7 - 21 : Hydraulic compact unit

MANUFACTURER'S DATA REVISION 5



7.6 FLIGHT CONTROL GRIPS 7.6.1 COLLECTIVE LEVER GRIP



- 1 Fixed landing light switch
- 2 Emergency floatation switch *
- 3 Hydraulic cut-off switch
- 4 Retractable landing light switch *
- 5 Retractable landing light position control *
- * OPTIONAL

MV.EC120.0045.01

- 6 Hoist cable cutter *
- 7 Engine starting pushbutton
- 8 VEMD scroll pushbutton
- 9 Windshield wiper pushbutton *
- 10 Start position (22° on governor twist grip input)

Figure 7 - 18 : Collective lever grip



MANUFACTURER'S DATA REVISION 4 7 - 21


7.8 ELECTRICAL SYSTEM

7.8.1 GENERAL

The generation and distribution system supplies the electrical network with 28 V DC regulated voltage. The network may be supplied by:

- A starter generator located on the engine accessory gear box.
- A battery located in the cargo bay at the tail boom-to-fuselage junction frame.
- An external power unit (EPU) plug (if fitted) on the right side (400A max).



Figure 7 - 22 : Electrical system



MV.EC120.0049.02

FLIGHT MANUAL EC120B



7.8.2 DESCRIPTION OF ELECTRICAL SYSTEM

Power sources are connected to the electrical master box (EMB) which ensures the following functions :

- regulation of the starter generator.
- electrical network protection against failure of power sources and distribution.
- connection of power sources to the electrical network.
- operating logic (network reconfiguration).
- interface between generation, distribution system and indicating, control and monitoring system.
- its own testability.

Power distribution is ensured by :

- a cargo compartment circuit breaker panel,
- a cockpit circuit breaker panel (CCBP).

7.8.3 ELECTRICAL DISTRIBUTION

The DC distribution system includes :

- an electrical master box (EMB) (2),
- a cargo compartment circuit breaker panel (3),
- a cockpit circuit breaker panel (CCBP) (1).





CARGO COMPARTMENT CIRCUIT BREAKER PANEL

The cargo compartment circuit breaker panel is installed in front of the EMB.



* Optional equipments



• COCKPIT CIRCUIT BREAKER PANEL

The CCBP is installed on the console.



* Optional equipments

Figure 7 - 25 : CCBP

MANUFACTURER'S DATA REVISION 5

•--



7.9 LIGHTING SYSTEM 7.9.1 INTERIOR LIGHTING

• GENERAL

Interior lighting is provided by :

- a spot light located on the overhead panel, for normal instrument panel lighting.
- two map lights on the overhead panel, which are supplied directly by the battery, for instrument panel and console emergency lighting.
- integral lighting of console instruments (including standby compass).
- LCD displays on VEMD and NR/Nf indicator.
- CWP integral lighting.
- a dome light for the passengers.
- an internal light for the stand-by compass.
- CONTROLS

Except for the map lights, the interior lighting is controlled by the OFF/DAY/NIGHT switch, the general lighting potentiometers on the LACU, and the NR/NF lighting potentiometer :

- OFF: the spot light and console instrument lighting are off; the LCD displays and CWP lights are at nominal brightness.
- DAY : the spot light and console instrument lighting are on ; the LCD displays and CWP lights are at nominal brightness.
- NIGHT : the spot light and console instrument lighting are on ; the LCD displays and CWP lights are dimmed.



MANUFACTURER'S DATA REVISION 3

1



- The brightness of the spot light and console instrument lighting can be adjusted using the general lighting potentiometers.
- Each map light is switched on by rotating the head of the light. Brightness is adjusted using a potentiometer located near the light.
- The passenger dome light is controlled by a switch located in front of the light.
- The stand-by compass light is controlled by a switch located on the compass.
- The brightness of LCD displays on NR/NF indicator (1) can be ajusted using the NR/NF lighting potentiometer (2) when the LACU switch is on NIGHT position.





7.9.2 EXTERIOR LIGHTING

The exterior lighting comprises position lights, anticollision light and a fixed landing light.

The position lights and anticollision light are switched ON/OFF by POS.LIGHT and A.COL LIGHT LACU pushbuttons. The landing light is switched ON/OFF by a switch on the collective lever grip.



7.10 CABIN VENTILATION / HEATING AND DEMISTING

7.10.1 AIR GENERATION

In flight, some outside air taken in through the front air intake, is diverted into the RH forward cowling compartment by the ventilation scoop. This air crosses the P2 venturi nozzle where it is mixed with P2 air. This air then supplies the distribution system via a hole in the cabin ceiling.

The cabin air distribution system comprises a duct fitted underneath the cabin ceiling and positioned on the aircraft center line. This duct is divided into two arms.







7.10.2 CONTROLS AND MONITORING

• VENTILATION CONTROL

The ventilation is controlled by adjusting louvres:

- Open/closed.
- Air flow adjustment.

• HEATING AND DEMISTING CONTROL

The warm air temperature setting is performed by the P2 gate valve control knob located on the cabin ceiling.

The louvres have to be closed for demisting operation.

MONITORING

The crew is informed that the P2 gate valve is in the open position by a P2 flag on the VEMD upper screen.



7.11 PITOT-STATIC SYSTEM

GENERAL

The Pitot tube picks up the total pressure (Pt) which is transmitted to the airspeed indicator. The tube incorporates a resistor for heating. An amber "PITOT" caution light on the caution and warning panel indicates that the heating system is not operating or has failed.

The two static pressure ports pick up the static pressure (Ps) which is transmitted to the pilot's conventional instruments (airspeed indicator, rate-of-climb indicator, altimeter) and to the VEMD for performance calculation.

The bleed valve is used to drain any condensation water which may accumulate within the system.

The air data system comprises a Pitot tube (7), two static pressure ports (1), a bleed valve (8), an altimeter (3), a rate-of-climb indicator (4), an airspeed indicator (2), and a temperature probe (6) connected to the VEMD (5).



Figure 7 - 28 : Pitot-static system

MANUFACTURER'S DATA REVISION 3





SECTION 8

HANDLING - SERVICING - MAINTENANCE

Page

8.1 GROUND HANDLING	8-1
8.1.1 EQUIPMENT REQUIRED	8-1
8.1.2 HANDLING	8-1
8.2 SERVICING INSTRUCTIONS	8-3
8.2.1 FUELS	8-3
8.2.2 FUEL ADDITIVES	8-3
8.2.3 LUBRICANTS	8-4
8.2.4 HYDRAULIC FLUIDS	8-5
8.2.5 REFUELLING	8-5
8.3 TEST SCHEDULE	8-8
8.3.1 GENERAL	8-8
8.3.2 TEST SHEETS	8-9
8.4 DAILY OPERATING CHECKS	8-25
8.4.1 INSPECTION ASSOCIATED WITH THE FLIGHTS OF THE	Ξ
DAY	8-25
8.4.2 OPERATION OF OPTIONAL INSTALLATIONS	8-32
8.4.3 COMMISSIONING IN COLD WEATHER CONDITIONS	8-33

FLIGHT MANUAL EC120 B



LIST OF FIGURES



FIGURE 8-1 : TOWING AND MANUAL POSITIONING DEVICE	8-2
FIGURE 8-2 : FILLER PLUG AND ELECTRO-STATIC	
CONNECTOR LOCATION	8-5
FIGURE 8-3 : SEQUENCE OF CHECKS	8-27





FLIGHT MANUAL EC120 B



8.1 GROUND HANDLING

8.1.1 EQUIPMENT REQUIRED

- For moving the aircraft by hand :
 - single or twin handling (optional) wheels.
 - jacking lever.
- For towing the aircraft with a tractor :

the above-mentioned equipment, plus :

- a towing bar installation.

8.1.2 HANDLING

• Moving the helicopter by hand

On prepared ground

- Position the ground handling wheels on the mounting studs according to aircraft balance.
- Install ground handling wheels (wheels outside skids).
- Check that wheels are correctly locked (see Detail A).

Lift the aircraft onto the wheels using a jacking lever.

Lock in this position with retaining pins.

ATTENTION

Do not use the single handling wheels if the weight of the aircraft exceeds 1400 kg (3086 lb).

On rough ground

- Use twin ground handling wheels (optional)
- Install as described above.
- Lift the aircraft with the hydraulic towing and manual positioning device (Fig. 8-1).
- Towing the helicopter with a tractor

Prepare the aircraft as above and attach the towing bar.





NOTE

The fenestron handle should always be used to guide the aircraft when towed.



Fig. 8-1 : Towing and manual positioning device



8.2 SERVICING INSTRUCTIONS

8.2.1 FUELS

The authorized fuels are given in the LIMITATIONS sections.

• Capacity

	Litres	U.S. gal	U.K. gal	Kg	lb
TOTAL FUEL				Ţ	
TANK CAPACITY	410.5	108.5	90.4	326.3	719.4
NON-CONSUMABLE					
FUEL	4.5	1.19	0.99	3.6	7.89
CONSUMABLE FUEL					
REMAINING WHEN	38	10.04	8.37	30.2	66.6
LIGHT COMES ON					

8.2.2 FUEL ADDITIVES

The anti-ice additive when used shall meet the requirements of French Specification AIR 3652 or the equivalent non-French specifications :

MIL.I 27686 - D.Eng. RD 2451 - PHILIPS PFA/55 MB - NATO S.748.

The additive is to be mixed with the fuel in the following proportions :

- Minimum concentration, by volume :
 - 0.035 % in a tank already filled.
 - 0.06 % in fuel to be used for refuelling.
- Maximum concentration, by volume : 0.15 %.





If there exists any doubt as to the concentration of additive in the contents of a fuel tank, the fuel is to be drained from the tank and replaced by fuel containing a known proportion of additive within the afore-mentioned limits unless it is possible to measure the concentration using a differential refractometer.

Instructions permitting the correct concentration of additive to be obtained are given by the vendor.

8.2.3 LUBRICANTS

• Engine Oil System

Lubricants and Commercial Descriptions

- Authorized lubricants : Refer to the LIMITATIONS section.

- Commercial descriptions : Refer to the TURBOMECA publications.

Capacity

Engine oil tank and system capacity : 4.6 litres (1.21 U.S. gal)

• Transmission Components

Lubricants

The authorized lubricants are given in the LIMITATIONS section.

Capacity Main gearbox (system included) : 4 litres (1.05 U.S. gal) Tail gearbox (system included) : 0.22 litre (0.05 U.S. gal)





8.2.4 HYDRAULIC FLUIDS

• Hydraulic Fluids

The authorized hydraulic fluids are given in the LIMITATIONS section.

- System
 - Total capacity of system : 2.2 litres (0.58 U.S. gal)
 - Operating pressure : 37 bars (536 psi).

The warning light situated on the warning-caution-advisory panel illuminates when the pressure is lower than 20 bars (290 psi).

8.2.5 REFUELLING



Fig. 8-2 : Filler plug and electro-static connector location



- Normal refuelling
 - Place the helicopter on a level surface.
 - Connect the bowser earthing cable to the electro-static balance connector (1) on the helicopter.
 - Check the quantity of fuel remaining in the tanks on VEMD fuel indicator.
 - Observe the following safety precautions :
 - Ensure that the aircraft electrical power supply is switched off.
 - · Place a fire extinguisher near the work area.
 - · Strictly prohibit smoking in the security area.
 - Prohibit the use of any means of lighting not conforming to the rules of safety.
 - Ensure, during refuelling (or defuelling), that the bowser (or the defuelling unit) is connected to the aircraft by the electrostatic balance connectors (1).
 - Strictly prohibit draining of fuel tanks, whether partial or total, inside a hangar or shop.
 - Fill the tanks, monitoring the quantity of fuel delivered on the bowser flowmeter.
 - Position and lock the filler plug (2).
 - Disconnect the bowser earthing connector from the aircraft electro-static balance connector.
 - Check that the difference in the aircraft fuel gauge readings corresponds to the quantity of fuel delivered and determine the corresponding weight.





• Refuelling with rotors spining.

WARNING

REFUELLING WITH ROTORS SPINING SHALL BE PERFORMED ONLY AFTER PRIOR AGREEMENT IS GIVEN BY THE COMPETENT AUTHORITY IN COMPLIANCE WITH OPERATIONAL REGULATIONS.

- Strictly comply with the instructions defined below.
- Head aircraft into forward wind sector $\pm 45^{\circ}$ if wind above 10 kt.
- Lock the collective pitch lever in full low pitch position.
- Check main rotor is at nominal speed with twist grip in flight position (TWT GRIP light "off").
- Limit refuelling at 95% in order to prevent any fuel spillage.
- The pilot must always have someone in view who can signal to the mechanic to stop refuelling.





8.3 TEST SCHEDULE

8.3.1 GENERAL

The test sheets are intended to sum up the checks to be carried out in flight or on the ground, with rotors turning either after replacement of main components, or after an extensive operation, or further to periodic inspections.

The test sheets are in the form of reproductible sheets which can directly be filled in by the crew.

CAUTION

Since these checks do not form part of normal helicopter operation, they shall be carried out only by qualified personnel under the operator's responsability.



ITR 6b



8.3.2 LIST OF TEST SHEETS

- No 0 FLIGHT REPORT
- No 1 VEMD CONFIGURATION
- No 2 GROUND RUN
- No 3 HOVER FLIGHT
- No 4 AUTOROTATION 65 kt
- No 5 MAXIMUM CONTINUOUS POWER LEVEL FLIGHT
- No 6 MAX TAKEOFF POWER
- No 7 PREFERENCE INJECTOR VALVE TESTING (AS SHEDULED BY THE ENGINE MANUFACTURER)

TEST SHEETS TO BE CONDUCTED ACCORDING TO THE COMPONENT REPLACED :

TEST SHEETS No →	0		1		2	2			3	4		5		6
COMPONENTS REPLACED V		Α	В	Α	В	C	D	Α	B		Α	B	C	
ENGINE OR MODULE REPLACEM.	•	1	•	•	•	1	•	•	•	•	•	1	•	•
MGB OR MODULE REPLACEMENT	•	1	1	•		•	•	•	•	•	1	•	1	1
MAIN ROTOR HUB	•	1	1	•	•	1	•	•	•	•	•	1	•	1
TAIL ROTOR	•	1	1	•	•	1	•	•	1	1	1	1	1	•
HYDRAULIC SYSTEM	•	1	1	1	1	•	1	1	1	1	1	•	1	1
VEMD REPLACEMENT	•	•	•	1	1	1	1	1	1	1	•	1	1	1



8.3.2 LIST OF TEST SHEETS

- No 0 FLIGHT REPORT
- No 1 VEMD CONFIGURATION
- No 2 GROUND RUN
- No 3 HOVER FLIGHT
- No 4 AUTOROTATION 65 kt
- No 5 MAXIMUM CONTINUOUS POWER LEVEL FLIGHT
- No 6 MAX TAKEOFF POWER

TEST SHEETS TO BE CONDUCTED ACCORDING TO THE COMPONENT REPLACED :

TEST SHEETS No →	0		L		1	2		1	3	4		5		6
COMPONENTS REPLACED V		Α	B	A	B	C	D	A	B	. 2	A	B	С	
ENGINE OR MODULE REPLACEM.	•	1	•	•	•	1	•	•	•	•		1	•	•
MGB OR MODULE REPLACEMENT	•	1	1	•	•	•	•	•	•	•	1	•	ï	1
MAIN ROTOR HUB	•	1	1.	•	•	1	•	•	•	•	•	1	•	1
TAIL ROTOR	•	1	1	•	•	1	•	•	1	1	1	1	1	•
HYDRAULIC SYSTEM	•	1	1	1	1	•	1	1	1	1	1	•	1	1
VEMD REPLACEMENT	20 M	•	•	1	1	1	1	1	1	1	•	1	1	1



-10	SHEET No O	HELICOPTER EC 120 B	FLIGHT	REPORT
t	AIRCR	AFT No :	VEMD	METEO
	DATE FLIGHT START DURATION CREW AREA	: : : :	Ng Total CYCLES : Nf Total Over limit : YES NO Failures : YES NO	Pressure :
h	WE	GHT	MAIN WORK COMPLETED BEFORE FLIGHT	REMARKS MADE BY CREW AFTER FLIGHT
MAN	EQUIPPED EMPTY V CREW	/EIGHT: 		
UFACTUR	FUEL :	kg lb l US gal		
ER'S D	ALTITUDE :	m ft	SPECIAL INSTALLATIONS	WRITER'S VISA
ATA	AIRSPEED :	km/h kt MPH		

FLIGHT MANUAL EC120 B

eurocopter



EC120 B

1B	EC 120 B	VEMD CONFIGURATION					
TEST PHASES ANI	D REQUIREMENTS	RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED				
VEMD CYCLE COUNT	ING tion)	- Removed VEMD (1) cycles	Ng (1) Nf (1)				
(alter tenioval and instana		- Installed VEMD (2) cycles	Ng (2) Nf (2)				
		Correction value of new VEMD cycles	=				
		- VEMD total cycles after 1st Start-up	+ +				
		• Engine cycles after 1st Start-up	=				
		- VEMD total cycles after 2nd Start-up	+ +				
		• Engine cycles after 2nd Start-up	= =				
		- VEMD total cycles after 3rd Start-up	+ +				
		• Engine cycles after 3rd Start-up	≖[
		- VEMD total cycles after 4th Start-up	+ +				
		• Engine cycles after 4th Start-up	=				

.

SHEET No 2A	HELICOPTER EC 120 B	GROUI	ND RUN
TEST PHASES AN	D REQUIREMENTS	RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED
ENGINE STARTING ENGINE STARTING Comply with the Normal Flight Manual SECTION • 45 % \leq Ng \leq 65 • Ng \approx 50 %	Procedures of the 4 %	Record parameters : Battery Voltage ≈ 25 V Battery Voltage ≥ 18 V • On warning panel : ENG. P Light goes out GENE Light goes out	Hp: OAT: U: U: U min: T4 max: (See limitation SECTION 2) YES NO YES NO
 Ng = 60 % 150 ≤ NR ≤ 250 NR ≤ 250 rpm 	rpm	FLI page is displayed on VEMD MGB, P Light goes out HYDR. Light goes out	YES NO YES NO YES NO
 "HORN" is engated as a second Parameters when position 	ged twist grip in Flight	 Aural warning sounds for NR between 250 and 370 rpm. Nf = NR stabilized ≈ 393 rpm. 	Begining Alarm End of Alarm NR min : NR min : Fuel QTY : Tq : T4 : Ng : U Batt : U Gen. : I Batt : I Gen. : Eng. P. : Eng. T. : NR : Nf :
BARRA MO			FLI]

5

FLIGHT MANUAL EC120 B

2R	EC 120 B	GROUN	D RUN
TEST PHASES ANI	REQUIREMENTS	RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED
craft on ground			
ACK AND BALANCE	<u>E TESTS</u>	- Full low pitch NR stabilized ≝ 393 rpm	
	-p-	• TRACK CHECKS The setting must be carried out with the yellow (II) blade as reference.	
		- Record parameters :	tračk
NC	ЭТЕ		
balance is to be checke blade track.	ed only after obtainning	BALANCE CHECKS	
		- Record parameters :	
		- Unbalance < 0.2 IPS	IPS Phase
	TEST PHASES ANI raft on ground ACK AND BALANCH ord track with strobosco ord track with strobosco NC balance is to be checke lade track.	TEST PHASES AND REQUIREMENTS raft on ground ACK AND BALANCE TESTS ord track with stroboscope NOTE balance is to be checked only after obtainning lade track.	TEST PHASES AND REQUIREMENTS RESULTS TO BE OBTAINED / LIMITATIONS raft on ground - Full low pitch NR stabilized a 393 rpm ord track with stroboscope - Full low pitch NR stabilized a 393 rpm ord track with stroboscope - TRACK CHECKS The setting must be carried out with the yellow (IP) blade as reference. NOTE - Record parameters : NOTE - BALANCE CHECKS Lade track. - Record parameters : - Unbalance < 0.2 IPS



FLIGHT MANUAL ECU20 B

8 - 16	SHEET No 2D	HELICOPTER EC 120 B	GROUM	ND RUN
	TEST PHASES ANI	REQUIREMENTS	RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED
	ENGINE SHUT - DOWN (see Normal Procedures : 3 - Twist grip on ground idle	SECTION 4) position	Stabilization	
	After 60 s - Twist grip on shut-off po	sition	 66 % ≤ Ng ≤ 70 %. VEMD : 3 Informations mode (for Ng ≤ 50 %) 	Idle Ng :
	- Engine shut-down time (*	')	from Ng = 50 % to Ng = 2 % ($t = 30$ s)	Duration : (*)
	- Time rotor brake		Apply at 150 rpm (t ≈ 25 s)	Duration :
	- Flight report page (autom	atic display)	• When Nf < 80 rpm	YES NO
	· .		Record parameters :	
1			Engine start-up_number	No :
M			Flight time	Duration :
NU			Ng cycles	Partial : Total :
FAC			Nf cycles	Partial : Total :
TURI			Failure detected	YES NO Codes
ER'S		<u></u>	Over limit detected	YES NO Values
DATA SION 3	(*) for information only	, not needed by Turbomeca		

.

وأعاقص

eurocopter

FLIGHT MANUAL EC120 B



-	
ı.	

SHEET NO	HELICOPTER	HOVER	FLIGHT
JB	EC 120 B	DESULTS TO BE OBTAINED / LIMITATIONS	DESILTS OPTAINED
HOVER FLIGHT CHE	CKS	RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED
Increase collective pitch to	o hover at 6 A in 2 s (max)	The rotor speed decay must be weakNo alarm NR min	YES NO
TRACK AND BALANC	<u>e tests</u>	• Check unbalance < 0.2 IPS	IPS : Phase :
		Check track with stroboscope	track :
		• Report parameters	Fuel QTY : Tq : T4 : Ng :
		Nf = NR stab. ≅ 406 rpm	U Batt : U Gen. : I Batt : I Gen. : Eng. P. : Eng. T. : NR : Nf :
			FLI :

FLIGHT MANUAL EC120 B

eurocopter

MANUFACTURER'S DATA REVISION 5

SHEET No HELICOPTER 4 EC 120 B		AUTOROTATION 65 kt			
TEST PHASES AND REQUIMENTS		RESULTS TO BE OBTAINED / LIMITATIONS	RJ	ESULTS OBTAINED	-
CHECK OF MAX. NR WARNING Perform autorotation with Vy = 65 kt and adjust the collective pitch to obtain NR > 420 rpm ADJUSTMENT OF THE LOW PITCH STOP		Max aural NR warning release at 420 rpm	YES	NO	
If possible, the minimum weight must be < 1450 kg.		Record parameters :	AUW:		Kar
Perform, a good steady state autorotation with, Vy = 65 kt, and the pitch on the minimum stop.		NR in compliance with the values computed by means of Figure 1, \pm 5 rpm	Hp: OAT:		
If it is impossible to position without exceeding the max η possible or decrease the weig	the pitch on the stop om, decrease the altitude if ht.	Correction: 1 turn of screw on the pitch stop screw to be tightened \approx -7 rpm	Fuel Qty:		
NOTE			NR:		1 Marshall
If the test is performed with the SURFAIR skis installed, add 4 rpm to the value read in flight before comparing the value with the rotor speed given by the		BOLOS ELERO DA VOL	Design NR:		
chart.	EC 130 B	AFTORDEAT	0)/ 9 2 F 7	to part and a	

FLIGHT MANUAL EC 120 B



FLIGHT MANUAL

EC120 B

rocopter





FLIGHT ANUAL

00			•	÷	• •		•
22	SHEET No 5B	HELICOPTER EC 120 B	MAXIMUM CONTINUOUS	S POW	VER LEVEI	J FLIC	GHT
	TEST PHASES ANI	D REQUIREMENTS	RESULTS TO BE OBTAINED / LIMITATIONS		RESULTS	OBTAL	NED
	HYDRAULIC CHECKS		Refer to SECTION 4				
	Reduce Speed < 70 kt		. Hydaulic shut off test.	l			
	CAU	TION	- Hydraulic collective switch : OFF				
	Hydraulic cut-off on collect forbidden with speed > 70	tive switch is) kt.	HYDR comes on	YES		NO	
			Weak loads at 70 kt	YES		NO	
	Increase speed at 100 kt.		No excessive load at 100 kt	YES		NO	
			- Hydraulic collective switch : ON				
MAN	Reduce speed \leq 70 ki		HYDR goes out	YES		NO	
UFAC		f					
H							
RE							
R'S EVI							
DA		1					
TA N 4							

00

•

FLIGHT MANUAL EC120 B

eurocopter

•

SHEET No 5C	HELICOPTER EC 120 B	MAXIMUM CONTINUOUS POWER LEVEL FLIGHT			
TEST PHASES AND REQUIREMENTS		RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED		
ANTI-VIBRATOR ADJUS	TEMENT				
		(TBD)			
n onen onen en er strever (* 1		n alter al 1997 - Andre Steller, Steller and Andre Steller 1997 - Andre Steller, Steller and Andre Steller			
		<30 ki izurieza pi 0.6 o zbiza $11.1 \simeq 1.1$ jeje			
		e esteve			
			1.1.4 YO.4		
		STRUCTURE STRUCTURE			

SHEET No 6	HELICOPTER EC 120 B	MAXIMUM TAKEOFF POWER		
TEST PHASES A	ND REQUIMENTS	RESULTS TO BE OBTAINED / LIMITATIONS	RESULTS OBTAINED	
MAXIMUM TAKEOFF P t is recommended to perform $J_p > 5000$ ft to reach the en orque limit.	OWER n this check with gine limit rather than the	Record parameters : When IAS < 40 kt increase pitch to obtain FLI = 10. A FLI of 10 corresponds to a Ng of 101 % in the flight enveloppe of	Hp: OAT:	
		Zp < 14765' OAT > -20℃	Ng :	
All air bleeds shut-off		Audio warning when FLI > 10 for more than 1.5 s $(transient rating FLI < 10 s)$	T4 :	

8 - 24

SHEET No 7	HELICOPTER EC 120 B	PREFERENCE INJECTOR VALVE TESTING (AS SHEDULE BY THE ENGINE MANUFACTURER)		
TEST PHASES A	ND REQUIMENTS	RESULTS TO BE OBTAIN / LIMITATIONS	RESULTS OBTAINED	
BEFORE ENGINE STAR And after changing the setti accordance with the Aircraf Record the setting of the idl from the FLIGHT position.	TING ng of the idle stop (in t Maintenance Manual task). e stop on the fuel control unit	Fuel control unit setting = 25°	Setting	
ENGINE STARTING Comply with the normal pro SECTION 4.	ocedures of the Flight Manual	Engine oil temperature stabilized	Oil engine Temperature	
Reduce quickly the twist gr to the IDLE position (perfo	ip from the FLIGHT position rm a total of 3 tests).	The engine must not flame out	1 st test YES NO 2nd test YES NO 3rd test YES NO	
ENGINE SHUTDOWN				
Comply with the normal pr SECTION 4.	ocedures of the Flight Manual			

NOTE : Do not omit to re-adjust the pitch in accordance with the Aircraft Maintenance Manual task.


8.4 DAILY OPERATING CHECKS

The FLIGHT-RELATED and INSPECTION CHECKS (VLV) to be performed after the last flight of the previous day and before the first flight of the day and the EXTERIOR CHECKS before each flight must be performed, either by a suitably trained pilot referring to present Flight Manual or by a qualified mechanic complying with the Aircraft Maintenance Manual (MMA).

In the course of daily inspections, if any doubt or defect is noted, the pilot must report to the maintenance supervisor for the action to be taken. The defect acceptance criteria for defects on the items checked during the daily inspections are listed in the Aircraft Maintenance Manual.

If as a result of a daily inspection, a detailed inspection or a maintenance operation is required in order to make the aircraft flight worthy, this must be performed under the responsibility of a qualified aircraft maintenance specialist, and must be recorded in the aircraft documents.

8.3.3 INSPECTION ASSOCIATED WITH THE FLIGHTS OF THE DAY : FLIGHT-RELATED CHECKS (VLV)

• GENERAL

This inspection is to be performed once at the end of a day of flying or before a new day of flying.

The inspection associated with the flights of the day is intended to maintain the aircraft in a flight worthy condition for a new day of flying. It consists in performing a visual or tactile inspection of the condition of a component, or an assembly, without the use of special techniques or tooling, in order to detect any defects which could be detrimental to its correct operation



MANUFACTURER'S DATA REVISION 5 FLIGHT MANUAL EC120 B



NOTE 1

Pay particular attention to those operations identified by an asterisk (*).

NOTE 2

In the event that the FLIGHT-RELATED CHECKS are performed by the pilot immediately before a new day of flying, it replaces the EXTERIOR CHECK to be performed prior to each flight.

NOTE 3

After a grounding lasting in excess of one week :

- Perform an inspection associated with the flights of the day before resuming flying.
- Wipe the servo piston rods with a cloth impregnated with hydraulic operating fluid before moving the flight controls.



• FLIGHT RELATED CHECKS

Remove picketing equipment if necessary, or install it if the inspection is performed after the last flight of the day.



Figure 8-3 : Sequence of checks

POSITION 1

_

Transparent panels	condition, cleanliness, clean if necessary
Door pillars, canopy arches	condition.
Pitot pressure point (pilot)	blank removed or fitted as applicable.
Sideslip indicator paddle	condition
Air intake	blank removed or fitted (clear of snow or foreign objects)



POSITION 2

•	Cabin access doors	condition,	attachment points,
		locking.	

- Static pressure portblanking removed or installed (as applicable).
- Landing gearcondition.
- LH side engine-MGB cowlingopening, condition of locking devices.
- MGBoil level.
- Hydraulic compact unitoil level, attachment points, pipes, clogging indicator retracted.
- Servos <u>and</u> hydraulic systemattachment points, absence of leaks, pipes.
- MGB suspension bars.....condition, attachment points.

ENGINE AND ENGINE BAY

- Plenum chambercondition, attachment points.
- Engine and accessoriesgeneral condition, absence of leaks, cleanliness, pipes.
- Engine casing.....condition around bossings.
- Oil filterpre-clogging indicator retracted.
- Fuel filterclogging indicator retracted.
- Engine.....oil level.
- Oil systemabsence of leaks.
- Engine controlscondition, absence of interference points.
- Engine mountscondition, attachment points.
- Cowling upper acess panel closed and locked.





- Transmission and engine	
deck	condition, cleanliness, absence
	of leaks.
- Ports and drains in	
transmission deck	unobstructed.
- Exhaust pipe	condition, blanking cover removed or installed.
- LH engine-MGB cowling	closed and locked.
- MAIN ROTOR HUB	attachment points, general condition of all components.
- Laminated spherical thrust	
bearings (elastomeric part)	condition, absence of cracks.
- Bonding braids	condition.
- Reciprocal ring contact	
surfaces	condition, greased.
- Blade droop restrainers	condition.
- Frequency adaptater	17
(elastomeric part)	condition of elastomer.
- Frequency adaptater ball ends	condition, attachment point.
- Pitch change rods	condition, absence of end play.
- Swashplate	condition.
- Rotating and stationary	
scissors	condition.
- Swashplate guide	condition.
- Anti-vibration system	condition, attachment points.
- Dome	condition, attachment points.
- MAIN ROTOR BLADES	attachment points, general condition, check for de-bonding at the leading edge, impact damage or erosion.
- Cargo bay	opened.
- Battery	condition, attachment points.
- Cargo bay	. Check for snow in the tail boom – Closed.





POSITION 3

-	Horizontal stabiliser, fin, rotor tunnel, tail skid	condition, attachment points, condition of navigation lights.
-	TRH, hub body and fairing	condition, absence of impact or cracks, no rotation of fairing, paint marks, clearance between blade tips and rotor tunnel.
-	Tail rotor blades, visible part	condition, absence of scores, erosion. Check for abnormal gap at the blades.
-	Tail boom	condition, condition of antennas.

POSITION 4

- TGBoil level.
- Stator.....condition.
- Tail rotor blades.....condition.
- Horizontal stabiliser, fin, rotor tunnel, tail skid.....condition, attachment points, condition of navigation lights.
- Tail boom.....condition, condition of antennas.





POSITION 5

- Static pressure pointblank removed or installed (as applicable).
- RH cargo bay door opening, attachment points, condition.
- Electrical master box circuit-breakers.....engaged.
- RH cargo bay door closing, locking.
- Ground power plug access panel.....closed.
- RH engine-MGB cowling opening, condition of locking systems.
- Fan and cooling radiator condition, cleanliness, absence of leaks.
- Engine air intake and transmission deck cleanliness, absence of foreign bodies.
- Servos and hydraulic system......attachment points, absence of leaks, pipes.
- RH engine-MGB cowling closing, correct locking.
- Landing gear.....condition.
- Lower central cowling closed.
- MAIN ROTOR BLADES attachment points, general condition, absence of bonding separation on the leading edge, absence of impact damage or erosion.
- Cabin access door condition, attachment, locking.

CABIN INTERIOR

- Seats condition, attachment points.
- Cabin general cleanliness.



MANUFACTURER'S DATA REVISION 5 8 - 31



8.3.4 OPERATION OF OPTIONAL INSTALLATIONS

The daily commissioning of each optional installation fitted to the aircraft requires :

- an inspection before the first flight of the day,
- an inspection after the last flight of the day.

These inspections consist in performing a visual examination of each optional installation, to check their general condition and their attachment points to the aircraft, in particular :

- windscreen wipers,
- fire extinguishers,
- ski landing-gear installations,
- emergency equipment,
- emergency flotation equipment,
- cargo sling,
- sand filters.

Optional installations requiring special inspection are listed below.

• EMERGENCY FLOTATION EQUIPMENT

Inspection before the first flight of the day :

- Lower the emergency flotation equipment, pins locked, locking pin installed.
- Check that the circuit breakers located in the cockpit and in the right hand cargo bay, are engaged.

Inspection after the last flight of the day : In the event of low level flight over the sea, wash down the landing gear arch assemblies.



MANUFACTURER'S DATA REVISION 5



• AGRICULTURAL SPRAYING INSTALLATION

This optional installation requires the presence of qualified personnel to perform the daily commissioning inspections.

- CARGO SLING
 - After the last flight of the day, lightly grease (G354) the end of the load hook at the bolt attachment point.

8.3.5 COMMISSIONING IN COLD WEATHER CONDITIONS

NOTE

Use of 3 cSt synthetic oil is recommended for low temperature operation.

- OPERATION IN SNOW
 - Clean the helicopter before takeoff ; blades, rotor head, windshield ...
 - Do not stay in HIGE with snow recirculation.
 - Replace the turnaround check by a complete exterior check





FLIGHT MANUAL EC 120 B SUPPLEMENT

LIST OF SUPPLEMENTS AND OPTIONALS INCOMPATIBILITY OF UTILIZATION EFFECT ON PERFORMANCE DATA



IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR SUPPLEMENTS LISTED IN SECTION 9 - 0. THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT SHALL BE CARRIED IN AIRCRAFT AT ALL TIMES.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED REVISION 2 : NOVEMBER 1998 9 - 0 - TITLE





LIST OF APPLICABLE CONDITIONAL REVISIONS (RC) PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following pink pages except those canceled when the conditions are complied with.

CAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

No	PAGE	DATE	APPLICABLE BEFORE CONDITION IS MET:			
RC 1	9-14-4	NOV. 00	SB N°32-001 (Skid blades landing gear)and MOD. N° A00075 (installation of tail skid)			
RC 2	9-4-1	AUG. 01	SB N°04.003 (Cold weather installation kit)			



LIST OF APPLICABLE CONDITIONAL REVISIONS (RC) PAGES (CONT'D)

No	PAGE	DATE	APPLICABLE BEFORE CONDITION IS MET:			
•						

DGAC APPROVED REVISION 3

9 - 0 - A2





LIST OF CONDITIONAL REVISIONS (CR) EFFECTIVE PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following pink pages except those canceled when the conditions are complied with.

CAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

No	PAGE	DATE	REMARKS / EFFECTIVITY		
			· · · · · · · · · · · · · · · · · · ·		
а. С					





DGAC APPROVED ORIGINAL ISSUE



LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) EFFECTIVE PAGES

The manual contains the following additional yellow pages.

No	PAGE	DATE	No	PAGE	DATE
				· · · · ·	
			-		
1.1					

9 - 0 - B





LIST OF VALID CONDITIONAL REVISIONS (RC) PAGES

This manual assigned to the helicopter mentioned on the title page, contains the following conditional revisions printed on pink pages after the last indicated date.

EAUTION

If a normal revision (NR) modifies the page number for any information concerned below, the reader will have to change the number of the pink page by hand, so that the information remains in accordance with the paragraph concerned.

DATE	NAME	NAME SB Nº		Embodiment of SB		VICA	
DAIL	INAME		Yes	No	RC N°	VISA	
		32-001 and A 00075			RC 1		



REVISION 3



LIST OF VALID CONDITIONAL REVISIONS (RC) PAGES (CONT'D)



r	DATE	NAME	SB N°	Embodiment of SB	VALID	VISA
				Yes No	RC Nº	VIDIC



REVISION 5





LIST OF INTERMEDIATE TEMPORARY REVISIONS (ITR) EFFECTIVE PAGES

The manual contains the following additional yellow pages.

No	PAGE	DATE	No	PAGE	DATE
					}
			1		
ł					



DGAC APPROVED REVISION 3



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
0.0.Title	2		,		
9-0-A1	5				
9-0-A1	3				
9-0-62	2			ŀ	
9-0-0	6				
9-0-E	6				
9-0-F	0				
2-0-1	Ŭ				
9-0-i	6				
9-0-ii	Õ				
<i>×</i> • n	, i i i i i i i i i i i i i i i i i i i	1			
9-0-1	0				
9-0-2	Ň				
	Ŭ				



DGAC APPROVED REVISION 6

÷

.



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL	0	APRIL 1998
REVISION	1	JULY 1998
REVISION	2	NOVEMBER 1998
REVISION	3	SEPTEMBER 1999
REVISION	4	OCTOBER 2000
REVISION	5	AUGUST 2001
REVISION	6	NOVEMBER 2001



DATE: 21 NOV 2001

APPROVED BY : DGAC





DGAC APPROVED REVISION 6 9-0-E



CUSTOMIZATION

A/C : EC 120 - S/N :

SECTION	PAGE	ISSUE	SECTION	PAGE	ISSUE
THIS AIRC REQUIRIN	RAFT DOE: G THE CUS	S NOT OFFI TOMIZATIO GREEN	ER ANY PAR' ON ON THE F PAGES	TICULAR F LIGHT MA	EATURES NUAL ON



DGAC APPROVED ORIGINAL ISSUE

÷

.



LIST OF SUPPLEMENTS

Some supplements covering installations or procedures not used on this helicopter may be withdraw from this manual. The complete list of supplements appears on this page.

No	DESCRIPTION					
0	Operational and Optional Supplements					
1	Reserved					
2	Reserved					
3	Reserved					
4	Operation in cold weather (- $40^{\circ}C \le OA$	T ≤ - 30°C)				
5	Reserved					
6	Engine failure training procedure					
7	Hydraulic pressure failure training proc	edure				
11	Ski					
12	External Load Transport : Cargo Sling					
13	LH Side Main Flight Controls					
14	Sand Filter					
15	Reserved					
16	Reserved					
17	Emergency Floatation Gear					
18	Electrical Hoist	(not available)				
19	Air Conditioning System					
20	Swiveling Landing Light Installation	(not available)				



DGAC APPROVED REVISION 6 FLIGHT MANUAL EC120 B



SPECIAL SUPPLEMENTS

No	DESCRIPTION					
50	Auxiliary Fuel Tank Operational	(not available)				
51	Agricultural Spraying System	(not available)				
52	Gyrostabilized Installation for Camera	(not available)				
53	Night Vision Goggles	(not available)				
54	Reserved					
55	G.P.S					



.

.



1 INCOMPATIBILITY OF UTILIZATION BETWEEN OPTIONAL EQUIPMENT ITEMS

(none)



DGAC APPROVED ORIGINAL ISSUE FLIGHT MANUAL EC120 B



2 INFLUENCE OF OPTIONAL EQUIPMENT ON PERFORMANCE DATA

(none)



DGAC APPROVED ORIGINAL ISSUE



LH Bubble Window EC|20 B

Rotorcraft FM Supplement No: 682

Eurocopter EC120 B

Rotorcraft Flight Manual Supplement No: 682 Issue 1

For

Installation of Left Hand Bubble Window

on

1058

1076

C-GRTN C-GRTA

This supplement must be attached to the DGAC Approved Rotorcraft Flight Manual, with the installation of LH Bubble window in accordance with Outback Aviation Drawing No: 1480 Issue 1, or later DOT/DAR approved revision, per P-LSH01- /D.

The information contained herein supersedes and supplements the information of the basic Rotorcraft Flight Manual; compliance with SECTION 1 - Limitations - is mandatory. For limitations, procedures and performance information not contained in this supplement, consult the basic Rotorcraft Flight Manual.

DOT Approved:					
TT TT	H W Wong Aircraft Certification Engineer Pacific Region				
Dated:					

Arctic Sunwest Charters Yellowknife, NWT

LH Bubble Window EC120 B

Rotorcraft FM Supplement No: 682

Log of Amendments

Installation of LH Bubble Window

Issue	Date	Signature	Effective	DOT approval
No:	Inserted		Pages	by/Date
1	23 Jan. 2001	کی کے بیٹر کا لیے اور جن ہے جن میں انداز کا ایک ہے کے ایک کے ایک کے ایک کے	٨١١	

DOT Approved: Dated: _____



Arctic Sunwest Charters Yellowknife, NWT LH Bubble Window EC120 B

Rotorcraft FM Supplement No: 682

SECTION 1 - GENERAL

The Eurocopter EC120 B rotorcraft may be fitted with a bubble window in the left hand crew door for vertical reference operations. The bubble window is approx 14 inches deep and replaces the original window.

Arctic Sunwest Charters Yellowknife, NWT

LH Bubble Window EC120 B

Rotorcraft FM Supplement No: 682

SECTION 2 - LIMITATIONS

The limitations laid down in the basic Flight Manual remain applicable but are amended by the following limitations with the Bubble window fitted.

2.1 GENERAL

2.1.1 Types of operation Day VFR only

2.3 FLIGHT ENVELOPE LIMITATIONS

2.3.1 Airspeed limitations Doors closed

Vne 110 KIAS

2.6 PLACARDS

Adjacent Airspeed Indicator:

V_{ne} with bubble door 110 KIAS

SECTION 3 - EMERGENCY PROCEDURES

NO CHANGE

SECTION 4 - NORMAL PROCEDURE

4.1 GENERAL

4.1.1 OPERATING LIMITATIONS Refer to SECTION 2

4.2 **PREFLIGHT CHECK**

4.2.1 EXTERIOR CHECK Add to station 2 Check bubble window for condition and security

SECTION 5-PERFORMANCE

Performance evaluation has not been carried out. However it remains the pilots responsibility to ensure that adequate performance is available prior to executing all maneuvers.

Use of the LH bubble Window result in the following degradation in performance;

Rate of climb no change

an increase up to 4% in torque

DOT	Approved:
Datec	l:

cruise



FLIGHT MANUAL EC 120 B SUPPLEMENT

OPERATION IN COLD WEATHER (-40°C ≤ OAT < - 30°C)

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9-0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : AUGUST 2001 9 · 4 - TITLE



PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
9-4-Title	0				
9-4-A 9-4-B	0				
9-4-1	0				
9-4-2 9-4-3	0				





DGAC APPROVED ORIGINAL ISSUE 9 - 4 - A

FLIGHT MANUAL EC120 B



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL ISSUE

0 AUGUST 2001

ORIGINAL ISSUE

APPROVED BY : DGAC

DATE: 03 AOUT 2001



DGAC APPROVED ORIGINAL ISSUE

9 - 4 - B



RC 2

FLIGHT MANUAL EC120 B

Replace the paragraph 2 by the following:

2 LIMITATIONS Flight is forbidden if the OAT is below - 30°C.

CAUTION THIS PAGE MUST NOT BE REMOVED FROM THE FLIGHT MANUAL UNTIL MODIFICATION SB Nº 04.003. HAS BEEN EMBODIED TO THE AIRCRAFT.

DGAC APPROVED AUGUST 01



1 GENERAL

This supplement specifies the operating envelope of the aircraft for: $-40^{\circ}C \le OAT < -30^{\circ}C$

2 LIMITATIONS

The limitations specified in the basic flight manual and in the flight manual supplements remain applicable (SEE SECTION 2) and are supplemented or modified by the following procedures:

- 2.1 VNE
 - Reduce VNE power on by 5 kt for OAT \leq 35°C

2.2	APPRO)VED	FUELS
-----	-------	------	--------------

- MAIN FUELS

USE FOR: $-40^{\circ}C \le OAT \le +50^{\circ}C$						
T	Specifications				Anti-ice	
Type of fuel	code	FRANCE	USA	UK	additive included	
Kerosene - 50 (AVTUR-FSII) (JP8)	F 34	AIR 3405 F 34	MIL-T-83133 (JP8)	D.ENG. RD 2453	Yes	
Kerosene - 50 (AVTUR) (JP1)	F 35	AIR 3405 F 35	ASTM-D-1655 JET A1	D.ENG.RD 2494	No	
Kerosene			ASTM-D-1655 JET A	0.150	No	

REPLACEMENT FUELS

USE FOR: - $40^{\circ}C \le OAT \le + 30^{\circ}C$ AND FOR Hp ≤ 9842 ft (3000 m)						
-	NATO		2	Anti-ice		
1 ype of fuel	code	FRANCE	USA	UK	additive included	
Wide cut (AVTAG FSII) (JP 4)	F 40	AIR 3407	MIL-T-5624 (JP4)	D.ENG.RD 2454	Yes	
Wide cut	-	-	ASTM-D-1655 JET B	-	no	

Anti-ice additive is mandatory for $OAT \le + 0^{\circ}C$.

DGAC APPROVED ORIGINAL ISSUE FLIGHT MANUAL EC120 B



2.3 APPROVED LUBRICANTS - ENGINE LUBRICANTS

USE FOR: - 40°C ≤ OAT ≤ + 30°C							
Oil type	NATO	Specifications					
	Code	FRANCE	USA	UK	Approved oil grades		
Synthétic 3 to 3,5 cSt at 98,9°C	0.148	AIR 3513	MIL-L-7808	-	ESSO TURBO OIL 2389 MOBIL OIL AVREX 256 TURBONYCOIL 160		
	0.150	AIR 3514	-	· •	TOTAL AERO TURBINE 312 ELF JET SYNTHETIC OIL 15 TURBONYCOIL 13 B		

- MAIN GEARBOX LUBRICANTS

USE FOR: - 40°C ≤ OAT ≤ + 0°C							
Oil type	NATO Code	Specifications					
		FRANCE	USA	UK	Approved on grades		
Synthétic 3 to 3,5 cSt at 98,9°C	0.148	AIR 3513	MIL-L-7808	-	ESSO TURBO OIL 2389 MOBIL OIL AVREX 256 TURBONYCOIL 160		
	0.150	AIR 3514	-	-	ELF JET SYNTHETIC OIL 15 TOTAL AERO TURBINE 312 TURBONYCOIL 13 B		

- TAIL GEARBOX LUBRICANTS Same as MGB.

1





3 EMERGENCY PROCEDURES

Procedure provided in the basic flight manual and in the flight manual supplements remain applicable and are supplemented by the following:

WARNING PANEL	CORRECTIVE ACTIONS
HYDR	<u>Approach :</u> - Perform a shallow approach, reduce speed gradually. Landing :
Hydraulic pressure < 20 bar	 Carry out a running landing at ground speed below 20 kt. On ground, reduce the twist-grip to IDLE. Lock the collective pitch when NR ≈ 260 rpm.

4 NORMAL PROCEDURES

The procedure specified in the basic flight manual and in the flight manual supplements remain applicable and are supplemented by the following:

- Disregard the possible illumination of FILT during the engine starting as long as engine oil has not reached the minimum temperature (0°C) for power input.

5 PERFORMANCE

Performance specified in the basic flight manual and in the flight manual supplements remain applicable.

- Read charts until 40°C.
- Use of the battery for starting:

OAT (°C)	- 40	- 30
Start-up on cold, charged battery.		
Start-up on warm (20°C), charged battery.		





FLIGHT MANUAL EC 120 B SUPPLEMENT

ENGINE FAILURE

TRAINING PROCEDURE



IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE: NOVEMBER 2001 9 - 6 - TITLE


LIST OF APPROVED EFFECTIVE PAGES

	PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
	9-6-Title 9-6-A 9-6-B	0 0 0				
	9-6-1 9-6-2	0 0				
-						



DGAC APPROVED ORIGINAL ISSUE



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL 0 NOVEMBER 2001

ORIGINAL ISSUE

DATE: 21 NOV 2001

APPROVED BY : DGAC





DGAC APPROVED ORIGINAL ISSUE





1 GENERAL

This procedure allows training for autorotation landing with a simulated engine flame-out or loss of power.

In case of engine sudden loss of power or flame-out, the helicopter will yaw to the right, the NR will drop down and the low NR warning sound will come on if NR goes below 370 RPM.

2 LIMITATIONS

The limitations specified in the basic flight manual and in the flight manual supplements remain applicable.

3 EMERGENCY PROCEDURES

The emergency procedures specified in the basic flight manual and in the flight manual supplements remain applicable.

4 NORMAL TRAINING PROCEDURES

4.1 Failure simulation

1. Collective pitchLo	WER to enter autorotation
-----------------------	---------------------------

- 2. NR MAINTAIN within the green range
- 3. Twist grip REDUCE to IDLE position
 - . red TWT GRP warning light lights

. engine is set to idle, $Ng \cong 67\%$

then:

4.2 Full touchdown autorotation training procedure

1. Autorotation procedure.......APPLY See SECTION 3 paragraph 3.2 page 3.2 of the present flight manual except for twist grip shut-off.

After landing :

- 2. Collective pitchDOWN to full low pitch
- 3. Twist grip INCREASE to FLIGHT position
 - . red TWT GRP warning light extinguishes,
 - . rotor speed accelerates to its normal governed value.





DGAC APPROVED ORIGINAL ISSUE 9-6-1



4.3	Power recovery autorotation training procedure									
	1. Collective pitch REDUCE, maintain NR in green range.									
	2. IAS Vy									
	3. Maneuver the aircraft into the wind on final approach.									
	• At height ≈ 70 ft									
	4. NR CHECK in green arc									
	5. Twist grip INCREASE to FLIGHT position . red TWT GRP light extinguishes, 									
	6. Collective pitch INCREASE slightly to maintain NR									
	7. Cyclic									
	• At 20 - 25 ft and at constant attitude									
	8. Collective pitch GRADUALLY INCREASE									
	to reduce the rate of descent and									
	forward speed.									
	9. Cyclic FORWARD slightly									
	to adopt a landing attitude.									
	10. Pedal ADJUST									
	to cancel any side-slip tendency.									
	11 Collective pitch INCREASE as necessary.									

NOTE

If necessary, it is possible to quickly switch back to the FLIGHT position of the twist grip at any time and for any NR value. However, it is better if the NR value is in the green range.

Autorotation training shall be conducted within gliding distance of a running landing suitable area.

5 PERFORMANCE

The performances specified in the Basic Flight Manual and in the flight manual supplements remain applicable.

DGAC APPROVED ORIGINAL ISSUE



FLIGHT MANUAL EC 120 B SUPPLEMENT

HYDRAULIC PRESSURE FAILURE

TRAINING PROCEDURE



IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : NOVEMBER 2001

9 - 7 - TITLE



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
9-7-Title	0				
9-7 - A	0				
9-7-B	0				
9-7- 1	0				
9-7-2	0				
	· · ·				
				ļ	





LOG OF APPROVED NORMAL REVISIONS

ORIGINAL 0 NOVEMBER 2001



APPROVED BY : DGAC

DATE: 21 NOV 2001





DGAC APPROVED ORIGINAL ISSUE

9 - 7 - B



1. GENERAL

This procedure allows training for hydraulic pressure failure on EC 120 B.

In case of loss of hydraulic pressure : **Bottom** illuminates and the « gong » reach sounds, the hydraulic pressure accumulators allow sufficient time to rejoin the recommended speed of 65 Kt. Then, the pilot must cut-off the residual hydraulic pressure by means of the switch on the collective lever and apply the emergency procedure.

2. LIMITATIONS

The limitations specified in the basic flight manual and in the flight manual supplements remain applicable.

3. EMERGENCY PROCEDURES

The emergency procedures specified in the basic flight manual and in the flight manual supplements remain applicable.

4. NORMAL TRAINING PROCEDURES

4.1 FAILURE SIMULATION

In steady cruise flight, depressing the "HYDR." guarded pushbutton on the LACU produces the same effects as a real failure :

- •The hydraulic pump pressure is by-passed,
- The main rotor accumulators give hydraulic assistance for a limited time.



Figure 1 : Hydraulic failure simulation pushbutton.

DGAC APPROVED ORIGINAL ISSUE



4.2 TRAINING PROCEDURE

1. LACU "HYDR." guarded pushbutton (1) ... DEPRESS.

Comes on + "GONG" sounds.

2. Hydraulic failure procedure APPLY.

See FLM SECTION 3 (§ 3.7.3).

When HYD switch (2) on collective lever is in OFF position : 3. LACU "HYDR." pushbutton RESET.

When on ground, or at any moment to restore hydraulic assistance : 4. HYD switch (on collective lever)......ON.

HYDR goes out.

CAUTION

If the HYDR. guarded push button on the LACU is not reset no hydraulic assistance can be restored.

5. PERFORMANCE

The performance given in the Basic Flight Manual and in the flight manual supplements remain applicable.



FLIGHT MANUAL EC 120 B SUPPLEMENT

EXTERNAL LOAD TRANSPORT " CARGO SLING "

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED REVISION 1 : JANUARY 1999 9 - 12 - TITLE



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV	REMARKS	PAGE	REV	REMARKS
	No			No	
9-12-Title	1				
9-12-A	3				
9-12-B	3				
9-12-1	- 0				
9-12-2	3				
9-12-3	2			1. A	
9-12-4	0		ļ]
9-12-5	0				
9-12-6	0			- A.	
9-12-7	0				
9-12-8	2				
9-12-9	2				
9-12-10	3]
9-12-11	3				
]				
					'
	1				
	1				
			1	}	
	1			1	



DGAC APPROVED REVISION 3



LOG OF APPROVED NORMAL REVISIONS

- ORIGINAL 0 JULY 1998
- REVISION 1 JANUARY 1999
- REVISION 2 SEPTEMBER 1999
- REVISION 3 NOVEMBER 2001

NORMAL REVISION 3

DATE: 21 NOV 2001

APPROVED BY : DGAC



DGAC APPROVED REVISION 3



1 GENERAL

The "CARGO SLING" external load carrying installation is composed of :

- A cargo hook suspended by four cables, equipped with a release unit. The release unit hook can be opened electrically in normal operation and mechanically in emergency conditions.
- An underslung load weight value in the VEMD PERFORMANCE page (figure 1).

NOTE

When fitting the cargo-sling equipment, the VEMD has to be configured with the cargo-sling installed.

The "SLING LOAD" line in the VEMD PERFORMANCE page is valid only if the "SLING" pushbutton on the LACU is "ON".

For AUW over 1750 kg, the performances have to be checked manually with the HOGE charts figures 5 or 6.

F	PERFORM	ANCE	
E.E.W	0970 кд	1.55	
CREW	0080 Kg		
PAY LOAD	0020 кg	Zp	07170 Et
USABLE FUEL	100 Kg	OAT	+14 °C
SLING LOAD	390 кg	IGE	1655 кg
A.U.W	1560 ка	OGE	1578 кg

Figure 1 : Performance page

MV.EC120.0092.00

DGAC APPROVED ORIGINAL ISSUE



- A control system is provided for the pilot (figure 2) :
 - . a "SLING" pushbutton (1) located on the LACU, for switching on the installation,
 - . a normal release control (2) on the cyclic stick (electrical mode),
 - . an emergency release handle (3) located under the collective stick (mechanical mode).



Figure 2 : Cargo sling controls

NOTE

A minimum weight of 2.5 kg (6 lb) is required to open the hook.

- Electric circuits protection :

- . the load indicator is protected by a 3 A fuse,
- . the release circuit is protected by a 15 A fuse.

The fuses are located on the cargo breakers panel.



1

2

LIMITATIONS

All limitations specified in the basic flight manual and in the flight manual supplements remain applicable, independently of the following.

2.1 Weight limitation

- Maximum permissible sling load :700 kg (1543 lb).
- Maximum take-off weight with an



The maximum take-off weight without external load remains limited to that specified in the limitations section of the basic flight manual.

2.2 Longitudinal CG. limits

With an external load, the longitudinal limits are defined according to the weight as per the graph below.



Figure 3 : Longitudinal CG chart with external load



DGAC APPROVED REVISION 2



2.3 Airspeed limitation

- Absolute maximum permissible speed with external load :.....110 kt.

NOTE

The pilot is responsible for determining the limit speed according to the load and sling length. Particular care must be exercised when bulky loads are being carried on the sling.

2.4 Instruction placards

An instruction placard in the cockpit indicates :

CARRYING OF EXTERNAL LOADS

CLASS OF APROVED AIRCRAFT/LOAD COMBINATION : B. WHEN EXTERNAL LOADS ARE CARRIED, NO PERSON MAY BE CARRIED UNLESS : - HE IS A FLIGHT CREW MEMBER ; - HE IS A FLIGHT CREW MEMBER TRAINEE ; OR - HE PERFORMS AN ESSENTIAL FUNCTION IN CONNECTION WITH THE EXTERNAL-LOAD OPERATION.

OR

EMPORT DE CHARGES EXTERNES

CLASSE DE COMBINAISONS GIRAVION-CHARGE APPROUVEE : B AUCUNE PERSONNE NE PEUT ETRE TRANSPORTEE A MOINS DE :

- ETRE UN DES MEMBRES DE L'EQUIPAGE

- SUIVRE UN COURS DE FORMATION EN TANT QUE MEMBRE D'EQUIPAGE OU

- REMPLIR UNE FONCTION ESSENTIELLE AYANT TRAIT A L'UTILISATION DU GIRAVION AVEC CHARGE EXTERIEURE.

A placard visible to the ground operator and located on the lower fairing near to the hook, indicates the maximum sling load.



3

EMERGENCY PROCEDURES

The procedures provided in the basic flight manual and in flight manual supplements remain applicable and are supplemented by the following :

3.1 Engine failure with external load

- IN CRUISE FLIGHT

1. Autorotation procedure APPLY

2. External load Release as soon as possible.

- IN HOVER

NOTE

Except during hooking phase, the pilot should move away to the right. Ground personals are to be forewarned that in the event of engine failure they are to move away to the left of the helicopter.





3.2 Sling load indication failure on VEMD Sling load indication in yellow

- [Sling] pushbutton...... CHECKED ON



NOTE

With yellow sling load indication on VEMD the electrical release control may be not available.

4 NORMAL PROCEDURES

The procedure provided in the basic flight manual and flight manual supplements remain applicable and are supplemented by the following.

- Carrying heavy loads is a delicate operation, due to the possible effects of a swinging load on the flight behavior of the helicopter. Consequently, pilots are advised to train with gradually increased sling loads before undertaking heavy load carrying operations.

CAUTION

In wet weather, thick rubber gloves should be worn by the operator handling the hook and load. Release the charge of stactic electricity by placing an electrical conductor cable or tube between the ground and the cargo release unit (hook).



4.1 Ground check of the installation

-	interior check	
	. [SLING] pushbutton	CHECK ON
		on LACU
	. PERFORMANCE page	SELECT
	. SLING LOAD line	WHITE

NOTE

If the "SLING LOAD" line is missing, check the VEMD configuration.

-	EXTERIOR CHECK	
	. Electrical hook opening	CHECKED
	. Mechanical hook opening	CHECKED

4.2 Take off check and procedure with external load

CAUTION

Use of P2 air bleeds are forbidden above the maximum continuous rating (Ng or T4)

1. External load	.Secured.
2. Collective	.Increase very smoothly
	while maintening the
	aircraft directly above
	the load.
3. Cables tanted	.Dwell briefly before raising
	the load.
4. Lift off the load	.Vertically.
5. Load indication	checked.
6. Take-off path	.ADJUST to adopt an
	immediate forward climb
	attitude.
7. All parameters	Checked.



DGAC APPROVED ORIGINAL ISSUE



4.3 Manoeuvres

All control movements should be made very gently, with very gradual acceleration and deceleration, and only slightly banked turns.

4.4 Approach and landing with external load.

CAUTION

Use of P2 air bleeds are forbidden above the maximum continuous rating (Ng or T4)

- Perform approach at minimum rate of descent.
- Establish zero translational ground speed sufficiently hight to ensure that the load is not dragged along the ground.
- Then descent vertically until the load is on the ground.
- Release the load.
- Load released CHECKED

NOTE

If the load is not released, actuate the emergency release handle

5 **PERFORMANCE**

The performance given in the Basic Flight Manual and in flight manual supplements remain applicable and are supplemented as following :

The performance curves for weights in excess of 1715 kg (3780 lb) are plotted in dotted line on the following performance charts.











DGAC APPROVED REVISION 2 9 - 12 - 9





Figure 5 : HOGE with cargo-sling

DGAC APPROVED REVISION 3

9 - 12 - 10





Figure 6 : HOGE with sand filter and cargo-sling



DGAC APPROVED REVISION 3 9 - 12 - 11



FLIGHT MANUAL EC 120 B SUPPLEMENT

LH SIDE MAIN FLIGHT CONTROLS

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France



9 - 13 - TITLE

FLIGHT MANUAL



EC120 B

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
9-13-Title 9-13-A 9-13-B	0 0 0				
9-13-1 9-13-2	0				
443) 				92.3	1996 - 1997 - 1997 1997 - 1997 - 1997 1997 - 1997 - 1997 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997

LIST OF APPROVED EFFECTIVE PAGES

DGAC APPROVED ORIGINAL ISSUE 9 - 13 - A



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL 0 NOVEMBER 1998



APPROVED BY : DGAC

DATE: 27 NOV. 1998



9 - 13 - B

DGAC APPROVED ORIGINAL ISSUE





1 GENERAL

This optional equipment consists of moving the main flight controls from the RH station to the LH station. The following equipment is moved :

- Cyclic stick friction lock.

Collective lever low-pitch locking device when the aircraft is fitted with single controls (1)

Emergency release handle when the aircraft is fitted with the "SLING" optional equipment (2)



Figure 1 : LH side locking of the collective lever

FLIGHT MANUAL





2 LIMITATIONS

The limitations specified in the basic flight manual and in the flight manual supplements remain applicable.

3 EMERGENCY PROCEDURES

The emergency procedures specified in the basic flight manual and in the flight manual supplements remain applicable.

4 NORMAL PROCEDURES

The normal procedures specified in the basic flight manual and in the flight manual supplements remain applicable and are supplemented by the following procedures :

- When dual controls are fitted :

Interior checks

- RH side collective lever low-pitch locking deviceInstalled
- LH side collective lever low-pitch locking device......Removed

- When LH side single controls are fitted :

Interior checks

- RH side pedals protective device Installed
- LH side collective lever low-pitch locking device.....Installed

5

PERFORMANCE

The performances specified in the Basic Flight Manual and in the flight manual supplements remain applicable.

DGAC APPROVED ORIGINAL ISSUE



9 - 13 - 2



FLIGHT MANUAL EC 120 B SUPPLEMENT

SAND FILTER AEROFLO

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.



EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED REVISION 1 : JANUARY 1999 9 - 14 - TITLE



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV	REMARKS	PAGE	REV	REMARKS
	No			No	
9-14-Title			· ·		
9-14-A	-3				
9-14-B	3				
0 14 1					
9-14-1			1		
9-14-2	0				
9-14-3			1		
9-14-4	2				
9-14-5	2			1	
9-14-0	5			1	· · ·
			[
1					
	1				
	1				
					ļ



DGAC APPROVED REVISION 3 9 - 14 - A



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL	0	JUNE 1998	

- REVISION 1 JANUARY 1999
- REVISION 2 SEPTEMBER 1999
- REVISION 3 NOVEMBER 2001

NORMAL REVISION 3

DATE: 21 NOV 2001

APPROVED BY : DGAC





9 - 14 - B



1 G

GENERAL

The sand filter installation is intended to protect the engine from sand ingestion, during hovering flight or when flying in sand-laden atmosphere.

It operates permanently whenever it is fitted on the aircraft.

The installation consists essentially of :

- A structural sand filter support fitted in front of the engine air intake,
- A rectangular filtering panel fitted on structural support,
- A pressurised air (P2) supply system.

In operation, the ambient air passes through the VORTEX tubes of the filtering panel. The sand is centrifuged and is ejected out towards the rear of the aircraft, through a duct which is flushed by the P2 air system.

2 LIMITATIONS

The limitations provided in the basic flight manual and flight manual supplements remain applicable and are supplemented by :

CAUTION

The flight is forbidden if the filtering panel is not fitted on his support.



DGAC APPROVED ORIGINAL ISSUE 9 - 14 - 1



3 EMERGENCY PROCEDURES

The overall emergency procedures provided in the basic flight manual and flight manual supplements remain applicable.

4 NORMAL PROCEDURES

The normal procedures provided in the basic flight manual and flight manual supplements, remain applicable and are supplemented by :

-	Exterior checks :	
	MGB cowl (starboard side)	OPENED
	Rectangular filtering panel	fitted, clear of snow or ice
	MGB cowl	CLOSED

- Flight in Sand-laden Atmosphere : Switch off the heating-demisting system.

5 **PERFORMANCE**

The performance given in the basic flight manual and in flight manual supplements remain applicable and are supplemented by graphs hereafter.

NOTE

VEMD engine power check and hovering performances are automatically modified if the sand filter is fitted.





Figure 1 : Engine power check with sand filter



DGAC APPROVED ORIGINAL ISSUE 9 - 14 - 3





Figure 2 : Hover in ground effect with sand filter

DGAC APPROVED REVISION 3







Replace figure 2 by the following :



Figure 2 : HIGE with sand filter

CAUTION

THIS PAGE MUST NOT BE REMOVED FROM THE MANUAL UNTIL MODIFICATIONS N° A 00075 AND SB N° 32.001 HAVE BEEN EMBODIED TO THE AIRCRAFT.

9 - 14 - 4

DGAC APPROVED NOVEMBER 00


FLIGHT MANUAL EC120 B





DGAC APPROVED REVISION 3 9 - 14 - 5

FLIGHT MANUAL EC120 B







DGAC APPROVED REVISION 3

÷



FLIGHT MANUAL EC 120 B SUPPLEMENT

EMERGENCY FLOATATION GEAR AERAZUR



IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France



DGAC APPROVED ORIGINAL ISSUE : JULY 1998 9 - 17 - TITLE



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
9-17-Title 9-17-A 9-17-B	0 1 1		ADVEMBE		120130 D8]
9-17-1 9-17-2 9-17-3 9-17-4 9-17-5	1 1 1 1 1				
		53) 	~	1 201207 	n a suitsid L
				2023030 	



LOG OF APPROVED NORMAL REVISIONS

- ORIGINAL 0 JULY 1998
- REVISION 1 NOVEMBER 2001

NORMAL REVISION 1

APPROVED BY : DGAC

DATE : 21 NOV 2001





GENERAL

The emergency floatation gear is approved for emergency use (not for ditching according to JAR / FAR 27) i. e. to aid in keeping rotorcraft sufficiently upright and in adequate trim to permit safe and orderly evacuation in emergency water landing.

The installation allows the aircraft to be landed also with floatation bags inflated, on a runway or a hard prepared surface.

The emergency floatation equipment consists of :

a landing gear assembly fitted with :

- two floatation units mounted parallel along each skid of the aircraft (1) (1')
- a system for inflating the floats from a cylinder (2) with pressure indicator.
- an electrical control system with a [FLOAT] pushbutton to arm the system on the LACU (4).
- a firing pushbutton (3) mounted on the pilot's collective grip, protected by a switch guard.



Figure 1 : Emergency floatation equipment



MV.EC120.0057.00



2 LIMITATIONS

All limitations specified in the basic flight manual and flight manual supplements remain applicable, independently of the following.

- Floatation equipment stowed - system armed or floatation equipment inflated :

. maximum indicated airspeed : 120 kt.

- Maximum inflation altitude : 13200 ft (4000 m).
- Maximum permissible loss of altitude after inflation : 6600 ft (2000 m).

When flying at less than 400 ft (122 m) above water, the floatation equipment must always be armed.

- The limit values of pressure in the inflation cylinder, provided by the following table, are applicable if the flight requests the emergency floatation gear in order to be operated.

TEMPERATURE	°C	-45	-40	-30	-20	-10	0	10	20	30	40	50	60	70
- , , , , , , , , , , , , , , , , , , ,	°F	-49	-40	-22	-4	14	32	50	68	86	104	122	140	158
MAX. PRESSURE	BAR	170	174	181	188	195	202	209	216	223	230	237	244	251
	PSI	2466	2524	2625	2727	2828	2930	3031	3133	3234	3336	3437	3539	3640
MIN PRESSURE	BAR	154	157	164	171	178	185	192	199	206	213	220	227	234
	PSI	2234	2277	2378	2480	2582	2683	2785	2886	2988	3089	3191	3292	3394

NOTE

The placard located adjacent to the cylinder provides the limit values.



3 EMERGENCY PROCEDURES

The procedures provided in the basic flight manual and in the flight manual supplements remain applicable and are supplemented by the following :

- INFLATION PROCEDURE

In the event of engine failure or other urgent requirement to ditch, check the rotor speed then apply the following procedure :

- [FLOAT] pushbutton PRESSED IN, two lights on.
- Floatation equipment cartridge FIRED (recommended firing IAS :

below 80 kt - 148 km/hP).

NOTE

A deceleration with a pitch down movement can occur when firing the floatation equipment at a speed greater than 80 kt (148 km/h).

AUTORATION PROCEDURE OVER WATER WITH EMERGENCY FLOATATION GEAR

1. Collective pitchREDUCE

to maintain NR in green arc.

- 2. IASVy.
- If relighting impossible or after tail rotor failure.
- 3. Twist Grip...... SHUT OFF position.
- 4. Maneuver to head the aircraft equally between the wind and wave direction on final approach.
- At height \cong 70 ft
- 5. Cyclic......Flare.
- At 20-25 ft at constant attitude
- 6. Collective pitch GRADUALLY INCREASE

.. GRADUALLY INCREASE to reduce the rate of descent and forward speed.

DGAC APPROVED REVISION 1

FLIGHT MANUAL EC120 B



7. Cyclic	FORWARD slightly to adopt ditching attitude of 10° nose-up and a forward speed less
	than 10kt on touch-down
8. Pedal	ADJUST
	to cancel any side-slip tendency.
9. Collective pitch	INCREASE
• •	to cushion touch down with
	minimum speed.

• <u>After touch-down</u>	
10.Collective pitch	Gradually decrease to fully down.
11.Rotor brake	APPLY.
12.Evacuate aircraft once the rotor ha	as stopped.

NOTE

Inflation of the emergency floatation bags reduces the rotor speed in autorotation by 10 rpm.

4 NORMAL PROCEDURE

The procedures provided in the basic flight manual and flight manual supplements remain applicable and are supplemented by the following :

- External checks :
 - Floatation unitslocked in the lowered position.
 - Protective covercheck condition.
 - Pressure in the inflation cylinder.....checked.
- Interior check
 - Arming of the emergency floatation equipment :
 - * [FLOAT] pushbutton.....PRESSED IN (2 lights ON).
 - Disarming the emergency floatation equipment
 - * [FLOAT] pushbutton.....PRESSED OUT (2 lights OFF).



FLIGHT MANUAL EC120 B

5 PERFORMANCE

When the floatation equipment is stowed, only the climb performance provided in section 5 is affected :

- the rate of climb must be reduced by 11%.



DGAC APPROVED REVISION 1 9 - 17 - 5



FLIGHT MANUAL EC 120 B SUPPLEMENT

AIR CONDITIONING SYSTEM

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : NOVEMBER 1998 9 - 19 - TITLE



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV	REMARKS	PAGE	REV	REMARKS
	No			No	
	•				
9-19-Title	0	}			
9-19 - A	1				
9-19-B	1	}			
9-19-1	0				
9-19-2	1				[
9-19-3	0				
9-19-4	0				}
9-19-5	0				
				1	
			1		
				1	
			[
					1 · · · ·
			1 · · ·		
				1	
		ļ			



· • •

DGAC APPROVED REVISION 1



LOG OF APPROVED NORMAL REVISIONS

- ORIGINAL 0 NOVEMBER 1998
- **REVISION** 1 NOVEMBER 2001

NORMAL REVISION 1

DATE : 21 NOV 2001

APPROVED BY : DGAC



DGAC APPROVED REVISION 1

9 - 19 - B



1 GENERAL

1.1 Description of the System

The purpose of the system is to maintain a comfortable temperature in the cabin. It is composed of:

. A compressor which is mechanically driven by a belt from the MGB output driving the engine oil cooler fan.

- . A condenser located between the MGB fan and the engine oil cooler.
- . A cabin fan.
- . An evaporator.
- . An air supply system only operating for cabin air recirculation.

The cabin outlet nozzles are identical to those of the basic aircraft.

- . A control unit located on the console comprising:
 - a three-position selector (1)
 - a fan speed adjustment potentiometer (2).



Figure 1 : Air Conditioning Control Unit





. An electrical supply and monitoring system. The cabin fan is switched on automatically when the heating system is on. A "P2 TEMP" amber light on the warning panel indicates that the maximum temperature has been reached in the cabin ventilation duct.

1.2 Air production

With the air conditioning option, cold and hot air production uses an internal air recirculation system. The air is no longer taken in from the outside, it is taken from the interior of the cabin at the rear RH side of the distribution duct. This air flows through the fan and then the evaporator where it is cooled, finally flowing through the P2 diffuser where it can be mixed with the hot air. This air then flows through the cabin roof to reach the cabin distribution duct. The air distribution in the cabin has not changed with regard to the basic version.

2 LIMITATIONS

The limitations provided in the basic flight manual and flight manual supplements remain applicable and are supplemented by the following limitations :



3

EMERGENCY PROCEDURES

The emergency procedures given in the basic flight manual and flight manual supplements remain applicable and are supplemented by the following procedures.

3.1 Ventilation System Failure

If the ventilation system does not operate (no air distribution via outlet nozzles), set the selector to the OFF position.

3.2 Air Conditioning System Failure

If the air conditioning system does not operate (no fresh air distribution via outlet nozzles), set the selector to OFF or FAN position.

3.3 Heating/Cabin Ventilation Failure





DGAC APPROVED ORIGINAL ISSUE



4 NORMAL PROCEDURES

The normal procedures provided in the basic flight manual and flight manual supplements, remain applicable and are supplemented by the following procedures :

4.1 Prestart Check

- Heating cockOPEN
- Cabin fanAutomatically ACTIVATED
- Heating cockCLOSE

4.2 Switching on and Switching off the System

Set the selector to the - FAN position to obtain cabin ventilation

- A/C position to obtain air conditioning.
- OFF position to switch off the system.

Use the potentiometer to adjust the air flow distributed in the cabin.

4.3 Heating System Operation

Open the cock located in the ceiling.

The "P2" open information is displayed on the VEMD screen. The air distribution fan is automatically activated at its maximum flow rate even if the air conditioning selector is set to OFF position.

Close the ceiling cock to stop heating ; this will also switch off the fan if the air conditioning selector is set to OFF position.

5 **PERFORMANCE**

The performances given in the basic flight manual and in flight manual supplements remain applicable and are supplemented by the following procedures when the air conditioning is in operation.

5.1 Hover Flight

When the air conditioning system is in operation, the pilot must reduce the hover performances given in SECTION 5 of the basic flight manual by 20 kg.





NOTE

The operation of the air conditioning system is not taken into account by the VEMD. When the air conditioning system is in operation, the pilot must reduce by 20 kg the performances calculated by the VEMD.

5.2 Climb

Performances in climb given in SECTION 5 of the basic flight manual are reduced by 20 ft/min.

5.3 Engine Power Check

The operation of the air conditioning system does not affect the engine power check given in the basic flight manual.





FLIGHT MANUAL EC 120 B SUPPLEMENT

GPS TRIMBLE TNL 1000 DC



THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR APPLICABLE FLIGHT MANUAL SUPPLEMENTS. THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : APRIL 1998 9 - 55 - TITLE

eurocopter

FLIGHT MANUAL EC120 B

LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
9-55-Title	0				
9-55-A	0				
9-55-B	0				
9-55-1	0				
9-55-2	0				
	1				
		1.1			
				· .	
1 .				-	1
	1		11	1	1





1 GENERAL

The TRIMBLE 1000 DC Global Positioning System complies with AC 20-138 requirements for use in day VFR conditions in sight of the ground or water.

2 LIMITATIONS

The limitations in the basic flight manual and flight manual supplements remain applicable and are supplemented or modified by the following limitations.

A placard located within pilot's sight field indicates :

GPS OPERABLE IN DAY VFR CONDITIONS IN SIGHT OF GROUND OR WATER ONLY GPS UTILISABLE EN VFR DE JOUR EN VUE DU SOL OU DE L'EAU UNIQUEMENT

- Use of the GPS is prohibited in approach mode.

3 EMERGENCY PROCEDURES

The emergency procedures in the basic flight manual and flight manual supplements remain applicable.

NOTE

Press the MSG key on the CDU to display the situation of the GPS and to scroll through next messages if any.

DGAC APPROVED ORIGINAL ISSUE EC120 B



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL 0 APRIL 1998



APPROVED BY : DGAC

DATE : - 1 AVR. 1998





9 - 55 - B

FLIGHT MANUAL

EC120 B



4 NORMAL PROCEDURE

The normal procedures in the basic flight manual and flight manual supplements in use remain applicable, and are supplemented by the following normal procedures :

4.1 BEFORE STARTING

- The PILOT GUIDE operating manual (reference : 80455-0612) must be up-to-date and kept on-board the aircraft.
- The crew must check the validity and accuracy of the data base (28 day validity) relative to the official documentation.
- Before the start of navigation, check that all the data is valid by reading the messages on the CDU.

NOTE

During the « en route » phase, the integrity of the position supplied by the GPS is not ensured. Consequently it is the responsibility of the crew to check the accuracy of the position every 15 minutes using either conventional VFR method or other navigation equipment if available.

Transmissions from the helicopter, via transmitters KX165 and KY196 can lead to momentary losses of GPS reception at the following frequencies:

121.150 MHz, 121.175 Mhz, 121.250 Mhz, 131.275 MHz.

Navigation calculation becomes nominal 2 to 3 seconds after the end of transmission.



5 STATUTORY PERFORMANCE

The statutory performance in the basic flight manual and flight manual supplements remains applicable.





FLIGHT MANUAL EC 120 B SUPPLEMENT

GPS TNL 2000 APPROACH PLUS

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR FLIGHT MANUAL SUPPLEMENTS LISTED IN SUPPLEMENT 9 - 0.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : JUNE 1999 9 - 55B - TITLE



FLIGHT MANUAL EC120 B

LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV	REMARKS	PAGE	REV	REMARKS
	No			No	
0.550 504	0				
9-55B - Title	0				
9-33B - A	0				
9-338 - В	U				
9-55B - 1	0				
9-55B - 2	Õ				
l					
1					





DGAC APPROVED ORIGINAL ISSUE



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL 0 JUNE 1999

ORIGINAL ISSUE

DATE :

0.2 JUIN 1995

APPROVED BY : DGAC





DGAC APPROVED ORIGINAL ISSUE



1 GENERAL

The TRIMBLE 1000 DC Global Positioning System complies with AC 20-138 requirements for use in day VFR conditions in sight of the ground or water.

2 LIMITATIONS

The limitations in the basic flight manual and flight manual supplements remain applicable and are supplemented or modified by the following limitations.

A placard located within pilot's sight field indicates :

GPS OPERABLE IN DAY VFR CONDITIONS IN SIGHT OF GROUND OR WATER ONLY GPS UTILISABLE EN VFR DE JOUR EN VUE DU SOL OU DE L'EAU UNIQUEMENT

Use of the GPS is prohibited in approach mode.

3 EMERGENCY PROCEDURES

The emergency procedures in the basic flight manual and flight manual supplements remain applicable.

NOTE

Press the MSG key on the CDU to display the situation of the GPS and to scroll through next messages if any.

4 NORMAL PROCEDURE

The normal procedures in the basic flight manual and flight manual supplements in use remain applicable, and are supplemented or modified by the following normal procedures :

4.1 BEFORE STARTING

- The PILOT GUIDE operating manual (reference : 82877) must be upto-date and kept on-board the aircraft.
- The crew must check the validity and accuracy of the data base (28 days validity) relative to the official documentation.
- Before the start of navigation, check that all the data is valid by reading the messages on the CDU.

NOTE

During the « en route » phase, if the integrity of the position supplied by the GPS is not ensured, consequently it is the responsibility of the crew to check the accuracy of the position every 15 minutes using either conventional VFR method or the other navigation equipment if available.

Transmissions from the helicopter, via KX165 and KY196 can lead to momentary losses of GPS reception at the following frequencies:

121.175 ± 0.025 Mhz, 131.275 ± 0.025 Mhz and 131.200 Mhz

Navigation calculation becomes nominal few seconds after the end of transmission.

5 STATUTORY PERFORMANCE

The statutory performance in the basic flight manual and flight manual supplements remains applicable.

DGAC APPROVED ORIGINAL ISSUE



Page

SECTION 10

OPERATIONAL TIPS

10.1 RECOMMENDATIONS FOR CARGO SLING	8+
OPERATIONS	
10.1.1 PERSONNEL TRAINING	
10.1.2 MANDATORY PRE-OPERATIONAL CHECKS	
10.1.3 AIRBORNE LOADS	
10.1.4 IN-FLIGHT PRECAUTIONS	
10.2 EMERGENCY LOCATOR TRANSMITTER	
(JOLLIET JE-2 NG)	
10.2.1 GENERAL	
10.2.2 DESCRIPTION-OPERATION.	
10.2.3 TESTING	
10.2.4 OPERATING PROCEDURE	
10.3 EMERGENCY LOCATOR TRANSMITTER	
(ELT-406)	
10.3.1 GENERAL	
10.3.2 DESCRIPTION-OPERATION	
10.3.3 TESTING	
10.3.4 OPERATING PROCEDURE	10-10
10.3 ADDITIONAL LANDING LIGHT, CONTROLLAB	LE IN
ELEVATION AND AZIMUTH	
10.4.1 GENERAL	
10.4.2 DESCRIPTION	
10.4.3 TESTING	



MANUFACTURER'S DATA REVISION 5 10 - i

FLIGHT MANUAL EC120 B



LIST OF FIGURES

		Page
FIGURE 10-1 :	REMOTE CONTROL SWITCH AND	
	EMERGENCY LOCATOR JE-2 NG	10-5
FIGURE 10-2 :	REMOTE CONTROL SWITCH AND	
	EMERGENCY LOCATOR 96-406	10-9
FIGURE 10-3 :	ADDITIONAL LANDING LIGHT, CONTROLLABLE	
	IN ELEVATION AND AZIMUTH	. 10-12





eurocopter





10.1 RECOMMENDATIONS FOR CARGO SLING OPERATIONS

10.1.1 Personnel Training

Cargo sling operations may only be conducted by pilots who already have considerable experience with this type of aircraft.

No pilot should perform solo external load flights without first having accomplished such operations in the company of an instructor.

Mechanics on ground duty must be fully informed by the pilot before each new operation, in particular as regards :

- their position on the ground considering the proposed flight path;
- the direction in which to move away ;
- the hook-up operation ;
- hand signals to be used or radio instructions ;
- protective equipment : helmets, gloves, glasses (if applicable) ;
- the number of round trips between replenishments;
- the manner of retrieving slings and nets.

10.1.2 Mandatory pre-operational checks

- Helicopter Condition

In addition to the normal pre-flight checks of the helicopter, the release unit must be carefully inspected and the mechanism checked for correct release operation.

- Condition of Sling Equipment

The nets, straps and slings must be examined thoroughly. Any worn or frayed components are to be discarded.

The cables, strops and shackles must be capable of carrying three times the maximum anticipated load.

- Preparation of Loads

Make sure that all participants are well aware of the weight of the loads.

Ensure that the method of suspension is understood.



MANUFACTURER'S DATA REVISION 2



- Condition of Loading and Unloading Areas Remove or tie down all that might be displaced by the rotor downwash.
- Total Weight of Helicopter with Load

Define maximum acceptable load compatible with terrain configuration and atmospheric conditions. The maximum all up weight of the aircraft is that at which O.G.E. hover can be held over the higher of the take-off or landing platforms.

10.1.3 Airborne loads

Heavy loads, such as bags of cement or drums of kerosen, which are carried in a net, present no particular problem.

Special precautions must be taken in the case of bulky loads, which have a tendency to oscillate and even to "float" during transport on the sling.

Permeability to air can have a stabilizing effect on a bulky load : for example, a teleferic car should be carried with both its doors open.

Never carry an airfoil alone : there is a great risk of the airfoil flying up into the tail rotor.

If several cables are used to sling the load, they must be long enough to form an angle of less than 45° between cables at the point of suspension under the helicopter; experience shows that oscillation of the load is thus less likely to occur.

On the other hand, if the load is slung on a single sling cable, it is preferable that a fairly short cable be used as there is then less risk of the load swinging, and it is easier to judge the height of the load during approach.

For the retrieval of crashed helicopters it is generally possible to use a lifting ring on the rotor shaft.





Airplanes are carried using straps passing under the fuselage or under the wings. The cables must be attached in such a way that the airplane is in a slightly nose-down attitude when the helicopter is in the hover.

10.1.4 In-flight precautions

After hooking on the load the ground mechanic is to check the position of the sling cables then move away. The pilot must then make sure that the mechanic has moved clear and then be advised by signs that he may lift off the load.

Power must be applied slowly enough to allow the helicopter to centre itself above the load.

A vertical take-off must be made, avoiding dragging the load along the ground or striking any obstacle.

Carefully avoid flying over houses, vehicles and persons.

If the load starts to swing, slowly reduce speed or make a gentle left turn.

Approach must be made head into the wind with gradual reduction in airspeed, and transition into hover high enough above the ground to eliminate the risk of dragging the load.

Set the load down, then reduce collective pitch sufficiently to slacken the cables before opening the release unit hook; this also allows the pilot to ensure that the load is deposited. If the cables are long enough, move sideways a little before opening the hook, to prevent the ring and tackle from falling onto the freight.

Even after the mechanic has signalled that the load is released, move away as if it were not ; this is an advisable precaution against possible misinterpretation of signals.

Never fly away with an empty net or an unballasted sling.





10.2 EMERGENCY LOCATOR TRANSMITTER (JOLLIET JE-2 NG)

10.2.1 General

The JOLLIET JE-2 NG emergency locator transmits radio beacon signals simultaneously on the international distress frequencies (121.5 Mhz and 243.0 Mhz) to aid helicopter search and rescue operations.

The unit operates automatically in the event of crash impact exceeding 5 g along the accelerometer axis.

It may be operated manually by means of a MANU-OFF-AUTO switch (3) on the transmitter front panel, or by means of a MANU-AUTO (2) remote control switch on "MANU" position

10.2.2 Description-Operation

- Components & location

- A transmitter, located on the RH side in the cargo hold : a placard (4) indicates its location and its use in the cockpit (1).
- An external antenna (6) permits signal transmission when operated on board.
- A cockpit remote control switch.
- A flexible antenna (5) on the transmitter can be used in MANUAL operation outside the helicopter.





Figure 10-1 : Remote control switch and emergency locator

10.2.3 Testing Procedure

NOTE

Testing is authorized only during the first five minutes of each hour for no more than three consecutive audio signals.

- Select an international distress frequency (121.5 Mhz or 243.0 Mhz) on the aircraft VHF or UHF system.
- Set the AUTO-MANU remote control switch to MANU for approximately one second.
- The transmitter output signal should be audible in the headphones.
- Set the switch to AUTO.



MANUFACTURER'S DATA REVISION 2



10.2.4 Operating Procedure

- Pre-Flight Checks
 - In cockpit : check that remote control switch is set to AUTO.
 - On transmitter : check that MANU-OFF-AUTO switch is set to AUTO.
- Post-Flight Check

After landing, set the VHF communications receiver to 121.5 Mhz to ensure that the emergency locator transmitter has not accidentally been switched on.



- Automatic Operation

The transmitter is actuated automatically in the event of an impact of at least 5 g (assuming the MANU-AUTO switch is set to AUTO).

NOTE

The impact detector (accelerometer) may be reset by means of the switch control on the transmitter front panel on "OFF/RST" position (2 à 3 s.). The reset stops the transmitter output signals if the unit is operating.

 Manual Operation The unit may be actuated manually by setting the control switch to "MANU".








- Portable Operation

The transmitter may be used for self-contained operation on the ground as follows :

- Remove the transmitter from its mounting bracket.
- Select an unobstructed area.
- Extend the built-in whip antenna.
- Place the unit upright with the antenna on top.
- Switch on the transmitter by setting the MANU-OFF-AUTO switch to "MANU".

- Complete cut-off

Set the transmitter switch to OFF/RST.





10.3 EMERGENCY LOCATOR TRANSMITTER (ELT 96 – 406)

10.3.1 GENERAL

The ELT 96-406 radio beacon is an emergency transmitter which is used to locate the helicopter in an emergency. It transmits simultaneously on the international frequencies (121.5 - 243 - 406 MHz).

The transmitter starts operating automatically in case of impact or in case of breakage of the electric cable loom A-B between the remote control switch and the emergency locator.

It may be switched on manually via the switch located on the top face of the transmitter or via the remote control switch located on the instrument panel.

10.3.2 DESCRIPTION OPERATION

- Components & location :

- A transmitter (4) attached to the structure inside the rear RH cargo hold.
- An external label indicating transmitter location (5).
- An (AUTO MANU) control switch located on the instrument panel on the left hand side (2).
- An (AUTO TEST/RESET) pushbutton located next to the control switch (1).
- A amber (XMIT ALERT) indicator light located on the instrument panel on the right hand side (3).
- A 3 Amp circuit breaker on CCBP.
- An external antenna (6).







Figure 10-2 : Remote control switch and emergency locator ELT 96-406

10.3.3 TESTING PROCEDURE

The manual testing procedure for emergency locator ELT 96-406 is prohibited.

Only the following auto-test procedure is authorised:

- Perform the test, by pressing the "AUTO TEST/RESET"(1) pushbutton..
- The amber "XMIT ALERT" (3) light comes on for approximately 1.5 s.



FLIGHT MANUAL EC120 B



10.3.4 OPERATING PROCEDURE

- Pre-flight check:

Check the following under the instrument panel:

• The remote control switch is set to "AUTO".



If the switch is set to "AUTO" and the connector is unplugged,

the transmitter will operate.

- Check the following on the transmitter:

- The connector is plugged in.
- The switch is set to "AUTO".

NOTE

If the indicator light flashes, it indicates that the batteries are faulty or the transmitter is inoperative.

- Post-flight check:

After landing, check for untimely transmitter operation (the amber "XMIT ALERT" light should be extinguished).

- Automatic operation:

The transmitter will begin operating automatically in case of impact if the remote control switch is set to the "AUTO" position. The amber "XMIT ALERT" light comes on during transmitter operation.



10 - 10



Resetting the impact detector :

- Control switch set to "AUTO".
- Press the "AUTO TEST/RESET" pushbutton.
- The transmitter should cease operating.

NOTE

If the transmitter continues transmitting, perform the operation again. If, after several attempts, the transmitter remains in operation, set the switch on its top face to "OFF".

In the event of untimely activation, advise the local authorities and give the aircraft call sign.

- Manual operation

The transmitter will begin operating when the remote control switch is set to "MANU".

The amber "XMIT ALERT" light comes on during transmitter operation.

- Portable operation:

This transmitter may be used on the ground, as follows:

- Set the switch to "OFF".
- Remove the transmitter from its support.
- Work in a clear space.
- Hold the transmitter in the vertical position with the antenna upwards.
- Set the switch to "MAN/RESET" to begin transmission







10.4 ADDITIONAL LANDING LIGHT, CONTROLLABLE

IN ELEVATION AND AZIMUTH

10.4.1 GENERAL

The additional landing light, controllable in elevation and azimuth, is an optional equipment designed for improving safety during approach and taxiing maneuvers.

This optional equipment is mounted on the underside of the lower structure, in the center of the fairing in front of the forward cross-tube of the landing gear.

Its power is 450 Watts.



10.4.2 DESCRIPTION

The installation comprises :

- a retractable and controllable light (3),
- a three-way switch (1) on each (pilot's and copilot's) collective pitch lever. This switch is used to turn on light and retract it automatically,
- a four-way switch (2) on each (pilot's and copilot's) collective pitch lever. This switch is used to control the light in elevation and azimuth,





- a blue "LAND LT" indicator light (4) on the instrument panel, which shows that the landing light is illuminated.

10.4.3 OPERATION

The landing light is turned on and off by means of the three-way switch (ON-OFF-RETRACT) on the collective pitch lever:

- In the "ON" position of the switch, the landing light is turned on and the "LAND TL" indicator light is illuminated.
- In the center "OFF" position of the switch, the landing light is turned off and the "LAND LT" indicator is out.
- The spring-loaded "RETRACT" position of the switch must be used to turn off and retract the landing light automatically. In this way, the landing light will always be turned off in the retracted position.

The extension and orientation of the landing light are controlled by means of the four-way switch.

10.4.4 PROTECTION OF THE CIRCUITS

The circuits are protected by means of:

- a 3 Amp fuse for the control circuits,
- a 20 Amp fuse for the lighting circuit .

The fuses are located on the side panel of the cargo compartment



Si vous trouvez des erreurs, utilisez cette feuille pour nous le faire savoir.

ERR

If errors are found in this manual, please use this form to report them to us.

MANUEL: MANUAL:

APPAREIL: AIRCRAFT:

LANGUE: LANGUAGE:

VERSION: VERSION:

	<u>REFERENCE</u> : Chap/Sect/Suj - Date - Page <i>Chap/Sect/Subj - Date - Page</i>	DESCRIPTION :	SUGGESTION :
		•	1
Ð	Pliez Postez Voir au Verso	To fold and	mail the form see overleaf
	, noz, , osiez, von au versu		nan ala lonni see ovenedi





MANUEL/MANUAL :

APPAREIL/AIRCRAFT:

ANGUE/LANGUAGE:

VERSION/VERSION:

ATTENTION :

LA VALIDITE DE CE MANUEL EST FONCTION DE SA QUALITE D'ORIGINE ET DE LA DISCIPLINE APPORTEE A SA TENUE A JOUR. - L'IMPRIMEUR EST DESIGNE AU VERSO

- LA RESPONSABILITE DE MISE A JOUR DOIT ÊTRE ENREGISTREE CI-APRES.

IMPORTANT NOTE :

THE PRACTICAL VALUE OF THIS MANUAL DEPENDS UPON ITS ORIGINAL QUALITY AND ITS BEING CORRECTLY UPDATED

- THE PRINTER'S NAME SPECIFIED OVERLEAF

- THE NAME OF THE PERSON RESPONSIBLE FOR KEEPING THE MANUAL UP-TO-DATE MUST BE RECORDED HEREAFTER.

REVISION		INCORPORATION INSERTED			REVISION		INCORPORATION INSERTED			
N° No	Date	Date	Par (NOM) By (<i>NAME</i>)	Visa Signature		N° No	Date	Date	Par (NOM) By (<i>NAME</i>)	Visa Signature
2	3198									
	ļ									
								L		
					IL					
					IL					
		İ								
][

LISTE DES REVISIONS / RECORD OF REVISIONS



MANUEL/MANUAL:

APPAREIL/AIRCRAFT:

LANGUE/LANGUAGE:

VERSION/VERSION:

L'impression de ce document, à la révision signalée page précédente, a été réalisée avec tous les soins de :

This document at the revision specified on the previous page, has been printed with great care by :

Imprimeur : TORRESPONDANCE Printer : 59, bd de la République 13100 - AIX EN PROVENCE Tél. : 04.42.27.06.86 - Fax. : 04.42.27.53.08 E-Mail : torrespondance@wanadoo.fr

Date : JUILLET 1998

Si vous trouvez des erreurs, utilisez La feuille « ERR » pour nous le faire savoir. If errors are foud in this Manual please use the « ERR » form to report them to us.

Pour toute réclamation s'adresser à : All comments should be adressed to : EUROCOPTER

Direction Technique Support Documentation technique Aéroport International Marseille-Provence 13725 MARIGNANE Cedex - France

Tél. : (33) (0) 4 42 85 96 75 Fax : (33) (0) 4 42 85 94 80

Les textes et figures contenus dans ce document ne peuvent être reproduits sans accord écrit de la Société EUROCOPTER.

Toute reproduction doit porter mention de l'accord et de l'autorité à l'origine de cette autorisation. No part of the text or illustrations contained in this document may be reproduced without the written approval of the company EUROCOPTER. Such approval and approving authority shall be mentioned on all reproductions.





FLIGHT MANUAL EC 120 B SUPPLEMENT

GPS TNL 2000 APPROACH

IMPORTANT NOTE

THE INFORMATION CONTAINED HEREIN SUPPLEMENTS OR SUPERSEDES THE INFORMATION GIVEN IN THE BASIC FLIGHT MANUAL AND/OR APPLICABLE FLIGHT MANUAL SUPPLEMENTS.

THE EFFECTIVITY OF THE SUPPLEMENT AT THE LATEST REVISION IS SPECIFIED ON THE LIST OF EFFECTIVE PAGES.

THIS SUPPLEMENT MUST BE INCLUDED IN THE FLIGHT MANUAL WHEN THE EQUIPMENT MENTIONED ABOVE IS INSTALLED ON THE AIRCRAFT.

EUROCOPTER Direction Technique Support Aéroport international Marseille-Provence 13725 Marignane Cedex - France

DGAC APPROVED ORIGINAL ISSUE : APRIL 1998 9 - 55A - TITLE



LIST OF APPROVED EFFECTIVE PAGES

PAGE	REV No	REMARKS	PAGE	REV No	REMARKS
9-55A - Title 9-55A - A 9-55A - B	0 0 0				
9-55A - 1 9-55A - 2	0 0				





FLIGHT MANUAL

EC120 B



LOG OF APPROVED NORMAL REVISIONS

ORIGINAL 0 APRIL 1998

ORIGINAL ISSUE

APPROVED BY : DGAC

DATE : - 1 AVR. 1998





eurocopter

FLIGHT MANUAL EC120 B

GENERAL

The Global Positioning System TRIMBLE 2000 APPROACH complies with AC 20-138 requirements for use in day VFR conditions in sight of the ground or water.

2 LIMITATIONS

The limitations in the basic flight manual and flight manual supplements remain applicable and are supplemented or modified by the following limitations.

- A placard located within pilot's sight field indicates :

GPS OPERABLE IN DAY VFR CONDITIONS IN SIGHT OF GROUND OR WATER ONLY GPS UTILISABLE EN VFR DE JOUR EN VUE DU SOL OU DE L'EAU UNIQUEMENT

- Use of the GPS is prohibited in approach mode.

3 EMERGENCY PROCEDURES

The emergency procedures in the basic flight manual and flight manual supplements remain applicable.

NOTE

Press the MSG key on the CDU to display the situation of the GPS and to scroll through next messages if any.

DGAC APPROVED ORIGINAL ISSUE 9 - 55A - 1

FLIGHT MANUAL

EC120 B



4 NORMAL PROCEDURE

The normal procedures in the basic flight manual and flight manual supplements in use remain applicable, and are supplemented or modified by the following normal procedures :

4.1 BEFORE STARTING

- The PILOT GUIDE operating manual (reference : 81449) must be upto-date and kept on-board the aircraft.
- The crew must check the validity and accuracy of the data base (28 days validity) relative to the official documentation.
- Before the start of navigation, check that all the data is valid by reading the messages on the CDU.

NOTE

During the « en route » phase, the integrity of the position supplied by the GPS is not ensured. Consequently it is the responsibility of the crew to check the accuracy of the position every 15 minutes using either conventional VFR method or the other navigation equipment if available.

Transmissions from the helicopter, via KY196 can lead to momentary losses of GPS reception at the following frequencies:

121.175 ± 0.25 MHz and 131.275 ± 0.25 MHz.

Navigation calculation becomes nominal 2 to 3 seconds after the end of transmission.

5 STATUTORY PERFORMANCE

The statutory performance in the basic flight manual and flight manual supplements remains applicable.



DGAC APPROVED ORIGINAL ISSUE

9 - 55A - 2



GREAT SLAVE HELICOPTERS LTD.



Group of Companies





EC120B Series Repetitive Airworthiness Directives and Service Bulletins

A/C Reg.:_____ A/C W.O. No.:_____

A/C T.A.T.:_____ Date:_____

* Denotes certification by approved pilots is acceptable

AD or SB Number	Subject Description	Compliance Due At	Initial
AD 2000-285-005 (A) R2	Sliding door inspection IAW SB 05A005	Each door installation.	
*AD 2000-176-004 (a) R2	Inspection of Engine-to-Main Gear Box (MGB) – Coupling Tube AssemblyIAW Alert Service Bulletin # 05A003	Daily or 5 hrs	
AD 1999-233	Replacement of fuel injection manifolds IAW SB A319 73 4001	200 hrs or 'Bad' Pwr check	
SB A319 72 4003	Dye Penetrant inspection of P3 air tapping bosses and FCU supply boss for cracks	100 hrs	
TD 28C004	Clean the in-line fuel strainer IAW Technical Directive 28C004	500 hrs or 2 years	