


TS-8000A

Thermostat with alarm Manual



I、 MAIN SETTING (Run Mode)



TEMPERATURE SETTING

Press **SET** (key lamp lights): this message will be displayed instead of the ° Set temperature value.
Press + or - to modify, press **SET** to escape.



MINIMUM ALARM TEMPERATURE

Press **MIN ALARM** (key lamp lights): this message will be displayed instead of the ° Set Minimum temperature value.
Press + or - to modify (*), press **ALARM MIN** to escape.



TEMPERATURE SETTING

Press **MAX ALARM** (key lamp lights): this message will be displayed instead of the ° Set Maximum temperature value.
Press + or - to modify (*), press **ALARM MAX** to escape.



* If option **o.ALA=1** (see **COSt**) the **c.AL_** or **c.AL-** message appears on display.
If option **o.ALA=2** (see **COSt**) the **r.AL_** or **r.AL-** message appears on display.

II、 VIEWING TEMPERATURE RECORDING



Press + :

--	--	--	--

 will be displayed followed by °Maximum Temperature Recording.

Press - :

--	--	--	--

 will be displayed followed by °Minimum Temperature Recording.

Values recorder are memory permanent stored: for memory clear keep pushed + keys for more than 3 seconds: **CLEA** message will be composed on display before clearing operation.

III、 PRESET PROGRAMS (Bootstrap)



At delivery this processor is ready programmed with the following (variable) settings.
To return to these settings at any time:

Power off the processor, press **ALARM MAX** key and keep it pressed giving power on: **boot** message will be displayed (release now **ALARM MAX** key).

t.Set = 25.0° AL _ _ = 10.0° AL - - = 30.0°

The **COSt** values are shown in **COSt** Programming.

IV、 COSt PROGRAMMING (System constants)



These settings refer to the mode operation of the system and must be made on initial start-up.

Press - / + together for at least one second.

the message **C.O.S.t.** will be displayed.

Press than repeatedly **ALARM MAX** until interested variable's message is displayed (see table below) : variable value and related message will be displayed.

Press + or - to set a new value and then **ALARM MAX** to confirm.

The next system constant will then appear.

You can press **ALARM MAX** for a least two second to escape and return to the Run Mode.



Mess.	Value	Meaning	Note
diFF	0.2°	°differential	*1)
o.ALA	=0	Alarm setting mode	*2)
C.AL_	0.0°	° Set temperature minimum alarm	*3)
C.AL-	40.0°	° Set temperature maximum alarm	*3)
tEnP	=1	Temperature representation (=1 °C, =2 °F)	*4)
Ad.tE	0.0°	°Input temperature sensor correction (+ or -)	*5)

*1) For more details see Operative Diagrams.

*2) **o.ALA = 0** : Minimum and maximum alarm sets user settable (see **ALARM** keys).

o.ALA = 1 : Minimum and maximum alarm absolute sets (see **COST *3**).

o.ALA = 2 : Minimum and maximum alarm relative sets (see **COST *3**).

*3) If **o.ALA = 1** : Minimum or maximum absolute alarm set value.

If **o.ALA = 2** : Minimum or maximum relative alarm set value.

For more details see Operative Diagrams.

*4) :=1 : °C Temperature range.

=2 : °F Temperature range.


*5) You can correct the readings on the various sensor (+ or -).

V、 STATE INDICATION LAMPS

The light situated at the bottom of the display show the state of the various relays as set out below:

Lamp.	State	N° Relay	Contact
HEAT	Heat On	1	3-4
COOL	Cool On	1	4-5
AL. MIN	Minimum Alarm On	2	6-7-8
AL. MAX	Maximum Alarm On	2	6-7-8

VI、 OPERATIVE DIAGRAMS




VII. INSTALLATION

How to connect the sensors

Connect the sensor provided as shown in the diagram. For remote connections use a standard 0.5-square millimeter two-pole wire, taking great care over the connections, by insulating and sealing the joins carefully. **-O.C.-** is displayed when the temperature sensor wiring is open, **-S.C.-** is displayed when the temperature sensor wiring is short circuit.

How to connect the line

Connect line on terminals **L-N**.



As it company policy to continually improve the products the Manufacturers reserve the right to make any modifications thereto without prior notice. They cannot be held reliable for any damage due to malfunction.