

Pixel 10 Pro Fold repair manual

Version 1.1, 2025



Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Google recommends that you seek professional assistance for all device repairs.

Self service repair isn't recommended unless you are an adult with the technical expertise to safely repair electronic devices. If you choose to perform self repair, you agree to assume the risk associated with such repair.



Use caution if you engage in repair.

When you open or repair your device, be careful of electric shock, device damage, fire and personal injury risks, and other hazards. Before you service the product, read the full set of precautions in this document.

Welcome!

We are here to help.

At Google, we innovate, design, and build to create helpful and sustainable products.

Product longevity is important to us and repairability is part of that. Repair enables our products to stay in-use and out of landfills.

If you have any questions or need support, please reach out.

support.google.com

This manual is organized into sections for easy and intuitive navigation.



Precautions

Safety is a top priority for Google.
Users should work in a safe
environment and have the necessary
skills and training to complete the
repairs safely.



Repair flows

Here, we have a flow chart of the most efficient repair methods.



Disassembly

Each section contains a list, in the order of device disassembly, of prerequisite steps, tools, fixtures, and parts to complete the repair.



Assembly

For each disassembly, we provide a guide to reassemble. This might include rework steps for certain components.



Troubleshooting and software

Use the diagnostic steps and tests recommended in this section to identify the source of device problems and issues.



Glossary

All the terms and acronyms you need to communicate with the same language.

Precautions Welcome Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Table of contents



Precautions

Electrical precautions

Tools and fixtures

Battery conditions

Laser product

Battery handling

Safety equipment

Glass handling

Introduction

Expanded views

Turning pixel on and off

Screw map

Tools and fixtures

Screen calibration

Replacement parts

ESD protection

Glossary

Liquid damage indicators

User PF repair

Inner display protective film

Inner display trim



Repair flows

Disassembly order

Assembly order



^K∘^N Disassembly-base

BG (back glass) sub

Logic board

Vibrator with cowling

Rear camera

mmWave module and IF FPC Base battery

Inner front camera

ID (inner display) sub

Bottom speaker



³o[∠] Assembly-base

ID (inner display) sub

Base battery

Rear camera

Vibrator with cowling

Logic board

Inner front camera

mmWave module and IF

FPC

BG (back glass) sub

Bottom speaker



OD (outer display) sub

Outer front camera

Lower board

Flip battery

Upper board

ID (inner display) sub



Assembly-flip

ID (inner display) sub

Outer front camera

Lower board


Flip battery

Upper board

OD (outer display) sub

Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Table of contents (continued)



Connectors location Sensor

Power FPS (power button)

Wireless charge Volume button

Mic 1 Rear camera

Mic 2 Outer front camera

Mic 3 Inner front camera

Top speaker USB

Bottom speaker mmWave

Vibrator Inner display

Outer display Inner display touch panel

Outer display touch panel UWB
RF (BT, Wi-Fi, GPS, NFC) Hinge

Battery

SIM



Software

Software tools

Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Flip Assembly-Flip Troubleshooting Software

Revision history

Version	Date	Change description
v1.0	August 15, 2025	First release
v1.1	September, 2025	 Revise service trim pictures. P.55,P.56,P.58,P.59,P.63,P.64,P.66,P.67 Modify the wording. P.60, P.68 Increase the opening pick insertion depth to from 3.5mm to 5.0 mm. P.78, P.80 Add picture to identify the area. P.152, P.153 Modify the direction of insert feeler gauge. P.201 Remove the duplicate page P.272 Revise the note. P.180, P.184 Remove the index of top speaker liner. P.236 Revise the note and picture for Rcam's PSAs. P.137 Correct the GPNs. P.230, P.235



Pixel 10 Pro Fold repair manual

Precautions

Important: Before you begin



Be careful if you engage in repair

When you open or repair the device, be careful of electric shock, device damage, fire and personal injury risks, and other hazards.

Always perform repairs in a clean work space with correct ventilation and no combustible materials.

Make sure that there are no additional screws or small parts left in the device after assembly.

Before you service the product, read the full set of precautions in this document.



Use caution:

Batteries should be carefully handled, and could be dangerous when damaged

- Fully discharge device battery before you attempt repair.
- Never bend, dent, puncture, or use tools to pry the battery.
- Store batteries in the replacement part packaging as soon as possible after removal to prevent damage.
- If a battery begins to vent, cover it in sand or use gloves and tongs to keep the battery in a fire safe container as soon as possible.
- Take care to prevent shorting of battery terminals or damage of the battery, as it could result in fire or overheating.
- Dispose of the battery according to local regulations.



Use caution

Pixel 10 Pro Fold contains a class 1 laser module

The design of the device incorporates optics and protective housing such that there's no access to a level of laser radiation above class 1 during normal use or approved servicing.

Use of controls or adjustments and performance of procedures other than those specified herein might result in hazardous radiation exposure.

Repair Flows

Important: Before you begin



Use caution

Part handling - glass

- Wear protective gloves and safety glasses when you handle damaged parts.
- Use protective film when you remove damaged parts.
- After removal, store the damaged part in the replacement part packaging as soon as possible to prevent injury.



Tools and fixtures

The use of Google-authorized tools and fixtures is **strongly recommended** to repair a device in a safe and effective manner.

Use caution:

- We don't recommend that you perform repairs without the specified tools and fixtures.
- Improper use of tools and fixtures might result in injury to yourself, the user of the device or other third parties, along with damage to the product, tools, fixtures, replacement parts, or other spare parts.



Important:


Before you disassemble the device


- Disconnect the device from all power sources before any disassembly.
- Make sure that the battery is fully discharged before any disassembly.
- If the phone battery shows signs of <u>swelling or damage</u>, or if the phone feels hot or emits a strong odor, *don't* attempt disassembly. Please reach out to Google <u>customer support</u>.
- Take care not to expose the phone or its components to liquids after disassembly.



Examples of unacceptable battery conditions that aren't suitable for repair*








Line protrusion

Bubbling




Scratch


Imprinted line



Contamination mark




Dot protrusion



Dent









Swelling or electrolyte leakage

^{*}These are examples of potentially dangerous battery conditions but don't reflect all possible dangerous conditions. Please follow the general safety guidance outlined in this document.

Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software



Pixel 10 Pro Fold repair manual

Introduction

Expanded views Turn the Pixel on and off

Screw map Tools and fixtures

Screen calibration Replacement parts

ESD protection Glossary

Liquid damage

indicators

Pixel 10 Pro Fold part ID


Pixel 10 Pro Fold: Expanded view

Reuse indications

Reusable without cleaning

Reusable after cleaning

Not reusable after disassembly




1 • Logic board	7 • Rear camera_TELE	13 Base battery	19 OD(Outer display) PSA	25 • Top rubber	31 • Flip bridge cowling
2 • ID(Inner display) sub	8 • Rear camera_UW	14 • Flip battery	20 ■ BG(Back glass) PSA	26 • Screw	32 • Inner FCAM cowling
3 BG (Back glass) sub	9 Rear camera_WIDE	15 • FPS kapton	21 • RF sponge	27 SIM tray	33 • OD(Outer display) cowling
4 OD(Outer display) sub	10 • Lower board	16 • Cable kapton	22 ■ Graphite sheet	28 Bottom speaker	34 • mmWave cowling
5 • Outer FCAM	11 • Upper board	17 • Conductive tape *2	23 • PL rubber	29 mmWave module	35 • Base bridge cowling
6 • Inner FCAM	12 • Vibrator with cowling	18 • Flip Battery jacket	24 • Bottom rubber	30 • IF FPC	36 • ID(Inner display) cowling


Disassembly-Base Assembly-Base Disassembly-Flip Welcome Precautions Introduction User PF Repair Repair Flows Assembly-Flip Troubleshooting Software

Screw map

These are the screws used in the Pixel 10 Pro Fold:









Screw G250-08002-10



Screw G250-08003-10 Screw G250-08004-20



Screw G250-08005-12



Screw G250-08248-00



Screw G250-08005-21



Screws are a single use item

Screws are a single use item and if removed from the device, they should be replaced with a new screw.

Torque spec: (0.8, 0.9, or 1.2) ±0.05kgf-cm







After removal, always replace with a new screw

Each screw is critical to the safe continued operation of the phone. As the thread locking adhesive can't be reactivated, always replace it with a new screw after removal.



Important!

Complete the following before you boot up the device:

- Except for the inner display **pre-installed user protective film**, nothing should touch the inner display. This includes protective films, cases, fingers, tape, labels, scratch covers, adhesives, and debris.
- The device should be in **unfold** mode and open completely.
- The device should be on a flat surface. Don't hold it in your hands.

After the above conditions are met, press the power button and power on the device. *Don't* touch the device until it's fully booted into the user operating system.



Display touch calibration

After any repair that requires you to open the phone, complete the display touch calibration during first boot.



Touch function

If this process isn't followed, the touch function of the screen might not work as intended.



ESD protection

Electro Static Discharge (ESD) could damage components, so it's important to work in an ESD-safe environment during repair.

Follow these four steps to keep ESD safe:



Stay grounded

Carry out repairs on an ESD mat, and the person who repairs the device should wear a grounded ESD strap.



Avoid static buildup

Don't wear synthetic fibers such as fleeces that could generate static.



Protective bags

Pack all ESD-sensitive parts in metalized protective bags during shipping.



Avoid touching the pins

Use ESD-safe tools to handle components to avoid touching the pins.



Did you know?

ESD is the sudden flow of electricity through two electrically charged objects. For example, ESD is a shock you feel when you walk on a carpet, and then touch a metal door handle.

Liquid damage indicators

Liquid Damage Indicators (LDI) are strips that change colors when a phone has been exposed to water or other liquids.

- Exposure to liquids could lead to the device malfunctioning, such as overheating or short circuits.
- There are **two LDIs** on this device.
- If either indicator has turned red, the device is considered to have been exposed to liquid.



On the logic board, near the charging port.



The SIM card tray on the flip enclosure is visible without disassembly of the device.

Turn the Pixel on and off



Turn the power on or off

- To turn on a device when it's powered off, press and hold the power button for a few seconds. <u>See where</u> the power button is located.
- To power off the phone:
 - Press and hold the power and volume up buttons for a few seconds. Then, tap **Power off** on screen.
 - For more information, see <u>Google</u> <u>Help page</u>.

Tip: Before you turn on the phone, charge it. <u>Learn how to charge</u>.



Turn screen off and back on

• To turn the screen on and off when the phone is turned on, press the power button once.

Tip: On some Pixel phones, you could see the time and some other information even when the screen is off. Learn which Pixel phones and how to turn Always show time and info off or on.



Restart or reboot

- 1. On most phones, press the phone's Power button for about 30 seconds, or until the phone restarts.
- 2. On the screen, you might need to tap **Restart**.

Disassembly-Flip

Assembly-Flip

Tools and fixtures

The use of Google-authorized tools and fixtures is strongly recommended to repair a device in a safe and effective manner.



Use caution

- We *don't* recommend that you perform repairs without the specified tools and fixtures.
- Improper use of tools and fixtures might result in injury to yourself, the user of the device or other third parties, along with the damage to the product, tools, fixtures, replacement parts, or other spare parts.




Google-approved fixtures: Pixel 10 Pro Fold

Google-approved fixtures are Google-tested and are strongly encouraged to ensure high quality and safe repairs.




























Google-approved fixtures: Pixel 10 Pro Fold


Google-approved fixtures are Google-tested and are strongly encouraged to ensure high quality and safe repairs.














Welcome Pred

Precautions

Introduction U

User PF Repair

Repair Flows





Standard tools


Standard tools are suggested to ensure high quality and safe repairs. These items *don't* need to be purchased from a Google-recommended supplier.































Standard consumables


Standard consumables are suggested to ensure high quality and safe repairs. These items *don't* need to be purchased from a Google-recommended supplier.


























Welcome Precautions Introduction User PF Repair Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software




Safety items


Safety items are suggested to ensure high quality and safe repairs. These items *don't* need to be purchased from a Google-recommended supplier.











Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software



Replacement parts

Important notice about replacement parts


- The use of Google-authorized replacement parts is strongly recommended.
- Performance within product specifications can't be assured if Google-authorized replacement parts aren't used.





Use caution


Use of replacement parts other than Google-authorized replacement parts, such as aftermarket batteries, might impact device safety, reliability, and performance. Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software







































Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software





































































Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software
































































































Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

































Replacement parts


Reuse indications







Not reusable after disassembly













Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Acronym or term	Definition
ESD	Electro Static Discharge The sudden flow of electricity through two electrically charged objects.
IPA	Isopropyl Alcohol Used to clean components and enclosures. Comes as pads or a solution.
FPC	Flexible Printed Circuit A type of low profile and flexible printed circuit.
OLED	Organic Light-Emitting Diode A type of flat panel display with an OLED to show images.
mmWave	Millimeter Wave The radio waves used to build a 5G network, to provide fast, reliable mobile data.
Sub6	Sub-6 GHz Refers to mid- and low-frequency bands under 6 GHz.
NG	Not Good. Usually refers to a condition that isn't acceptable.
SBOM	Service Bill of Materials

Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Flip Assembly-Flip Troubleshooting Software



Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software



Welcome User PF Repair Repair Flows Disassembly-Base Assembly-Base Disassembly-Flip Assembly-Flip Software Precautions Introduction Troubleshooting

Glossary

Acronym or term	Definition
RF	Radio Frequency
GPS	Global Positioning System
PSA	Pressure Sensitive Adhesive
WIDE	Wide Angle Lens
FPS	Finger Print Sensor
PL	Proximity-Light
ANT	Antenna
VOL	Volume
РСВ	Printed Circuit Board
CPSA	Conductive Pressure Sensitive Adhesive
TSPK	Top Speaker
TP	Touch Panel
WLC	Wireless Charging

Welcome Precautions Introduction User PF Repair Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software



Pixel 10 Pro Fold repair manual

User PF Repair

Inner display protective film

Inner display trim

Inner display protective film

The user ID PF is intended to provide additional protection to the inner display during use of the device.



Use caution

Use safety gloves when you handle damaged displays as splinters during removal could cause injury.

Apply protective film to broken glass before removal.

Review all safety precautions before you begin work.



Prerequisites

Before you begin a repair, ensure to **power off** the device and disconnect any charging cables.



Tools

Universal base plate 12 mm

Universal holder #2

Universal holder limiting block #2

Universal press plate 12 mm

Universal scraper-large

Pixel 10 Pro Fold ID PF or trim supporting rubber

Screen protector accessories


Dust cleaning tool




ID protective film replacement

Here's the list of parts for the ID protective film disassembly.









Reusable without

cleaning

Reuse indications


Reusable after

cleaning

Not reusable


after disassembly

Trim difference



Prepare usage

- Place the universal ID PF or trim supporting rubber on the universal holder #2, and place the universal holder limiting block #2 on top.
- Place the fixture in position D1 on the universal base.



Welcome Precautions Introduction **User PF Repair** Repair Flows Disassembly-Base Assembly-Flip Assembly-Flip Troubleshooting Software

Remove the base and flip trims

- Make sure that the device is powered off before you proceed.
- Place the device in the **universal holder #2** with the inner display facing upward.
- Use a **spudger** and carefully lift the ends of both the **base** and **flip trim**, starting near the folding **hinge**.
- Remove the **flip trim** with your **hand**, and remove the **base trim** with your **hand**.
- Use a **spudger** to remove any adhesive residue from the **enclosure**.



- There are two **notched cutouts** on the upper and lower left of the **user PF**, as shown in **Fig 1**. Insert the **guide sticker liner** into one of them, as shown in **Fig 2**.
- Insert the plastic deeper to separate the user PF from the ID.
- Slowly tear off the user PF by **hand** and hold down the **ID**. Move the hand along to avoid the damage to the screen, as shown in **Fig 3**.



Note

Don't wear gloves when you handle the user PF.
Use a magnifying glass if needed.




Use caution

Peel off the user PF from the notched cutouts on the upper or lower left of the user PF to avoid the damage the inner display.









Welcome Precautions Introduction User PF Repair Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Clean the display

- Use **IPA** and a **dust-free cloth** to clean the screen of dust and residue.
- Use a dust cleaning tool and **screen protector accessories** to remove all dust from the display.



Use caution




Remove the release liners

Slowly peel off the front liner 2 and the back liner 2 from the user PF.

Part: G806-14356-99 (user PF)



Use caution



Welcome Precautions Introduction User PF Repair Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Remove the back liner-1


- Gently peel the layered structure between **front liner-1**, **PF**, and **back liner-1** to identify the **back liner-1** side, as shown in **Fig 1**.
- Insert a guide sticker from the corner at a 45 degrees angle to peel the black liner 1, as shown in Fig 2.


Part: G806-13134-00 (guide sticker)



Use caution

Make sure that only one single layer, which is the back liner-1 is removed from the user PF.





Align the PF with fixture


- Locate the two Universal holder #2 alignment posts near the inner display FCAM.
- Place the guide plastic of the user PF through the posts, and ensure that there are no creases on the plastic around the posts.


Part: G806-14356-99 (user PF)



Use caution

Make sure that the device leans on the L-shape limiting block without any gap.





Welcome Precautions Introduction User PF Repair Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Apply the PF

- Gently angle the **user PF** at a 75 degrees angle to the inner display with one **hand**.
- Align the universal scraper-large to the screen with the other hand.
- Starting from the edge, slowly apply the protective film onto the screen with the **universal scraper-large**. Move forward with moderate pressure.

Part: G806-14356-99 (user PF)




Use caution

Make sure that the environment is clean for this process.

Avoid back-and-forth movements.





Apply the PF (continued)

- Glide the **universal scraper-large** on the **user PF** to wipe bubbles towards the edges of the PF, as shown in **Fig 1**.
- Use a **dust-free cloth** to gently press the hinge area and the four edges to ensure that the **user PF** adheres properly, as shown in **Fig 2**.

Part: G806-14356-99 (user PF)



Use caution





Remove the liner

After you attach the user PF to the inner display, wait for 5 minutes. Then, carefully peel off the front liner-1, and ensure that the PF stays attached.

Part: G806-14356-99 (user PF)



Note


Wait for 5 minutes before you remove the front liner-1.



Use caution

The PF is prone to scratches after the front liner-1 is removed.

Don't use the universal scraper, other tools, or try to remove any blemishes after you remove the liner.





Keep the device unfolded

Keep the device unfolded for at least **an hour** after PF application.



Use caution

Avoid to fold or repair it during this time.

Don't use scrapers, dust-free cloth, or tools on the screen during the dwell period.



Inner display trim

Solution 1: use alignment fixture



Remove the base trim liner

- Slowly peel off the outer liner from the **base trim**, and move your other hand along.
- Use **ESD tweezers** to remove the trim and carefully grab the first blue release liner. Repeat for the second and third blue release liners.

Part: G730-09903-00 (trim base)



Use caution

Make sure that the environment is clean for this process.

Be careful not to touch the trim or blue liner.






Place the base trim

Place the guide plastic of the **base trim** through the **universal holder #2** alignment posts, and ensure that there are no creases on the plastic around the posts.



Use caution

Make sure that the device leans the L-shape limiting block without any gap.







Apply the base trim

- Allow the base trim to adhere naturally.
- Press the edges near the hinge on both sides.
- Push outward to ensure that the trim is in the groove.



Use caution

Make sure that the environment is clean for this process.



Assembly-Flip

Software

Troubleshooting



Remove the flip trim liner

- Slowly peel off the outer liner from the **flip trim**, and move your other hand along.
- Use ESD tweezers to remove the trim and carefully grab the first blue release liner. Repeat for the second and third blue release liners.


Part: G730-09911-00 (trim flip)



Use caution

Make sure that the environment is clean for this process.

Be careful not to touch the trim or blue liner.






Place the flip trim

- Remove the device from the fixture, rotate 180 degrees, and place it back down on the fixture.
- Place the guide plastic of the flip trim through the universal holder #2 alignment posts, and ensure that there are no creases on the plastic around the posts.



Use caution

Make sure that the device leans the L-shape limiting block without any gap.







Apply the flip trim

- Allow the **flip trim** to adhere naturally.
- Press the edges near the hinge on both sides.
- Push outward to ensure that the trim is in the groove.



Use caution





Press the base and flip trims

- Take the device out of the fixture.
- Fold the device and then press the first area for 20 seconds and press the second area for another 20 seconds to activate the base and flip trim PSAs.
- Unfold the device and gently remove both liners.



Use caution



Inner display trim

Solution 2: assemble manually



Remove the base trim liner

- Slowly peel off the outer liner from the **base trim**, and move your other hand along.
- Use **ESD tweezers** to remove the trim and carefully grab the first blue release liner. Repeat for the second and third blue release liners.


Part: G730-09903-00 (trim base)



Use caution

Make sure that the environment is clean for this process.

Be careful not to touch the trim or blue liner.





Place the base trim

Align the **base trim** with the lower left corner of the enclosure, and ensure that it sits flush within the frame.



Use caution





Apply the base trim

- Allow the **base trim** to adhere naturally.
- Press the edges near the hinge on both sides.
- Push outward to verify that the trim is in the groove.



Use caution





Remove the flip trim liner

- Slowly peel off the outer liner from the **flip trim**, move your other hand along.
- Use **ESD tweezers** to remove the trim and carefully grab the first blue release liner. Repeat for the second and third blue release liners.


Part: G730-09911-00 (trim flip)



Use caution

Make sure that the environment is clean for this process.

Be careful not to touch the trim or blue liner.





Place the flip trim

- Rotate the device 180 degrees.
- Align the flip trim with the lower left corner of the enclosure, also verify that it sits flush within the frame.



Use caution





Apply the flip trim

- Allow the **flip trim** to adhere naturally.
- Press the edges near the hinge on both sides.
- Push outward to ensure that the trim is in the groove.



Use caution



User PF Repair

Solution 2: assemble manually



Press the base and flip trims

- Take the device out of the fixture.
- Fold the device and then press the first area for 20 seconds and press the second area for another 20 seconds to activate the base and flip trim PSAs.
- Unfold the device and gently remove both liners.



Use caution



Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software




Pixel 10 Pro Fold repair manual


Repair flows

Disassembly order

Assembly order

Pixel 10 Pro Fold-base side (BG) disassembly flowchart









Base battery removal:

To make removal and replacement of the base battery easier: first take out the BG subassembly, then remove the vibrator with cowling, and finally, detach the base battery.

Pixel 10 Pro Fold-flip side (OD) disassembly flowchart







Flip battery removal:

To make removal and replacement of the flip battery easier: first take out the outer display, and then the flip battery.



Note

The lower board and upper board are on the same layer. You could remove them independently.


Assembled without a

fixture

fixture

Assembled with a

Pixel 10 Pro Fold-base side (BG) assembly flowchart





Use caution

When you perform the inner display replacement, follow the sequence to assemble the base side then the flip side.



How to read this chart

To reinstall the base battery:

Install the base battery, vibrator with cowling, inner front camera, then the BG sub.

To reinstall the logic board:

Install the logic board, IF FPC or mmWave module, bottom speaker, base battery, vibrator with cowling, inner front camera, then the BG sub.

New ID sub:

The new inner display sub includes the FPS and the sidekey.

Upper board


Assembled without a

fixture

fixture

Assembled with a

Pixel 10 Pro Fold-flip side (OD) assembly flowchart





Use caution

When you perform the inner display replacement, follow the sequence to the assembly base side then the flip side.



How to read this chart

To reinstall the flip battery:

Install the flip battery, then the outer display.

To reinstall the lower board:

Install the lower board, flip battery, then the outer display.

New ID Sub:

The new inner display sub includes the Ant 1 FPC and top speaker with Ant 4 FPC.



Pixel 10 Pro Fold repair manual


Disassembly-base

BG sub Inner front camera Rear camera

Vibrator with cowling Bottom speaker Base battery

mmWave module and IF Logic board Inner display sub

FPC



BG (back glass) sub

The inner front camera cowling makes sure that connectors remain engaged with the logic board and acts as a heatsink.



Use caution

Use safety gloves to handle damaged back glass as some splinter during removal could cause injury.

Apply protective film to the broken glass before removal.

Review all safety precautions before you begin work.



Prerequisites

Before you begin a repair, be sure to **power off** the device and disconnect any charging cables.



Tools

Universal holder #2

Universal holder limiting block #2

Pixel 10 Pro Fold-BG press rubber

Pixel universal base plate 12 mm

Universal press pate 12 mm

Universal press fixture

Universal supporting rubber

Torx plus 3IP screwdriver

Tweezers

Spudger

Opening pick

Big suction cup

3M AP111 primer


Absorption-bulb

Feeler gauge 0.2t




BG sub replacement

Here's the list of parts for the BG sub disassembly.











Reuse indications

Reusable without you clean

Reusable after

you clean

Not reusable after disassembly

Avoid the spring damage

Before you remove the BG sub, be aware of the springs underneath, refer to the figure for locations.



Use caution

Avoid damage to the springs during disassembly.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Mark the opening pick


- Use an opening pick to separate the BG from the enclosure. If you Insert it too far, it could damage the device.
- The device has two adhesive widths. Measure 2.0 mm and 5 mm from the tip and mark the opening pick with a permanent mark.



BG Sub

Use caution

Follow the steps to mark your pick and prevent damage.



Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Separate the BG

- Use caution when you separate the adhesive to avoid damage to the spring contacts.
- Apply a suction cup to the BG, close to the USB side, as shown in **Fig 1**.
- Hold the device and pull up the suction cup forcefully until a gap appears, then insert an opening pick into the gap, as shown in Fig 3.



Use caution

Don't insert your opening pick deeper than 2.0 mm when you separate the adhesive, as it risks damaging the spring contacts.









BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Cut through the BG adhesive

- Slide your opening pick clockwise.
- Cut adhesive on the left edge where PSA is smaller, then open toward the hinge to separate the larger adhesive side.
- Use the large suction cup to hold the BG after you open the device.



Disassembly sequence


1 (insert opening pick with 2.0 mm) → 2 (2.0 mm) → 3 (2.0 mm) → 4 (5.0 mm)



Use caution

Don't fully remove the BG yet, as it's still connected by the flam board flex.





BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Detach the BG

- Remove three FCAM cowling screws with a torx plus 3IP screwdriver.
- Remove the **FCAM cowling** to reveal the **FLAM FPC B2B connector**.

Part: G250-08004-20 *3 (screws)


Part: G730-09675-00 (inner FCAM cowling)



Use caution

Don't reuse the screw.

Avoid to damage the adjacent battery, flex board, springs, and the connector underneath.




BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the BG

• Disengage **connector** and remove the **BG**.





BG sub: Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub



Vibrator with cowling

The vibrator with cowling is screwed to the enclosure.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

BG sub





Torx plus 3IP screwdriver




Vibrator with cowling

Here's the list of parts for the vibrator disassembly.









Reusable without cleaning

Reuse indications

Reusable after

cleaning

Not reusable after disassembly

Remove the graphite

- Peel the bottom of the **graphite sheet** and slowly move towards the top of the device.
- Part of the graphite sheet is lightly adhered to the copper foil on the logic board; peel it away slowly to avoid breaking the copper foil.

Part: G864-01067-00 (graphite sheet)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.

Don't reuse the part.



BG Sub Vibrator with cowling; mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the vibrator with cowling

Unscrew the **four vibrator cowling screws** with a torx plus 3IP screwdriver, and remove the vibrator with cowling.

Part: G250-08004-20 *4 (screws)

Part: G949-01536-00 (vibrator with cowling)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub



mmWave module and IF FPC

mmWave are the radio waves used to build a 5G network that provides fast and reliable mobile data with low latency for the latest devices.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that should be removed first:

BG sub



Torx plus 3IP screwdriver

Tweezers

Spudger

IPA and cloth

Dust-free cotton swabs




mmWave module and IF FPC


Here's the list of parts for the mmWave module and IF FPC disassembly.












Reuse indications


Reusable without you clean


Reusable after

you clean



Not reusable after disassembly







Remove the screws

- Remove **six screws** with a torx plus 3IP screwdriver.
- Remove the base bridge, the mmWave, and the ID cowlings.

Part: G250-06986-00 *1 (screw)

Part: G250-06623-00 *5 (screws)

Part: G730-09678-00 (base bridge cowling)

Part: G730-09676-00 (mmWave cowling)

Part: G730-09680-00 (ID cowling)



Use caution

Be cautious when you use the screwdriver. Avoid to damage the adjacent battery.

Incorrect use of the screwdriver might result in injuries to yourself or others, as well as damage to the battery or the product.



Note

Don't reuse the screws.



A: G250-06986-00

B: G250-06623-00

BG Sub Vibrator with Cowling mmWave Module and IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Disengage flexes

Disconnect the revealed **flexes** in the designated order with the **ESD spudge**r.



Disassembly sequence

1 (base battery) → 2 (base bridge bottom) → 3 (base bridge top) → 4 (inner display) → 5 (IF FPC)



Note

Use a spudger to avoid damage to the components.



BG Sub Vibrator with Cowling mmWave module and IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Remove the mmWave module and IF FPC

• mmWave module is lightly adhered to the enclosure. Insert a spudger to detach the **mmWave module**.

Part: G345-01633-02 (mmWave module)

Part: G652-10426-01 (IF FPC)



BG Sub Vibrator with Cowling mmWave module and IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub


Finished! Want assembly instructions? →

Disconnect the IF FPC

Separate the **IF FPC** from the **mmWave module**.

Part: G345-01633-02 (mmWave module)

Part: G652-10426-01 (IF FPC)



BG Sub Vibrator with Cowling mmWave module and IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Disassembly-Base Welcome Precautions Introduction User PF Repair Repair Flows Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software



Inner front camera

The inner front camera is fastened to the enclosure and connected to the logic board.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that should be removed first:

- BG sub
- Inner FCAM




Spudger



Inner front camera

Here's the list of parts for the inner front camera disassembly.







Finished! Want assembly instructions? →

Remove the inner FCAM

- Disconnect the inner front camera connector with the ESD spudger.
- Remove the inner front camera.

Part: G949-01530-00 (inner front camera)



Note

Use the **ESD spudger** to avoid damage to the components.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner front camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub



Bottom speaker

The bottom speaker is adhered to the enclosure. Be careful not to damage the speaker membrane.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

- BG sub
- Vibrator with cowling




Tweezers

Spudger

Torx plus 3IP screwdriver

IPA and cloth


Dust-free cotton swabs




Bottom speaker

Here's the list of parts for the bottom speaker disassembly.









Reusable without cleaning

Reuse indications

Reusable after

cleaning

Not reusable after disassembly

Remove the screw

- Remove the screw with a torx plus 3IP screwdriver.
- Detach the right end of the **conductive fabric** with a **spudger** or **tweezers**.

Part: G250-08005-12 (screw)

Part: G806-14375-00 (conductive fabric)



Note

Don't reuse the screw or conductive fabric.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the bottom speaker

Press the screw boss area with the point of the **ESD spudger** and pry up to eject the **bottom speaker**.

Part: G863-00646-00 (bottom speaker)



Use caution

Be careful to avoid damage to the components on the **bottom** speaker.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom speaker Logic Board Rear Camera Base Battery Inner Display Sub



Logic board

The logic board consists of the memory, storage, processor, and communication components such as Wi-Fi and mmW.



Use caution


Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that should be removed first:

- BG sub
- Vibrator with cowling
- mmWave module
- Inner front camera
- Bottom speaker



Universal holder #2

Universal holder limiting block #2

Universal supporting rubber

Pixel 10 Pro Fold-thermal grease alignment fixture-1 or -2


Torx plus 3IP screwdriver

Tweezers

Spudger


Dust-free cotton swabs


IPA and cloth




Logic board

Here's the list of parts for the logic board disassembly.









Reusable without you clean

Reuse indications

Reusable after you clean Not reusable after disassembly

Remove the logic board screws

Remove the **four logic board screws** with a torx plus 3IP screwdriver.

Part: G250-06623-00 *4 (screws)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Note

Don't reuse the screws.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Disconnect the FPS flex

- Peel off the Kapton tape covering the MLB ZIF connector, as shown in Fig 1.
- Open the latch with the ESD spudger, as shown in Fig 2.
- Apply **masking tape** to the top of the ribbon cable which creates a tab for better grip, as shown in **Fig 3**.
- Pull the tape downward forcefully to extract the ribbon cable from the ZIF connector.

Part: G806-14456-01 (FPS Kapton)



Note


To avoid damage to the cable, make sure that the masking tape is properly aligned with the top of the cable.




Note

Don't reuse the FPS Kapton.

Use a spudger to avoid damage to the components.







BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the logic board

- Use a **spudger** to pry up the **logic board** from the mmWave recess.
- The **logic board** is embedded in the USB slot. To release it, pull it upward toward the top of the device.

Part: multiple part numbers (logic board)



Use caution

Be careful to avoid damage to the components on the logic board.

Be careful not to touch other components with the thermal grease during removal.






Note

Don't wear gloves when you handle the logic board.

Grip the logic board with your fingers.





BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub



Rear camera

The rear camera module carries all the rear cameras. It's possible to replace a single camera.



Use caution

Review all safety precautions before you begin work.



Prerequisites


Here's the list of components that you should be removed first:

- **BG** sub
- Vibrator with cowling
- mmWave module
- Inner front camera
- **Bottom speaker**
- Logic board




Spudger


Tweezers





Rear camera

Here's the list of parts for the rear camera disassembly:












Reusable without you clean


Reuse indications


Reusable after you clean



Not reusable after disassembly









Remove the Kapton and cable

• Detach the **Kapton tape** between the WIDE and tele cameras, and unlatch the **coaxial cable connector** with **tweezers**.


Part: G806-13991-01 (cable Kapton)

Part: G821-01179-00 (coaxial cable RCAM)



Note

Don't reuse the coaxial cable and Kapton.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Disconnect the rear cameras


- Disconnect the **three rear camera connectors** from the **logic board** with a spudger.
- Slightly rotate the entire module counterclockwise, and remove the rear cameras from the logic board manually, as shown in Fig 3.
- Unlatch the **coaxial cable connector** on the other side of the logic board, as shown in **Fig 4**.





Use caution


The rear camera module has cables on both sides of the logic board.

Be cautious when you remove it to avoid damaging the springs.









BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →


Separate the cameras


The rear cameras feature a modular design. To separate the WIDE or UW cameras from the module, cover each lens with its cap and simply push from the lens side.


Part: G949-01532-00 (rear camera_UW)

Part: G949-01533-00 (rear camera_WIDE)

Part: G949-01531-00 (rear camera_tele)







BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Base battery



Use caution

Use caution if you engage in repair.

When you open or repair the device, be careful of electric shock, device damage, fire and personal injury risks, and other hazards.

Before you service the product, read the full set of **precautions** in this document.

Battery handling

- Never bend, dent, puncture, or use tools to pry the battery.
- Store batteries in the replacement part packaging as soon as possible after removal to prevent damage.
- If a battery begins to vent, cover it in sand or use gloves and tongs to keep the battery in a fire safe container as soon as possible.
- Take care to prevent shorting of battery terminals or damage the battery, as it could cause fire or overheating.
- Dispose of the battery according to the local regulations.

Confirm before you proceed

- The battery is fully discharged and the device is disconnected from all power sources.
- Inspect the battery to see whether the phone battery shows signs of <u>swelling</u>, <u>damage</u>, or if the phone feels hot or emits a strong odor. If so, <u>don't</u> attempt disassembly. Reach out to Google customer support instead.
- Take care not to expose the phone or its components to liquids after disassembled.

Repair Flows



Base battery

We recommend that you use the universal disassembly fixture to hold the device during the battery removal process.

It's recommended to remove the battery with a pull jacket.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

- BG sub
- Vibrator with cowling



Pixel universal disassembly fixture V3 -base Heat plate Pixel 10 Pro Fold spare dece clip - universal

Universal holder #2 dssy fixture V3

Universal holder Limiting Block #2 Adsorption-bulb

Universal supporting rubber Tweezers

Universal press plate 12 mm 3M AP111 primer

Battery press rubber (base side)

Universal press fixture


IPA and cloth

Dust-free cotton swabs



Base battery

Here's the list of parts for the base battery disassembly.







Base battery cell difference

	Battery cell source (ATL) G949-01539-00		Battery cell source (LWN) G949-01540-00	
Base battery GPN				
Model name and part no. printing	GU46C/ 8230061000		GU46C/ 8230061100	
Note 1. Always replace the base and flip batteries at the same time with the correct model name which is the same previous foldable phone projects. 2. Make sure, that the new content is the same projects.	▲ □ CAUTION-Risk of fire and burns. Do not open, crush, heat above 45°C, or incinerate. Read manual and follow instructions. 注意:電池有起火和燃烧风烧, 切奶拆除、桶屋、焚烧成加热至超过损任。45 度, 清除性便用, 注意。电池有起火和燃烧风险, 切奶拆除, 桶匠、焚烧成加热至超过损任。45 度, 浸水后进性便用, 请详解说明书并按照指示使用。 Rec argeable U+ion 处理。GU46C(1; 1945/26(2) Typical Capacity, 1352mAh/5.26Wh Nominal Volt Quality Catact Calcity(横隔帘服和铜窗室窗盖) 最多V+与132(2) Typical Capacity, 1352mAh/5.26Wh Nominal Volt Quality Catact Calcity(横隔帘服和铜窗室窗盖) 最多V+与132(2) Typical Capacity, 1352mAh/5.26Wh Nominal Volt Quality Catact Sutylefin Rapide Endish Last Propanesultone Critical Raw Materials: Bauxite. Cobalt, Fluorspar, Light Rare Earth Elements, Lithium, Phosphorus Zhejung Sumwed Electronic Co., Lid 法汇款投资金子有限公司 Made in China/中国製造中国制造。g.co/regulatory Google 1600 Amphitheatre Parkway, Mountain View, CA 94043 US g.co/pixelrepair	IS 16046 (Part 2)/ IEC 62133-2 R-41251445 WWW.bis.gov.in P\$ Li-ion00 MH46584 78 *** *** *** ** ** ** ** ** *	▲ CID CAUTION: Risk of fire and burns. Do not open, crush, heat above 45°C, or incinerate. Read manual and follow instructions. 注意: 電池有起火和燃烧風味, 切勿所解, 福田、技術或加热至超过損氏 45 度, 浸水 大き 1. 人名加 表达阅读明书并限情示使用。 注意: 电池有起火和燃烧风味, 切勿折解, 福田、技術或加热至超过損氏 45 度, 浸水 大き 1. 人名加 表达阅读明书并限情示使用。 Read Train 表达阅读明书并限情示使用。 Read Train 表达阅读明书并取情法示使用。 Read Train 表达阅读明书 Pals 2/62〕 Typical Capacity: 1352mAh/5.26Wh Nominal Volt (1872	IS 16046 (Part 2)/ IEC 62133-2 R-41251445 WWW.bis.gov.in Li-ion00 6 MAH45584 78 REVIEW 134500 14 1502 15 1
Make sure that the new base and flip battery are from the same cell source.	P- P	Back	P- P	Back





Examples of unacceptable battery conditions that aren't suitable for repair*











Pouch damage

Dent

Line protrusion


Scratch

Contamination mark

Dot protrusion









Bubbling Imprinted line

Swelling or electrolyte leakage

^{*}These are examples of potentially dangerous battery conditions but don't reflect all possible dangerous conditions. Follow the general safety guidance outlined in this document.

Unstick the pull jacket

- Use a pair of blunt nose tweezers or your fingers to peel the pull jacket away from the battery, as shown in **Fig 1**.
- The part of the pull jacket is folded under the green tabs. Unfold and pack them to cover partial of green tab by masking tape (size: 10mm * 20mm) to strengthen handling, as shown in Fig 2 and Fig 3.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.







BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Soften the glue

Place the unfolded device with the ID face down on the heat plate set to 158 °F (70 °C) for 10 minutes to soften the base battery adhesive.



Use caution


A heat plate is a hot surface. Use caution as it could cause burns.



Use caution

Use safety gloves to handle damaged displays as they could splinter during removal and cause injury. Apply protective liner to broken glass before removal.

Review all <u>safety precautions</u> before you begin work.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub


Adjust the pull jacket

- Secure the fixture on the working surface.
- Fold the device, and secure it on the fixture.
- Wear ESD finger cots to increase friction to prevent slipping.
- Move the pull jacket back and forth to scrape the bottom PSA entirely, don't over the yellow dot line.



Note

If the pull jacket breaks, **insert a new flip pull jacket** (G806-14434-00) through the opening on the lower side of the base battery and reheat the device 3 minutes if it feels cooled down.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the battery

- Grip the **pull jacket** with your fingers and pull straight up with steady force to separate the adhesive under the **base battery**.
- Gently remove the base battery and store it safely.

Part: multiple part numbers (base battery)



Use caution

Lift the battery as soon as the device leaves the heat plate before the adhesive cures.


keep small screws and sharp objects away from the battery.

Don't reuse the part.



Note

Wear finger cots to increase friction.



BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub



ID (inner display) sub Base side

If you reuse the ID sub, verify that any thermal paste or adhesive residue is completely removed.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

- BG sub
- Vibrator with cowling
- mmWave module
- Inner front camera
- **Bottom speaker**
- Logic board
- **Base battery**



Torx plus 3IP screwdriver

Tweezers

Spudger


Dust-free cotton swabs


IPA and cloth





Inner display sub (base side)

If you reuse the enclosure, verify that any thermal paste or adhesive residue is completely removed.












Reusable without you clean


Reuse indications


Reusable after you clean



Not reusable after disassembly

















Inner display sub (base side)

If you reuse the enclosure, verify that any thermal paste or adhesive residue is completely removed.





Remove the FPS support

- Remove the **two FPS support screws** with a torx plus 3IP screwdriver, as shown in **Fig 1**.
- Push the **FPS support** inward with the flat end of a spudger, as shown in **Fig 2**.
- Gently pry up and remove the FPS spacer-1 and the FPS spacer-2 with tweezers, as shown in Fig 3.

Part: G250-06986-00*2 (screw)

Part: G730-09651-01 (FPS support)

Part: G730-09645-01 (FPS spacer-1)


Part: G852-05081-01 (FPS spacer-2)



Note

Don't reuse the screw and the FPS support.

The inner display sub includes the FPS. Only perform this and the next step if the FPS is damaged.







BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Remove the FPS (power button)

- Push the FPS inward, as shown in **Fig 1** and push the FPS outward to remove the **FPS** module, as shown in **Fig 2**.
- Pull out the FPS module, as shown in **Fig 3** and release the FPS FPC slowly, as shown in **Fig 4**.


Part: multiple part numbers (FPS)




Note

Don't reuse the part.

The inner display sub includes the FPS. Only perform this step if the FPS is damaged.









BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the sidekey

- Release the sidekey FPC from the enclosure, as shown in Fig 1.
- Gently pull upward on the FPC to remove the **sidekey module**, as shown in **Fig 2**.
- Remove two VOL spacers from the enclosure slot, as shown in Fig 3.

Part: G949-01541-00 (sidekey module)


Part: G852-05079-01*2 (VOL spacer)




Note

Don't reuse the part.

The inner display sub includes the sidekey. Only perform this step if the sidekey is damaged.







BG Sub Vibrator with Cowling mmWave Module & IF FPC Inner Front Camera Bottom Speaker Logic Board Rear Camera Base Battery Inner Display Sub




Pixel 10 Pro Fold repair manual

Assembly-base

Inner display sub mmWave module and IF FPC Vibrator with cowling

Rear camera Bottom speaker Inner front camera

Logic board Base battery BG sub



ID (inner display) sub Base side

Replace the VOL and FPS CPSA

- Use a **spudger** to remove remaining adhesive from the **enclosure**. Clean with a **dust-free cloth** and **IPA**, as shown in **Fig 1**.
- Apply the FPS CPSA, VOL top and bottom CPSA to the designated position, as shown in Fig 2.
- Use a **spudger** to firmly press over the CPSA, to ensure strong adhesion.

Part: G806-13929-00 (FPS flex CPSA)

Part: G806-13930-00 (VOL CPSA_top)

Part: G806-13931-00 (VOL CPSA bottom)




Note

Don't remove the release liner yet.









A: G806-13929-00

B: G806-13930-00

C: G806-13931-00

Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Vibrator with Cowling Inner Front Camera BG sub

Assemble the FPS (power button)

- Fold the flex and insert the FPS flex from the slot through the middle frame, as shown in **Fig 1**.
- Push the button outward. Install the FPS spacer-1 and FPS spacer-2 into the slot of the middle frame with tweezers, as shown in **Fig 2**.

Part: multiple part numbers (FPS)


Part: G730-09645-01 (FPS spacer-1)


Part: G852-05081-01 (FPS spacer-2)



Note

The inner display sub includes the FPS and the sidekey. Only perform this and the next three steps if the FPS and the sidekey is damaged.





Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Assemble the FPS (power button)

- Tear off the two blue liners, as shown in Fig 1.
- Align the fixing hole and make sure that the white line is aligned with the shell, as shown in **Fig 2**.
- Assemble the FPS support to the designated position, as shown in Fig 3.
- Tighten the screws with the torx plus (3IP) screwdriver in a sequence.


Part: G730-09651-01 (FPS support)


Part: G250-06986-00*2 (screw)




Note

The inner display sub includes the FPS and the sidekey. Only perform this and the next three steps if the FPS and the sidekey are damaged.









Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Assemble the sidekey

- Tear off the two blue liners, as shown in Fig 1.
- Install the sidekey FPC to the middle frame and align the fixing holes, as shown in **Fig 2**.
- Insert the **VOL spacer** into the gap to fix the volume button, as shown in **Fig 3**.
- Push downward to fix the **VOL spacer** to the designated position, as shown in **Fig 4**.

Part: G949-01541-00 (sidekey)

Part: G852-05079-01 *2 (VOL spacer)





Note


Clean the rubber surface with dust-free cotton swabs before installation.











Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Reuse the ID sub or use new ID sub

- Use a spudger to remove remaining adhesive from the enclosure.
 Remove large chunks with fingers or tweezers. Clean with a dust-free cloth and IPA.
- Scrape thermal grease from enclosure areas with a spudger's flat end.
 Gently clean residue with a cloth.
- Remove **masking tapes** (no. 1 to 4) and the **wrap** on the **hinge** from the **base enclosure** for the new ID sub. Fold the liner of inner FCAM (no. 5) in advance to avoid interference with logic board assembling.

Part: G806-13943-00 (inner FCAM foam)



Use caution

Don't get conductive thermal grease on other components.

Don't use IPA to clean thermal grease.



Note

If the inner FCAM PSA sponge is damaged or broken, replace it with a new one.

Paste the PSA sponge along the upper left corner as shown in figure.









New ID sub

Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Clean off the thermal grease


- Use the flat end of a spudger to scrape away the old thermal grease from the **logic board**.
- For any residue, gently clean the surface with a dust-free cloth.



Use caution

Don't get conductive thermal grease on other components.

Don't use IPA.



Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub


Clean the base battery PSA residue


- Use a spudger's flat end to scrape up residue from the base battery area.
- Remove large adhesive chunks with your fingers or tweezers, then repeat for any remaining adhesive.
- Clean the base battery area with a dust-free cloth and IPA.



Note

The inner display subassembly includes the base battery PSA. Perform this step only when you reuse the inner display subassembly.





Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Replace the base battery PSA


- Apply the **base battery PSA** to the recess in the upper right corner.
- Use a **spudger** to firmly press over the PSA, to ensure strong adhesion.

Part: G806-15394-00 (base battery PSA)



Note

Don't remove the release liner yet.



Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Paste the mic 1 and mic 3 meshes

- Remove damaged mic 1 and mic 3 meshes.
- Wrap a spudger with a dust-free cloth. Dip it in IPA and clean up any residue.
- Attach new meshes to the designated position.

Part: G806-14011-00 *2 (mic mesh)




Use caution

Check the two meshes and replace them if they're damaged.

Make sure that the environment is clean for this process.



Inner display sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub



Rear camera

Assemble the rear cameras

• The rear cameras have a modular design. When you use a new **tele** camera module, remove the 2 blue liners.

Part: G949-01531-00 (rear camera tele)

Part: G806-13993-02 (UW cam bracket PSA)

Part: G806-13994-01 (WIDE cam bracket PSA)



Note

Replace the PSAs on the frame if they're damaged.



Inner Display Sub Rear camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Install the coaxial cable

- Turn the logic board to the back side, and latch the coaxial cable tip.
- Run the cable through the recess under the rear camera cutout and onto the front side.


Part: G821-01179-00 (coaxial cable RCAM)



Note

The logic board includes the coaxial cable.

Perform this step only if the cable is unlatched.



Inner Display Sub Rear camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Disassembly-Base Welcome Precautions Introduction User PF Repair Repair Flows Assembly-Base Disassembly-Flip Assembly-Flip Troubleshooting Software

Connect the rear cameras

- Install the rear camera_tele to the logic board, as shown in Fig 1.
- Install the rear camera_WIDE and rear camera_UW to the logic board and attach the connectors, as shown in Fig 2.
- Attach rear camera_tele connector to the logic board in Fig 3.

Part: G949-01532-00 (rear camera_UW)


Part: G949-01533-00 (rear camera WIDE)

Part: G949-01531-00 (rear camera tele)




Make sure that every connector is securely attached to the logic board.


Take a close look at the connectors from different angles to help you align them properly.







Inner Display Sub mmWave Module & IF FPC Vibrator with Cowling Inner Front Camera Logic Board **Bottom Speaker** Base Battery BG sub Rear camera



Logic board

Check the logic board



Use caution

Before you work on the logic board, check for spring deformation and damage to components near the edges.


Pay extra attention to the springs when you assemble to avoid damage to them.


General rules




















Inner Display Sub Rear Camera Logic board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Fasten the coaxial cable

- Gently press the coaxial cable into the channels on the logic board with tweezers, as shown in Fig 1.
- Latch the coaxial cable tip.
- Paste the Kapton between the WIDE and tele lenses, as shown in Fig 2.

Part: G821-01179-00 (coaxial cable RCAM)


Part: G806-13991-01 (cable Kapton)



Note

The logic board includes the coaxial cable.

Perform this step only if the cable is unlatched.





Inner Display Sub Rear Camera Logic board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Apply the masking tapes and grease guide


- Keep the **Pixel 10 Pro Fold thermal grease alignment fixture-2** on the enclosure.
- Keep the Pixel 10 Pro Fold thermal grease alignment fixture-1 on top of fixture-2, and secure it with masking tape, as shown in Fig 1.



Note

Use the C-shaped cutouts on the fixture for proper placement.

If any masking tape gets in the way, remove it first, keep the fixture, and then attach it back in place.







Alignment fixture-1

Inner Display Sub Rear Camera Logic board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Apply the thermal grease

- Apply small beads (0.1 g \pm 5%) of thermal grease into the two cutouts, holding the fixture with the other hand, as shown in **Fig 1**.
- Distribute the grease evenly with an **ESD spudger** or **EVA sponge**, moving in a single upward direction, as shown in **Fig 2**.
- Lift fixture-1 straight up to avoid contamination, as shown in Fig 3.

Part: G160-01058-00 (thermal grease)




Use caution

Review all safety precautions before you begin work.

Clean the Pixel 10 Pro Fold thermal grease alignment fixture-1 and ESD spudger after each use.

Avoid applying conductive thermal grease to nearby components.







Inner Display Sub Rear Camera Logic board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Apply the thermal grease (continued)

- Apply small beads (0.2 g \pm 5%) of thermal grease into the five cutouts, holding the fixture with the other hand, as shown in **Fig 1**.
- Distribute the grease evenly with an **ESD spudger** or **EVA sponge**, moving in a single upward direction, as shown in **Fig 2**.
- Lift fixture-2 straight up to avoid contamination, as shown in Fig 3.
- Remove all masking tape.

Part: G160-01058-00 (thermal grease)



Use caution

Review all safety precautions before you begin work.


Clean the Pixel 10 Pro Fold thermal grease alignment fixture-2 and ESD spudger after each use.

Avoid applying conductive thermal grease to nearby components.



Note

Use a dust-free cotton swab to clean up any excess thermal grease.









Inner Display Sub Rear Camera Logic board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Prepare for the assembly

- If you use a new ID sub, remove the mic 3, copper foil, vibrator, mic 1, and left bottom liners. Lift the inner FCAM liner.
- Lift the base top or bottom bridge FPC, inner display FPC, and fold the FPS FPC downward to prevent them from being trapped under the logic board.



Note

Remove masking tape from the inner display, base top bridge, base bottom bridge, and FPS connectors.


Leave the battery PSA liner in place.




Note


Clean the rubber surface with dust-free cotton swabs before installation.

Remove the mic protective liners on the logic board if you use a new logic board.









Reuse ID sub

New ID sub

Keep the logic board

- Keep a piece of **liner** on the mic1 mesh located in the lower left corner of the **logic board**.
- Insert the sticking out lower tip of the **logic board** into the USB slot to install it downward, and pull out the inserted liner.
- Install the **logic board** by gently pushing it to the left to prevent spring damage.
- Make sure that the **inner display FPC** passes through the gap between the **logic board** and the bottom of the **RCAM**.



Note

Don't wear gloves when you handle the logic board.

During installation, make sure that the base top bridge, base bottom bridge, and FPS cables aren't trapped under the logic board.




Note

Make sure that the logic board is properly installed sits against the alignment pins, as shown in **Fig 1**, and it sits against the retaining wall, as shown in **Fig 2** and **Fig 3**.









Inner Display Sub Rear Camera Logic board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Insert the FPS flex to ZIF connector


- Insert the FPS flex into the ZIF housing, to ensure full seating, as shown in **Fig** 1.
- Lock the latch for secure connection, as shown in Fig 2.
- Apply Kapton for insulate and protect, as shown in Fig 3.


Part: G806-14456-01 (FPS Kapton)





Note


Check if the FPS flex cable is fully seated in the housing.











Screw the logic board in place

- Tighten the four logic board screws.
- Tighten the screws a second time to make sure that there's firm attachment.


Part: G250-06623-00 *4 (screws)



Note

Don't reuse the screws.






mmWave module and IF FPC

Reuse the mmWave module

- Use a **spudger** to remove residual thermal pad and replace the new **thermal pad** between the two FOFs.
- Tear off the blue liner.

Part: G864-01047-00 (5G thermal pad)





Inner Display Sub Rear Camera Logic Board **mmWave Module and IF FPC** Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Connect the mmWave module and IF FPC

- Connect the IF FPC to the mmWave module.
- Keep the mmWave module and IF FPC onto the enclosure, and connect it to the logic board.

Part: G345-01633-02 (mmWave module)


Part: G652-10426-01 (IF FPC)



Note

Check if every connector is fully attached.







Screw the mmWave cowling

- Fasten the **mmWave cowling screws** with a torx plus 3IP screwdriver.
- Tighten the screws a second time to secure them in place.

Part: G730-09676-00 (mmWave cowling)

Part: G250-06623-00*2 (screw)

Part: G250-06986-00 (screw)



Note

Don't touch the flash spring.







A: G250-06623-00

B: G250-06986-00

Connect the base bridges

Connect the base top and bottom bridges to the logic board.



Note

Check if every connector is fully attached.




Connect the ID


Lift up the ID sub at a 45 degrees angle and buckle the connector from the right to left.



Note

Check if every connector is fully attached.





Inner Display Sub Rear Camera Logic Board **mmWave Module and IF FPC** Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Reuse the ID cowling

- Use a **spudger** to remove residual adhesive from the **cowling**.
- If residue remains, clean the surface with a **dust-free cloth** and **IPA**.
- Apply a new ID cowling PSA to the designated position, as shown in Fig 2.

Part: G730-09680-00 (ID cowling)

Part: G806-14384-00 (ID cowling PSA)



Note

The ID cowling comes with the PSA. Perform this step only when you reuse the part.



Install the base bridge and ID cowlings

- Insert the bridge of the **base bridge cowling** into the enclosure groove, as shown in **Fig 1**.
- Install the **ID cowling**, and make sure that the lower right and left end touches the retaining wall, as shown in **Fig 2** and **Fig 3**.
- Screw both cowlings into place with a **torx plus 3IP screwdriver**.
- Tighten the screws a second time for a secure fit.

Part: G730-09678-00 (base bridge cowling)


Part: G730-09680-00 (ID cowling)


Part: G250-06623-00*3 (screw)

Part: G806-14384-00 (ID cowling PSA)










Inner Display Sub Rear Camera Logic Board **mmWave module and IF FPC** Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub



Bottom speaker


Apply the bottom speaker tape

- If you reuse the **bottom speake**r, remove the adhesive with a spudger. Wrap a spudger with a **dust-free cloth**. Dip it in **IPA** to clean residue.
- Apply the conductive tape to the bottom speaker and align it with the curve in the upper left corner.
- Clean the **rubber** in the bottom with a dust-free cotton swab.

Part: G863-00646-00 (bottom speaker)

Part: G806-14375-00 (conductive fabric)





Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Attach the bottom speaker

- Remove any residual bottom speaker PSA and replace it with a new one
 if you reuse the enclosure.
- Tear off the blue liner.
- Install the **bottom speaker** at an angle under the **enclosure rim**.
- Press down for six seconds.

Part: G806-13932-00 (bottom speaker CPSA)






Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub

Secure the bottom speaker


- Tighten bottom speaker screw.
- Tighten the screws a second time for a secure fit.
- Remove the conductive tape liner and ID cowling liner.
- Peel off the liner from the opposite side of the conductive tape and paste on the designated position, as shown in **Fig 1**.

Part: G250-08005-12 (screw)





Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom speaker Base Battery Vibrator with Cowling Inner Front Camera BG sub



Base battery


Apply the 3M AP111 primer

- Apply IPA around the enclosure's edges with a dust-free cotton swab.
- Apply one round of **3M AP111 primer** around the **enclosure**'s edges with a **dust-free cotton swab**.



Use caution

After the primer is applied, complete the assembly in 25 minutes.



Align the BG PSA

- Slowly remove the larger liner from the **adhesive sheet** to expose the adhesive.
- Keep the sheet over the device, to align it with the top side of the **enclosure**.

Part: **G806-14457-00** (BG PSA)



Use caution

Don't touch the adhesive.

If it gets dirty, replace it.



Activate the adhesive

- Make sure that the **adhesive** is fully seated on the **enclosure**.
- Activate it with a **spudger**.





Remove the liner (first layer)

Pull the tab carefully to remove the liner.



Use caution

Don't lift the adhesive.

Don't remove the second layer of the liner.



Grab the tab here.

Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base battery Vibrator with Cowling Inner Front Camera BG sub

Apply the AP111 primer

- Remove debris and loose screws from the enclosure before you install the base battery.
- Peel off the blue liner.
- Apply AP111 across the base battery's back side, excluding the pull jacket.

Part: multiple part numbers (base battery)



Use caution

Review all safety precautions before you begin work.

Make sure that the battery cosmetic checks are completed.





Position the base battery

- Confirm the battery model to be **GU46C**, as shown in **Fig 1**. If the model number isn't **GU46C**, please *don't* use the battery.
- Use an adsorption bulb with a smaller suction cup to pick up the battery.
- Align it to the **upper-right** corner of the depression and push it to upper side and right side as much as possible.
- Remove the adsorption bulb and the white liner carefully.



Use caution

Review all safety precautions before you begin work.



Note

The white liner ensures that the battery is in the correct position.

Don't remove it prior to the installation.





Note

Don't use the suction cup on the pull jacket.




Fig 1





Inner Display Sub

Rear Camera

Logic Board

mmWave Module & IF FPC

Bottom Speaker

Base battery

Vibrator with Cowling

Inner Front Camera

BG sub

Press the base battery

- Keep the universal supporting rubber #2 on the universal holder #2, and keep the universal Holder limiting block #2 on top.
- Keep the fixture in position B2 on the universal base.
- Keep the Pixel 10 Pro Fold base battery press rubber on top of the universal holder #2, as shown in Fig 1.
- Keep the universal press plate 12 mm on the Pixel 10 Pro Fold base battery press rubber, as shown in Fig 2.
- Keep it in the universal press fixture. Press the handle down for 25 seconds, as shown in Fig 3.




Fig 2

base



Universal



Use caution


Keep hands clear during operation.



Note

Make sure that all protective films are removed before you press.

Inner Display Sub **Base battery** Inner Front Camera Rear Camera Logic Board mmWave Module & IF FPC **Bottom Speaker** Vibrator with Cowling BG sub



Vibrator with cowling

Apply the graphite sheet

- Align the **graphite sheet** with the outline.
- Press down on the **adhesive** to secure it and remove air pockets.
- Remove the liner.

Part: G864-01067-00 (graphite sheet)



Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery **Vibrator with cowling** Inner Front Camera BG sub

Apply the RF sponge

- Attach the **RF sponge**, to ensure that the slanted corner aligns with the slanted side of the triangle.
- Carefully remove the liner.

Part: G806-15352-00 (RF sponge)



Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery **Vibrator with cowling** Inner Front Camera BG sub

Connect to the logic board

Connect the base battery to the logic board.



Note

Make sure that the connector is securely attached to the logic board.



Place the vibrator with cowling

- Install the **vibrator with cowling** at an angle to the left so it goes under the hook, as shown in **Fig 1**.
- Tighten the four vibrator cowling screws.
- Tighten the screws a second time to ensure that there's a firm attachment.

Part: G949-01536-00 (vibrator with cowling)

Part: G250-08004-20 *4 (screws)



Use caution

Be careful when you use the screwdriver. Don't damage the adjacent battery.

Incorrect use of the screwdriver might result in injuries to yourself or others, along with the damage to the battery or the product.



Note


Tear off the blue liner if you use new vibrator with cowling.







Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery **Vibrator with cowling** Inner Front Camera BG sub



Inner front camera

Attach the inner FCAM

- Remove the inner FCAM cap and protective film before installation, if you use a new inner FCAM or new ID sub.
- Assemble the inner FCAM in the enclosure slot.
- Connect the inner FCAM connector to the logic board.

Part: G949-01530-00 (inner front camera)




Note

Check if every connector is fully attached to the logic board.



Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner front camera BG sub



BG (back glass) sub

Reuse the BG

- Use a **spudger** to remove glue from the **BG**.
- Use fingers or **tweezers** to remove large **adhesive** chunks. Repeat for any adhesive.
- If residue remains, clean the surface with a dust-free cloth and IPA.

Part: multiple part number (BG sub)





Apply the AP111 primer

- Apply **IPA** around the **BG** sub's edges with a **dust-free cotton swab**.
- Apply one round of **3M AP111 primer** around the edges with a **dust-free cotton swab**.


Part: multiple part number (BG sub)



Use caution

After the primer is applied, complete the assembly in 25 minutes.






Connect the flam board

- Place the **BG** on top of the **enclosure** and prop up the BG sub.
- Apply even pressure with tweezers to connect the flam board to the logic board.



Note

Remove masking tape from a new BG






Use caution

When you attach the BG, **don't** damage or deform the FPC.

Check if every connector is fully attached to the **logic board**.



Check the display

- Remove the inner display process protective film.
- Power on with ESD spudger and **wait at least 10 seconds** to check if the device works properly. Power off after check.




Use caution

Don't touch the ID's TP until it turns to the **welcome page** since touch panel self calibration is in progress.

Follow the instruction: **TP calibration note**





Pixel 10 Pro Fold Repair Manual v1.0 ©Google 2025 | Page 181

Reuse the inner FCAM cowling

• Apply a new **alignment mylar** to the designated position, as shown in **Fig 2**.

Part: G730-09675-00 (inner FCAM cowling)


Part: G806-16220-00 (alignment mylar)



Note

The inner FCAM cowling comes with the alignment mylar. Perform this step only when you reuse the part.





Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG Sub

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 182

Secure the inner FCAM cowling

- Place the **FCAM cowling** on the **flam board FPC**, to cover the **connector**.
- Tighten the screws with a **torx plus 3IP screwdriver**.

Rear Camera


Logic Board

- Tighten them again for secure placement.
- Remove the alignment mylar.


Part: G730-09675-00 (inner FCAM cowling)

Part: G250-08004-20 *3 (screws)

Inner Display Sub



mmWave Module & IF FPC





Pixel 10 Pro Fold Repair Manual v1.0 ©Google 2025 | Page 183

Base Battery

Bottom Speaker

Remove the caps and liners


- Use **tweezers** to remove the **RCAM caps** from the new RCAM modules.
- Use tweezers to grab the second layer of the BG liner and two ID cowling blue liners carefully pull it away.

Part: G806-14457-00 (BG PSA)




Note

Remove RCAM lens and vent liner from a new BG.







Inner Display Sub Rear Camera Logic Board mmWave Module & IF FPC Bottom Speaker Base Battery Vibrator with Cowling Inner Front Camera BG Sub

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 184

Press the BG


- Align the **BG** vertically on the **enclosure**.
- Press around it with both hands.



Note

Press the top middle side first, then follow with the two long sides and the bottom side.





Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 185

Press the BG

- Place the universal supporting rubber #2 on the universal holder #2, and place the universal holder limiting block #2 on top.
- Place the fixture in position D2 on the universal base.
- Apply the Pixel 10 Pro Fold BG press rubber on top of the universal holder #2, as shown in Fig 1.
- Place the universal press plate 12 mm on the press rubber, as shown in Fig 2.
- Place it in the universal press fixture and press the handle down for 45 seconds, as shown in Fig 3.



Use caution

Keep hands clear during operation.



Note

Make sure that all protective films are removed before you press.




Note

Make sure that the Pixel universal holder is in the right position.









Inner Display Sub Logic Board mmWave Module & IF FPC Vibrator with Cowling Inner Front Camera **BG Sub** Rear Camera **Bottom Speaker** Base Battery

Pixel 10 Pro Fold Repair Manual v1.0 @Google 2025 | Page 186




Pixel 10 Pro Fold repair manual

Disassembly flip

Outer display Outer front camera

Lower board Flip battery

Upper board Inner display sub



OD (outer display) sub

The outer display module is connected to the lower board, so be careful with the flex when you open the device up.



Use caution

Use safety gloves when you handle damaged displays as splinters during removal could cause injury.

Apply protective film to broken glass before removal.

Review all safety precautions before you begin work.



Prerequisites

Before you begin a repair, be sure to **power off** the device and disconnect any charging cables.



Tools

Pixel 10 Pro Fold main holder

Pixel 10 Pro Fold OD press rubber

Pixel universal base

Universal press plate 12 mm

Universal press fixture

Opening pick

Large suction cup

Torx plus 3IP screwdriver

Tweezers

Spudger

3M AP111 primer

Absorption bulb


IPA and cloth


Dust-free cotton swabs



Outer display

The outer display module is connected to the lower board, so be careful with the flex when you open the device up.











Reuse indications

Reusable without

cleaning

Reusable after

cleaning

Not reusable after disassembly

Locate the driver IC

- Before you remove the **outer display module**, be aware that there's a **driver IC** underneath.
- Avoid any damage to the **driver IC (COF area)** during the disassembly process.



Outer Display/Lower BoardUpper BoardOuter Front CameraFlip BatteryInner Display Sub

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 190

Mark the opening pick

- Use an opening pick to separate the OD from the enclosure. If you insert it too far, it could damage your device.
- Measure 2.0 mm from the tip and mark the opening pick with a permanent mark.

Lower Board


Upper Board



Use caution

Outer Display/

Follow the steps to mark your pick and prevent damage.



Flip Battery

Outer Front Camera

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 191

Inner Display Sub

Separate the OD

- Apply a suction cup to the OD, as close to FCAM side, as shown in **Fig 1**.
- Use one hand to firmly hold the device. With the other hand, strongly pull up the large suction cup to create a gap between the OD and the enclosure, as shown in **Fig 2**. Make sure that the device isn't open.
- Insert the opening pick into the gap, as shown in Fig 3.



Use caution

Don't insert your opening pick deeper than 2 mm when you separate adhesive, as you risk damage to the display.









Outer Display/Lower BoardUpper BoardOuter Front CameraFlip BatteryInner Display Sub

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 192

Detach the OD

- Slide your **opening pick** clockwise.
- Open toward the **hinge** to separate the adhesive.
- Turn over the OD. Use the **suction cup** to hold it after the device is open.



Disassembly sequence


1 (insert opening pick with 2.0 mm) \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5



Use caution

Don't fully remove the OD yet, as it's still connected to the device by the OD flex.







Outer Display/Lower BoardUpper BoardOuter Front CameraFlip BatteryInner Display Sub

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 193

Remove the OD cowling

- Remove **three OD cowling screws** with a torx plus 3IP screwdriver, as shown in **Fig 1**.
- Remove the **OD cowling**.

Part: G250-08248-00 (screw)

Part: G250-08005-21 (screw*2)

Part: G730-09622-01 (OD cowling)



Note

Don't reuse the screws.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Finished! Want assembly instructions? →


Disconnect the OD

- Disconnect the **flip battery** with a spudger.
- Loosen the **OD** connector with a spudger and then remove the **OD**.




Note

Use a spudger to avoid damage to the components.



Assembly-Base Disassembly-Flip Software Welcome Precautions Introduction User PF Repair Repair Flows Disassembly-Base Assembly-Flip Troubleshooting



Lower board

The lower board communicates with the components, such as the flip battery, lower bridge FPC, and the outer display.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

Outer display



Torx plus 3IP screwdriver

Spudger


Feeler gauge 0.25t

Dust-free cotton swabs




Lower board

Here's the list of parts for the lower board disassembly.












Reuse indications

Reusable without cleaning



Reusable after cleaning

Not reusable after disassembly

Remove the screws and cowling

- Remove the two **flip bridge cowling screws** with a torx plus 3IP screwdriver.
- Remove the **flip bridge cowling** along with the **conductive tape** attached to it.

Part: G730-09662-00 (flip bridge cowling)

Part: G250-08002-10 (screw*2)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Note

Don't reuse the screws.



Disconnect the flip bridge and ANT 1

- Disconnect the **flip bridge bottom** and **top connectors** with a spudger.
- Disconnect the **ANT 1 connector** with a spudger.
- Apply masking tape to the flip bridge and ANT 1 connectors to avoid damage.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.





Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 199

Detach the rubber and conductive tape

Remove the **rubber** and the **conductive tape** below with a **spudger**.

Part: G806-15616-00 (bottom rubber)

Part: G806-14472-00 (conductive tape)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Note

Don't reuse the parts.



Remove the lower board

- Slightly lift the **lower board** with a spudger, as shown in **Fig 1**.
- Insert a 0.25 mm **feeler gauge** and slide upwards to cut the **PSA** attached to the lower board near the left edge of the enclosure, as shown in **Fig 2**.
- Gently remove the lower board with your bare hand.

Part: G949-01534-00 (lower board)




Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.

There are **six adhesive areas** behind the lower board. Handle with care to prevent damage or distortion.







Upper board

The upper board consists of the p sensor, light sensor, and communication components, such as the SIM card, upper bridge FPC, and the outer front camera.

Be aware that a replacement SIM tray doesn't have the IMEI number present.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

Outer display




SIM card pin

Torx plus 3IP screwdriver

Feeler gauge 0.25t


Spudger

Tweezers





Upper board


Here's the list of parts for the upper board disassembly.












Reusable without cleaning

Reuse indications

Reusable after cleaning



Not reusable after disassembly



Remove the SIM tray and detach pull jacket

- Eject the **SIM tray** with an **ejector pin**.
- Detach the flip battery pull jacket from the upper board with a spudger.

Part: multiple part numbers (SIM tray)

Part: G806-14434-00 (pull jacket)





Remove the screw, rubber and tape

- Remove the upper board screw with a torx plus 3IP screwdriver.
- Remove the **rubber** and the **conductive tape** with a **spudger**.

Part: G250-08003-10 (screw)

Part: G806-15617-00 (upper rubber)

Part: G806-14472-00 (conductive tape)



Note

Don't reuse the parts.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Remove the upper board

- Slightly lift the **upper board** with a spudger, as shown in **Fig 1**.
- Insert a 0.25 mm **feeler gauge** and slide downwards to cut the **PSA** attached to the upper board near the left edge of the enclosure, as shown in **Fig 2**.
- Gently remove the **upper board** with your bare hand.

Part: G949-01535-00 (upper board)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.

There's one **adhesive area** behind the upper board. Handle with care to prevent damage or distortion.





Finished! Want assembly instructions? →

Inspect the P-sensor rubber

- Inspect the **P-sensor rubber**.
- If it's damaged, remove it. If it isn't damaged, leave it in place.

Part: G806-14452-01 (P-sensor rubber)




Note


Don't reuse the P-sensor rubber after removal.



Use caution

Skip this step if the P-sensor rubber is undamaged or intact.





Outer front camera

The outer front camera isn't fastened to the enclosure, it's simply connected to the upper board.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

- Outer display
- Upper board




Spudger



Outer front camera

Here's the list of parts for the outer front camera disassembly.





Finished! Want assembly instructions? →

Remove the outer front camera


Disconnect the **outer front camera** with a **spudger**.


Part: G949-01529-00 (outer front camera)



Note

Use a spudger to avoid damage to the components.





Flip battery

Precautions



Use caution

Use caution if you engage in repair.

When you open or repair the device, be careful of electric shock, device damage, fire and personal injury risks, and other hazards.


Before you service the product, read the full set of **precautions** in this document.

Battery handling

- Never bend, dent, puncture, or use tools to pry the battery.
- Store batteries in the replacement part packaging as soon as possible after removal to prevent damage.
- If a battery begins to vent, cover it in sand or use gloves and tongs to keep the battery in a fire safe container as soon as possible.
- Take care to prevent shorting of battery terminals or battery damage, as it could cause fire or overheating.
- Dispose of the battery according to local regulations.

Confirm before you proceed

- Battery is fully discharged and the device is disconnected from all power sources.
- Inspect the battery to see whether the phone battery shows signs of <u>swelling</u>, <u>damage</u>, or if the phone feels hot or emits a strong odor. If so, <u>don't</u> attempt disassembly. Reach out to Google customer support instead.
- Take care, not to expose the phone or its components to liquids after disassembly.



Flip battery

We recommend that you use the universal disassembly fixture to hold the device when the battery removal is in process.

It's recommended to remove the battery with a pull jacket.



Use caution

Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

- Outer display
- Lower board



Heat plate

Universal holder #2

Universal holder limiting block #2

Universal supporting rubber

Universal press plate 12 mm

Battery press rubber (flip side)

Universal press fixture

Pixel universal disassembly fixture

V3 -base

Pixel 10 Pro Fold spare dece clip universal dssy fixture V3

Adsorption-bulb

Tweezers

3M AP111 primer


IPA and cloth

Dust-free cotton swabs




Flip battery

Here's the list of parts for the flip battery disassembly.









Flip battery cell difference


	Battery cell source (ATL)		Battery cell source (LWN)	
Flip battery GPN	G949-0153 7 -00		G949-0153 <mark>8</mark> -00	
Model name and part no. printing on the battery.	G3M28/ 8230060800		G3M28/ 8230060900	
	Google Δ CD CAUTION. Risk of fire and burns. Do not open, crustly, heat above 45°C, or incontrols. Risk of fire and burns. Do not open, crustly, heat above 45°C, or incontrols. Risk in State of the Company of the	Li-ion 00		Li-ion 00
 Note 1. Always replace the base and flip batteries at the same time with the correct model name which is the same previous foldable phone projects. 2. Make sure that the new base and flip battery are from the same cell source. 	Treat Treat Treatment of the Property of the P	IS 16046 (Part 2)/ IEC 62133-2 R-41251445 www.bis.gov.in -ATL 3: \$9V+ 4: 13Wh 1898 Back	Front Front Form Form	IS 16046 (Part 2)/ IEC 62133-2 R-41251445 www.bis.gov.in Back



Examples of unacceptable battery conditions that aren't suitable for repair







Line protrusion

Bubbling




Scratch


Imprinted line



Contamination mark




Dot protrusion



Dent









Swelling or electrolyte leakage

^{*}These are examples of potentially dangerous battery conditions but don't reflect all possible dangerous conditions. Follow the general safety guidance outlined in this document.

Release the pull tab and adjust pull jacket

- Slightly pull the **pull tab** downward with tweezers and wrap it around the tweezers. Repeat to release it from under the **flip battery**, as shown in **Fig 1**.
- Partially the pull jacket is folded under the green ends. Unfold and pack it to cover partial of the green tab by masking tape (size: 10 mm * 20 mm) to strengthen handling, as shown in Fig 2.
- Pull up the upper side of the jacket to lift up the battery a little bit and then
 move the jacket to the left of the battery. Stop at the yellow line, as shown in
 Fig 2.

Part: G806-17439-01 (bond PSA)

Part: G806-14434-00 (pull jacket)



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Note

Add tape to the flip bridge cowling area to protect the pull jacket from sharp objects, ensuring it moves freely.







Soften the adhesive

With the device unfolded, place the device **ID** face down on the **heat plate** set to **158°F (70°C) for 10 minutes** to soften the **flip battery** adhesive.



Use caution

The heat plate is a hot surface. Use caution as it could cause burns.



Use caution

Use safety gloves to handle damaged displays as they could splinter during removal and cause injury. Apply protective liner to broken glass before removal.

Review all <u>safety precautions</u> before you begin work.



Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub

Secure the device

- Secure the fixture on the working surface.
- Fold the device, and secure it on the fixture.



Use caution

The heat plate is a hot surface, so caution to avoid burns.



Outer Display Lower Board Upper Board Outer Front Camera **Flip Battery** Inner Display Sub

Adjust the pull jacket

Pull the **pull jacket** back and forth to move the left end toward the bottom of the **flip battery**.



Use caution

Avoid use of sharp objects or tools to prevent damage to the **battery**.



Note

The back-and-forth motion cuts through the adhesive under the flip battery.

It might require some strength.
Wear finger cots to increase
friction.



Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the battery

- Insert a 0.05 mm liner in the lower right corner, as shown in **Fig 1**, then move the **bottom pull jacket** behind the liner. Reheat the device 3 minutes, if it feels cooled down.
- Pull the **pull jacket** back and forth upward to cut through the top-right adhesive under the **flip battery**.
- Gently remove the **flip battery** and store it safely.

Part: multiple part numbers (flip battery)



Use caution

Lift the battery as soon as the device leaves the heat plate before the adhesive cures.

keep small screws and sharp objects away from the battery.


Don't reuse the part.




Note


Wear finger cots to increase friction.

If the pull jacket breaks, **insert a new one** (G806-14434-00) through the opening at the lower side of the battery and reheat the device 3 minutes, if it feels cooled down.





Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub



ID (inner display) sub

If you reuse the inner display sub (flip side), ensure that any adhesive residue is completely removed.



Use caution


Review all safety precautions before you begin work.



Prerequisites

Here's the list of components that you should remove first:

- Outer display
- Lower board
- Upper board
- Flip battery




Torx plus 3IP screwdriver

Spudger

Tweezers

IPA and cloth

Dust-free cotton swabs





Inner display sub (flip side)


Here's the list of parts for the inner display sub disassembly.











Reusable without

Reuse indications


Reusable after

cleaning




Not reusable

after disassembly
















Inner display sub (flip side)


Here's the list of parts for the inner display sub disassembly.












Reusable without

cleaning

Reuse indications

Reusable after

cleaning



Not reusable after disassembly





Remove the top speaker screw

Remove the **top speaker screw** with a torx plus 3IP screwdriver.

Part: G250-08003-10 (screw)



Note

Don't reuse the screw.




Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub

Remove the top speaker

- Insert an ESD spudger under the **shielding bracket** to pry up the **top speaker**, as shown in **Fig 1**.
- Lift the **top speake**r to the left, detach the **contact pad**, and remove the module, as shown in **Fig 2**.

Part: G949-01544-00 (top speaker with ANT 4 FPC)





Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub

Remove the ANT 1 FPC screw

Remove the ANT 1 FPC screw on the wall with a torx plus 3IP screwdriver.

Part: G250-06986-00 (screw)



Note

Don't reuse the screw.



Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub

Finished! Want assembly instructions? →

Remove the ANT 1 FPC


Unstick the ANT 1 FPC from the connector and remove it completely.

Part: G949-01545-00 (ANT 1 FPC)



Note

Don't reuse the part.



Outer Display Lower Board Upper Board Outer Front Camera Flip Battery Inner Display Sub




Pixel 10 Pro Fold repair manual

Assembly flip

Inner display sub Lower board

Outer front camera Flip battery

Upper board Outer display



ID (inner display) sub Flip side

Prepare for ANT 1 FPC attachment

- Use a **spudger** to remove residual glue from the enclosure.
- If there's still residue, clean the surface with a dust-free cloth and IPA.
- Apply the **ANT 1 CPSA**, folding it along the enclosure frame, as shown in **Fig 1**.
- Attach the ANT 1 PSA 1, ANT 1 PSA 2, and ANT 1 PSA 3, as shown in Fig 2.
- Remove the liners.

Part: G806-13628-01 (ANT 1 CPSA)

Part: G806-13625-01 (ANT 1 PSA 1)

Part: G806-13626-01 (ANT 1 PSA 2)


Part: G806-13627-01 (ANT 1 PSA 3)



Note

The inner display sub includes the ANT 1 FPC.

Perform this step only if the ANT 1 FPC is damaged.








A: G806-13628-01

B: G806-13627-01

C: G806-13626-01

D: G806-13625-01



Install the ANT 1 FPC

- Attach the **ANT 1 FPC** to the **inner display sub**, follow the sequence to assemble. Fold the middle part along the retaining wall to the bottom.
- Press down for 5 seconds.

Part: G949-01545-00 (ANT1 FPC)




Note


The inner display sub includes the ANT 1 FPC.

Perform this step only if the ANT 1 FPC is damaged.

Make sure that the flex fits around the three positioning posts, as shown in **Fig 1** and **Fig 2**.







Attach the ANT 1 FPC

- Tear off the liner and apply the ANT 1 bracket to the positioning hole.
- Tighten the **screw** with a torx plus 3IP screwdriver.
- Tighten the screw a second time for a secure fit.


Part: G730-09634-01 (ANT 1 bracket)

Part: G250-06986-00 (screw)



Note

The inner display sub includes the ANT 1 FPC. Perform this step only if the ANT 1 FPC is damaged.



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Reuse the top speaker

- Remove residual adhesive with an ESD spudger, as shown in Fig 1.
- Clean the surface with a dust-free cloth dampened with IPA.
- Apply the **top speaker CPSA** and **contact pad PSA** according to the outline, as shown in **Fig 2**.
- Tear off the liners.

Part: G806-14305-00 (TSPK CPSA)


Part: G806-14307-01 (pad PSA)




Note

The inner display sub includes the top speaker with ANT 4 FPC.

Perform this step only if the top speaker is damaged.





Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Attach the top speaker

- Install the **top speaker** to the **enclosure** and press it to make sure that it fits completely, as shown in **Fig 1**.
- Fix the pad according to the designated position, as shown in **Fig 2**. Tighten the **screw** with a torx plus 3IP screwdriver. Tighten the screw a second time for a secure fit.
- Tear off the blue liner if you use the new top speaker.


Part: G949-01544-00 (top speaker with ANT 4 FPC)

Part: G250-08003-10 (screw)









Replace the board PSA

Replace the six lower board PSAs and one upper board PSA.

Part: G806-13629-01 (lower PCB PSA-1) *2

Part: G806-13630-01 (lower PCB PSA-2)*2

Part: G806-13631-01 (lower PCB PSA-3)

Part: G806-14387-01 (lower PCB PSA-6)

Part: G806-14959-00 (upper PCB PSA)



Note

The inner display sub includes the PSAs. Perform this step only if the OD sub is disassembled.

Don't remove the release liner just yet.



A: G806-13630-01

B: G806-13629-01

C: G806-13631-01

D: G806-14387-01

E: G806-14959-00

Reuse the ID sub or use new ID sub

- Use a **spudger** to remove remaining adhesive from the **enclosure** and **flip battery** area.
- Remove large chunks with fingers or tweezers. Clean with a dust-free cloth and IPA.
- Remove masking tapes, liners (no. 1 to 4) and the wrap on the hinge from the flip enclosure for the new ID sub.



Use caution

Be careful to avoid damage to the foam on the enclosure side during deglue the residual glue.



Note


The inner display subassembly includes the flip battery PSA.
Perform this step only when need to reusing the inner display subassembly.



Note

The yellow highlight is where the residual adhesive exists.







Reuse ID sub

New ID sub

Place flip battery PSA

- Paste the **flip battery PSA** along the upper-right corner.
- Paste the pull tab along the retaining wall in the lower right, and make sure that the black dot is in the center.
- Run a spudger over the PSA to strengthen adherence.


Part: G806-15380-01 (flip battery PSA)


Part: G806-17439-01 (flip battery bond PSA)



Note

Don't remove the release liner just yet.





Outer front camera

Attach the outer front camera


Latch the outer FCAM connector to the **upper board**.


Part: G949-01529-00 (outer front camera)



Note

Make sure that the connector is fully attached to the **upper board.**





Upper board

Place the upper board

- Tear off the blue liner, as shown in **Fig 1**.
- Push the **upper board** upward at an angle to install it onto the enclosure, as shown in **Fig 2**.


Part: G949-01535-00 (upper board)



Note

Install the upper board under the hook. Refer to the relative position.





Install the SIM tray and upper board

- Insert the SIM tray into the slot.
- Fasten one upper board screw with a **torx plus 3IP screwdriver**, tightening twice.

Part: multiple part numbers (SIM tray)

Part: G250-08003-10 (screw)



Note

Wear a glove when handling the SIM tray; on the contrary, don't wear gloves when handling the upper board.



Note

Clean the rubber surface with dust-free cotton swabs before installation.





Apply the P-sensor rubber

Apply the P-sensor rubber to the upper board and check for misalignment.

Part: G806-14452-01 (P-sensor rubber)




Note


Skip this step if the rubber is intact.

Make sure that the rubber is properly aligned.









Lower board

Place the lower board

- Remove the liners from the six lower board PSAs, as shown in Fig 1.
- Push the **lower board** downward at an angle to install it onto the enclosure, as shown in **Fig 2**.
- Make sure that the lower board sits against the alignment pins and the retaining wall, as shown in Fig 3.

Part: G949-01534-00 (lower board)




Note

Remove remaining adhesive from the lower board.







Inner Display Sub Outer Front Camera Upper Board **Lower Board** Flip Battery Outer Display

Apply the conductive tapes

Attach the **conductive tapes** to the indicated areas.

Part: G806-14472-00 (conductive tape)*2



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Connect upper, lower and ANT 1 boards

Snap the ANT 1, flip top and bottom bridge FPC connectors.



Note

Check that three connectors are fully engage to the **lower board** and the **upper board**.



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Reuse the flip bridge cowling

- Tear off the conductive tape. Use a **spudger** to remove residual adhesive from the **cowling**.
- If residue remains, clean the surface with a **dust-free cloth** and **IPA**.
- Apply a new **conductive tape** to the designated position, as shown in **Fig 2**.

Part: G730-09662-00 (flip bridge cowling)


Part: G806-14461-00 (conductive tape)



Note

The flip bridge cowling comes with the conductive tape. Perform this step only when you reuse the part.





Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Install the flip bridge cowling and rubbers

- Insert the bridge of the **flip bridge cowling** into the enclosure groove, as shown in **Fig 1**.
- Fasten the two flip bridge cowling screws with a torx plus
 3IP screwdriver, as shown in Fig 2.
- Tear off the blue liner of conductive tape and paste on the enclosure.
- Attach the two rubber strips onto the upper and lower boards, as shown in Fig 3.

Part: G730-09662-00 (flip bridge cowling)

Part: G250-08002-10 (screw*2)

Part: G806-14461-00 (conductive tape)

Part: G806-15617-00 (upper rubber)

Part: G806-15616-00 (bottom rubber)




Fig 2



Fig 3



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display



Flip battery

Remove the liners

- Remove any debris or loose screws from the **enclosure** before the procedure.
- Apply pressure on the **adhesive** strips with a **spudger** or fingers for proper adhesion.
- Remove the blue **liners** and **masking tapes** if you use a new ID sub.
- Remove the blue liner.



Use caution

Review all safety precautions before you begin work.

Make sure that the battery cosmetic checks are completed.







New ID sub

Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Apply pull jacket

- Attach the **pull jacket** so that it aligns with the **pull tab** and the left edge of the enclosure. Ensure that it attaches vertically next to the SIM slot.
- Remove the blue liners of the pull jacket and pull tab.

Part: G806-14434-00 (pull jacket)



Note

Peel off the liner from the opposite side of the removal tab.






Use caution

Review all safety precautions before you begin work.

Make sure that the battery cosmetic checks are completed.





Apply the AP111 primer

Evenly apply the primer across the flip battery's entire back surface.

Part: multiple part numbers (flip battery)



Use caution

Review all safety precautions before you begin work.

Make sure that the battery cosmetic checks are completed.



Position the flip battery

- Confirm the battery model to be G3M28, as shown in Fig 1. If the model number isn't G3M28, please don't use the battery.
- Use an adsorption bulb to pick up the battery.
- Align it to the upper-right corner of the depression and push it to the upper side and right side as much as possible.
- Remove the adsorption bulb and the white liner carefully.



Note

The white liner ensures that the battery is in the correct position.


Don't remove it prior to install.



Use caution

Review all safety precautions before you begin work.

Make sure that the battery cosmetic checks are completed.







Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery Outer Display

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 254

Fig 1

Press the flip battery

- Place the universal supporting rubber #2 on the universal holder #2, and place the universal holder limiting block #2 on top.
- Place the fixture in position B2 on the universal base.
- Place the Pixel 10 Pro Fold flip battery press rubber on top of the universal holder #2, as shown in Fig 1.
- Place the universal press plate 12 mm on the Pixel 10 Pro Fold flip battery press rubber, as shown in Fig 2.
- Place it in the universal press fixture. Press the handle down for 25 seconds, as shown in Fig 3.





base



Use caution


Keep hands clear during operation.



Note

Make sure that all protective films are removed before you press.

Inner Display Sub Flip Battery Outer Front Camera Upper Board Lower Board Outer Display



OD (outer display) sub

Solution 1: reuse the outer display

Solution 1: reuse the outer display



Reuse the OD

- Use a spudger to remove remaining glue from the OD. Remove large adhesive chunks with your fingers or tweezers.
- Repeat for any adhesive residue.
- If any remains, clean the surface with a dust-free cloth and IPA.




Note

The yellow highlight indicates areas with residual adhesive.



Use caution

Don't use the deglue machine on the driver IC area.



Solution 1: reuse the outer display



Apply the 3M AP111 primer

- Apply the **IPA** around the edges of the **enclosure** with **dust-free cotton swabs**.
- Apply the 3M AP111 primer around the edges of the enclosure with dust-free cotton swabs.



Use caution

After the **primer** is applied, complete the assembly in 25 minutes.



Solution 1: reuse the outer display



Align the OD PSA

- Slowly remove the larger liner from the **adhesive sheet** to expose the adhesive.
- Place the sheet over your phone, and align it with the device's top.
- Use your hand to apply the **adhesive** onto the enclosure top side.

Part: G806-14480-00 (OD PSA)



Use caution

Don't touch the adhesive.

If it gets dirty, replace it.



Solution 1: reuse the outer display



Activate the adhesive

- Make sure that the **adhesive** fully adheres to the **enclosure**.
- Activate it with a **spudger**.



Note

Inspect for any misalignment.



Solution 1: reuse the outer display



Remove the liner (first layer)

Carefully pull the tab to remove the **liner**, and avoid lifting the **adhesive**.



Use caution

Don't remove the second layer of the liner yet.



Solution 1: reuse the outer display



Apply the 3M AP111 primer on the OD

- Apply the IPA around the edges of the OD with dust-free cotton swabs.
- Apply the 3M AP111 primer around the edges of the OD with dust-free cotton swabs.



Use caution

After the **primer** is applied, complete the assembly in 25 minutes.



Solution 1: reuse the outer display



Connect the OD sub

- Use an **adsorption bulb** to prop up the **OD**.
- Apply even pressure across the connector to connect the OD to the lower board and ensure a full engagement.
- Apply even pressure across the connector to connect the flip battery to the lower board and ensure a full engagement.

Part: G949-01528-00 (OD sub)



Use caution

When you attach the **OD**, ensure that the **driver IC (COF)** isn't damaged or deformed.

Check if all connectors are fully attached to the **lower board**.



Main Body

CG

Solution 1: reuse the outer display



Check the display

- Remove the inner display process protective film.
- Power on with ESD spudger and wait at least 10 seconds to check if the device works properly. Power off after check.



Use caution

Don't touch the ID's TP until it turns to the **Welcome page** since touch panel self calibration is in progress.

Follow the instruction: **TP calibration note**



Solution 1: reuse the outer display



Place the OD cowling

- Install the **OD cowling** on the **lower board** with tweezers.
- Fasten three OD cowling screws with a torx plus 3IP screwdriver, and tighten twice.
- Power on to check the device's functionality and power off afterward.

Part: G250-08248-00 (screw)

Part: G250-08005-21 (screw*2)

Part: G730-09622-01 (OD cowling)



Use caution

Be cautious when you use the screwdriver. Avoid damaging the adjacent battery.

Incorrect use of the screwdriver might result in injuries to yourself or others, as well as damage to the battery or the product.




Note

There's a hook behind the upper side of the cowling. Install the cowling at an angle so that the hook clings to the flex below.

Gently pull it downward to ensure proper alignment.





A:G250-08248-00

B: G250-08005-21

Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery **Outer Display**

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 265

Solution 1: reuse the outer display



Remove the liner

Carefully peel the OD PSA liner counterclockwise with tweezers.

Part: G806-14480-00 (OD PSA)



Note

Remove the outer FCAM cap if you use a new outer FCAM.





Pick the tab here.

Solution 1: reuse the outer display



Attach the OD

- Assemble the OD onto the device, and remove the adsorption bulb.
- Press around the OD sub with both hands.



Note

Press the top side middle first, then follow with the two long sides and the bottom side.



Solution 1: reuse the outer display



Press the OD

- Place the universal supporting rubber #2 on the universal holder #2, and place the universal holder limiting block #2 on top.
- Place the fixture in position C2 on the universal base.
- Apply the Pixel 10 Pro Fold OD press rubber on top of the universal holder #2, as shown in Fig 1.
- Place the universal press plate 12 mm on the press rubber, as shown in Fig 2.
- Place it in the universal press fixture and press the handle down for 45 seconds, as shown in Fig 3.



Use caution

Keep hands clear during operation.



Note

Make sure that all protective films are removed before you press.




Note

Make sure that the Pixel universal holder is in the right position.






Universal base



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery **Outer Display**

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 268



Outer display

Solution 2: use a new outer display sub

Solution 2: use a new outer display sub



Apply the 3M AP111 primer

- Apply the IPA around the edges of the enclosure with dust-free cotton swabs.
- Apply the 3M AP111 primer around the edges of the enclosure with dust-free cotton swabs.



Use caution

After the **primer** is applied, complete the assembly in 25 minutes.



Solution 2: use a new outer display sub



Connect the OD sub

- Use an adsorption bulb to prop up the **OD**.
- Apply even pressure across the connector to connect the OD to the lower board and ensure a full engagement.
- Apply even pressure across the connector to connect the flip battery to the lower board and ensure a full engagement.

Part: G949-01528-00 (OD sub)



Use caution

When attaching the **OD**, ensure that the **driver IC (COF)** isn't damaged or deformed.

Check if all connectors are fully attached to the **lower board**.



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery **Outer Display**

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 271

Solution 2: use a new outer display sub



Place the OD cowling

- Install the OD cowling on the lower board with tweezers.
- Fasten three OD cowling screws with a torx plus 3IP screwdriver, and and tighten twice.
- Power on to check the device's functionality and power off afterward.

Part: G250-08248-00 (screw)

Part: G250-08005-21 (screw*2)

Part: G730-09622-01 (OD cowling)



Use caution

Be cautious when you use the screwdriver. Avoid damaging the adjacent battery.

Incorrect use of the screwdriver might result in injuries to yourself or others, as well as damage to the battery or the product.



Note

There's a hook behind the upper side of the cowling. Install the cowling at an angle so the hook clings to the flex below. Pull it downward gently to ensure proper alignment.





A:G250-08248-00

B: G250-08005-21

Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery **Outer Display**

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 272

Solution 2: use a new outer display sub



Remove the liner, film and cap

- Carefully peel the OD PSA liner with tweezers.
- Remove the masking tape, outer FCAM film, and sponge liner, as shown in Fig 1.




Use caution

Make sure that the environment is clean for this process.



Note

Remove the outer FCAM cap if you use a new outer FCAM.





Solution 2: use a new outer display sub




Attach the OD

- Assemble the **OD** onto the device, and remove the **adsorption** bulb.
- Press around the OD sub with both hands.



Note

Press the top side middle first, then follow with the two long sides and the bottom side.



Solution 2: use a new outer display sub



Press the OD

- Place the universal supporting rubber #2 on the universal holder #2, and place the universal holder limiting block #2 on top.
- Place the fixture in position C2 on the universal base.
- Apply the Pixel 10 Pro Fold OD press rubber on top of the universal holder #2, as shown in Fig 1.
- Place the universal press plate 12 mm on the press rubber, as shown in Fig 2.
- Place it in the **universal press fixture** and press the handle down for **45** seconds, as shown in **Fig 3**.



Use caution

Keep hands clear during operation.



Note

Make sure that all protective films are removed before pressing.



Note

Make sure that the Pixel universal holder is in the right position.





Universal base



Inner Display Sub Outer Front Camera Upper Board Lower Board Flip Battery **Outer Display**

Pixel 10 Pro Fold Repair Manual v1.0 Google 2025 | Page 275




Pixel 10 Pro Fold repair manual

Troubleshooting

Connectors location FPS (power button) Inner display **Bottom speaker** Inner display touch panel Volume button Power Vibrator Wireless charge **Outer display** Rear camera UWB Outer front camera Mic 1 Outer display touch Hinge panel Mic 2 Inner front camera RF (BT, WiFi, GPS, NFC) Mic 3 USB **Battery** Top speaker mmWave SIM Sensor

Connectors location


Loc	Location and description			
Α	Inner front camera connector			
В	Upper bridge FPC connector			
С	Inner display connector			
D	FPS (power button) connector			
E	Bottom bridge FPC connector (include flip battery pins)			
F	Base battery connector			
G	USB port			
Н	UWB spring			
ı	Flam board connector			
J	NFC or WLC spring			
K	IF FPC connector			
L	Bottom speaker spring			
М	Tele camera connector			
N	Vibrator spring			



Location and description WIDE camera connector UW camera connector Sidekey spring Flash spring

Connectors location

Location and description Outer front camera connector Upper bridge FPC connector Т Top speaker spring U Lower bridge FPC connector Outer display connector Upper bridge FPC connector (flip side) (to T) X Upper bridge FPC connector (base side) (to B) Bottom bridge FPC connector (base side) (to E) Z Inner display FPC connector (to C) a Bottom bridge FPC connector_1 (flip side) (to V) Bottom bridge FPC connector_2 (flip side) (to flip battery) Magnet Power Profile d NFC or WLC contact pad Flam board FPC connector (to I) UWB contact pad Antenna 1 FPC connector Antenna FPC connector (to h)









Power

Symptom	Potential root cause	Procedure	
4	Damage	 Inspect the USB-C connector for debris preventing charging. Inspect the device if it's damaged. Inspect the liquid damage indicators. 	
T001: doesn't power on T002: powers off suddenly T004: wired charging failure	Battery capacity problem	 Insert the USB cable and try to charge the device for at least 10 minutes, or a dummy battery to see if the device is out of battery capacity. If not, go to the next step. 	
	Connectivity problem	 Check if the base side's connectivity between the base battery connector, bottom bridge FPC connector (for flip battery), and logic board is normal. Check if the flip side's connectivity between the flip battery connector and the lower board connector is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
	Module problem	 Use a functional logic board, base or flip battery, inner display sub and lower board to cross-check with the original ones. Replace the defective component. 	 Disassembly Logic board Base battery Flip battery Inner display sub Lower board

Wireless charge

Symptom	Potential root cause	Procedure	
	Connectivity problem	 Check if the connectivity between the BG sub's WLC pad and the logic board is normal. If there's no mark on the pin contact pads, it shows poor connectivity. 	Connectors location
T003: wireless charging failure		If marks are observed, clean the contact pad and test again.	
	Module problem	 Use a correct BG sub and logic board to cross-check with original ones. Replace the defective component. 	Disassembly • Logic board
			BG sub

Mic 1

Symptom	Potential root cause	Procedure	
\$	Mesh not clean	 Take a microscope to check the mic hole. For example, block by burrs or overflowing glue. Clean the hole and test audio. 	
T010: mic 1 no sound T011: mic 1 low sound T012: mic 1 distorted sound	Assembly problem	 Disassemble the device and check if the mic 1 mesh is fully seated, as shown in Fig 1. Check if the mic 1 liner is removed, as shown in Fig 2. If not, go to the next step. 	Fig 1
3 2 2 G		• Test mic 1 again.	Fig 2
	Module problem	 Use a correct logic board and inner display sub to cross-check with the original ones. Replace the defective component. 	Disassembly Logic board Inner display sub
1 Mic 12 Mic 23 Mic 3			

Mic 2

Symptom	Potential root cause	Procedure	
Q	Connectivity problem	 Check if the connectivity between the flam board connector and the logic board is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
T013: mic 2 no sound T014: mic 2 low sound			
T015: mic 2 distorted sound			
	Module problem	Use a correct BG sub and logic board to cross-check with the original ones.	Disassembly
3		Replace the defective component.	BG sub
G G			Logic board
1 Mic 1			
2 Mic 23 Mic 3			
3 Mic 3			

Mic 3

Symptom	Potential root cause	Procedure
ψ	Mesh not clean	 Take a microscope to check the mic hole, for example block by burrs or overflowing glue. Clean the hole and test audio.
T016: mic 3 - no sound T017: mic 3 - low sound T018: mic 3 - distorted sound	Assembly problem	 Disassemble the device and check mic 3 mesh is fully seated, as shown in Fig 1. Check if the logic board mic 3 liner is removed, as shown in Fig 2. If not, go to the next step. Fig 1 Fig 2
1 Mic 12 Mic 23 Mic 3	Module problem	 Use a correct logic board and inner display sub to cross-check with the original ones. Replace the defective component. Disassembly Logic board Inner display sub

Top speaker

Symptom	Potential root cause	Procedure	
\$	Connectivity problem	 Check if the connectivity between the top speaker pad and the upper board is normal. If there's no mark on the pin contact pads, it shows poor connectivity. If they aren't fully attached, reassemble and then test again. 	Connectors location
T019: top speaker no sound T020: top speaker low sound T021: top speaker distorted sound	Module problem	If the sound quality is still poor, use a correct top speaker, upper board, and inner display sub to cross-check with the original ones.	Disassembly Top speaker (inner display sub)
		Replace the defective component.	 Upper board Inner display sub

Bottom speaker

Symptom	Potential root cause	Procedure	
Q	Mesh problem	 Visually inspect the exterior of the phone and check for a polluted mesh on the bottom speaker port. Use a soft ESD brush to remove any debris. Test audio. 	
T023: bottom speaker no sound T024: bottom speaker low sound T025: bottom speaker distorted sound	Internal debris	 If the sound quality is still poor, inspect the mesh and the speaker with a microscope. Disassemble the device and inspect the speaker. Remove any debris and test audio. 	
	Connectivity problem	 Check if the connectivity between the bottom speaker pad and the logic board is normal. If there's no mark on the pin contact pads, it shows poor connectivity. If they aren't fully attached, reassemble and then test again. 	Connectors location
	Module problem	 If the sound quality is still poor, use a correct bottom speaker and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblyBottom speakerLogic board

Vibrator

Symptom	Potential root cause	Procedure	
T026: vibrator failure	Connectivity problem	 Check if the connectivity between the vibrator pad and the logic board is normal. If there's no mark on the pin contact pads, it shows poor connectivity. Test the vibrator again. Check the function by triage test. 	Connectors location
	Component problem	 Use a correct vibrator with a cowling and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblyVibrator with cowlingLogic board

Outer display

Symptom	Potential root cause	Procedure	
	Damage	Inspect the display for damage and replace if necessary.	
T027: display blank T028: display dead pixel, dark spots or foreign material			
T029: display bright pixel, bright or colored spots	Connectivity problem	Check if the connectivity between the outer display connector, lower board, and the lower bridge connector is normal.	Connectors location
T030: display vertical or horizontal lines		 and the lower bridge connector is normal. If they aren't fully attached, reassemble and then test again. 	
T031: display black, white, or colored screen			
T032: display flickering or abnormal			
T033: display image quality			
T034: display color mura	Dead pixels Distorted graphics	 Remove the outer display module, fit a replacement part without adhesive and test. 	Disassembly
T035: display light leakage	Flickering	 If the issue is resolved, apply adhesive and fit a new outer display module. 	Outer display
T036: display backlight issue	Color issues		
T037: display shadow			
T038: display permanent burnin			
T039: display temporary burnin			

Outer display (continued)

Symptom	Potential root cause	Procedure	
T040: display single crack T041: display multiple cracks T042: display to back cover gap	Dimple issues	Remove the outer display module to check the display copper.	Outer display
T043: display cosmetic defects	Component problem	 Use a correct outer display, lower board, and inner display sub to cross-check with the original ones. Replace the defective component. 	DisassemblyOuter displayLower boardInner display sub

Outer display touch panel

Symptom	Potential root cause	Procedure	
T044: multi-touch poor response T045: multi-touch no response T046: multi-touch erratic response	Connectivity problem	 Check if the connectivity between the outer display connector and the lower board is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
	Touch screen	 Remove the outer display module, fit a replacement part without the adhesive and test. If the issue is resolved, apply the adhesive and fit a new outer display module. 	Disassembly Outer display
	Dead pixels Distorted graphics Flickering Color issues	 Use a correct outer display, lower board, and inner display sub to cross-check with the original ones. Replace the defective component. 	DisassemblyOuter displayLower boardInner display sub

RF (BT, WiFi, GPS, NFC)

Symptom	Potential root cause	Procedure	
T047: RF failure T048: Wi-Fi connectivity issues T049: bluetooth connectivity T050: GPS failure	Connectivity problem	 Check if the screws are loose, springs are damaged, and the coaxial cable of logic board is unlatched. Check if the connectivity between the BG sub, inner display sub, and logic board is normal. If there's no mark on the pin contact pads, it shows poor connectivity. If marks are observed, clean the contact pad and test again. If not, go to the next step. 	Connectors location
T051: NFC connectivity Issues	Module problem	Use a correct BG sub, logic board, coaxial cable RCAM, lower board, top speaker with ANT 4 FPC, ANT 1 FPC and inner display sub to cross-check with corresponding failure ones.	 Disassembly BG sub Logic board Coaxial cable RCAM Lower board Top speaker with ANT 4 FPC ANT 1 FPC Inner display sub

Battery

Connectivity problem • Check if the base side's connectivity between the base battery connectors location • Check if the base side's connectivity between the base battery, and logic board is normal. • Check if the flip side connectivity between the flip battery connector and the lower board connector is normal. • If they aren't fully attached, reassemble and then test again. • Use a correct base battery and logic board to cross-check with original ones. • Disassembly • Base battery	Symptom	Potential root cause	Procedure	
 Use a correct flip battery, lower board and inner display sub to cross-check with the original ones. When it's confirmed that the battery is abnormal, replace the two batteries together. Flip battery Lower board Inner display sub 	T054: battery draining fast		 connector, bottom bridge FPC connector for flip battery, and logic board is normal. Check if the flip side connectivity between the flip battery connector and the lower board connector is normal. If they aren't fully attached, reassemble and then test again. Use a correct base battery and logic board to cross-check with original ones. Use a correct flip battery, lower board and inner display sub to cross-check with the original ones. When it's confirmed that the battery is abnormal, replace the two 	Disassembly Base battery Logic board Flip battery Lower board

SIM

Symptom	Potential root cause	Procedure	
!:!	Connectivity problem	 Check if the connectivity between the SIM slot and the SIM tray is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
T056: SIM failure			
	Component problem	 Use a correct upper board and inner display sub to cross-check with the original ones. Replace the defective component. 	DisassemblyUpper boardInner display sub

Sensor

Symptom	Potential root cause	Procedure	
T059: proximity sensor failure	SW problem	Make sure that the SW is already updated to the latest version.	
	Assembly issue	Check the P-sensor rubber to ensure that it's in the correct position. Make sure that there's no foreign substance that covers the P-sensor area.	Assembly P-sensor rubber status
T060: ambient light sensor failure	Connectivity problem	Check the function by triage test.	
T061: accelerometer sensor failure T062: gyroscope sensor failure T063: hall sensor failure T066: pressure sensor failure T099: rainbow sensor defect T108: LDAF laser module T118: magnetometer failure T149: accelerometer sensor_2 failure T150: gyroscope sensor_2 failure T155: ambient light sensor_2 failure	Module problem	 Disassemble and check the appearance of the proximity sensor, so that it isn't abnormal. Use a correct upper board, logic board, and inner display sub to cross-check with the P-sensor, light sensor 1, and the light sensor 2 failure. Use a correct upper board, logic board, and inner display sub to cross-check with the accelerometer 1 or 2, the gyro sensor 1 or 2, the magnetic sensor and the hall sensor 1 or 2 failure. Use a correct BG sub to cross-check with the rainbow or the flicker sensor and the LDAF failure. Replace the defective components. Note P-sensor, light sensor 1, accelerometer 2, gyro sensor 2, and magnetic sensor at the upper board. Light sensor 2, accelerometer 1, gyro sensor 1, hall sensor, and barometer at 	Disassembly Upper board (P-sensor rubber) Lower board Logic board BG sub
		the logic board. Rainbow sensor and LDAF at the BG sub.	Inner display sub

Sensor location

No	Function	Logic board	Upper board	Lower board	BG sub
1	Light sensor 1		Ο		
2	Light sensor 2	0			
3	P sensor		Ο		
4	Barometer	0			
5	Gyroscope 1	0			
6	Gyroscope 2		O		
7	Accelerometer 1	0			
8	Accelerometer 2		O		
9	Rainbow				Ο
10	LDAF				Ο
11	Magnetic sensor		Ο		
12	Hall sensor	0			

FPS (power button)

Symptom	Potential root cause	Procedure	
	Connectivity issue	 Check if the connectivity between the fingerprint sensor module connector and the logic board are normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
T064: fingerprint sensor failure T068: power button failure	Component issue	 Use a correct fingerprint sensor module and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblyFPS (inner display sub)Logic board

Volume button

Symptom	Potential root cause	Procedure	
4)	Connectivity issue	 Check if the connectivity between the sidekey module and the logic board is normal. If they aren't fully assembled, reassemble and then test again. 	Connectors location
T069: volume button failure	Component issue	 Use a correct sidekey module and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblySidekey (inner display sub)Logic board

Rear camera

Symptom	Potential root cause	Procedure	
	SW problem	Make sure that the SW is already updated to the latest version.	
T072: camera AR failure T073: camera rear photo quality T074: camera rear video quality T078: can't switch between cameras T079: camera damage T111: main RCAM crashes T112: UW RCAM crashes T114: main RCAM no preview T115: UW RCAM no preview	Connectivity problem Module problem	 Inspect whether the camera lens area is damaged. Check the function by triage test. Disassemble the device to check if the camera connector is seated properly. Power on the unit and check the camera fail symptom. Check the rear camera BTB and the logic board side to identify if the assembly is deformed or flex crack, and reboot the device again to check if the fail symptom exists. If the fail symptom still exists, cross-check the logic board itself or the camera 	Connectors location Disassembly
T116: ultrawide rear camera photo quality T117: ultrawide rear camera video quality T196: tele RCAM crashes T197: tele RCAM no preview T198: tele rear camera photo quality T199: tele rear camera video quality		module (UW, WIDE, or tele) to determine if the fail symptom is caused by the camera module or the logic board.	Logic boardRear camera

Outer front camera

Symptom	Potential root cause	Procedure	
T075: camera front photo quality T076: camera front video quality T078: can't switch between cameras T079: camera damage T110: FCAM crashes T113: FCAM no preview	Connectivity problem	 Inspect the camera lens area for damage. Check the function by triage test. Disassemble the device to check if the camera connector is seated properly. Power on the unit and check the camera failure symptom again. Check the outer front camera BTB, upper board, and upper bridge connector side to identify if the assembly is deformed or flex crack, and reboot the device again to check if the fail symptom exists. 	Connectors location
	Module problem	If the fail symptom still exists, use a correct logic board, outer camera module, and inner display sub to cross-check with original ones.	DisassemblyUpper boardOuter front cameraInner display sub

Flashlight

Symptom	Potential root cause	Procedure	
	Connectivity problem	 Check if the connectivity between the flam FPC of BG and the logic board is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
T077: camera flash not working	Module problem	 Use a correct BG sub and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblyBG subLogic board

Inner front camera

Symptom	Potential root cause	Procedure	
T078: can't switch between cameras T079: camera damage T156: camera front inner photo quality T157: camera front inner video quality T158: inner FCAM crashes T159: inner FCAM no preview	Cosmetic problem Connectivity problem	 Inspect the camera lens area for damage. Check the function by triage test. Disassemble the device to check if the camera connector is seated properly. Power on the unit and check the camera fail symptom again. Check the inner front camera BTB and the logic board side to identify if assembly is deformed or flex crack, and reboot device again to check if the fail 	Connectors location
	Module problem	If the fail symptom still exists, cross-check the logic board itself or the camera module to determine if the fail symptom is caused by the camera module or the logic board.	Disassembly Inner front camera
		logic board.	Logic board

USB

Symptom	Potential root cause	Procedure	
T085: USB-C failure	Connectivity problem Module problem	 Check the function by triage test. Disassemble the device to check if the logic board is seated properly. Power on the unit, and check the failure symptoms again. Check the logic board side to identify if the assembly is deformed and reboot the device again to check if the fail symptom exists. 	Connectors location Disassembly Logic board

mmWave

Symptom	Potential root cause	Procedure	
((•)) T105: 5G_low med band failure T106: 5G high band failure	Connectivity problem	 Inspect the mmWave module and check if the IF FPC is correctly seated. Check if the connectivity between the IF FPC and the logic board is normal. Check if the connectivity between the inner display sub and the logic board is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
	Module problem	Use a correct mmWave module, IF FPC, and logic board to cross-check with the original ones.	DisassemblymmWaveIF FPCLogic board

Inner display

T175: inner_display_displays cosmetic defects

T187: protection film tear or removal

T190: bump in Inner_display

T176: inner display screen is broken but display is working

T186: protection film bubbles or delamination at hinge

T191: inner dsplay_patchy thick band of dead pixels

Symptom	Potential root cause	Procedure	
	Damage Bubble	Inspect the inner display for damage or bubble between display and protective film and replace if necessary.	
T160: inner display blank T161: inner display dead pixel, dark spots, or foreign material T162: inner display bright pixel, bright, or colored spots	Connectivity problem	 Check if the connectivity between the inner display connector and the logic board is normal. If they aren't fully attached, reassemble and then test again. 	
T163: inner display vertical or horizontal lines T164: inner display black, white, or colored screen T165: inner display flickering or abnormal T166: inner display image quality T167: inner display color mura	Dead pixels Distorted graphics Flickering Color issues	 Remove the inner display sub module, fit a replacement part without the adhesive and test. If the issue is resolved, apply adhesive and fit a new inner display sub module. 	
T168: inner display light leakage T169: inner display backlight issue T170: inner display shadow T171: inner display permanent burnin T172: inner display temporary burnin T173: inner display display single crack T174: inner display displays multiple cracks	Module problem	 If fail symptom still exists, use a correct inner display sub and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblyInner display subLogic board

Inner display touch panel

Symptom	Potential root cause	Procedure	
	Connectivity problem	 Check if the connectivity between the inner display connector and the logic board is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
T177: inner display multi-touch poor response T178: inner display multi-touch no response	Touch screen	 Remove the inner display sub module, fit a replacement part without adhesive and test. If the issue is resolved, apply adhesive and fit a new inner display sub module. 	Disassembly Inner display sub
T179: inner display multi-touch erratic response	Module problem	 Use a correct inner display sub and logic board to cross-check With the original ones. Replace the defective component. 	Disassembly Inner display sub Logic board

UWB

Symptom	Potential root cause	Procedure	
$\widehat{\mathbf{S}}$	Connectivity problem	 Check if the connectivity between the BG sub and the logic board is normal. If they aren't fully attached, reassemble and then test again. 	Connectors location
T181: ultra-wideband (UWB) failure	Module problem	 Use a correct BG sub and logic board to cross-check with the original ones. Replace the defective component. 	DisassemblyBG subLogic board

Hinge

Symptom	Potential root cause	Procedure				
T188: hinge function abnormal T189: hinge function abnormal CID	 Follow the table below to check if the hinge function is abnormal. Use a correct inner display sub to cross-check with the original ones. Replace the defective component. 		ub			
Check item	Verification method		Verification photo			
Open angle	Unfold the device completely, to on the holder (ID face down an hinge area has any hump or su	d up) to check if the	ID face down or up			
Hinge torque	Put the device on the desk and open it at around 45 degrees and 135 degrees and 135 degrees. Put the device on the desk and open it at around 45 degrees and 135 degrees and 135 degrees. 45 degrees or 135 degrees angle					
Hinge noise	Remove the ID process PF before the test. Find a quiet area to listen at 30 cm distance to check if there's noise during folding and unfolding action three times.			30 cm	→ (C	



Pixel 10 Pro Fold repair manual

Software

Software tools

Description	Documentation
Update or reinstall the software on Pixel devices	Google Pixel Update and Software Repair