




HF 231

OPERATION, MAINTENANCE AND SPARE PARTS

FARMI

HYDRAULIC FEEDER

HF 231



From machine:329 4157

**READ THIS OPERATION AND MAINTENANCE MANUAL
CAREFULLY BEFORE USING THE MACHINE**

Farmi Forest Corporation

Ahmolan tie 6
FIN-74510 PELTOSALMI
FINLAND
Tel. +358 (0) 17 83 241
Fax. +358 (0) 17 8324 372

HF 231

WARNING SYMBOLS IN THIS MANUAL



Imminent danger which could cause serious personal injury or death.



Danger which could cause personal injury.



Conditions or misuse that could damage equipment or machinery.

NOTE!

Reminders, such as for performing checks or carrying out maintenance or repair procedures.

INTRODUCTION

This manual includes the information and maintenance instructions required for operating the machine in the optimal manner.

Although you have experience in using this kind of machinery, read the operation and maintenance instructions carefully since they include information enabling efficient and safe operation. Regular maintenance is the best way to guarantee the efficient and economical performance of the machine.



Each and every operator must read, understand, and follow all safety instructions and procedures.

CUSTOMER FEEDBACK

We are happy to receive your opinions and suggestions for improvements by mail, fax or e-mail. All implemented suggestions for improvements will be rewarded.

FARMI Forest

Ahmolantie 6
FIN-74510 PELTOSALMI
FINLAND
Tel. +358 (0) 17 83 241
Fax. +358 (0) 17 823 606

HF 231

GUARANTEE GIVEN BY THE MANUFACTURER OF A DEVICE INTENDED AS A MACHINE PART

Farmi Forest Corporation
Ahmolantie 6, FIN-74510 PELTOSALMI, Finland

Informs that the machine, launched on to the market,

FARMI Hydraulic feeder

(make)

HF 231

(type)

(serial number)

which is incapable of operating individually, has been intended as a structural part of a machine in such a way they together form the machine referred to in Directive 98/37/EEC and in the amendments related to it as well as in the national statutes which bring them into force.

It shall meet the fundamental requirements of Directive 98/37/EEC relating to this machine part.

The following unified standards have been applied to the design of the machine:

EN292-2, EN294, EN60204-1

The following national standards and specifications have been applied to the design of the machine:

PrEN13252, prEN1553-1

In addition, we inform that this machine part shall not be taken into use before a guarantee of the conformance to the EU requirements has been given, in accordance with Directive 98/37/EEC, the amendments related to it and the national statutes (VPn 1314/94) which bring them into force, of the machine of which it is a part.

Peltosalmi

(place)



Juha Hallivuori

01.09.2002

(date)

FARMI Forest

Ahmolantie 6
FIN-74510 PELTOSALMI
FINLAND
Tel. +358 (0) 17 83 241
Fax. +358 (0) 17 823 606

HF 231

1.SAFETY	5
1.1.GENERAL	5
1.2.OPERATIONAL SAFETY	5
1.3.OPERATION	5
1.4.OILS AND GREASES	6
1.5.MAINTENANCE	6
1.6.LIFTING	6
2.SAFETY INSTRUCTIONS FOR HYDRAULIC SYSTEMS	6
3.PLATES AND STICKERS	7
4.FEED CHUTE PRESENTATION	9
4.1.FIELD APPLICATION	9
4.2.MAIN COMPONENTS	9
5.TECHNICAL DATA	9
6.MOUNTING	10
7.OPERATION	11
7.1.CONTROL HANDLE	11
7.2.SAFETY HANDLE	11
7.3.OPERATION	11
7.4.SETTING THE FEEDER SPEED	12
7.5.EMTYING THE CHIPPER AFTER USE	12
8.CHANGING THE HYDRAULIC UNIT FOR USE WITH CONSTANT PRESSURE PUMPS	12
9.MAINTENANCE	12
10.HYDRAULICS CIRCUIT DIAGRAM	13
SPARE PARTS	14
HF 231	14
2–LEVER USE HF 231	18
HYDRAULICS	20
DIRECTIONAL CONTROL VALVE	24

Thread	Millimeter	Inch
M6	10	7/16
M8	13	1/2
M10	17	11/16
M12	19	3/4
M16	24	15/16
M20	30	1 3/16

WHEN ORDERING SPARE PARTS, PLEASE INDICATE MACHINES TYPE FROM THE MACHINE PLATE, SPARE-PARTS ORDER NUMBER, DESCRIPTION AND QUANTITY REQUIRED.

Example: HF 231, Upper feed roller, 1 pc

1.SAFETY

1.1.GENERAL

These safety instructions are intended for personnel operating, servicing, and repairing FARMI equipment.

These instructions will help you to:

- operate the machine safely
- operate the machine appropriately and effectively
- notice, avoid, and prevent potentially hazardous situations

The manufacturer has supplied safety instructions for the machine. The instructions must be kept in the compartment of the machine that is reserved for the instructions, and they must always be available on the site where the machine is used. Before using the machine, each and every operator of the machine must read the safety, maintenance, and operation instructions. These instructions must always be followed.

The machine meets the specified technical standards as well as required and appropriate safety regulations.

In addition to those in the manual, the instructions of the local occupational safety authorities as well as national laws and regulations must be followed.

Using the machine for tasks other than those for which it is intended or exceeding its performance is not appropriate use of the machine. The manufacturer/supplier is not responsible for damage resulting from this kind of usage.

1.2.OPERATIONAL SAFETY



DANGER!

**Occupational accidents often take place in abnormal or nonstandard situations.
Consider all possible, even unlikely, situations that could occur during each task.**

- Due to design considerations, the machine's noise level may exceed 85 dB; wear hearing protection and other appropriate safety equipment.
- Ensure that occupational safety regulations are followed when working.
- Familiarize yourself with the machine's risk zones and prevent unauthorized persons from entering these zones.
- During operation, the operator of the machine is responsible for the safety and risk zones for the entire work site.
- Each time the machine is to be used, first check its operational safety and correct any deficiencies.
- Before starting and using the machine, ensure that it does not pose a danger to other persons or a risk of damage.
- Exceeding the specified performance ratings is prohibited.
- Do not operate the machine while sick or under the influence of alcohol or drugs.
- All of the machine's safety and warning labels must be legible and undamaged. Replace if necessary.
- The operator of the machine must always have unobstructed visibility on-site. If necessary, an assistant must be provided to the operator.
- In the event of any defect compromising operational safety, stop the machine!
- If it is not possible to correct the impairment to operational safety, work must be stopped.

1.3.OPERATION

- Familiarize yourself with the capacity and limitations of the machine and equipment, as well as how they can be used most efficiently.
- Familiarize yourself carefully with the operation and functions of the machine before operating it.
- The operator of the machine must also be familiar with the operation of the accessories.
- Do not stand unnecessarily close to the machine during operation.
- Prevent unauthorized persons from entering the working area during operation.
- The operator of the machine must always have unobstructed visibility of the site.
- Operating a damaged or defective machine is prohibited.
- Ensure the following:
 - That the safety and protective devices of the machine are not removed or modified and that they are used properly.
 - Regular safety tests and similar inspections are carried out.
- Remember that the manufacturer of the machine is not responsible for damage that is caused by:
 - incorrect, careless, or inappropriate use
 - misuse caused by errors on the part of untrained personnel
- When leaving the machine, always secure it from unauthorized and unintended operation.
- When parking, ensure that the machine is properly supported.
- Avoid placing sudden, demanding loads on the machine.
- Use the controls carefully, especially in cold conditions.

HF 231

1.4.OILS AND GREASES

- Always use the oil grades recommended by the manufacturer.
- Use the recommended oils in cold conditions.
- Never mix different fluids or oils with each other.
- Follow the manufacturer's lubrication instructions.

1.5.MAINTENANCE

- Modifications without the manufacturer's permission are prohibited.
- Remember that the manufacturer of the machine is not responsible for damage that is caused by:
 - modifications made without the manufacturer's permission
 - use of non-original spare parts
 - normal wear
- Safety devices must be re-fitted immediately after maintenance.
- Never try to take hold of moving parts when the engine is running.
- Ensure that the machine cannot be started during maintenance.
- Electrical and hydraulic failures are to be repaired by authorized personnel only. The same applies to the welding of load-bearing structures.
- Follow the maintenance intervals listed, and perform the indicated annual safety inspections.

1.6.LIFTING

- Lift only with the proper type of lifting device, and ensure that it has an appropriate lifting capacity.
- Ensure that the lifting equipment is in good working condition. The lifting equipment must be inspected regularly.
- Ensure that you know the weight of the load to be lifted and never exceed the lifting capacity stated by the manufacturer of the lifting device.
- Select routes for lifting that pose no danger.


2.SAFETY INSTRUCTIONS FOR HYDRAULIC SYSTEMS

1. Hydraulic systems must be serviced by qualified, experienced hydraulics mechanics only.
2. Check the machine for any leaks and repair them before using the machine.
3. Clean the area to be repaired. Do not use solvents to clean components.
4. Never repair the hydraulic system when it is pressurized.
5. Support the machine before servicing or making repairs. Do not detach the cylinders or their valves before supporting the machine.
6. When replacing hydraulic components and hoses, use original spare parts or parts recommended by the manufacturer. In particular, ensure that the pressure classes correspond to the operating pressure.
7. If oil gets in the eyes, rinse them thoroughly with water and consult a doctor.
8. Oil can be removed from skin by wiping and washing. Use safety equipment when handling oils and greases.
9. Prevent hydraulic oil from escaping into the environment. Waste oil must always be collected in a container to keep the environment clean!
10. When working in ecologically sensitive areas, use bio-oils.
11. Keep oil indoors in closed, original containers. Pour the oil into the tank directly from the container.
12. All caps, funnels, screens, and filling holes must be clean.


HF 231

3.PLATES AND STICKERS


These decals and stickers must be found from feeder. Missing ones must be renewed immediately.



Number 1. Hearing protection (41018330).
2 Pcs.
Wear hearing protection.




Number 2. Lifting point (41014270).
3 Pcs.




Number 3. Note! (41015690).
2 Pcs.
Stand on the left side of feeder.


HF 231




Number 4. Stay away from revolving part (41015600).
2 Pcs.



Number 5. Safety handle left (41016000).
This sticker shows the movements of the safety handle.
S**T****O****P** = stop
N = neutral
R = reverse




Number 6. Safety handle right (41015990).
This sticker shows the movements of the safety handle.
R = reverse
S**T****O****P** = stop
N = neutral




Number 7. Maximum hydraulic pressure 175 bar(41015580).



Number 8. Manufacturer (40605214).



Number 9. Control handle right (41016010)
This sticker shows the movements of the control handle.
R = reverse
S**T****O****P** = stop
F = feed



Number 10. Control handle left (41016020).
This sticker shows the movements of the control handle.
F = feed
S**T****O****P** = stop
R = reverse

HF 231

4.FEED CHUTE PRESENTATION

4.1.FIELD APPLICATION

The hydraulic feed chute HF 231 makes feeding difficult material easier and more effective. The chip quality improves due to constant feeding speed and is less dependent on knives sharpness.

The HF231 can be driven by the tractor hydraulics or by the optional independent hydraulic unit HD11.

HF231 is easily mounted to the same attachment as the mechanical feed chute and the drop spout.

4.2.MAIN COMPONENTS

- 1.Control handle
- 2.Directional valve
- 3.Flow regulator
- 4.Hydraulic motors
- 5.Feed rollers
- 6.Frame
- 7.Feed chute
- 8.Safety handle




Fig.1.Main parts.

5.TECHNICAL DATA

HF 231	
Feed roller	2 pcs. Ø208 mm (8 3/16")
Max. tree diameter	260 mm (10 1/4")
Hydraulic motors	250 cm ³ (15 1/4 in ³)
Oil demand, P.T.O speed chip 3/16", 540 rpm. chip 3/16", 1000 rpm.	30 l/min (6 1/2 UK gal / min.) 52 l/min (11 1/2 UK gal / min.)
Feed chute opening size	820 mm x 787 mm (32 5/16" x 31")
Dimensions	1090 x 871 x 1820 mm
Weight	210 kg (463 lbs)

6.MOUNTING

1. The hydraulic feeder and mechanical feeders include fitting blocks that are installed between the chipper and feeder. The fitting blocks are installed so that the two guide pins located at the bottom section of the feed opening go through the holes in the fitting block and secure the block. See Fig. 2.




Fig. 2. Installing the fitting block.

2. Attach the feeder frame to the chipper pins and lock bolts. Fig. 3.




Fig. 3. Mounting the feeder on the chipper.

3. Attach the feed chute to the frame with two M10x110 bolts and lock nuts. Fig. 4.




Fig. 4. Installing the hinge bolts.

4. Lock the chute in the operating position.
5. Connect the hydraulic hoses. Connect the pressure hose (P on the valve) to the pressure connector of the tractor's hydraulic system. The maximum operating pressure is 175 bar. Connect the return hose (T) to the return connector of the double-acting valve, or preferably directly to the tank. Fig. 5.




Fig. 5. Connecting the hydraulics, feed.

7. OPERATION

7.1. CONTROL HANDLE

The HF 160 is operated with a control handle, which has 3 positions:

1. FEED FORWARD F

The feeder reel spins inwards and wood can be fed into the chipper. The handle locks in this position.

2. STOP

The feeder reel ceases to spin and the feeding stops. The handle locks in this position.

3. REVERSE R

The feeder reel spins outward and wood comes out of the feeder.




Fig 6. Control handle.

7.2. SAFETY HANDLE

The HF 160 has been equipped with a safety handle, which operates as a safety appliance and as the emergency stop control. The safety handle has 4 positions:

1. STOP

The feeder reel ceases to spin and the feeding stops.

2. NEUTRAL N

The chipper controls are done through the control handle.

3. STOP

The feeder reel ceases to spin and the feeding stops.

4. REVERSE R

The feeder reel spins outward.




Fig 7. Safety handle.

7.3. OPERATION


1. Ensure that the feed funnel is empty. Turn on the tractor hydraulics or connect an external power source (OEM).
2. Before feeding the material, ensure that nails, stones etc will not get into the chipper amongst the material to be chipped.
3. If necessary, set the revolving speed of the feeder reel to correspond to the revolving speed of a grinding wheel.

The speed is suitable when the wood does not push against the grinding wheel or the feeder reel spikes do not slow down the feeding of wood. See paragraph 7.4.

4. Set the control handle in the **FEED F** position. The feeder reel will begin to roll when the air has left the hydraulic circuit.
5. Feed the wood into the feed chute. Let go of the wood immediately after the feeder reel begins to pull it



Do not work in front of the feeder if not necessary!
Feeder reels can wrench the wood up or to the right.



Make sure that your clothes or hair do not get tangled in the revolving parts of the appliance when it is turned on.
Feeding rope or barbed wire into the chipper is dangerous, because the rope can get caught on the operator and pull him/her with it to the feed chute.
Never push limbs into the feed chute when the appliance is turned on.

- When chipping a large tree with a low capacity tractor, the tractor's revolutions will endeavour to fall especially towards the end of a long tree. Stop the feeding occasionally by switching the control handle to **STOP** -position. When the revolutions have increased sufficiently, continue feeding by switching the control handle to **FEED F** -position.
- If you need to remove the tree from the feed funnel in the middle of chipping, switch the control handle to **REVERSE R** -position and hold it there until the feeder reel releases the tree.



Oil will heat when travelling through the hydraulic pump, hydraulic motor and the valves. The heating can be considerable if the tractor has a small hydraulic tank. Check the oil temperatures twice an hour to prevent the oil from overheating. If the oil overheats, let it cool down by stopping the chipping.



Observe the revolutions of the feeder reels. If the feeder reel stops, switch the control handle to **REVERSE R** position. If the feeder reels are stopped when the control handle is in **FEED FORWARD F** position, the oil flows through the pressure limit valves and heats very quickly.

7.4. SETTING THE FEEDER SPEED



Do not set the feeder speed when the feeder reels are revolving. This damage the valve. Stop the feeder reels for the duration of the setting and try the speed afterwards.

- Using the flow control valve, set the revolution speed of the feeder reel to correspond with the cutting speed of the blades. By turning the knob anticlockwise, the revolution speed of the feeder reel grows, correspondingly by turning it clockwise, the revolution speed will diminish. See Fig 8.




Fig 8. Feeder reel speed settings.

- The speed is suitable when the wood does not push against the grinding wheel or the feeder reel spikes do not slow down the feeding of wood.
- Make sure that you are using clean oil in the hydraulic system. Dirt in the oil will damage valves and hydraulic motors.

7.5. EMTYING THE CHIPPER AFTER USE

- Before stopping the chipper, chip about Ø 80–100 mm wood. Let the blades cut a few centimetres, after which reverse the feed direction to clean the blades. Leave the tree into the feeder to remind you that the chipper has been emptied. This way you will avoid a possible jam when you turn on the chipper next time.



When you stop the chipper, wait for all movement to stop. The grinding wheel will continue to revolve like a flywheel once the power outlet has been switched off.

8. CHANGING THE HYDRAULIC UNIT FOR USE WITH CONSTANT PRESSURE PUMPS

The chipper valve is built for fixed displacement pumps. If your tractor has a constant pressure pump, the hydraulic feeder unit should be modified as follows:

- Insert a plug in the directional control valve – see Fig 9.
- Remove the hose and T-nipple and insert a plug in the end of the flow regulator valve – see Fig 10.
- Connect the tank hose directly to the directional control valve – see Fig 11.




Fig 9. Inserting the plug.




Fig 10. Removing the hose and T-nipple and inserting the plug in the end of the flow regulator valve.




Fig 11. Connecting the tank hose.

- Instructions for connecting the hydraulics when using the optional hydraulic unit can be found in hydraulic units mounting instructions.

9. MAINTENANCE

- The feed roller bearings are sealed and do not require periodic maintenance.
- Lubricate the roller bracket shaft slide bearings after every 20 operating hours.
- Check and tighten loose bolts at regular intervals.
- Check the condition of the hydraulic hoses and regularly inspect the connections for leaks.
- Be sure to use only clean oil in the hydraulic system. The presence of impurities in oil damages the valves and hydraulic motors.

HF 231

10.HYDRAULICS CIRCUIT DIAGRAM





Fig 12.43484050.

HF 231

HF 231




HF 231

HF 231

Part Osa Teil Pièce	Order No. Til.nro. Best Nt No. de ordre	Description Bezeichnung	Nimitys Désignation	Remarks Huom. Obs Obs	Qty. Kpl. St. Pc.
1.	13291562 ...	Frame Rahmen	Runko Châssis		1
2.	13291802 ...	Fastening flange Rollebefestigung	Rullan kannatin Support du rouleau		1
3.	33291873 ...	Fastener Träger	Kannatin R	Support	1
4.	43293786 ...	Fastener Träger	Kannatin L	Support	1
5.	33291931 ...	Motor mounting flange Motorträger	Moottorin kiinnitin	Support du moteur	1
6.	43291962 ...	Protective rubber Schutzgummi	Suojakumi	Caoutchouc de protection	2
7.	43291970 ...	Fastener Verschluss	Suojakumin kiinnitin	Support	4
8.	43291988 ...	Upper roller support Obere Walzenstütz	Ylärollan tuki	Support du rouleau	1
9.	43292002 ...	Lower roller support Untere Walzenstütz	Alarullan tuki	Support du rouleau	1
10.	43291996 ...	Spring lever Federhebel	Jousen vipu	Levier	1
11.	23292048 ...	Lower feed roller Untere Walzen	Alasyöttörulla	Rouleau d'alimentation	1
12.	23292105 ...	Upper feed roller Obere Walzen	Yläsyöttörulla	Rouleau d'alimentation	1
13.	54511431	Bearing Lager	Laakeri	Palier	2
14.	52230034 ...	Circlip Sicherungsring	Akselivarmistin	Arrêt de sécurité de l'ax	2
15.	52090438 ...	Hexagonal screw Sechskanntschaube	Kuusioruubi	M10x20 DIN 7991 ... Vis hexagonale	4
16.	-				
17.	-				
18.	-				
19.	-				
20.	-				
21.	54561022 ...	Bearing Lager	Laakeri	Palier	2
22.	52110046	Nut Mutter	Mutteri	M10 DIN934	9
23.	52211042	Washer Scheibe	Aluslevy	M10 DIN 127	6
24.	52060332 ...	Hexagonal screw Sechskanntschaube	Kuusioruubi	M10 x 110 DIN931 ... Vis hexagonale	2
25.	23295678 ...	Chute Trichter	Suppilo	Trémie	1

HF 231

HF 231




HF 231

HF 231

Part Osa Teil Pièce	Order No. Til.nro. Best Nt No. de ordre	Description Bezeichnung	Nimitys Désignation	Remarks Huom. Obs Obs	Qty. Kpl. St. Pc.
26.	52117108	Lock nut	Lukkomutteri	M10 DIN985	1
		Schlossmutter	Écrou à mâchoires		
27.	94617073 ...	Spring	Jousi	1	
		Feder	Ressort		
28.	52200045 ...	Washer	Aluslevy	M10 DIN126	4
		Scheibe	Rondelle		
29.	-				
30.	33297380 ...	Adaptor piece	Täytepala		1
		Anpassteil	Bloc de montage		
31.	52062023 ...	Hexagonal screw	Kuusioruuvi	M12x30 DIN933	4
		Sechskanntschaube	Vis hexagonale		
32.	52211059	Washer	Aluslevy	M12 DIN 127	4
		Scheibe	Rondelle		
33.	52110053	Nut	Mutteri	M12 DIN934	2
		Mutter	Ecrou		
34.	52110020	Nut	Mutteri	M6 DIN934	9
		Mutter	Ecrou		
35.	52060225 ...	Hexagonal screw	Kuusioruuvi	M10x25 DIN933	4
		Sechskanntschaube	Vis hexagonale		
36.	43292325 ...	Spacer ring	Soviterengas		2
		Distanzring	Anneau intermédiaire		
37.	52832102 ...	Rivet	Vetoniitti	4,8x15	3
		Niete	Rivet explosif		
38.	52060381 ...	Hexagonal screw	Kuusioruuvi	M6x12 DIN933	6
		Sechskanntschaube	Vis hexagonale		
39.	52004272 ...	Hexagonal screw	Kuusioruuvi	M10x35 DIN7991 10.9 6	
		Sechskanntschaube	Vis hexagonale		

HF 231

2 lever use – 2 vipukäyttö – 2 Hebelgebrauch – 2 Utilisation levier




HF 231

2 lever use – 2 vipukäyttö – 2 Hebelgebrauch – 2 Utilisation levier

Part Osa Teil Pièce	Order No. Til.nro. Best Nt No. de ordre	Description Bezeichnung	Nimitys Désignation	Remarks Huom. Obs Obs	Qty. Kpl. St. Pc.
1.	43299610	Additional visor Verlängerungsstück	Jatkopala Entonnoir d'alimentation		1
2.	43486320	Swing rod Stange	Keinun tanko Tige oscillante		1
3.	43486400	Safety handle Sicherheitsgriff	Turvasanka Manette de sécurité		1
4.	–				
5.	43486370	Connector Konnektor	Liitin Connecteur		1
6.	43486240	Plastic collar Büsche	Muoviholki Bague en plastique		2
7.	43486300	Control handle Bedienungshebel	Ohjauskahva Manette de contrôle		1
8.	43299850	Control rod Benienungstange	Ohjaustanko Tige de contrôle		1
9.	43486230	Cover Deckel	Kansi Couvercle		1
10.	54916085	Pipe connector Konnektor	Kiinnike .. Stauff 322 Connecteur de tuyaux		6
11.	54916044	Pipe connector Konnektor	Kiinnike .. Stauff 218 Connecteur de tuyaux		6
12.	43486450	Connector Konnektor	Liitin .. M10 .. Connecteur		1
13.	52060050	Screw Schraube	Kuusioruuvi .. M6X40 DIN933 8.8ZN Vis		2
14.	43299660	Protective gutter Platte	Suojakouru .. Goulotte de protection		1
15.	52060068	Screw Schraube	Kuusioruuvi .. M6x50 DIN933 8.8ZN Vis		4
16.	52117066	Lock nut Schlossmutter	Lukitusmutteri .. M6 DIN985 .. Ecrou à mâchoires		12
17.	52060696	Screw Schraube	Kuusioruuvi .. M8x25 DIN933 8.8ZN13 Vis		
18.	52200334	Washer Scheibe	Aluslevy .. M8 DIN440 ZN .. Rondelle		26
19.	52110038	Nut Mutter	Mutteri .. M8 DIN934 8.8ZN .. Ecrou		13
20.	52111051	Nut Mutter	Mutteri .. M8 DIN936 8.8ZN .. Ecrou		1
21.	52117108	Lock nut Schlossmutter	Lukitusmutteri .. M10 DIN985 .. Ecrou à mâchoires		3
22.	52070125	Socked head screw Innensechskantschraube	Kuusiokoloruubi .. M6x40 DIN912 8.8ZN Vis hexagonale à tête creuse		6
23.	52001548	Socked head screw Innensechskantschraube	Kuusiokoloruubi .. M6x25 DIN912 8.8ZN Vis hexagonale à tête creuse		6
24.	52842168	Ring cotter Ringsplint	Rengassokka .. 6,5x40 .. Clavette ronde		1
25.	43299480	Slip bearer, right Verschluss, rechts	Liun kannatin, oikea .. Coussine, droit		1

HF 231

2 lever use – 2 vipukäytö – 2 Hebelgebrauch – 2 Utilisation levier




HF 231

2 lever use – 2 vipukäyttö – 2 Hebelgebrauch – 2 Utilisation levier

Part Osa	Order No. Til.nro.	Description Bezeichnung	Nimitys Désignation	Remarks Huom.	Qty. Kpl.
Teil Best Nt				Obs	St.
Pièce No. de ordre				Obs	Pc.
26.	43299490	Slip bearer, left Verschluss, links	Liun kannatin, vasen Coussine, gauche		1
27.	52070620	Screw Schraube	Kuusioruuvi M8x16 DIN7500 D Vis		2
28.	52060233	Screw Schraube	Kuusioruuvi M10x30 DIN933 8.8ZN2 Vis		
29.	52200029	Washer Scheibe	Aluslevy M6 DIN126 5.8ZN .. 12 Rondelle		

HF 231

Hydraulics–Hydrauliikka–Hydraulik–Hydraulique



43484880


HF 231

Hydraulics–Hydrauliikka–Hydraulik–Hydraulique

Part Osa Teil Pièce	Order No. Til.nro. Best Nt No. de ordre	Description Bezeichnung	Nimitys Désignation	Remarks Huom. Obs Obs	Qty. Kpl. St. Pc.
1.	56001951 ...	Hydraulic motor	Hydraulimoottori	OMP400	2
		Hydraulikmotor	Moteur hydraulique		
1.1....	58217746 ...	Seal kit	Tiivistesarja		1
		Dichtungssatz	Série isolation		
1.2....	57609125 ...	Key	Kiila		1
		Keil	Coin		
2.	-				
3.	56075252 ...	Flow divider valve	Virtauksenjakoventtiili		1
		Stromteilventil			
4.	56070832 ...	Flow regulator valve	Virtauksensäätöventtiili		1
		Durchflussmengenregler	Soupape de contrôle du débit		
5.	56075260 ...	Directional control valve	Suuntaventtiili	Eur	1
		Steuerventil	Vanne de direction		
6.	43486490 ...	Plate	Levy		1
		Platte	Plat		
7.	-				
8.	-				
9.	-				
10.	-				
11.	03485310 ...	Hose assy	Letkuasetelma		1
		Schlauchsatz	Ensemble de tuyaux		
11.1.	56525157 ...	Hose assy	Letkuasetelma	V1/2"S L=1,0m	2
		Schlauchsatz	Ensemble de tuyaux		
11.2.	56526130 ...	Hose assy	Letkuasetelma	K1/2"S L=0,9m	2
		Schlauchsatz	Ensemble de tuyaux		
11.3.	56526015 ...	Hose assy	Letkuasetelma	K1/2"S L=0,3m	1
		Schlauchsatz	Ensemble de tuyaux		
11.4.	03485290 ...	Hose assy	Letkuasetelma	Osat:12,13,14,15,16 ..	1
		Schlauchsatz	Ensemble de tuyaux		
11.5.	03485360 ...	Hose assy	Letkuasetelma	Osat:13,17,18,19 ..	1
		Schlauchsatz	Ensemble de tuyaux		
11.6.	03484320 ...	Hose assy	Letkuasetelma	Osat:14,15,16,20,21 ..	1
		Schlauchsatz	Ensemble de tuyaux		
11.7.	54921473 ...	Hose cover	Letkusuoja	10 m	1
		Schutz	Tuyau de protection		
12.	56526288 ...	Hose assy	Letkuasetelma	K1/2"S L=2,3m	1
		Schlauchsatz	Ensemble de tuyaux		
13.	52390200 ...	Usit ring	Usit – rengas	U21,5x28,7x2,5	13
		Usit – Dichtung	Bague Usit		
14.	52432051 ...	Double fitting	Kaksoisnippa	R1/2"	8
		Doppelnippel	Double embout		
15.	52449022 ...	Quick fitting	Pikaliitinnippa	1/2" SK	2
		Schnappkupplung	Embout douille à baïonnette		

HF 231

Hydraulics–Hydrauliikka–Hydraulik–Hydraulique



43484880


HF 231

Hydraulics – Hydraulikka – Hydraulik – Hydraulique

Part Osa Teil Pièce	Order No. Til.nro. Best Nt No. de ordre	Description Bezeichnung	Nimitys Désignation	Remarks Huom. Obs Obs	Qty. Kpl. St. Pc.
16.	54922141 ...	Plug Schutz	Suojahattu Bouchon	1/2"	2
17.	56526049 ...	Hose assy Schlauchsatz	Letkuasetelma Ensemble de tuyaux	K1/2"S L=0,45m Corps de la douille baïonnette	1
18.	52435336 ...	Bulkhead fitting Nippel	Läpivientinippa Embout de passage	R1/2"	1
19.	52449758 ...	Quick fitting coupling Schnappkupplung	Pikaliitinrunko Corps de la douille baïonnette	R1/2" Flat	1
20.	56526353 ...	Hose assy Schlauchsatz	Letkuasetelma Ensemble de tuyaux	K1/2"S L=3,0m	1
21.	52449766 ...	Quick fitting Schnappkupplung	Pikaliitinippa Embout douille à baïonnette	R1/2" Flat	1
22.	52090438 ...	Socked head screw Innensechskantschraube ...	Kuusiokoloruvi Vis hexagonale à tête creuse	M10x20 DIN7991 ...	2
23.	52070414 ...	Socked head screw Innensechskantschraube ...	Kuusiokoloruvi Vis hexagonale à tête creuse	M8x60 DIN912	3
24.	52060175 ...	Hexagonal screw Sechskanntschorbaue	Kuusioruvi Vis hexagonale	M8x25 DIN933	12
25.	52110038 ...	Nut Mutter	Mutteri Ecrou	M8 DIN934	2
26.	52443686 ...	T– nipple T-Nippel	T– nippa Embout en T	R1/2"	2
27.	52442175 ...	Angle nipple Winkelnippel	Kulmanippa Embout coudé	R1/2"	1
28.	52442365 ...	Angle nipple Winkelnippel	Kulmanippa Embout coudé	R1/2"	3
29.	52435773 ...	Swivel fitting Copplung	Yhdysnippa Embout de raccord	R1/2"	3
30.	-
31.	556013246 ...	Directional control valveFitting Steuerventil	Suuntaventtiili Vanne de direction	1
32.	52200037 ...	Washer Scheibe	Aluslevy Rondelle	M8 DIN126	2
33.	43487680 ...	Limiter Begrenzer	Rajoitin Limite	1

HF 231

Directional control valve – Suuntaventtiili – Steuerventil – Vanne de direction



Part Osa Teil Pièce	Order No. Til.nro. Best Nt No. de ordre	Description Bezeichnung	Nimitys Désignation	Remarks Huom. Obs Obs	Qty. Kpl. St. Pc.
	56075260 ...	Directional control valve Suuntaventtiili Eur Steuerventil Vanne de direction			1
1.	58219007 ...	Rear case Hintergehäuse	Takakotelo Boîtier arrière		1
2.	58218975 ...	Lever case Hebelgehäuse	Vipukotelo Boîtier de levier		1
3.		Pressure relief valve Druckventil	Painerajaventtiili 175 bar Soupape de décharge		1
4.		Spindle Spindel	Kara Tiroir cylindrique		1







GUARANTEE

FARMI Forest products are guaranteed to be free from defects in materials and workmanship for 12 months from the date of purchase.

This warranty does not cover defects resulting from:

- misuse of the product
- inadequate maintenance
- modifications of the product made without the manufacturer's consent

The warranty is effective only, if the lower portion of this page is completed and returned to the manufacturer within 14 days of receipt of the product..


Important

Before putting your FARMI to use, be sure to read the instruction and service booklet provided with the machine

FARMI Forest Corporation
Ahmolantie 6
74510 PELTOSALMI



FARMI Forest
Ahmolantie 6
FIN-74 510 PELTOSALMI
FINLAND





Date of delivery: ___ / ___ 20___

Dealer: _____

Dealer's address: _____

Dealer's tel: _____

Product and type: _____

Serial number: _____



Return to the manufacturer

Date of delivery: ___ / ___ 20___

Dealer: _____

Dealer's address: _____

Dealer's tel: _____

Customer: _____

Customer's address: _____

Customer's tel: _____

Product and type: _____

Serial number: _____

Notes: _____



FARMI[®]
Forest
Made in Finland

