FEL-PRO INSTALLATION TIPS

The gasket furnished for this application replaces the OE pre-applied RTV silicone sealant. It is designed to allow the reuse of the existing cover.

Scrap the cover flanges with a plastic scraper to remove the existing sealant. Since the cover is aluminum care should be taken to avoid damaging the gasket surface.

Once the flange is clean and all residual sealant has been removed place the gasket on the cylinder head according to the directions stamped on the gasket with the “COVER SIDE” stamp showing up towards the valve cover.

Place the cover on the gasket, install the fasteners, and tighten to specs.

© 2002 Federal-Mogul Corporation
Printed in U.S.A.
Form No. I-2022 (Rev. 7/02)