

INSTRUKCJA UŻYTKOWANIA WYCIERACZKA DO BUTÓW

PRZED UŻYCIEM

Upewnij się, że wycieraczka jest stabilna i nieuszkodzona przed pierwszym użyciem.

OPIS UŻYTKOWANIA I MONTAŻU

Używaj wycieraczki do czyszczenia obuwia, pocierając podeszwą o jej powierzchnię. Wycieraczka jest gotowa do użycia bez montażu.

CZYSZCZENIE I KONSERWACJA

Regularnie oczyszczaj wycieraczkę z brudu. W zależności od materiału, odkurzaj lub myj wodą z detergentem.

OSTRZEŻENIA

Używaj wycieraczki zgodnie z przeznaczeniem. Nie przechowuj jej w wilgotnym miejscu i unikaj nadmiernego obciążenia.

PRODUCENT

Mirosław Gockowiak, Ciele, ul. Przylesie 3, 86-005 Białe Błota, Wyprodukowano w ChRL,

Numer partii:

Ciele, ul. Niedźwiedzia 11, 86-005 Białe Błota, gpsr@gockowiak.pl, www.tohurt.pl

INSTRUCTIONS FOR USE

SHOE DOORMAKER

BEFORE USE

Make sure the doormat is stable and undamaged before first use.

USAGE AND ASSEMBLY DESCRIPTION

Use the doormat to clean shoes by rubbing the sole against the surface. The doormat is ready to use without assembly.

CLEANING AND MAINTENANCE

Regularly clean the doormat from dirt. Depending on the material, vacuum or wash with water and detergent.

WARNINGS

Use the doormat as intended. Do not store it in a damp place and avoid excessive loading.

MANUFACTURER

Mirosław Gockowiak, Ciele, ul. Przylesie 3, 86-005 Białe Błota, Made in the People's Republic of China,

Batch number:

Ciele, ul. Niedźwiedzia 11, 86-005 Białe Błota, gpsr@gockowiak.pl, www.tohurt.pl