

SEREK LAMPKA NOCNA LED INSTRUKCJA OBSŁUGI		UWAGA! RYZYKO ZADŁAWIENIA Małe części. Nie dla dzieci poniżej 10 roku życia. Przedmiot kolekcjonerski. Nie zabawka. WARNING! CHOKING HAZARD Small parts. Not for children under 10 years of age. Adult collectable. Not a toy.
---	--	--

	Serek Lampka Nocna LED Przełącznik światła Przełącznik Wskaźnik ładowania Gniazdo ładowania USB-C	Ładowanie Lampka posiada wbudowany akumulator. Używaj ładowarki DC5V $\equiv$ 1A lub portu USB w komputerze do ładowania produktu. Wskaźnik ładowania (zaznaczony na poprzedniej stronie) zapala się podczas ładowania i gaśnie po pełnym naładowaniu. Kabel USB - USB-C (w zestawie)	Funkcje Włączanie/wyłączanie Naładuj produkt do pełna przed pierwszym użyciem. Przestaw przełącznik w odpowiadające miejsce: OFF - jeśli chcesz wyłączyć światło, 50% - jeśli chcesz włączyć światło z 50% mocy, 100% - jeśli chcesz włączyć światło z pełną mocą. Delikatnie puknij Serek, aby włączyć/wyłączyć światło. Opóźnienie czasowe Przestaw przełącznik w odpowiadające miejsce: ∞ - jeśli chcesz, aby światło stałe świeciło, 30 - jeśli chcesz, aby zgasło po 30 minutach, 60 - jeśli chcesz, aby zgasło po 60 minutach.	Parametry Produktu Nazwa produktu: SEREK LAMPKA NOCNA LED Symbol: MW20544 Kolor produktu: Żółty Napięcie znamionowe: DC5V $\equiv$ 1A Prąd znamionowy: 0.2A Pojemność akumulatora: 1200mAh Moc: 1W Waga: 163g Materiał: ABS+HIPS+Silikon Wymiary: 114x151x67mm	Uwaga! • Naładuj produkt do pełna przed pierwszym użyciem lub po długim czasie nieużywania. • Produkt nie powinien być umieszczany pod kątem większym niż 6°. • Nie używaj produktu w środowisku o wysokiej temperaturze lub wysokiej wilgotności. • Trzymaj produkt z dala od wody. • Produkt posiada wbudowany akumulator litowy. • Nie rozkręcaj, nie naprawiaj, nie modyfikuj produktu na własną rękę. • Źródło światła w produkcji jest niewymienialne.
CHEESE LED NIGHT LIGHT USER GUIDE	Cheese LED Night Light Light switch Timer button Charging indicator USB-C Charging port	Charging The product has a built-in battery, please use a DC5V $\equiv$ 1A adapter or a computer USB port when charging. The charging indicator (shown on previous page) lights up while charging and turns off when fully charged. USB - USB-C cable (included)	Functions Power ON/OFF Please charge the product fully before first use. Push the light switch to desired position: OFF - if you want to turn OFF the light, 50% - if you want to turn ON the light at 50% brightness, 100% - if you want to turn ON the light at full brightness. Lightly tap the Cheese to turn it ON/OFF Timer Push the timer switch to desired position: ∞ - if you want the light to stay on, 30 - if you want the light to turn off after 30 minutes, 60 - if you want the light to turn off after 60 minutes.	Product Parameters Product name: CHEESE LED NIGHT LIGHT Symbol: MW20544 Product color: Yellow Rated voltage: DC5V $\equiv$ 1A Rated current: 0.2A Battery capacity: 1200mAh Rated power: 1W Weight: 163g Material: ABS+HIPS+Silicone Dimensions: 114x151x67mm	Warning! • Please charge the product fully before using it for the first time or after a long time of not using it. • The product shall not be placed at an angle of inclination of more than 6°. • Don't use the product in a high-temperature and high-humidity environment. • Keep the product away from water. • This product's built-in lithium battery can not be replaced. • Do not disassemble, repair or modify the product by yourself. • The light source of this product is not replaceable.