

INSTRUKCJA OBSŁUGI LAMPKI NOCNEJ Z PROJEKTOREM NL-08 I NL-09

NL-08 LAMPKA LED

NL-09 LAMPKA LED



Serdecznie dziękujemy za zakup lampy LED **NL-08** lub **NL-09** marki LEDLUMEN®. Mamy nadzieję, że będą Państwo zadowoleni z dokonanego wyboru w całym okresie użytkowania.

DANE TECHNICZNE

Moc w trybie włączenia	3W
Napięcie zasilania	DC 5V
Prąd zasilania	1A
Barwy światła	ciepła, chłodna, niebieska
Bateria typu 18650 Li-Ion	1200 mAh
Kabel zasilający USB-C	50 cm
Oddawanie barw	Ra > 80
Materiał obudowy	ABS + PC
Stopień ochrony	IP20

INSTRUKCJA DOTYCZĄCA PRZYCISKÓW



Przycisk ON/OFF

Krótko nacisnąć, aby włączyć/wyłączyć zasilanie i rozpocząć korzystanie z projektora.



Regulacja jasności

Krótko nacisnąć, aby dostosować jasność światła (3 poziomy jasności do wyboru).




Zmiana koloru LED

Gdy światło jest włączone, krótko nacisnąć przycisk, aby przełączyć pomiędzy kolorami światła a trybem zmiany kolorów.



Przycisk obrotu

Krótko nacisnąć, aby włączyć/wyłączyć obrót światła projekcyjnego. Przycisk obrotu działa tylko wtedy, gdy światło jest włączone.



wskaźnik zasilania




gniazdo USB-C


W ZESTAWIE



Podstawa lampy projekcyjnej



Oslona lampy projekcyjnej




Przezroczysta tuba




Przezroczysta górna pokrywka



Prostokątny film projekcyjny



Okrągły film projekcyjny



Kabel do ładowania USB typu C

SPOSÓB UŻYTKOWANIA



Tryb lampki nocnej
lampa nocna z założoną osłoną



Tryb projekcji: zdejmij osłonę lampy i włącz przełącznik zasilania, aby wyświetlać wzory na ścianie lub suficie.

Wskazówka: Efekt projekcji jest lepszy, gdy jest wyświetlany w ciemnym pomieszczeniu.

PROCEDURA WYMIANY FILMU PROJEKCYJNEGO

1



1. Chwyćając za osłonę lampy projekcyjnej, zdejmij klosz, obracając go w kierunku przeciwnym do ruchu wskazówek zegara.

2



2. Wyjmij przezroczystą tubę znajdującą się w środku urządzenia, obracając ją w kierunku przeciwnym do ruchu wskazówek zegara.

3



3. Po wyciągnięciu przezroczystej pokrywki, usuń okrągły i prostokątny film projekcyjny.

4



4. Wybierz nowy okrągły i prostokątny film projekcyjny i zdejmij warstwę ochronną z boku.

5



5. Zroluj prostokątny film i dopasuj go do zaczepów.

6



6. Nowy zwinięty film wprowadź od spodu tuby lampy.

7



7. Najpierw umieść nowy okrągły film w przezroczystej pokrywce lampy, a następnie zamknij tubę lampy i pokrywę.

8



8. Skieruj stopkę tuby lampy na zaczep uchwyty lampy projekcyjnej, zamknij ją i obróć zgodnie z ruchem wskazówek zegara, aby ją zablokować.

9



9. Obróć osłonę lampy projekcyjnej zgodnie z ruchem wskazówek zegara, aby ją zamontować.

UWAGA!

1. Nie demontuj, nie uderzaj, nie ściskaj ani nie wrzucaj do ognia.
2. Nie używaj produktu w wilgotnym środowisku ani w wysokiej temperaturze.
3. Źródło światła w produkcie nie podlega wymianie. Po wygaśnięciu źródła światła należy wymienić cały produkt.
4. Odłącz zasilanie, jeśli produkt nie będzie używany przez dłuższy czas. Zaleca się ładowanie produktu co 30 dni, aby zapobiec skróceniu żywotności baterii litowej.
5. Podczas regularnego użytkowania nie umieszczaj produktu na powierzchni nachylonej pod kątem większym niż 6 stopni.
6. Dzieci poniżej 5. roku życia powinny korzystać z produktu pod nadzorem osoby dorosłej.
7. Produkt zawiera wbudowaną baterię litową, która nie podlega wymianie.
8. Osoby z niedowidzeniem lub astygmatyzmem, a także dzieci, nie powinny przez dłuższy czas patrzeć bezpośrednio na źródło światła produktu.

USER MANUAL FOR PROJECTOR NIGHT LAMPS NL-08 AND NL-09

NL-08 LED LAMP

NL-09 LED LAMP



Thank you very much for purchasing the LEDLUMEN[®] LED lamp **NL-08** or **NL-09**. We hope that you will be satisfied with your choice throughout the entire period of use.

TECHNICAL SPECIFICATIONS

Power in On mode	3W
Supply voltage	DC 5V
Power current	1A
Light colors	warm, cool, blue
Battery Type 18650 Li-Ion	1200 mAh
USB-C power cable	50 cm
Color rendering	Ra > 80
Enclosure material	ABS + PC
Protection rating	IP20

BUTTON INSTRUCTIONS



ON/OFF Button

Press briefly to turn the power on/off and start using the projector.



Brightness Adjustment

Press briefly to adjust the light: brightness (3 brightness levels to choose from).



LED Color Change

When the light is on, press the button briefly to switch between light colors and color change mode.



Rotation Button

Press briefly to turn the projection light rotation on/off. The rotation button only works when the light is turned on.



Power indicator




USB-C port


SET CONTENTS




Projector lamp base



Projector lamp cover




Transparent tube




Transparent top lid



Rectangular projection film



Round projection film




Type C USB charging cable

INSTRUCTIONS FOR USE



Night Light Mode

Night light with the cover attached



Projection Mode Remove the lamp cover and turn on the power switch to project patterns onto the wall or ceiling.

Tip: The projection effect is better when displayed in a dark room.

PROJECTION FILM REPLACEMENT PROCEDURE

①



1. Grasp the projector lamp cover; and remove the lampshade by turning it counterclockwise.

②



2. Remove the transparent tube located inside the device by turning it counterclockwise.

③



3. After removing the transparent cover, take out the round and rectangular projection films.

④



4. Select the new round and rectangular projection films and remove the protective layer from the side.

⑤



5. Roll up the rectangular film and align it with the clips.

⑥



6. Insert the new rolled-up film from the bottom of the lamp tube.

⑦



7. First, place the new round film into the transparent lamp cover; then close the lamp tube and the cover;

⑧



8. Aim the lamp tube's base at the clip on the projector holder; close it, and turn it clockwise to secure it.

⑨



9. Turn the projector lamp cover clockwise to install it.

CAUTION!

- Do not disassemble, strike, crush, or throw into fire.
- Do not use the product in damp environments or at high temperatures.
- The light source in the product is non-replaceable. If the light source expires, the entire product must be replaced.
- Disconnect the power supply if the product will not be used for an extended period. It is recommended to charge the product every 30 days to prevent shortening the lifespan of the lithium battery.
- During regular use, do not place the product on a surface inclined at an angle greater than 6 degrees.
- Children under the age of 5 should use the product only under adult supervision.
- The product contains a built-in lithium battery that is non-replaceable.
- Individuals with visual impairments, astigmatism, or children should not look directly at the product's light source for extended periods.