

Rechargeable COB + XPE Headlamp

with motion sensor

Operating instructions:

1. Mode Switching

Short Press switch-on button: COB Cool White High--COB Cool white Low--COB Warm White High--COB Warm White Low-- Side Light High--Side Light Low--Off.

Continuous press Switch-on button approx. 3 seconds = COB Cool White and COB Warm both are activated; Short Press once more, Strobe is activated.

2. Motion Sensor

Continuous press Motion Sensor button approx. 3 seconds = Motion Sensor;

When the motion Switch is activated, the indicator lights up Orange (Red+Green)



3. Charging the headlamp

As the requirement of the Safe Transport of Goods, the battery can only store cell capacity less than 30%. Before using, please charge the battery via the charger cable.



Open the cover of the charge pocket. Plug the USB-C male end of the cable in the USB-c pocket of the headlamp, plug the USB 2.0 male end into a output DC5V USB port of Wall Adapter / Car Charger.

4. Maintenance and disposal

Cleaning only after switching off and cooling the headlamp.

Clean the headlamp with a dry or slightly moistened, fiber-free cloth.

Do not use aggressive or chemical detergents

Regular check for damage

Store in a dry place protected from heat and cold

Waste equipment must not be disposed of in household waste!

If the device can no longer be used, every consumer is legally obliged to use old equipment separated from household waste

e.g. at a collection point of his municipality/district. This ensures that the waste equipment is professionally exploited and negative effects on the environment are avoided. Therefore, electrical appliances are marked with the symbol shown.

Batteries and accumulables must not be disposed of in household waste! Every consumer is required by law to use all batteries and accumulable batteries, whether they contain pollutants or not, to a collection point of his municipality/-district or in the trade, so that it can be used for an environmentally friendly disposal can be carried out.

Please release batteries and accumulators only when discharged!

Instrukcja obsługi:

1. Wybór trybu pracy latarki

Naciśnij przycisk ON/OFF aby wybrać jeden z trybów: COB zimne 100% - COB zimne 50% - COB ciepłe 100% - COB ciepłe 50% - XPE boczne 100% - XPE 50% - OFF. Naciśnij przycisk ON/OFF i przytrzymaj przez 3s. aby włączyć jednocześnie światło COB ciepłe i zimne. Kolejne naciśnięcie włączy tryb stroboskopowy.

2. Czujnik ruchu

Naciśnij i przytrzymaj przycisk sensora, aby włączyć czujnik ruchu. Gdy czujnik jest włączony, dioda świeci na pomarańczowo.



3. Ładowanie akumulatora

Zgodnie z wymogiem Bezpiecznego Transportu Towarów akumulator może przechowywać tylko pojemność ogniwi mniejszą niż 30%. Przed użyciem naładuj baterię.



Podnieś osłonę gniazda ładowania. Podłącz wtyk USB-C do gniazda w latarce, a drugi koniec kabla USB podłącz do źródła zasilania DC 5V (ładowarka sieciowa, samochodowa, powerbank, komputer itp.)

4. Konserwacja i utylizacja

Latarkę należy czyścić tylko po wyłączeniu zasilania i schłodzeniu soczewki.

Latarkę należy czyścić suchą lub lekko zwilżoną ściereczką.

Nie używaj agresywnych ani chemicznych środków czyszczących

Regularnie sprawdzaj, czy nie ma uszkodzeń

Przechowywać w suchym miejscu, w temperaturze pokojowej.

Zużytego sprzętu oraz baterii nie wolno wyrzucać razem z odpadami komunalnymi!

Jeżeli urządzenie nie nadaje się już do użytku, każdy konsument jest zobowiązany do zutylizowania sprzętu w punkcie zbiórki odpadów elektronicznych w swojej gminie/powiecie.

Przed oddaniem zużytych akumulatorów do punktu zbiórki odpadów należy doprowadzić do całkowitego rozładowania ogniwi.