

Assembly and use instructions.

1. Unfolding and folding the dryer.

- lift the upper frame until the latch locks (click sound).
- to fold the dryer, hold the upper frame and unlock the latches.

2. Advantages:

- Space saving
- ability to dry long clothes
- easy to store
- durable construction

Dimensions after unfolding: height 138 cm * width 58 cm * length 51 cm

Warning!

Heavy clothes such as jackets and trousers should be hung on the external frame. The maximum load on a single rod is 1 kg.

The load should be distributed evenly.

When folding the dryer, be careful not to hurt your hands, hold the frame and unlock the locks one by one and let the structure fold.

Never open two latches at the same time.

Instrukcja montażu i użytkowania.

1. Rozkładanie i składanie suszarki.

- podnieś górną ramę, aż zatrzask się zablokuje (dźwięk kliknięcia).
- aby złożyć suszarkę, przytrzymaj górną ramę i odblokuj zatrzaski.

2. Zalety:

- Oszczędność miejsca
- Możliwość suszenia długich ubrań
- Łatwość przechowywania
- Wytrzymała konstrukcja

Wymiar po rozłożeniu: wys 138 cm* szer 58 cm * dł.51cm

Ostrzeżenie!

Ciężkie ubrania jak kurtki i spodnie powinny być wieszane na zewnętrznej ramie. Maksymalne obciążenie pojedynczego pręta wynosi 1 kg.

Obciążenie powinno być rozłożone równomiernie.

Podczas składania suszarki uważaj aby nie zranić rąk, trzymając za ramę odblokuj pojdyńczo zamki i pozwól konstrukcji się złożyć.

Nigdy nie otwieraj dwóch zatrzasków w jednym momencie.