

instruction manual Carefully review this manual before operating the product.	Specifications: <table border="1"> <tr><td>BT Version:</td><td>V5.4</td></tr> <tr><td>Frequency:</td><td>2,402~2,480 Ghz</td></tr> <tr><td>BT Range:</td><td>33 feet without obstacle</td></tr> <tr><td>Support Profile:</td><td>HSP/HFP/A2DP/AVRCP</td></tr> <tr><td>Earbud Battery:</td><td>3.7V 35mAh</td></tr> <tr><td>Charging Case Battery:</td><td>3.7V 50mAh</td></tr> <tr><td>Microphone:</td><td>SI, 42dB ± 3dB</td></tr> <tr><td>Speaker:</td><td>φ13mm, 32Ω, 3mW</td></tr> <tr><td>Charging Input Current:</td><td>DC 5V 1A</td></tr> <tr><td>Charging port:</td><td>Type-C</td></tr> <tr><td>Type-C port Charge Time:</td><td>About 2 hours</td></tr> <tr><td>Earbud Work Time per Charge(at 70% volume):</td><td>About 6 hours</td></tr> </table> Package Include: Case*1 Earbud (L/R)*1 Charging Cable*1 Manual*1 Extra Ear Caps*2 Pairs Power Off: When the earbuds are in the case, open the case to power on. Power Off/Earbuds Charging: When the case has power, pull the earbuds into the case and close it, the earbuds will power out and start charging automatically. Auto Power Off: The earbuds will power off automatically if not paired in 3 minutes.	BT Version:	V5.4	Frequency:	2,402~2,480 Ghz	BT Range:	33 feet without obstacle	Support Profile:	HSP/HFP/A2DP/AVRCP	Earbud Battery:	3.7V 35mAh	Charging Case Battery:	3.7V 50mAh	Microphone:	SI, 42dB ± 3dB	Speaker:	φ13mm, 32Ω, 3mW	Charging Input Current:	DC 5V 1A	Charging port:	Type-C	Type-C port Charge Time:	About 2 hours	Earbud Work Time per Charge(at 70% volume):	About 6 hours	Earbuds battery low reminder: There will be an audio prompt every 1 minute, and orange indicator flash every 1 minute Case Battery low reminder: The case battery screen will show battery level after you unlock the screen. Case charging: Use provided Type-C cable to charge the case with DCSV power adapter only. (Do not use power supply higher than 5V, it may damage the product thus can't be charged.) Note: Please maintain a charge at least every 3 months, if the product will not be in use for a long time, to keep the battery active and prolong the life. Diagram & Button Operations:	Earbud indicator: Waiting for pairing: Flash orange and white L&R Paired: One flash orange and white, the other one flash white every 5 seconds L/R Paired with Phone: Indicator go off Charging: Stay orange Charging finished: Go off MFB: Play/Pause music/Answer phone calls: Touch 1 time Hang up/Reject phone calls: Touch and hold for about 2 seconds Previous Track: Touch Left earbud 2 times Next Track: Touch Right earbud 2 times Activate phone voice control: Touch 3 times ANC On/Ambient Sound On/ANC Off: Touch and hold for about 3 seconds to switch, you can hear an audio prompt. Power on: Touch and hold for 3 seconds(When the earbuds are outside of the case, and in power off state.) Touch Display Screen: Call Control Touch the screen to control answering, hanging up and rejecting calls Music Control Switch Noise Reduction Mode Touch to switch from ANC Off/ANC On/Ambient Sound On mode	Looking for earphones Select L or R, and then touch start the earbuds will play a beep sound after you find it, touch the pause icon to stop the beep. Alarm clock settings Touch the left/right icon to set an alarm for 5/10/30/60min, the earbuds will play a beep sound after the count down you can touch repeat to set alarm, or touch stop to end the beep. Date and time Touch setup to set the date and time, touch save after finished. Screen brightness Touch the left/right icon to reduce/increase the screen brightness. Equalizer Touch the left right icon to select from normal/rock/pop/classic/jazz mode.	Set Language Touch the left/right icon to select from 16 languages:Simplified Chinese, English, Traditional Chinese, Japanese, Russian, German, Korean, French, Turkish, Arabic, Portuguese, Spanish, Vietnamese, Thai, Malay, Italian Set Screen Wallpaper Touch the left/right icon to change lock screen wallpaper. Photo taking Touch the icon to take a photo. Flashlight function Touch open and the screen will turn white, touch the screen to return. Like When streaming Tiktok video, touch the like icon to mark, like, touch the left/right icon to switch Previous/Next video. Note: 1.When operating touch screen for the functions of your phone, like switching previous/next music, videos, taking photos, etc. need to keep the charging case and phone within 8 meters. 2.When the charging case battery is below 10%, can't do touchscreen operations.	Type-C charging Port: Use DC 5V power adapter only. (Do not use power supply higher than 5V.) One earbud indicator flash while every 5 seconds, while the other one flash orange and white, means L & R are paired. Case Button: Press to turn on/off the display screen. Pairing: 1.Earbuds Pairing: Open the case, the L & R earbuds will enter pairing mode and pair	2.Earbuds Pair with Phone: Turn on the Bluetooth of your phone, search for "AuraTouch Pro" and pair. FAQ: The product can't pair with my phone. 1.Please turn off the BT of other devices, make sure the earbuds are in pairing mode. 2.Clear the pairing history of your phone. Turn off the BT then turn on, and try again.	Important Notes and Safety Precautions Fully charge the earbuds before first use to ensure proper operation. Use only 5V-1A power adapters or certified USB ports on computers for charging. Avoid using the device near Wi-Fi routers and other high-frequency transmitters that may cause signal interference. It is recommended to operate the device within a 15-meter range without physical obstacles to maintain a stable Bluetooth connection. If you experience issues with one earbud, re-pair both earbuds following the pairing instructions. Do not use or store the device in environments with high temperatures or excessive humidity, as this may damage the product or reduce its performance. Avoid dropping the earbuds or charging case, as impact may cause mechanical damage and affect device functionality. Do not disassemble or attempt to repair the device yourself. For any problems, please contact the authorized dealer or manufacturer. Technical Specifications: Operating Frequency/Range: 2402~2480 MHz Maximum RF Output Power: +1.42 dBm
BT Version:	V5.4																															
Frequency:	2,402~2,480 Ghz																															
BT Range:	33 feet without obstacle																															
Support Profile:	HSP/HFP/A2DP/AVRCP																															
Earbud Battery:	3.7V 35mAh																															
Charging Case Battery:	3.7V 50mAh																															
Microphone:	SI, 42dB ± 3dB																															
Speaker:	φ13mm, 32Ω, 3mW																															
Charging Input Current:	DC 5V 1A																															
Charging port:	Type-C																															
Type-C port Charge Time:	About 2 hours																															
Earbud Work Time per Charge(at 70% volume):	About 6 hours																															

AuraTouch Pro TWS Earbuds

Specyfikacja:

Wersja Bluetooth:	V5.4
Zakres częstotliwości:	2,402~2,480 Ghz
Zasięg Bluetooth:	Do 10 metrów (bez przeszkód)
Obsługiwane profile:	HSP/HFP/A2DP/AVRCP
Pojemność akumulatora słuchawki:	3,7V 35mAh
Pojemność akumulatora etui:	3,7V 500mAh
Czułość mikrofonu:	SiL -42dB ± 3dB
Głośnik:	φ13mm, 32Ω, 3mW
Wejście ładowania:	DC 5V 1A
Port ładowania:	Type-C
Czas ładowania etui:	Około 2 godziny
Czas odtwarzania (przy 70% głośności):	Około 6 godzin

Zawartość zestawu:

- Etui ładujące × 1
- Lewa i prawa słuchawka × 1 para
- Kabel do ładowania Type-C × 1
- Instrukcja obsługi × 1
- Dodatkowe silikonowe końcówki × 2 pary

Włączanie: Otwórz etui ładujące — słuchawki włączą się automatycznie.

Wyłączanie i ładowanie: Włóż słuchawki z powrotem do etui i zamknij pokrywę. Słuchawki wyłączą się i rozpoczną ładowanie automatycznie.

Auto-wyłączanie: Słuchawki wyłączą się automatycznie, jeśli nie zostaną sparowane w ciągu 3 minut.

Status wskaźników słuchawk:

Parowanie: Miganie na pomarańczowo i biało ostrzegawczo co minutę oraz pomarańczowo i biało, druga na biało co 5 sek.

Połączone z telefonem: Dioda gaśnie.

Ładowanie: Stałe światło pomarańczowe.

Nieładowanie: Dioda gaśnie.

Obsługa MFB: Odtwarzanie/Pauza, odbieranie połączeń: Jedno dotknięcie.

Zakończenie/Odrzucenie połączenia: Przytrzymaj przez 2 sekundy.

Poprzedni utwór: Podwójne dotknięcie lewej słuchawki.

Następny utwór: Podwójne dotknięcie prawej słuchawki.

Asystent głosowy: Potrójne dotknięcie ANC / Ambient / Normal: Przytrzymaj 3 sekundy.

Ręczne włączenie: Przytrzymaj 3 sekundy (poza etui w trybie wyłączonym).

Elementy i obsługa dotykowa:

- Wskaźnik LED słuchawek/Mikrofon
- MFB (wielofunkcyjny przycisk)
- Mikrofon
- Bluetooth Icon
- Wyświetlacz poziomu baterii słuchawk
- Ecran dotykowy
- Przycisk etui
- Time
- Wyświetlacz poziomu baterii etui
- Port ładowania Type-C

Funkcje ekranu dotykowego:

Sterowanie połączeniami: Stuknij, aby odebrać, zakończyć lub odrzucić połączenie.

Sterowanie muzyką: Stuknij środkową ikonę, aby otworzyć/pauzować lewa/prawa — zmiana utworu.

Tryby redukcji szumów: Stuknij, aby przełączyć ANC / Ambient / Wyłączone.

Znajdź słuchawkę:

Wybierz L lub R, stuknij „Stuknij” — sygnalizator dźwiękowy. „Pause” aby zatrzymać.

Alarm:

Ustaw minutnik na 5/10/30/60 min. Po zakończeniu — sygnał w słuchawkach.

Data i godzina:

Ustaw i zapisz w „Setup”.

Jasność ekranu:

Dostosuj ikonami w lewo/prawo.

Equalizer:

Wybierz spośród Normal / Rock / Pop / Classic / Jazz.

Język:

16 języków: angielski, chiński uproszczony/tradycyjny, japoński, niemiecki, francuski, hiszpański itd.

Tapeta:

Zmień tło ekranu blokady.

Zdjęcie:

Dotknij ikony, aby wyzwać aparat w telefonie.

TikTok:

Środkowa ikona — polubienie, lewa/prawa — zmiana wideo.

Uwaga:

Funkcje ekranu działają od odległości 8 metrów. Przy poziomie baterii etui <10% dotyk nieaktywny.

Port ładowania type-C:

Używaj tylko zasilacza DC 5V. (Nie używaj zasilacza wyższego niż 5V.)

Przycisk sprawy:

Naciśnij, aby włączyć / wyłączyć ekran wyświetlacza.

Instrukcja parowania:

1.Parowanie słuchawk: Otwórz etui, L&R parują się automatycznie.

2.Połączenie z telefonem:

Włącz Bluetooth w telefonie, wyszukaj „AuraTouch Pro”, wybierz i połącz. Dioda gaśnie po połączeniu.

3.Automatyczne połączenie:

Przy kolejnym użyciu — włącz BT w telefonie, otwórz etui — słuchawki łączą się z ostatnim urządzeniem.

Q2: Słaby dźwięk lub mały zasięg.

A: Upewnij się, że nie ma przeszkód ani zakłóceń (routeiry Wi-Fi, mikrofalówki) w pobliżu.

Q3: Opóźnienia dźwięku.

A: Minimalne opóźnienia są normalne w BT, wersja 5.4 ogranicza je do minimum.

Q4: Etui nie ładuje słuchawk / nie wyłączają się po włożeniu.

A: Naładuj etui. Sprawdź, czy usunięto folię zabezpieczającą ze styków.

Q5: Problemy z mikrofonem.

A: Upewnij się, że masz założoną słuchawkę i że mikrofon nie jest zalepczyszczony.

Q6: Tylko jedna słuchawka się łączy.

A: Najpierw sparuj L&R, dopiero potem z telefonem.

Q7: Niski poziom głośności.

A: Sprawdź głośność w telefonie i słuchawkach. Użyj dobrze dopasowanych końcówek.

FAQ:

Q1: Nie można sparować z telefonem.
A: Wyłącz inne urządzenia Bluetooth. Wyczyść historię połączeń w telefonie. Wyłącz i włącz BT, spróbuj ponownie.

Ważne uwagi i środki ostrożności

Przed pierwszym użyciem naładuj słuchawki całkowicie, aby zapewnić ich prawidłowe działanie.

Do ładowania używaj wyłącznie zasilaczy o parametrach 5V/1A lub certyfikowanych portów USB w komputerach.

Unikaj używania urządzenia w pobliżu routeirów Wi-Fi oraz innych nadajników o wysokiej częstotliwości, które mogą powodować zakłócenia sygnału.

Zaleca się użytkowanie urządzenia w zasięgu do 15 metrów bez przeszkód, aby zapewnić stabilne połączenie Bluetooth.

W przypadku problemów z jedną ze słuchawek należy ponownie wykonać parowanie zgodnie z instrukcją obsługi.

Nie używaj ani nie przechowuj urządzenia w miejscach o wysokiej temperaturze lub dużej wilgotności, aby uniknąć uszkodzeń i obniżenia wydajności.

Unikaj upuszczania słuchawek i etui, ponieważ może to prowadzić do uszkodzeń mechanicznych i nieprawidłowego działania.

Nie rozkręcaj ani nie ingeruj samodzielnie w urządzenie. W przypadku jakiegokolwiek problemu skontaktuj się z autoryzowanym sprzedawcą lub producentem.

Parametry techniczne:
Zakres częstotliwości pracy: 2402–2480 MHz
Maksymalna moc sygnału RF: +14,2 dBm

- 1 -
- 2 -
- 3 -
- 4 -
- 5 -
- 6 -
- 7 -
- 8 -
- 9 -