AT-HDR-SW-52ED

HDR 5 x 2 Switcher | 100m

API Command Reference

October 2026



Table of Contents

Version Information **3**
Sales & Customer Support 3
Introduction **4**
General 4
Command Quick Reference **5**
Commands **7**

Version Information

This document lists the commands for controlling the AT-HDR-SW-52ED over RS-232 and Telnet. Its version history follows the original command reference.

Version	Date	Notes
1	Jul 2023	Initial release
HR 1.0	October 2026	Converted to the Hall Research document format. No command changes.

Sales & Customer Support

Item	Details
Main Office (US)	Hall Research, 1234 Lakeshore Dr Suite #150, Coppell, TX 75019
Support Hours	Monday – Friday, 8:00 a.m. – 6:00 p.m. (CST)
Website	https://www.hallresearch.com
Product Page (AT-HDR-SW-52ED)	https://www.hallresearch.com/product/AT-HDR-SW-52ED

IMPORTANT: Visit hallresearch.com/product/AT-HDR-SW-52ED for the latest firmware updates and documentation.

Introduction

General

This document provides an alphabetical list of commands available for the AT-HDR-SW-52ED. Commands are not case-sensitive. If the command fails or is entered incorrectly, then Command FAILED:(CommandName) is returned. Commands can be sent using RS-232 or Telnet. There should be a 500 millisecond delay between each command sent to the unit. The default port for Telnet is 23.

IMPORTANT: Each command is terminated with a carriage-return (0x0d) and the feedback is terminated with a carriage-return and line-feed (0x0a).

Command Quick Reference

Select a command name to go to its full description.

Command	Description
AudioSrc	Sets the audio source for the optical port on the unit
AutoSW	Enables or disables auto switching between input ports
Blink	Enables or disables blinking of the POWER LED indicator on the front panel
Broadcast	Enables or disables broadcast mode
ButtonPower	Assigns the POWER button to the specified control protocol
ButtonVol	Assigns the VOLUME buttons to the specified control protocol
CliIPAddr	Specifies the IP address of the device to be controlled
CliMode	Sets the IP login mode
CliPass	Sets the login password for the device to be controlled
CliPort	Specifies the port number of the device to be controlled
CliUser	Sets the login username for the device to be controlled
Cspara	Sets the baud rate, data bits, parity bit, and stop bits for the (console) RS-232 port
CtlType	Sets the control protocol used to communicate with the display device
DispAutoPwr	Sets the state for auto display power control
EDIDCopy	Copies the downstream EDID from either the HDMI OUT or HDBaseT OUT port and stores the result in the specified memory location
HDCPSet	Set the HDCP reporting mode of the specified HDMI input port
help	Displays the list of available commands
help X	Displays help for the specified command
InputBroadcast	Sets the broadcast mode of the device
InputStatus	Event-driven API command
IPCFG	Displays the current network settings for the unit
IPDHCP	Enables or disables DHCP mode on the unit
IPLogin	Enables or disables the use of login credentials when starting a Telnet session on the unit
IPPort	Sets the Telnet listening port for the unit
IPQuit	Closes the current Telnet session
IPStatic	Sets the static IP address, subnet mask, and gateway (router) address of the AT-HDR-SW-52ED

Command	Description
IPTimeout	Specifies the time interval of inactivity before the Telnet session is automatically closed
IROff	Disables the IR receiver (window) on the unit
IROn	Enables the IR receiver (window) on the unit
Lock	Locks all the buttons on the front panel
Mreset	Resets the unit to factory-default settings
OutputStatus	Event-driven API command
PWOFF	Executing this command will power off the AT-HDR-SW-52ED
PWON	Executing this command will power on the AT-HDR-SW-52ED
PWSTA	Displays the current power state of the AT-HDR-SW-52ED
Reboot	Performs a soft reboot of the AT-HDR-SW-52ED
RepCmdTime	Sets the number of times a command will be sent
RepeatCmd	Enables / disables the RepCmdTime feature
RHostName	Displays the hostname of the unit
RS232para	Sets the RS-232 setting of the HDBaseT output of the device
RS232zone	Sends commands through the HDBaseT output
ScalerMode	Enables or disables the scaler on the AT-HDR-SW-52ED
SHostName	Sets the hostname of the unit
Status	Displays which input is routed to which output
System sta	Displays the status of the unit
TrigCEC	Sends the specified command to the display using CEC
TrigIP	Sends the specified command to the display over IP
TrigRS	Sends the specified command to the display using RS-232
Type	Displays the model information of the unit
Unlock	Unlocks the buttons on the front panel
Version	Displays the current firmware version of the unit
VOUT1	Increases / decreases the audio output volume
VOUTMute	Mutes / unmutes the output volume for the specified output
x1$	Enables or disables the HDMI OUT port
x1AVx1	Routes the specified input to the specified output
x2$	Enables or disables the HDBaseT OUT port

Commands

AudioSrc

Sets the audio source for the optical port on the unit. HDMI audio is de-embedded and heard on the specified output. Specify the sta argument to display the current setting.

Syntax

```
AudioSrc X
```

Parameter	Description	Range
X	Value	local, remote, sta

Example

```
AudioSrc local
```

Feedback

```
AUDIOSRC LOCAL
```

AutoSW

Enables or disables auto switching between input ports. Specify the sta argument to display the current setting.

Syntax

```
AutoSW X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
AutoSW on
```

Feedback

```
(no feedback)
```

Blink

Enables or disables blinking of the POWER LED indicator on the front panel. When set to on, the POWER LED indicator button will flash, alternating between blue and red, and can be used to physically identify the unit on a network. The POWER LED indicator will flash until the Blink off command is executed. on = enables blinking; off = disables blinking. Specify the sta argument to display the current setting. The default setting is off.

Syntax

```
Blink X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
Blink on
```

Feedback

```
Blink on
```

Broadcast

Enables or disables broadcast mode. By default, broadcast mode is set to on. When set to on, any system changes will be broadcast to the web server and on the control system (if connected), via TCP/IP and RS-232. To separate control between the web server and Telnet/RS-232, set this feature to Off. Command queries such as IPCFG and Type will only return information to the requester. Specify the sta argument to display the current setting.

Syntax

```
Broadcast X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
Broadcast on
```

Feedback

```
Broadcast on
```

ButtonPower

Assigns the POWER button to the specified control protocol. By default, the POWER button will toggle the state of the AT-HDR-SW-52ED between power on and standby. To assign the POWER button to control the power state of a sink device, set this value to the desired protocol. The default setting is none. Specify the sta argument to display the current setting.

Syntax

```
ButtonPower X
```

Parameter	Description	Range
X	Value	none, cec, rs-232, ip,sta

Example

```
ButtonPower cec
```

Feedback

```
BUTTONPOWER CEC
```

ButtonVol

Assigns the VOLUME buttons to the specified control protocol. By default, the VOLUME buttons control the output amplitude of the L/R audio port. To assign the VOLUME button to control the volume of a sink device, set this value to the desired protocol. The default setting is aud. Specify the sta argument to display the current setting.

Syntax

```
ButtonVol X
```

Parameter	Description	Range
X	Value	aud, cec, rs-232, ip, sta

Example

```
ButtonVol CEC
```

Feedback

```
BUTTONVOL CEC
```

CliIPAddr

Specifies the IP address of the device to be controlled. The IP address must be expressed using dot-decimal notation. Specify the sta argument to display the IP address of the connected device.

Syntax

```
CliIPAddr X
```

Parameter	Description	Range
X	Value	IP address

Example

```
CliIPAddr 192.168.10.20
```

Feedback

```
CLIIPADDR 192.168.10.20
```

CliMode

Sets the IP login mode. The default setting is non-login. Set this value to login to prompt for login credentials. Specify the sta argument to display the current setting.

Syntax

```
CliMode X
```

Parameter	Description	Range
X	Value	IP address

Example

```
CliMode login
```

Feedback

```
CLIMODE LOGIN
```

CliPass

Sets the login password for the device to be controlled.

Syntax

```
CliPass X
```

Parameter	Description	Range
X	Password	20 characters (max.)

Example

```
CliPass Fl0ti11a
```

Feedback

```
CLIPASS Fl0ti11a
```

CliPort

Specifies the port number of the device to be controlled. Specify the sta argument to display the current setting.

Syntax

```
CliPort X
```

Parameter	Description	Range
X	Port number	0 ... 65535, sta

Example

```
CliPort 23
```

Feedback

```
CLIPORT 23
```

CliUser

Sets the login username for the device to be controlled.

Syntax

```
CliUser X
```

Parameter	Description	Range
X	Username	20 characters (max.)

Example

```
CliUser Bigboss
```

Feedback

```
CLIUSER Bigboss
```

Cspara

Sets the baud rate, data bits, parity bit, and stop bits for the (console) RS-232 port. Each argument must be separated by a comma; no spaces are permitted. Brackets must be specified when executing this command. Specify the sta argument to display the current settings.

Syntax

```
Cspara[W,X,Y,Z]
```

Parameter	Description	Range
W	Baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200
X	Data bits	7, 8
Y	Parity bit	0, 1, 2 (0 = None, 1 = Odd, 2 = Even)
Z	Stop bits	1, 2

Example

```
Cspara[9600,8,0,1]
Cspara sta
```

Feedback

```
CSPARA[9600,8,0,1]
CSPARA[9600,8,0,1]
```

CtlType

Sets the control protocol used to communicate with the display device. Specify the sta argument to display the current setting.

Syntax

```
CtlType X
```

Parameter	Description	Range
X	Value	cec, rs-232, ip, sta

Example

```
CtlType cec
```

Feedback

```
CTLTYPE CEC
```

DispAutoPwr

Sets the state for auto display power control. Set to on to allow the AT-HDR-SW-52ED to send the power-on command to the display when an A/V signal is detected. When the AV signal is no longer present, the AT-HDR-SW-52ED will send the power-off command to the display. If this feature is not desired, then set to off. The default setting is on. If the AT-HDR-SW-52ED is placed in Matrix Mode, then this value will automatically be set to off. Specify the sta argument to display the current setting.

Syntax

```
DispAutoPwr X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
DispAutoPwr off
```

Feedback

```
DISPAUTOPWR OFF
```

EDIDCopy

Copies the downstream EDID from either the HDMI OUT or HDBaseT OUT port and stores the result in the specified memory location. If no device is detected on the output, then the message Error copying EDID, please check the specified output for connection will be returned.

Syntax

```
EDIDCopyX Y
```

Parameter	Description	Range
X	Output	1, 2 (1 = HDMI OUT, 2 = HDBaseT OUT)
Y	Memory location	1 ... 8

Example

```
EDIDCopy1 3
```

Feedback

```
EDIDCOPY1 3
```

HDCPSet

Set the HDCP reporting mode of the specified HDMI input port. Some computers will send HDCP content if an HDCP-compliant display is detected. Setting this value to off, will prevent the source from negotiating HDCP with any compliant sink devices. Setting this value to on will enable HDCP negotiation. Specify the sta argument to display the current setting.

Syntax

```
HDCPSetX Y
```

Parameter	Description	Range
X	HDMI input	1 ... 5
Y	Value	on, off, sta

Example

```
HDCPSet2 off
```

Feedback

```
HDCPSET2 OFF
```

help

Displays the list of available commands. To obtain help on a specific command, enter the help command followed by the name of the command.

Syntax

```
help
```

This command does not require any parameters.

Example

```
help
```

Feedback

```
User Command List
-----------------
AudioSrc
AutoSW
Blink
...
...
```

help X

Displays help for the specified command.

Syntax

```
help X
```

Parameter	Description	Range
X	Command	Command

Example

```
help unlock
```

Feedback

```
Unlock. Unlocks all the buttons on the
front panel.
```

InputBroadcast

Sets the broadcast mode of the device. This option determines whether or not system changes are announced over TCP/IP and RS-232 connections to any listening devices.

Syntax

```
InputBroadcast X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
InputBroadcast off
```

Feedback

```
INPUTBROADCAST OFF
```

InputStatus

Event-driven API command. Feedback indicates if a source device is present, based on both the HDMI 5V and TMDS lines. If a source is detected on the input, then a 1 will be returned. Inputs with no source connected will return a 0. If a PC is connected to an HDMI input, then the following is true: a. The control system, using either RS-232 or Telnet, will receive InputStatus 10000. b. Disconnection of the PC will return InputStatus 00000. User polling can be performed by using the following: InputStatus.

Syntax

```
InputStatus X
```

This command does not require any parameters.

Example

```
InputStatus
```

Feedback

```
INPUTSTATUS 10100 // inputs 1 and 3
```

IPCFG

Displays the current network settings for the unit.

Syntax

```
IPCFG
```

This command does not require any parameters.

Example

```
IPCFG
```

Feedback

```
IP ADDR: 10.20.20.38
NETMASK: 255.255.255.0
GATEWAY: 10.20.20.1
IP PORT: 23
```

IPDHCP

Enables or disables DHCP mode on the unit. Setting this value to off disables DHCP mode. The default setting is on. If this feature is disabled, then a static IP address must be specified for the unit. Refer to the IPStatic command for more information. Specify the sta argument to display the current setting.

Syntax

```
IPDHCP X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
IPDHCP off
```

Feedback

```
IPDHCP OFF
```

IPLogin

Enables or disables the use of login credentials when starting a Telnet session on the unit. Setting this value to on will prompt for both the username and password. Uses the same credentials as the web server. If no login credentials are required, set this value to off. Specify the sta argument to display the current setting.

Syntax

```
IPLogin X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
IPLogin off
```

Feedback

```
IPLOGIN OFF
```

IPPort

Sets the Telnet listening port for the unit. It should be noted that port numbers range from 0 to 65536. However, port numbers 0 through 1024 are reserved for privileged services and are designated as well-known ports. Consult an IT administrator on port use, if necessary. Specify the sta argument to display the current setting.

Syntax

```
IPPort X
```

Parameter	Description	Range
X	Port	0 ... 65535, sta

Example

```
IPPort 23
```

Feedback

```
IPPORT 23
```

IPQuit

Closes the current Telnet session. This command will only function over a Telnet session. If this command is entered within an RS-232 session, then Command FAILED will be returned.

Syntax

```
IPQuit
```

This command does not require any parameters.

Example

```
IPQuit
```

Feedback

```
Connection to host lost.
```

IPStatic

Sets the static IP address, subnet mask, and gateway (router) address of the AT-HDR-SW-52ED. If the AT-HDR-SW-52ED is in DHCP mode, executing this command will automatically switch the unit to use the specified static IP address information. Each argument must be expressed in dot-decimal notation and separated by a space. The default static IP address is 192.168.1.254.

Syntax

```
IPStatic X Y Z
```

Parameter	Description	Range
X	IP address	0 ... 255 (per octet)
Y	Subnet mask	0 ... 255 (per octet)
Z	Gateway (router)	0 ... 255 (per octet)

Example

```
IPStatic 192.168.1.112 255.255.255.0 192.168.1.1
```

Feedback

```
IPSTATIC 192.168.1.112 255.255.255.0 192.168.1.1
```

IPTimeout

Specifies the time interval of inactivity before the Telnet session is automatically closed. Set this value to 0 to specify no time out interval. Specify the sta argument to display the current setting.

Syntax

```
IPTimeout X
```

Parameter	Description	Range
X	Interval (in seconds)	0 ... 60000, sta

Example

```
IPTimeout 300
```

Feedback

```
IPTIMEOUT 300
```

IROff

Disables the IR receiver (window) on the unit. By default, the receiver is disabled.

Syntax

```
IROff
```

This command does not require any parameters.

Example

```
IROff
```

Feedback

```
IROFF
```

IROn

Enables the IR receiver (window) on the unit. By default, the receiver is disabled.

Syntax

```
IROn
```

This command does not require any parameters.

Example

```
IROn
```

Feedback

```
IRON
```

Lock

Locks all the buttons on the front panel. This feature is useful when the unit is installed in a rack environment or other remote location, to prevent unauthorized tampering or accidental pressing of the front-panel buttons. Also refer to the Unlock command.

Syntax

```
Lock
```

This command does not require any parameters.

Example

```
Lock
```

Feedback

```
LOCK
```

Mreset

Resets the unit to factory-default settings.

Syntax

```
Mreset
```

This command does not require any parameters.

Example

```
Mreset
```

Feedback

```
MRESET
```

OutputStatus

Event-driven API command. Feedback indicates if a sink device is present, based on the state of both the HDMI HPD and TMDS signals. If a sink is detected on an output, then a 1 will be returned. Outputs with no sink connected will return a 0. For example, the AT-HDR-SW-52ED has one HDMI output and one HDBaseT output, for a total of two outputs. Therefore, if all outputs were connected to a sink device, then the OutputStatus command would be formatted as: OutputStatus 11

Syntax

```
OutputStatus
```

This command does not require any parameters.

Example

```
If the local HDMI display is disconnected from the AT-HDR-SW-52ED, and the HDBT port is used, then the following
is true:
a. The control system, using either RS-232 or Telnet, will receive OutputStatus 01. The first digit in the output always indicates the HDMI output.
b. Reconnecting the display will return OutputStatus 11.
If all displays are powered-off using CEC, the following is true:
a. The control system, using either RS-232 or Telnet, will receive OutputStatus 00. Note that some displays may only mute video, while the HDMI HPD line is kept high.
```

Feedback

```
(no feedback)
```

PWOFF

Executing this command will power off the AT-HDR-SW-52ED. Execute the PWON command to power on the unit.

Syntax

```
PWOFF
```

This command does not require any parameters.

Example

```
PWOFF
```

Feedback

```
PWOFF
```

PWON

Executing this command will power on the AT-HDR-SW-52ED. Execute the PWOFF command to power off the unit.

Syntax

```
PWON
```

This command does not require any parameters.

Example

```
PWON
```

Feedback

```
PWON
```

PWSTA

Displays the current power state of the AT-HDR-SW-52ED.

Syntax

```
PWSTA
```

This command does not require any parameters.

Example

```
PWSTA
```

Feedback

```
PWON
```

Reboot

Performs a soft reboot of the AT-HDR-SW-52ED.

Syntax

```
Reboot
```

This command does not require any parameters.

Example

```
Reboot
```

Feedback

```
REBOOT
```

RepCmdTime

Sets the number of times a command will be sent. This may be required in systems where a command must be transmitted more than once, before an acknowledgement message is received. Specify the sta argument to display the current setting.

Syntax

```
RepCmdTime X
```

Parameter	Description	Range
X	Value	2 .. 4, sta

Example

```
RepCmdTime 2
```

Feedback

```
REPCMDTIME 2
```

RepeatCmd

Enables / disables the RepCmdTime feature. Specify the sta argument to display the current setting.

Syntax

```
RepeatCmd X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
RepeatCmd on
```

Feedback

```
REPEATCMD ON
```

RHostName

Displays the hostname of the unit. Execute the SHostName command to set the hostname.

Syntax

```
RHostName
```

This command does not require any parameters.

Example

```
RHostName
```

Feedback

```
RHostName SW52ED-060798
```

RS232para

Sets the RS-232 setting of the HDBaseT output of the device. Each argument must be separated by a comma; no spaces are permitted. Brackets must be specified when executing this command.

Syntax

```
RS232para[W,X,Y,Z]
```

Parameter	Description	Range
W	Baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200
X	Data bits	7, 8
Y	Parity bit	0, 1, 2 (0 = None, 1 = Odd, 2 = Even)
Z	Stop bits	1, 2

Example

```
RS232para[9600,8,0,1]
```

Feedback

```
RS232PARA[9600,8,0,1]
```

RS232zone

Sends commands through the HDBaseT output. Refer to the User Manual of the display device for a list of available commands. The command string argument must be enclosed within brackets. The command line must not contain any spaces.

Syntax

```
RS232zone[X]
```

Parameter	Description	Range
X	Command string	ASCII only

Example

```
RS232zone[command]
```

Feedback

```
RS232ZONE[command]
```

ScalerMode

Enables or disables the scaler on the AT-HDR-SW-52ED. Setting this value to on will downscale 4K content to 1080p when the output device detects a 1080p display on the output. When set to off, the output resolution / timing will be the same as the input source. The default setting is off. Specify the sta argument to display the current setting.

Syntax

```
ScalerModeX Y
```

Parameter	Description	Range
X	Output	1, 2 (1 = HDMI OUT, 2 = HDBaseT OUT)
Y	State	on, off, sta

Example

```
ScalerMode1 on
```

Feedback

```
SCALERMODE1 ON
```

SHostName

Sets the hostname of the unit. Names exceeding 15 characters in length will be truncated to characters 1 through 15. Execute the RHostName command to display the hostname.

Syntax

```
SHostName
```

Parameter	Description	Range
X	Hostname	15 characters (max.)

Example

```
SHostName
```

Feedback

```
SHOSTNAME SW-52ED-ConfRm
```

Status

Displays which input is routed to which output. Result is returned as xYavxZ, where Y is the input and Z is the output.

Syntax

```
Status
```

This command does not require any parameters.

Example

```
Status
```

Feedback

```
X1AVX1,X1AVX2
```

System sta

Displays the status of the unit.

Syntax

```
System sta
```

This command does not require any parameters.

Example

```
System sta
```

Feedback

```
Model: AT-HDR-SW-52ED
MAC Addr: b8-98-b0-06-07-98
Address Type: DHCP
IP Addr: 10.20.20.38
Netmask: 255.255.255.0
Gateway: 10.20.20.1
HTTP Port: 80
Telnet Port: 23
Firmware: 1.0.0
On/Up Time <dd HH:mm:ss>: 00 13:32:19
Hostname: SW52ED-060798
```

TrigCEC

Sends the specified command to the display using CEC. Note that CEC is an HDMI protocol. Therefore, HDBaseT outputs will trigger CEC commands from the connected receiver. Do not add a space between the command and the first argument.

Syntax

```
TrigCECX Y
```

Parameter	Description	Range
X	Output	1, 2
Y	Command	on, off, vol+, vol-, mute, input

Example

```
TrigCEC1 vol+
```

Feedback

```
TRIGCEC1 VOL+
```

TrigIP

Sends the specified command to the display over IP. Do not add a space between the command and the first argument.

Syntax

```
TrigIPX Y
```

Parameter	Description	Range
X	Output	1, 2
Y	Command	on, off, vol+, vol-, mute_on, mute_off

Example

```
TrigIP1 vol+
```

Feedback

```
TRIGIP1 VOL+
```

TrigRS

Sends the specified command to the display using RS-232. Do not add a space between the command and the first argument.

Syntax

```
TrigRSX Y
```

Parameter	Description	Range
X	Output	1, 2
Y	Command	on, off, vol+, vol-, mute_on, mute_off

Example

```
TrigRS1 vol+
```

Feedback

```
TRIGRS1 VOL+
```

Type

Displays the model information of the unit.

Syntax

```
Type
```

This command does not require any parameters.

Example

```
Type
```

Feedback

```
AT-HDR-SW-52ED
```

Unlock

Unlocks the buttons on the front panel. Also refer to the Lock command.

Syntax

```
Unlock
```

This command does not require any parameters.

Example

```
Unlock
```

Feedback

```
Unlock
```

Version

Displays the current firmware version of the unit.

Syntax

```
Version
```

This command does not require any parameters.

Example

```
Version
```

Feedback

```
V1.0.0
```

VOUT1

Increases / decreases the audio output volume. In addition to specifying an integer value, the + and - arguments can be used to increase or decrease the volume level by 1. Specify the sta argument to display the current setting.

Syntax

```
VOUT1 X
```

Parameter	Description	Range
X	Value	-90 ... 10, +, -, sta

Example

```
VOUT1 -10
```

Feedback

```
VOUT1 -10
```

VOUTMute

Mutes / unmutes the output volume for the specified output. Do not include a space between the command and the first argument. Specify the sta argument to display the current setting.

Syntax

```
VOUTMuteX Y
```

Parameter	Description	Range
X	Output	1, 2, 3, 4 (1 = analog audio, 2 = S/PDIF, 3 = HDMI, 4 = HDBaseT)
Y	Value	on, off, sta

Example

```
VOUTMute2 on
```

Feedback

```
VOUTMUTE2 ON
```

x1$

Enables or disables the HDMI OUT port. Set this value to off to disable the port. Specify the sta argument to display the current setting.

Syntax

```
x1$ X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
x1$ off
```

Feedback

```
X1$ OFF
```

x1AVx1

Routes the specified input to the specified output. If the system is in Matrix Mode, then 1 or 2 can be specified as output flags.

Syntax

```
xYAVxZ
```

Parameter	Description	Range
Y	HDMI input	1 ... 5
Z	Output	1, 2 (1 = HDMI OUT, 2 = HDBaseT OUT)

Example

```
x1AVx2
```

Feedback

```
X1AVX2
```

x2$

Enables or disables the HDBaseT OUT port. Set this value to off to disable the port. Specify the sta argument to display the current setting.

Syntax

```
x2$ X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
x2$ off
```

Feedback

```
X2$ OFF
```