



VALVE INSERTION TOOL

- For the installation or removal of snap-in type tubeless tire valves.

Proper Use:

1. Dismount tire from wheel.
2. Insert tool from outside of wheel toward inside.
3. Thread valve onto valve tool.
4. Pull valve through rim hole until it snaps into place. If necessary leverage tool on the side of rim being careful to not damage rim edge.

HERRAMIENTA PARA INSERTAR VÁLVULAS

- Para instalar o quitar válvulas de llantas sin cámara de inserción a presión.

Uso Apropriado:

1. Desmonte la llanta de la rueda.
2. Inserte la herramienta por la parte externa de la rueda hacia la parte interna.
3. Enrosque la válvula en la herramienta para válvulas.
4. Jale la válvula a través del orificio del aro hasta que quede fija en su lugar. Si es necesario, apalanque la herramienta en el lado del aro teniendo cuidado de no dañar el borde del aro.

