

## ***HIGH PERFORMANCE VALVES***

- HEAVY DUTY RUBBER GROMMET • CLAMP-IN STYLE
- CORROSION RESISTANT STEEL CONSTRUCTION

### Instructions for use:

1. Deflate tire and remove from rim.
  2. Remove old valve stem.
  3. Depending on rim hole size, place the appropriate grommet at the base of the valve.
  4. Insert the new stem from the inside of the wheel and hand tighten the nut.
  5. Torque the nut to 25-45 inch-pounds.
  6. Mount tire and inflate to recommended psi.
- 

## ***VÁLVULAS DE ALTO RENDIMIENTO***

- ARANDELA AISLANTE DE USO RUDO • ESTILO ABRAZADERA
- FABRICACIÓN DE ACERO RESISTENTE A LA CORROSIÓN

### Instrucciones de uso:

1. Desinfe la llanta y quítela del aro.
2. Retire al vástago de la válvula usada.
3. Dependiendo del tamaño del orificio en el aro, coloque la arandela de aislamiento apropiada en la base de la válvula.
4. Inserte el nuevo vástago por la parte interna de la rueda y apriete a mano la tuerca.
5. Apriete la tuerca a 25-45 pulgadas-libra.
6. Monte la llanta e ínfelela a la presión recomendada en psi.