



### Directions for use:

1. Remove valve cap from the inside wheel.
2. Screw extension onto valve stem. Ensure that the fit is secure.
3. Mount clamp to a secure location on the outside wheel. For best results, choose a location close to the center of the hub.
4. Remove valve cap from extension.
5. Slide extension through clamp opening and snap into place.
6. Check air pressure and adjust to vehicle manufacturer's recommended psi.
7. Replace valve cap.

**NOTE:** Do not use on tire with a recommended pressure over 150psi. Please follow the manufacturer's recommended tire pressure.

---

### Uso apropiado:

1. Remueva la tapa de la válvula de la llanta de adentro.
2. Atornille la extensión en la válvula. Asegure que encaje correctamente.
3. Monte la abrazadera para asegurar un lugar en la parte de afuera de la llanta. Para mejores resultados, escoja un lugar cerca de la parte central del rin.
4. Quite la tapa de la válvula de la extensión.
5. Deslize la extensión atraves de la abrazadera y ajuste en su lugar.
6. Verifique la presión del aire y ajuste a la presión recomendada por el fabricante en psi.
7. Reponga la tapa de la válvula.

**AVISO:** No se use en llantas con una presión recomendada de 150psi o mas. Por favor siga la recomendación del fabricante.

**WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

### Accessories Marketing, Inc, a division of ITW, Inc.

125 Venture Drive, Suite 210, San Luis Obispo, CA 93401 USA

### ITW AAMTech

100 Hassall Street, Wetherill Park, NSW 2164 AUS

[www.slime.com](http://www.slime.com)

PART# 20140 05.23.14



Made in China