

TPMS (Tire Pressure Monitoring System) SNAP-IN VALVE

To replace broken or malfunctioning Snap-In TPMS Valve Stems. It is recommended to have a tire care professional install this replacement TPMS Snap-in Valve.

Please note: When tightening the self-tapping machine screw, DO NOT hold the TPMS device. Only hold the valve stem. Failure to follow can cause damage to the TPMS device.

VÁLVULA INSERTABLE TPMS (sistema de monitoreo de la presión de las llantas)

Para reemplazar vástagos de válvula TPMS insertable rotos o que funcionen mal. Se recomienda que un profesional en mantenimiento de llantas reemplace esta válvula de reemplazo insertable TPMS.

Atención: cuando apriete el tornillo autorroscante, NO sostenga el dispositivo TPMS. Solo sostenga el vástago de la válvula. Si no hace esto, puede causar daño al dispositivo TPMS.

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.