

TREAD DEPTH GAUGE - Proper Use:

1. For each measurement, fully extend tread depth probe by pushing on the top of the gauge.
2. Place probe in the center, inner and outer grooves of the tire. Checking multiple grooves allows you to check for uneven wear.
3. Press on the black platform until the underside is rested on the top of the tire tread.
4. Take the measurement by reading the first visible number above the metal gauge barrel.
5. Repeat for next tire.

NOTE: Readings in the yellow and red zones indicate low tire tread levels.

MEDIDOR DE PROFUNDIDAD DE RODAMIENTOS - Uso Correcto:

1. Para cada medición, extienda completamente la sonda de profundidad del rodamiento presionando la parte superior del medidor.
2. Coloque la sonda en los surcos central, interno y externo de la llanta. La verificación de varios surcos le permite comprobar si el desgaste es desigual.
3. Presione la plataforma negra hasta que el lado inferior repose sobre la superficie superior del rodamiento de la llanta.
4. Tome la medición con la lectura del primer número visible arriba del cilindro metálico del medidor.
5. Repita lo mismo en otra llanta.

NOTA: Las lecturas en las secciones amarilla y roja indican niveles bajos del rodamiento de la llanta.