



DUALLY/RV TIRE GAUGE

Maintaining the proper pressure in your vehicle's tires will minimize tread wear, increase gas mileage and improve handling.

PROPER USE:

- Check pressure before driving
- Make sure valve is free of dirt and debris
- Press gauge firmly onto valve stem and read PSI on gauge
- Reset dial by depressing pressure release button on side of unit
- Inflate to recommended pressure

NOTE: Do NOT overinflate

MEDIDOR DE AIRE TIPO COMPÁS

El mantener la presión adecuada en las llantas de su vehículo puede prolongar la vida de las llantas, aumenta el kilometraje de la gasolina, y mejorará el manejo.

INSTRUCCIONES DE USO:

- Revise la presión antes de manejar
- Asegúrese que no haya ningún objeto en la válvula
- Apriete el medidor en la válvula y lea el PSI (presión) en la compás
- Oprima el botón en el medidor para reiniciar el proceso
- Infle a la presión recomendada

NOTA: NO sobre-infle



©Accessories Marketing, Inc.
800 Farroll Road Grover Beach, CA 93433 USA
P.O. Box 197, Oaklands Park, SA 5046 Australia
www.slime.com

PART # 2020-A 06.22.11



7 16281 22020 3

Made In China