

## **TIRE GAUGE HIGH PRESSURE GAUGE**

5.68 in. x 0.69 in. x 0.57 in.

(144.27mm x 17.53mm x 14.48mm)

You can improve your gas mileage by around 3.3% by keeping your tires inflated to the proper pressure. Under-inflated tires can lower gas mileage by 0.4% for every 1 psi drop in pressure of all four tires. Properly inflated tires are safer and last longer.

### **Proper Use:**

- Check pressure before driving
- Make sure valve is free of dirt and debris
- Press gauge firmly onto valve stem and read PSI on indicator
- Inflate to recommended pressure

**NOTE:** Do NOT over-inflate.

---

## **MEDIDOR DE AIRE**

5.68 in. x 0.69 in. x 0.57 in.

(144.27mm x 17.53mm x 14.48mm)

Usted puede mejorar el rendimiento del combustible en alrededor del 3.3% al mantener sus llantas infladas a la presión indicada. Las llantas mal infladas pueden reducir el rendimiento de la gasolina en un 0.4% por cada disminución de 1 PSI en las cuatro llantas. Las llantas infladas correctamente son más seguras y duran más.

### **Instrucciones de Uso:**

- Revisar la presión antes de manejar
- Asegurese que no haiga ningún objeto en la válvula
- Apriete el medidor en la válvula y lea el PSI (presión) en la varilla
- Infle a la presión recomendada

**NOTA:** NO sobre-infle.