BLOW

Instrukcja Obsługi
User Manual

BLOW PL | EN

Opis produktu / Product description



BLOW PL | EN/FR/ES/DE

Zawartość opakowania Specyfikacja

- 1 x inteligentna pompa elektryczna
- 1 x gęś do jaśni
- 1 x adapter Schradera
- 1 x dentyl
- 1 x kabel type C
- 1 x kabel USB
- 1 x wzór do przechowywania

- Wymiary: 190x126x81mm
- Waga netto produktu: 750g
- Ciśnienie: 0-10 BAR
- Temperatura pracy: -10~40 C
- Pojemność baterii: 2500 Wh
- Ładowanie: Wejście USB-C 5V/2A
- Wyjście USB: 5V 2A

Power on | Power off

1. Włączanie i wyłączanie
Włączanie:
Nacisnij i przytrzymaj przycisk zasilania przez 3 sekundy.
Wyłączanie:
Nacisnij i przytrzymaj przycisk zasilania przez 3 sekundy.

2. Wskaźnik baterii
Stan trzech ostatnich poziomów naładowania

4 kreski: 80% ~ 100%
3 kreski: 60% ~ 79%
2 kreski: 30% ~ 59%
1 kreska: 0% ~ 29%
1 kreska migająca: poniżej 5%

Menu Interwał

3. Przycisk Start/Stop
Gdy urządzenie jest włączone, naciśnij przycisk Start/Stop, aby rozpocząć napełnianie i automatycznie zatrzymać po osiągnięciu żądanej wartości ciśnienia.

BLOW PL | EN/FR/ES/DE

Jak zacząć

Podłączanie: Podłącz zaciski zasilania do interfejsu zasilania elektrycznego a czerwone i zielone kwadrty będą migać naprzemiennie.

Uwaga: Aby naprawić akumulator zasilany, upewnij się, że zasilanie wynosi więcej niż 50% lub podłącz akumulator do ładowania.

Podłączanie wejścia z czujnikiem Schradera

Włącz czujnik ciśnienia, naciśnij przycisk Start/Stop, aby rozpocząć napełnianie i automatycznie zatrzymać po osiągnięciu żądanej wartości ciśnienia.

Włącz pompę i podłączamy wejście do zawór Schradera

Rozwiej rozwiej elektryczna, motocykle i samochody z wentylem w zawór Schradera.

Podłącz zawór Schradera do złącza wejścia, aby rozpocząć pompowanie.

Valve | Valve connector

Adapter Presta

Rowery szosowe i inne rowery wymagają użycia adaptera Presta podczas pompowania.

1. Podłącz adapter Presta do złącza wejścia, aby rozpocząć pompowanie.
2. Podłącz dzwon aby rozpocząć ładowanie.

Valve | Valve connector

Gęś do jaśni

Ręcznie, nadaj napełnieć za pomocą gęś. Nadmuchiwanie. Po osiągnięciu żądanej gęś, dopcia, wlać do otworu, gdzie, aby go nadmuchać.

BLOW PL | EN/FR/ES/DE

Instrukcja

Wejście ładowania typu C 5V 2A.
Podłącz pompę za pomocą kabla ładującego i zasilacza.

- Migający zielony wskaźnik ładowania
- Gdy zasilanie wskaźnika świeci ciągłym światłem, ładowanie zostało zakończone.

Uwaga: Pompa ma można używać podczas ładowania.

Podłączanie wejścia z czujnikiem Schradera

Rowery, rowery elektryczne, motocykle i samochody z wentylem w zawór Schradera.

Podłącz zawór Schradera do złącza wejścia, aby rozpocząć pompowanie.

Valve | Valve connector

Adapter Presta

Rowery szosowe i inne rowery wymagają użycia adaptera Presta podczas pompowania.

1. Podłącz adapter Presta do złącza wejścia, aby rozpocząć pompowanie.
2. Podłącz dzwon aby rozpocząć ładowanie.

Valve | Valve connector

Gęś do jaśni

Ręcznie, nadaj napełnieć za pomocą gęś. Nadmuchiwanie. Po osiągnięciu żądanej gęś, dopcia, wlać do otworu, gdzie, aby go nadmuchać.

BLOW PL | EN/FR/ES/DE

Sprawdzanie ciśnienia

Po włączeniu pompy i podłączeniu wejścia przekształcającego do czujnika ciśnienia, wybierz odpowiednią pompę wybraniem jej pod zmierzoną wartość ciśnienia.

Przełączanie trybu

Naciśnij przycisk trybu (orange), aby wybrać 3 trybów pompowania: Tryb samochodowy: Zakresie wartość - 2,5 BAR (Zakres 0,1~6,8 BAR) Tryb motocyklowy: Zakresie wartość - 2,5 BAR (Zakres 0,1~6,8 BAR) Tryb rowerowy: Zakresie wartość - 1,8 BAR (Zakres 0,1~6,0 BAR). Tryb niestandardowy: Zakresie wartość - 0,05 BAR (Zakres 0,1~12,0 BAR) Tryb piłki: Zakresie wartość - 0,8 BAR (Zakres 0,1~6,0 BAR)

Przełączanie jednostek

W dowolnym naciśnięciu przycisku zmiany jednostek, możesz przełączyć jednostkę ciśnienia. Może ha przełączanie jednostek:
- BAR / 0,1 BAR
- 1 BAR / 100 KPA
- 1 kg/cm² / 98 KPA

Światło LED

- Króżek naciśnięcie: włącz światło LED
- Króżek naciśnięcie: wyłącz światło LED (migające światło)
- Króżek naciśnięcie trzy razy: włącz tryb stroboskopowy
- Na koniec króżek naciśnięcie, aby wyłączyć światło.

Ustawienie ciśnienia

- Króżek naciśnięcie przycisku gdy/aktiv gdy ciśnienie wynosi mniej niż 10 sekunda, ustawienie ciśnienia: 1 ~ 10 sekunda.
- Przycisk 10 (10), dostępny ciśnienia: 0 ~ 1 (10).
- Długie naciśnięcie: szybkie dostosowanie ciśnienia.

Uwaga: Kompressor automatycznie zapisuje wybraną wartość i uzbrzymia ciśnienia. Przy kolejnym użyciu wystarczy wybrać scenę, a wcześniej ustawione wartości będą automatycznie zdeklarowane.

BLOW PL | EN/FR/ES/DE

Rozwiązywanie problemów

Przyczyna ciśnienia

- Rower dziecięcy: 1,2m-2,0T BAR
- Rower: 2,0T-2,5T BAR (Zakres 0,1~6,0 BAR)
- Rower górowy: 2,7b-4,5 BAR
- Rowery elektryczne: 1,8-3,0T BAR
- Motocykle: 2,5T-3,5T BAR
- Samochody: 2,0-2,5 BAR
- Kosiążkowy: 0-0,8-0,02 BAR
- Piłka nożna: 0,8-1,0 BAR
- Piłka ręczna: 0,8-0,02 BAR
- Siatkówka: 0,29-0,32 BAR
- Rugby: 0,62-0,69 BAR

Pompowanie

- Sprawdź czy jest wystarczająca ilość energii.
- Sprawdź czy wskaźnik ciśnienia jest włączony.
- Upewnij się, że wszystkie połączenia są dobrze dokręcone.
- Sprawdź czy pompowany przedmiot nie ma wycieków.
- Sprawdź czy jest szczelny.

Brak ciśnienia

- Sprawdź czy jest wystarczająca ilość energii.
- Sprawdź czy wskaźnik ciśnienia jest włączony.
- Upewnij się, że wszystkie połączenia są dobrze dokręcone.
- Sprawdź czy pompowany przedmiot nie ma wycieków.
- Sprawdź czy jest szczelny.

Niewystarczające ciśnienie

- Sprawdź czy ciśnienie zmierzone na pewno jest wyższe niż ustawione. Jeśli tak, to pompa działa poprawnie.
- Sprawdź czy jest wystarczająca ilość energii.
- Wybrano nieprawidłowy tryb dostosowania wartości od 0,1 to 10,0x BAR

Wyłączanie pompowania

- Produkty z małym ciśnieniem, takie jak piłki, mogą nie być w pełnym pomiarowym urządzeniu.
- Sprawdź czy ustawiona wartość ciśnienia pozwoli się dopiero po kolejnym pompowaniu.

Automatyczne wyłączenie po 3 minutach:

- Jeśli urządzenie jest włączone, ale nie jest używane, zostanie wyłączone.

Wskaźnik cieśnienia wyłącza się po kilkowaniu:

- Wyznaczył kolorowy wskaźnik i zdążyć na zgaśnie z normalnym pompowaniem.

Środki ostrożności

1. Nie przekraczaj urządzenia podczas pracy.
2. Nie rozbiej, ani nie przerzuć z pobliża materiałów łatwopalnych i wybuchowych.
3. Wtaraj się unikać wilgoci, zawodów i upadków.
4. Nie dotykaj urządzenia mokrymi rękami, aby uniknąć porażenia.
5. Wkładowana bateria litowa. Nie wrzucaj produktu do ognia.
6. Trzymaj poza zasięgem dzieci.

BLOW EN | EU/TR/AUP

Package Contents

- 1 x Smart Electric Pump
- 1 x Adapter
- 1 x Schrader Air Hose
- 1 x Valve
- 1 x Type-C Cable
- 1 x Nozzle
- 1 x carry bag

- Dimensions: 190x126x81mm
- Net Weight: 750g
- Pressure: 0-10BPR
- Working Temperature: -10~40 C
- Battery Capacity: 2500 Wh
- Charging Input: 5V/2A/2A
- USB Output: 5V 2A

Power on | Power off

Power on and off

Power on:
Press and hold the power button for 3 seconds.

Power off:
Press and hold the power button for 3 seconds.

Battery Indicator
The number of bars indicates the charge level:

4 bars: 80% ~ 100%
3 bars: 60% ~ 79%
2 bars: 30% ~ 59%
1 bar: 0% ~ 29%
1 flashing bar less than 5%

Start/Stop button
When the unit is on, press the Start/Stop button to begin inflating and automatically stop when the desired pressure is reached.

BLOW EN | EU/TR/AUP

Charging

Type-C charging input 5V 2A.
Connect the pump with the charging cable and power adapter.

- Blinking green light: charging
- Steady green light: fully charged

Note: The pump cannot be used while charging.

Valve | Valve connector

Presta Adapter

Road bikes and other bikes require: Use a Presta adapter when inflating.

1. Connect the Presta adapter to the inflation port.
2. Unscrew the tire cap.
3. Connect the connector to begin charging.

Valve | Valve connector

Bob Needle

Balls, should be inflated using a needle. Inflation: After finishing inserting the needle and connection, insert into the balls hole to inflate it.

BLOW EN | EU/TR/AUP

Connecting the Schrader Valve Hose

Bicycles, e-bikes, motorcycles and cars with Schrader valves can use this device. Connect the bicycle valve to the hose connector to start inflating.

Valve | Valve connector

Presta Adapter

Road bikes and other bikes require: Use a Presta adapter when inflating.

1. Connect the Presta adapter to the inflation port.
2. Unscrew the tire cap.
3. Connect the connector to begin charging.

Valve | Valve connector

Bob Needle

Balls, should be inflated using a needle. Inflation: After finishing inserting the needle and connection, insert into the balls hole to inflate it.

BLOW EN | EU/TR/AUP

JUMP STARTER

Connection:
Connect the ignition clamp to the starting battery, ensuring the red and green lights will flash alternately.

Note: To ensure effective ignition, make sure the power supply is more than 50%. At zero voltage, ensure the power supply is above 75%.

Battery connection:
Open the ignition clamp and attach the ignition clamp to the car battery. The positive terminal of the ignition clamp should be connected to the positive terminal of the car battery, and the negative terminal of the ignition clamp corresponds to the negative terminal of the car battery.

Ignition:
Return to the car and start the engine. Immediately after a successful start, disconnect the starting power.

Note: To ensure a successful ignition, complete the ignition procedure within 30 seconds.

BLOW EN | EU/TR/AUP

Checking the Pressure

After turning on the pump and connecting the air hose to the tire valve, the current tire pressure value will be displayed at the top of the pump's display.

Mode Switching

Press the mode button (⏻) to select one of the 5 pumping modes: Car mode: Recommended value - 2.5 BAR (Range: 0.1~6.8 BAR) Motorcycle mode: Recommended value - 2.5 BAR (Range: 0.1~6.8 BAR) Bicycle mode: Recommended value - 1.8 BAR (Range: 0.1~6.0 BAR) Custom mode: Recommended value - 0.05 BAR (Range: 0.1~12.0 BAR) Ball mode: Recommended value - 0.8 BAR (Range: 0.1~6.0 BAR)

Unit Switch

Without pressing and holding the unit switch button, you can switch the pressure units. The unit conversion formula:
- 1 BAR = 0.8 kPA
- 1 BAR = 100 kPA
- 1 kg/cm² = 98 kPA

LED Light

Short press button on the LED light:
Short press twice: turn on SOS mode (flashing light).
Short press three times: turn on strobe mode.
Finally, short press to turn off the light.

Pressure Setting

- Short press the up/down button when the pressure is below 100 PSI, the pressure value will flash.
- Within 10 PSI, adjust the pressure by +1 / -1PSI.
- Long press quickly adjust the pressure.

Note: The compressor automatically saves the selected scene and pressure settings. Next time you use it, you just need to select the scene, and the previously set pressure value will be automatically loaded.

BLOW EN | EU/TR/AUP

Pressure Reset

After turning on the power, if the hose is not connected to the object being inflated, the pressure sensor will automatically reset. Simultaneously pressing the buttons simultaneously for 2 seconds. The display will return to normal once it is fully illuminated.

Note: The product has been factory calibrated. Differences in altitude or sensors may cause the displayed value to not be zero. A manual reset can correct the pressure reading. The Pressure Measurement Calibration tool recommended at high temperatures.

Checking the Recommended Pressure

To ensure safety, before starting, check the required pressure for the given object by referring to the manual or other guidelines to avoid injury caused by insufficient pressure.



- Car Tires:
- The Pressure range for car tires is marked on the side of the tire. The pressure depends on the vehicle load. For detailed pressure recommendations, refer to the vehicle manual.
- Bicycle Tires:
- The air pressure range for bicycle tires is marked on the side of the tire. The pressure depends on the rider's weight. For detailed pressure recommendations, refer to the bicycle manual.
- Balls:
- The inflation pressure for balls (e.g., basketball, volleyball) is marked on the product or inflation hole. The pressure depends on the ball's size and intended use. For detailed recommendations, refer to the manual for the specific ball.

NOTE: When unscrewing the hose and connector will be hot due to

BLOW EN | EU/TR/AUP

Pressure Sensor

After turning on the power, if the hose is not connected to the object being inflated, the pressure sensor will automatically reset. Simultaneously pressing the buttons simultaneously for 2 seconds. The display will return to normal once it is fully illuminated.

Note: The product has been factory calibrated. Differences in altitude or sensors may cause the displayed value to not be zero. A manual reset can correct the pressure reading. The Pressure Measurement Calibration tool recommended at high temperatures.

Checking the Recommended Pressure

To ensure safety, before starting, check the required pressure for the given object by referring to the manual or other guidelines to avoid injury caused by insufficient pressure.

- Car Tires:
- The Pressure range for car tires is marked on the side of the tire. The pressure depends on the vehicle load. For detailed pressure recommendations, refer to the vehicle manual.
- Bicycle Tires:
- The air pressure range for bicycle tires is marked on the side of the tire. The pressure depends on the rider's weight. For detailed pressure recommendations, refer to the bicycle manual.
- Balls:
- The inflation pressure for balls (e.g., basketball, volleyball) is marked on the product or inflation hole. The pressure depends on the ball's size and intended use. For detailed recommendations, refer to the manual for the specific ball.

NOTE: When unscrewing the hose and connector will be hot due to

BLOW EN | EU/TR/AUP

Example pressures

- Children's bicycle: 1.2m-2.0T BAR
- Bicycle: 2.7b-4.5 BAR (Range: 0.1~6.0 BAR)
- Road bicycle: 2.7b-4.5 BAR
- Electric bicycles: 1.8-3.0 BAR
- Motorcycle: 2.5T-3.5T BAR
- Cars: 2.0-2.5 BAR
- Basketball: 0.8-1.0-0.02 BAR
- Volleyball: 0.8-1.0-0.02 BAR
- Soccer ball: 0.8-1.0-0.02 BAR
- Volleyball: 0.29-0.32 BAR
- Rugby: 0.62-0.69 BAR

Troubleshooting

Slow Inflation:
- Check if there is sufficient power.
- Ensure the pump is not overheated.
- Ensure all connections are tightly secured.Check if the item being inflated has any leaks.

No Pressure:
- Check if there is sufficient power.
- Check if the current tire pressure is higher than the set pressure.
- Ensure the pump is not overheated.
- Check if the inflation mode is correct.
- Select the appropriate mode to adjust values from 0.1x-10.0x BAR.

Inflation Stops Before Reaching Target:
- Low-pressure products, such as basketballs, may not be within the device's measurement range.For an empty tire, the pressure value will be zero. Manual reset is required.

Automatic Shutdown After 3 Minutes:
- Press and hold the unit button to wake up.

Pressure Reading Not Changing:
- Replace the charging cable and adapter with safety-compliant ones.

Precautions

1. Do not leave the device unattended while in operation.
2. Do not place it near flammable and explosive materials.
3. Avoid exposure to water and falls.
4. Do not place the product in areas that are too cold or too hot.
5. Built-in lithium battery. Do not throw the product into fire.
6. Keep out of reach of children.