VIDEO TO VGA

USER'S MANUAL

Model No:CL-VV03

Use Display Device instead of monitor, consumedly save the cost of monitoring.

Introduction of Production

It can change the interlacing signals of S-Video of video into VGA signals non-interlacing. Let your monitor change into flicker free display. Flicker free display is good display. It also can be connected to VCD/DVD/Webcam/Set-top Box etc. And make your monitor be like digital TV.

Functional features of production:

•Advanced can frequency improves the technique, Refresh rate can be easily switched between 60Hz—75Hz, while the pictures don't flick.
•Resolving capability can be easily switched among (600 x 800, 1024 x 768, 1280 x 1024, 1280 x 720, 1400 x 900, 1600 x 900, 1680 x 1050), CRT and LCD monitor are compatible.
•The Function of Extra Strong 3D image denoising makes the pictures clear and steady.
•Distinguishing PIP function, and the size and position of the windows can be adjusted
•The AV/S-Video terminator input interface can be connect to DVD/PDP/PS2/Game Console etc.
•Broadband PC/TV selector switch(200MHz)

Package:

VIDEO TO VGA	1PC
AV/BNC Line	1PC
VGA Line	1PC
S-Video	1PC
Power Adapter	1PC
User's Manual	1PC

Schematic diagram of connection:



Explanations of Interface:



Name	Explanation
(1)DC 5V	Connect to DC 5V Power
(2) Video IN	Connect to Video camera/DVD/VCD/Game Console（AV/BNC）
(3) S-Video IN	Connect to S-Video camera/DVD/VCD/Game Console
(4) VGA IN	Connect to AGP(Accelerated Graphics Port)
(5) VGA OUT	Connect to monitor

Functions of keystrokes:



Name	Explanation
(6)AV/SV/VGA	Pressing this keystroke can easily switch Video/S-Video/VGA
(7)STILL	Pressing this keystroke can change the current pictures into still image. And realize the function of taking photos
(8)PIP	Press the condition of PIP, Realize that AV/S-Video opens a window to monitor on the condition of VGA. Let you can watch the pictures monitored when you use computer. press MENU, the pictures can be move. press MODE, the pictures can be zoom. Press PIP again, you can exit PIP MODE.
(9)MODE	Pressing this keystroke can changes Resolution and refresh rate of pictures.
(10)MENU	Pressing it can open the operate Menu. Press ↑ ↓ ←→can change the relevant information
(11)P.P	Press it can changes chroma of the color（Bright,Soft,Normal,User）