SOLARIS

SUNNY 150 V2

150W COB

Technical:

Voltage：AC90-240V 50/60HZ

Power supply: 150W

Light source: 1PCS*150W led

Channel: 3CH/1CH

Operation: DMX512, Auto, Sound, Master-slave



Please read manual carefully before use.

Thank you so much to choose this product; it is adopting the most advanced lamps, which is called LED lamps. It conquers a lot of disadvantages such as power wasting, short using life, high temperature, etc. It has advantages of power saving, long life (it can reach 60,000.00 hours in general circs), high brightness, fresh colors…It is the best stage illuminating and various effect decorative products.

WARNINGS:

1. Inspect the device carefully before installation in case of loose during transportation.

2. Don’t put the product on the shakable or moist place.

3 . Please keep the voltage stable, otherwise it will destroy the parts easily.

4. Check the voltage before turning on lamp. While power off, it needs 15minutes to cool before reconnecting the power.

5. Please keep the lamp dry and cool, .avoid working at 40℃ or above to guarantee its lifespan.

6 .Disconnect the power before installation or removing and ask professional technician to repair in case of malfunction. (Check fusestube first).

DMX512Control：3Channel Model(A001)

No.	Show	Function	Instruction
1	d001	001- 512	DMX512 address Code Settings-1 Channel Mod
2	A001	001- 512	DMX512 address Code Settings-3 Channel Mod
3	u255	000 - 255	White dimming, from dark to light.
4	F255	000 - 255	stroboscopic, speed from slow to fast.5 values start and control
5	t---	00-99	Temperature control display

二、

DMX512Control： 1Channel Model(D001)

Channel	Function	Instruction
CH1	W dimming	White linear dimming from dark to bright

Channel	Function	Instruction
CH1	Total dimming	White linear total dimming, from dark to bright
CH2	total stroboflash	White total strobe, controlled by slow to fast,5 values
CH3	W dimming	White linear dimming from dark to bright

Special function description

Press and hold the "MENU" key not to release until the "0000" is displayed, and the first bit flash, then release the key, switch the function sequence number according to the "MENU", press ENTER, and save the setting and exit.

Digital tube display menu description