

## **08800 Installation Instructions**

Prior to installation, use masking tape to position the LED blinker in the desired location. Route wires through existing mirror arm or, if necessary, drill a 3/16" hole through the vehicle. The white wire is the ground wire, and should be secured to a metal ground. The red wire should be spliced to the turn signal wire for the side of the vehicle on which it is positioned. Once wiring is complete, clean mounting surface to remove all oil, grease and wax. Peel off tape backing and firmly apply pressure while mounting. Allow 24 hours for adhesive to cure. NOTE: removing LED blinker after placement will reduce adhesion.