



**Before returning this product
to the store of purchase**

Contact Dee Zee if you experience the following problems:

- Missing Parts
- Installation Problems/Questions
- Warranty Questions

1.800.779.2102

Hours of operation: 8am - 5pm CST, Mon-Friday

Review complete warranty policy and register your product at:

www.deezee.com/warranty.php

INSTALLATION INSTRUCTIONS

CHEVROLET SILVERADO GRILLE GUARD 07

PART#501514/501515

PARTS LIST:

1	Grill Guard	2	Upper Support Brackets
2	Frame Mounting Brackets	2	Lower Frame Support Brackets
8	12-1.75mmX30mm Hex Head Bolts	8	12mm Nylock Nuts
16	12mm Fender Washers	2	8-1.25mmX30mm Head Bolts
2	8mm Nylock Nuts	4	8mm Flat Washers

PROCEDURE:

- 1. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. DO NOT ATTEMPT INSTALLATION ALONE; PERSONAL INJURY OR DAMAGE TO THE TRUCK MAY RESULT.**
2. Locate, remove and set aside the hardware kit and the brackets. Determine the driver and passenger sides for the brackets.
3. Open the hood and remove the radiator cover to access the small radiator shield (Fig 1)
4. Use a small flat head screw driver to remove the retainer plugs (Fig 2)
5. Use a 10MM socket to remove the small shield between the radiator and the grille.(Fig 3)
6. Using a pair of "needle nose" pliers squeeze the eight grille mounting clips. (Fig 4) Begin from one end of the grille and insert a small screwdriver into the clips to prevent them from popping back into place. Remove the grille by pulling on it gently and evenly forward.
7. Remove the two top existing frame bolts and install them into the upper brackets. Reinstall the bolts but leave them loose temporarily. (Fig 5).
8. Reinstall your grille at this time, line up the clips and gently push it into place. Do not reinstall top covers at this time.
9. Using a sharp utility knife cutout an opening to allow the bumper brackets to pass through (Fig 6)
10. To install the lower two frame mounting bracket and two support brackets, remove the tow hook bolts and use them to install the frame brackets and the support brackets. The tow hooks remain in their stock position in the frame rails (Fig 7).
11. Connect the lower support bracket to the frame mounting bracket using one of the 12mm bolts two washers and Nylock nut supply with your bumper guard (Fig 7).
12. With help position the grille guard and install the six 12MM bolts into the bottom bracket (Fig 8)
13. Install the two 8MM bolts and lock nuts in the top brackets. (Fig 9)
14. Level and adjust the bar and the brackets and tighten all the fasteners. (Fig 10)
15. After you are sure all mounting bolts are tight reinstall the top plastic shields.



