

11050

07-09 CHEVY

SUBURBAN/TAHOE/AVALANCHE
LTZ MODELS



11050

07-09 CHEVY

SUBURBAN/TAHOE/AVALANCHE
LTZ MODELS

07-09 CHEVY SUBURBAN/TAHOE/AVALANCHE LTZ

Console Armrest Trim

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

1 T1 Series Console Armrest Trim

Step 1

Clean the area where the Trim Plate will be installed with alcohol and a clean rag. Test fit the trim plate. Remove the plastic backing on the adhesive on the back of the Console Armrest Trim.

Step 2

Position the Console Armrest Trim on top of the factory center console. Press down on the Console Armrest Trim to ensure the adhesive backing adheres to the factory center console.