

56183 DODGE NITRO JEEP LIBERTY

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

6/3/2013

English

1. Open the tailgate and remove the two bolts holding each taillight assembly in place (A). Carefully remove the taillight assemblies taking care not to break the alignment tabs. Separate the vehicle's taillight wiring harness connectors on both sides of the vehicle (B).

2. Starting on the driver's side, insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-Connector end with the green wire down through the opening under the taillight assembly (C). Under the vehicle route the green wire along the backside of the bumper to the passenger side and up through the opening on the passenger side. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Behind the driver's side taillight, locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Route the black power wire from the battery as shown on the included CME-PCL-INS sheet.

6. Adhere the black converter box to the frame of the vehicle behind the taillight housing on the driver's side using the double sided tape provided. Find a flat, clean surface that is out of the path of road spray from the tires (D).

7. Route the 4-flat to the center of the vehicle's bumper and secure any loose parts of the T-Connector using cable ties provided.

8. Insert the 10 AMP fuse provided into the inline fuse holder to complete the install.

9. Reinstall all items removed during installation.

WARNING:

Failure to mount the module in a protected area can cause loss of warranty, product failure including lamp malfunction, overheating and potential fire.

IMPORTANT:

The battery connection must be fuse protected, 10 amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed the tow vehicle's lamp load rating or the product rating, whichever is lower:

Signal circuits – 3.0 amps per side
Tail / Running Lights – 6.0 amps total

Check vehicle owner's manual or contact vehicle manufacturer for more information.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813



