

KickBack Mud Flaps Installation Instructions



Kick Back Mud Flap
Driver's Side (1)

PACKAGE CONTENTS:

- 2 - Mud Flaps with Weights
- 2 - Kick Back Brackets
- 8 - SS Self Drilling Screws
- 6 - SS Button Head Bolts
- 4 - 1/4 - 20 Bolts
- 10 - 1/4 - 20 Nylon Hex Nut
- 18 - Black Plastic Washer
- 2 - Twist Brackets



Kick Back Mud Flap
Passenger's Side (1)

RECOMMENDED INSTALLATION TOOLS :

- Power Drill with 1/8" and 1/4" drill bits
- 5/16" Socket with Drill Attachment
- 7/16 Wrench or Socket/Driver

VEHICLE PREPARATION:


Your vehicle's fender mounting area should be cleaned prior to the installation of your new Husky KickBack Mud Flaps.



Installation

Read all directions thoroughly prior to the installation of your KickBack Mud Flap.

Attach the flap with the weights to the upper mounting brackets with the SS button head bolts through the upper bracket, flap, washer, and into the nylon lock nut on the backside of the mud flap (3 plcs per bracket). The solid 1" strip on the backside (corrugated side) of mud flap gets positioned on the outboard side of the mud flap (See Arrows).



1. Clean the mounting location on your vehicle and check the location of factory fasteners and factory holes that can be used to fasten the mud flap. We recommend using the factory locations when possible then use the provided SS self tapping screws for further retention.



2. Align the 1" solid outer edge of the mud flap with the outer edge of the tire to get maximum coverage and protection and for easy alignment.

Note: These are general mounting guidelines and the mud flaps can be mounted in many different ways to provide whatever coverage you deem necessary.



3. Transfer the factory hole locations to the mud flap mounting bracket. Mark the factory fasteners and other fastening locations with a small ball of clay or similar material.



4. Align the mud flap so the bottom of the flap is parallel to the ground and at your desired height. Press the mounting bracket firmly against the fender to transfer the fastening locations.



5. Drill fastening holes at the pre-marked locations in the upper bracket to accommodate factory fastener size. If using supplies SS self drilling screws, drilling a small 1/8" pilot hole may help to ease installation.



6. Fasten the mud flap to the truck with the factory fasteners. Check that the mud flap is parallel with the ground before tightening.



7. Install the SS self drilling screws for the other pre-drilled locations on the mud flap.
A minimum of 4 fastening locations per mud flap is recommended.



FOR REAR MUD FLAP INSTALLATION

The twist bracket is used to brace the inboard side of the mud flap to the inside of the rear fender.

8. Locate an existing hole or factory fastener on the underside of the fender behind the mud flap (if available) to mount the twist bracket. If an existing hole is not available, a hole will need to be drilled through the body. Using the twist bracket as a template mark and drill a 1/4" hole on the inboard side of the mud flap (and underside of the body if no hole was available). Install 1/4 - 20 hex bolts and nylon lock nuts to fasten the twist bracket to the body and mud flap. The twist bracket can be bent to accommodate different angles or lengths.



9. Repeat steps 1- 8 on the opposite side of the vehicle.

Congratulations,
You have now successfully installed
your new Husky Liners KickBack Mud
Flap. If you have any questions please
call us at 1-800-344-8759.

HUSKY LINERS KICKBACK MUD FLAP LIMITED LIFETIME WARRANTY

WINFIELD CONSUMER PRODUCTS WARRANTS YOUR HUSKY LINERS MUDGUARD WITH A LIMITED LIFETIME WARRANTY TO THE ORIGINAL PURCHASER. IF YOUR FINISHED PRODUCT IS FOUND DEFECTIVE, WINFIELD CONSUMER PRODUCTS WILL AUTHORIZE THE REPLACEMENT OF YOUR PRODUCT AT NO CHARGE TO THE ORIGINAL PURCHASER. THIS WARRANTY COVERS PRODUCT REPLACEMENT ONLY. WINFIELD CONSUMER PRODUCTS WILL NOT PROVIDE A MONETARY REFUND FOR THE PRICE OF THE PRODUCT OR CHARGES INCURRED DURING INSTALLATION. THIS WARRANTY IS NOT TRANSFERABLE. WINFIELD CONSUMER PRODUCTS ASSUMES NO LIABILITY FOR PRODUCT FAILURE DUE TO ACCIDENT, COLLISION, NEGLIGENCE, VANDALISM OR ABUSE.

THERE IS NO WARRANTY OF MERCHANTABILITY AND NO WARRANTY THAT THE PRODUCT SHALL BE FIT FOR ANY PARTICULAR PURPOSE OR USE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION.

THIS PRODUCT IS TO BE USED IN COMPLIANCE WITH ALL APPLICABLE STATE OR PROVINCIAL LAWS. INSTALLATION OF THIS PRODUCT IN A MANNER THAT VIOLATES STATE OR PROVINCIAL LAW IS A MISUSE OF THE PRODUCT AND VOIDS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY. WINFIELD CONSUMER PRODUCTS SHALL NOT BE LIABLE IN ANY MANNER WHATSOEVER FOR DAMAGES RELATED TO THE USE OF THIS PRODUCT IN AN ILLEGAL MANNER.

FOR WARRANTY SERVICE CONTACT YOUR HUSKY LINERS DEALER OR CALL WINFIELD CONSUMER PRODUCTS AT (800) 344-8759.