

RANCH HAND

1-800-366-9712

INSTALLATION INSTRUCTIONS

2006-`08 DODGE 1500 (except 1500 MEGA CAB)

PART # FSD06HBL1

1. If fog lights are present, unhook wires. Remove factory bumper by removing the 8 bumper bolts. There are 4 on each side.
2. Mount the Summit frontend by using eight ½” bolts. *Provided.*
3. Raise the frontend to the desired height and center from left to right. Tighten bolts.
4. Use ¼” bolts to install the license plate.
5. Remove fog lights and fog light brackets from factory bumper. There will be three 10mm bolts for each bracket. Follow instructions of LBD031BL1 to install fog lights.
6. There is a ¼” hole on the side end cap to bolt fender flare.
7. *MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!*

WARNING

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 10/20/08