




INSTALLATION INSTRUCTIONS

PART No.

FB22004

**Jeep® JK Wrangler
Front Stubby Winch Bumper w/ Tube Guard**



* 14" LED light sold separately – Fishbone FBTM135 recommended

REQUIRED TOOLS

- 18mm Wrench
- 18mm Socket
- 16mm Wrench
- 16mm Socket

HARDWARE CONTENTS

		QTY
D-Rings		2
M10 Hex Bolt		8
M10 Lock Washer		8
M10 Flat Washer		16
M10 Hex Nut		8
M12 Hex Bolt		6
M12 Lock Washer		6
M12 Flat Washer		12
M12 Hex Nut		6

2200400

Jeep® JK Wrangler Front Stubby Winch Bumper w/ Tube Guard

1) REMOVE YOUR FACTORY BUMPER

Begin by removing your factory bumper. Ensure you disconnect your factory fog lights before you pull your bumper away.

2) PREP YOUR NEW BUMPER FOR INSTALL

Before installing your bumper on your Jeep, we suggest attaching your bumper tube, your optional 14" light bar, winch and fairlead (if applicable).

INSTALL YOUR BOLT-ON TUBE

Using one (1) M12 bolt, one (1) M12 lock washer, two (2) M12 flat washers, and one (1) M12 nut per hole, secure your tube to the top side of your bumper. The front face of this tube will be secured when the bumper is attached to your Jeep.



INSTALL THE FAIRLEAD BRACKET

If you wish to install a winch on your bumper, begin assembly by attaching the fairlead bracket. Secure the bracket to the bumper with one (1) M12 bolt, one (1) M12 lock washer, two (2) M12 flat washers, and one (1) M12 nut in both through holes.



INSTALL YOUR FAIRLEAD AND WINCH


We recommend installing the fairlead first as you'll have access to the bolts at this time. Follow the instructions that came with your winch to install the fairlead and winch body to the pre-drilled holes on your new bumper.



INSTALL YOUR 14" LIGHT BAR

If you have purchased the optional 14" LED light bar for your bumper, we recommend installing it after your winch. The LED will make it difficult to get the mounting hardware for the winch installed.

Using the supplied hardware that came in the LED kit, secure it to the bumper between the inner brackets.



Jeep® JK Wrangler Front Stubby Winch Bumper w/ Tube Guard

3) INSTALL YOUR BUMPER

2 PERSON LIFT



WITH THE WEIGHT OF THE WINCH AND BUMPER, IT IS HIGHLY ADVISED TO HAVE HELP WHEN INSTALLING THE BUMPER!

With the help from a second pair of hands, lift the bumper up to the frame of the Jeep. Using the M10 hardware, insert an M10 bolt and washer through the front of the bumper and into the bumper bracket on the frame of your Jeep. Secure each bolt with an M10 flat washer, M10 lock washer, and M10 nut.



5) RUN YOUR WIRING

Wire your new LED light using the supplied wiring. **DO NOT WIRE THIS DIRECTLY TO YOUR OEM FOG LIGHT HARNESS.**

Wire your winch according to the winch manufacturer's instructions.

6) ENJOY YOUR NEW FISHBONE OFFROAD BUMPER!



4) MOUNT THE SUPPLIED D-RINGS.