

8800-ITS Mortise Lockset

Wiring Diagram and Installation Instructions

ACCENTRA


ASSA ABLOY

Handling the Latchbolt

1. Insert flat blade screwdriver into cover slot.
2. Pull back on screwdriver until latchbolt extends past base front and rotate the head to the desired position.

Handling the Hubs

1. Locate RED MARK on locking piece.
2. Push toggle button slide away from square spindle hole.
3. With blade screw driver push RED MARK on slide nearest square spindle hole.
4. RED MARK indicates locked side!



8800-ITS Mortise Lockset

Wiring Diagram and Installation Instructions

1. Remove Cylinder Monitor Assembly from Lockbody by gently pushing up through the opposite side of cylinder hole.



2. Remove spring from assembly. **Use caution not to stretch or otherwise deform the spring.**




3. Remove Inner Shell from Outer Shell by gently pressing the Inner Shell upwards from the bottom. **Use caution not to damage sensor wires.**




80-9086-0054-010 06/24

Experience a safer
and more open world



4. Turn Inner Shell on side. Align the inner shell with the diagonal slot in the Outer Shell. Slide the Inner Shell through the Outer Shell.



1-855-557-5078 Ext. 2 • www.accentra-assaabloy.com


Copyright © 2023,2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

8800-ITS Mortise Lockset


Wiring Diagram and Installation Instructions

ACCENTRA
ASSA ABLOY

5. Feed Inner Shell (with wire and sensor) back through the Cylinder hole in the lockbody to the other side.




6. Turn the Inner Shell on its side and slide it down into the Outer Shell.




7. Assemble Inner Shell into Outer Shell. Guide the sensor wire out the top of the lock.



8. Install spring into assembly. **Use caution not to stretch or otherwise deform the spring.**



9. Gently press Cylinder Monitoring Assembly into cylinder hole on the new side of the lockbody.




ELECTRIFIED OPTIONS

Molex®		8890 Options		8891-ITS	
		Function	Color	Function	Color
8-pin	1,2	Power	Black/Red	Power	Black/Red
	3,4	LPM ----- OR ----- LBM	Green/Gray Green/Green	LPM	Green/Gray
	5,6	DB-In	Yellow/Yellow	CX	Brown/Brown
	7,8	DPS* (Less DB)	Blue/Blue	DPS*	Brown/Blue
4-pin	1,2	Open Loop REX	White/White	Open Loop REX	White/White
	3,4	Closed Loop REX	Gray/Gray	Closed Loop REX	Gray/Gray

* Deadbolt not available with DPS function.

REFERENCES	
REX	Request to Exit
LBM	Latch Bolt Monitor
LPM	Latch Performance Monitor
DBM	Deadbolt Monitor
DB	Deadbolt
DB-In	Deadbolt Retracted
DB-Out	Deadbolt Extended
DPS	Door Position Sensor
CX	Cylinder Monitor



ASSA ABLOY ACCENTRA™ Mortise 8890 / 8891
* 12 VDC (RED – RED) / 24 VDC (BLACK – BLACK)

