

Architectural Door Accessories

ASSA ABLOY

Pemko Floor Molding, Trim & Handyshapes

The global leader in
door opening solutions

Applies to the following products:

2250W, 2175W, 2300W, 2219W, 2350W, 2500W


Installation Instructions:

1. Measure length of seam to be covered.
2. Measure, mark and trim product to length using tin snips or hacksaw.
3. Place product over seam and screw in place:
 - a. Wood floor installation: secure to floor with supplied screws.
 - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).



↑
**Covers
Floor
Seams**

Tools Required:



www.pemko.com

| | | | |
|---|---|--|--|
| MEMPHIS, TN USA P: 800 824-3018 F: 800 243-3656 | VENTURA, CA USA P: 800 283-9988 F: 800 283-4050 | VANCOUVER, BC CA P: 877 535-7888 F: 877 535-7444 | TORONTO, ON CA P: 877 535-7888 F: 877 535-7444 |
|---|---|--|--|

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

FM6_WEBINS
Rev 2 - 01.25.17
Page 1 of 1