

PFS-81 Sidelite Connector w/Fin Installation Instructions


ASSA ABLOY

The global leader in
door opening solutions

For Installation Assistance, Call 855.594.6989 • www.assaabloyglass.us


Tools Needed:
Torque Wrench and Bit
Screwdriver (Phillips)
5mm Hex Wrench

NOT TO SCALE



Parts Included

PFS-81



PFS-81 Parts List

1	Cover Plate
2	1 1/16" - M6 x 27 Screws (6)
3	Bracket
4	Bushings (6)
5	3/4" - M4 x 20 Phillips Head Screws (3)
6	Bracket

7	Cover Plate
8	Cover Plate
9	Bracket
10	Bracket
11	Cover Plate


1. Prepare the Glass

USE FABRICATION SKETCH TO DRILL AND CUT GLASS.

- Cut away glass (shaded area) along dotted line to match sketch dimensions.
- Drill six $13/16"$ (20 mm) diameter holes.

NOT TO SCALE

DIMENSIONS IN INCHES (MILLIMETERS)



Caution: Office copiers, printers and facsimile machines may change the size of a drawing and make it inaccurate to use as a template.

ASSA ABLOY


The global leader in
door opening solutions

Copyright © 2017, ASSA ABLOY Inc. All rights reserved. Reproduction in whole or in part
without the express written permission of ASSA ABLOY Inc. is prohibited.

2. Attach Fin to Support Bracket

Make sure the surface is thoroughly cleaned and remove all screws.


- Attach Bracket ⑨ to Bracket ⑥ with Screws ⑤ using screwdriver ensuring that the bushing side of Bracket ⑥ is facing the glass.



3. Fasten Support Brackets

Make sure the surface is thoroughly cleaned and remove all screws.

- Insert four Bushings ④ into prepped $13/16$ " (20 mm) diameter holes to join Brackets ③ & ⑥.
- Place Bracket ⑥ into prepped area of glass, join Bracket ③ from the other side. Insert four Screws ② into holes and tighten with 5mm hex wrench to hold brackets together. Do not tighten completely to allow for adjustments throughout installation.
- Align fitting to desired position. Torque four Screws ② to 12 nm.



ASSA ABLOY


The global leader in
door opening solutions

Copyright © 2017, ASSA ABLOY Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Inc. is prohibited.

PFS-81 - 06/17


4. Adhere Cover Plates

- Remove adhesive strip paper on both Brackets **3** & **6** to adhere Cover Plates **1** & **7**.
- Hook Cover Plates **1** & **7** over hinge side locking pins.
- Push in spring loaded locking pin on opposite side of Bracket.
- Snap on Cover Plates.



5. Install Fin

- Insert two Bushings **4** into prepped $13/16$ " (20 mm) diameter holes to join Brackets **9** & **10**.
- Place Bracket **9** into prepped area of glass, join Bracket **10** from the other side. Insert Screw **2** into Bracket **9** hole and tighten with 5mm hex wrench to hold Brackets together. Do not tighten completely to allow for adjustments throughout installation.
- Insert remaining Screw **2** into Bracket **10**, align fitting to desired position. Torque both Screws **2** to 12 nm.



ASSA ABLOY


The global leader in
door opening solutions

Copyright © 2017, ASSA ABLOY Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Inc. is prohibited.

PFS-81 - 06/17

6. Adhere Cover Plates

- Remove adhesive strip paper on both Brackets **9** & **10** to adhere Cover Plates **8** & **11**.
- Hook Cover Plates **8** & **11** over hinge side locking pin.
- Push in spring loaded locking pins on top & bottom of Bracket.
- Snap on Cover Plates.



ASSA ABLOY

The global leader in
door opening solutions

Copyright © 2017, ASSA ABLOY Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Inc. is prohibited.

PFS-81 - 06/17

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience

ASSA ABLOY

www.assaabloyglass.us

USA:
ASSA ABLOY Glass Solutions
Rockwood, PA 15557
Phone: 855.594.6989