

Architectural Door Accessories

ASSA ABLOY

Pemko Modular Ramps

The global leader in
door opening solutions

Applies to the following products:

**R.5F_, R.75F_, R1F_, R1.25F_, R1.5F_, R1.75F_, R2F_,
R2.25F_, R2.5F_, R2.75F_, R3F_, R3.25F_, R3.5F_,
R3.75F_, R4F_, R4.25F_, R4.5F_, R4.75F_**

Installation Instructions:


1. Assemble interlocking ramp component sections together.
2. Cut ramp as necessary to fit.
3. Position Miter Returns, Ramp Wings and Wing Extenders (if purchased) on each side of ramp. (Ramps without Wings, etc. should have the ends filled with grout. Do not leave ramp ends open).
4. Drill pilot holes in floor through pre-drilled holes in ramp.
5. Caulk ends of ramp and under full length of legs (important for effective sealing and moisture control).
6. Secure ramp to floor with supplied screws (when fastening to concrete, use anchors. Anchors are not included).

Testing/Ratings:

Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes. (Thresholds may or may not contain gasketing material).



Tools Required:



www.assaabloydooraccessories.us

MEMPHIS, TN USA	VENTURA, CA USA	VANCOUVER, BC CA	TORONTO, ON CA
P: 800 824-3018	P: 800 283-9988	P: 877 535-7888	P: 877 535-7888
F: 800 243-3656	F: 800 283-4050	F: 877 535-7444	F: 877 535-7444

Copyright © 2018 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

MR_WEBINS
Rev 1 - 03.18
Page 1 of 1