
Installation Instructions



281 Powerglide Series


Closer with Regular Arms (Without Holder) 🕁

281 Series Non Sized Adjustable from Sizes 1 thru 6



1-800-727-5477 • www.sargentlock.com


Experience a safer Copyright © 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents. A7278F12/22 Rev 6 and more open world



Closer with Regular Arms


Installation Instructions

To Determine Your Hand of Door



Spring Power Adjustment

Adjust spring according to the appropriate application chart.



| Chan dand and Tan Jawk Angliantiana | | | | |
|---|--|-----------------------|---------------------|--|
| | Standard and Top Jamb Applications | | | |
| Number of Turns of Spring Power Adjusting Screw | | | | |
| | From Factory Setting (Use Chart as Guide ONLY) | | | |
| Door Width in (mm) | Approximate Door Weight (Pounds) | 281 Exterior Doors | Interior Doors * | |
| 24(610) | 80 | Factory Set | | |
| 30(762) | 110 | 1-5 CW | | |
| 32(813) | 115 | 1-3 CVV | 1-5 CCW | |
| 36(914) | 130 | 5-8 CW | | |
| 40(1016) | 150 | J-0 CVV | | |
| 42 (1067) | 155 | 8-13 CW | Factory Set | |
| 44 (1118) | 165 | 0-13 CVV | | |
| 46(1168) | 170 | 13-15 CW | 1-5 CW | |
| 48 (1219) | 180 | 13-13 CW | 1-5 CVV | |
| over 48 (1219) | — | up to 19 CW as req. | 5 CW & up as req. | |

| Parallel Arm Application Only | | | |
|---|-------------------------------------|-----------------------|----------------------|
| Number of turns of Spring Power Adjusting Screw From Factory Setting (Use Chart as Guide ONLY) | | | |
| Door Width in (mm) | Approximate Door Weight (Pounds) | 281 Exterior Doors | Interior Doors* 🛃 |
| 24(610) | 80 | 2-7 CW | |
| 30(762) | 110 | | — |
| 32 (813) | 115 | 7-11 CW | 1-5 CCW |
| 36 (914) | 130 | 7-11 CVV | 1-5 CCVV |
| 40 (1016) | 150 | | Eactory Sot |
| 42 (1067) | 155 | 11-15 CW | Factory Set |
| 44 (1118) | 165 | | |
| 46 (1168) | 170 | 1-8 CW | |
| 48 (1219) | 180 | 13-17 CVV | |
| over 48 (1219) | _ | up to 19 CW as req. | 8 CW & up as req. |

*If interior doors do not have to comply with ADA & requirements, exterior door settings are recommended. Where strong drafts exist, increase spring power as needed by turning spring adjustment screw clockwise. If necessary, reduce spring power by turning screw counterclockwise.

1-800-727-5477 • www.sargentlock.com

Copyright \otimes 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.

2

A7278F 12/22 Rev 6 Experience a safer and more open world





Closer with Regular Arms

Installation Instructions

281 Standard Application Instructions

1. Prepare door and frame.

| Arm Type | Mounting | Max Door Opening | Dim A | Dim B |
|---------------------|-----------|---------------------|-------|---------|
| Regular | Standard | 120° | 7" | 12-1/8" |
| Arm No Holder | Alternate | € 160° € | 5" | 10-1/8" |


← If Butt, Frame, and Wall conditions permit, door will open 180° NOTES:

1. Right hand door shown, left hand door opposite.

- 2. This dimension is taken from hinge edge of door for invisible hinges.
- 3. Drill and tap and use screws provided or use mortise nuts when required.


Alternate mounting is recommended for ADA compliant doors

2. Mount bracket and closer to door.



4. Attach Arm.


Attach foot to frame with pivot away from hinge.



3. Attach foot and pivot to frame.

Right Hand

Attach arm with index mark on spindle aligned as shown. Secure with screw and washer. Insert rod end into swivel arm and tighten arm screw.




You've installed the 281 Powerglide Series Closer - Standard Mount. Go to page 6 for closer adjustments and cover installation.

1-800-727-5477 • www.sargentlock.com

Copyright © 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.

3

A7278F 12/22 Rev 6 Experience a safer and more open world



10-3/8"

€ of Hinge Pivot:

Butts, offset Pivots, Swing Clear,

Center Hung, or Invisible hinges

1"


SARGENT


ASSA ABLOY

Top of Door

Use Mounting bracket

as drill thru template






Closer with Regular Arms

Installation Instructions

281 Top Jamb Application Instructions

1. Prepare door and frame.




| Arm Type | Reveal Depth | Dim A | Max Door Opening |
|-----------|---------------------|-----------|---------------------|
| "O" Arm | 0" to 2" | 9-5/16" | 180° |
| "OZ" Arm | 2-1/8" to 5" | 10-1/8" | 140° |
| "OZA" Arm | 5-1/8" to 8" | 10-15/16" | 140° |

IMPORTANT: Use alternate mounting if door can open beyond limits shown for standard mounting.


NOTES:

1. Left hand door shown. Right hand door opposite.

- 3. This dimension is taken from hinge edge of door for invisible hinges.
- 4. Drill and tap and use screws provided or use mortise nuts when required.



4. Install main arm and spindle.



You've installed the 281 Powerglide Series Closer - Top Jamb Mount. Go to page 6 for closer adjustments and cover installation.

1-800-727-5477 • www.sargentlock.com

 $\label{eq:copyright} @ 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.$

4

A7278F 12/22 Rev 6 Experience a safer and more open world

Approved 2022-12-08

SARGENT ASSA ABLOY

Closer with Regular Arms

SARGENT ASSA ABLOY

Installation Instructions

281 Parallel Arm Application Instructions

1. Prepare door and frame.

| Max Door Opening | Dim A | Dim B |
|---------------------|--------|---------|
| 120° | 4-1/2" | 10-1/2" |
| *180° 🌒 | 1-5/8" | 7-5/8" |


NOTES:

1. Left hand door shown. Right hand opposite.


- Do not use this mounting for "swing clear" hinges. 2.
- 3. This dimension is taken from hinge edge of door for invisible hinges.
- 4. \bigcirc May be reduced by 1/2" to avoid door trim.

Drill & tap and use screws provided or use mortise nuts when required.


Remove backing from self adhesive tape and use bracket as drill-through template.




3. Attach foot bracket to frame stop.



4. Assemble the spindle.





You've installed the 281 Powerglide Series Closer - Parallel Arm Mount.


Go to page 6 for closer adjustments and cover installation.

1-800-727-5477 • www.sargentlock.com

Copyright © 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.

5


A7278F 12/22 Rev 6 Experience a safer and more open world



Closer with Regular Arms

Installation Instructions

Final Adjustment and Regulating Procedure



1-800-727-5477 • www.sargentlock.com

 $\label{eq:copyright} @ 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.$

6

A7278F 12/22 Rev 6 Experience a safer and more open world



Approved 2022-12-08


Closer with Regular Arms

Installation Instructions

Using Mortise Nuts with Sargent Door Closers

NOTES:

- 1. See instruction or data sheet packed with door closer for dimensions locating the closer body and foot on door and frame.
- 2. Mortise nut shown is designed for unreinforced metal doors.
- 3. For top jamb and corner bracket applications: The door closer foot will be attached to the door in a manner similar to that shown for mounting the closer body.
- 4. For doors 2-1/4" thick: Mortise nut shown for 1-3/4" thick doors will be furnished along with appropriate length thru-bolts. Door construction must provide a bridge type reinforcement to prevent the door rail from collapsing when thru-bolts are tightened.



 $\label{eq:copyright} @ 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.$

Experience a safer and more open world

SARGENT ASSA ABLOY

Approved 2022-12-08



This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

Attention Installer: Improper installation may result in damage to the product and void the factory warranty.

1-800-727-5477 • www.sargentlock.com

Copyright © 2003, 2008, 2014, 2020, 2022, SARGENT Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of SARGENT Manufacturing Company is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.

A7278F 12/22 Rev 6

Experience a safer and more open world

