



- ⑥ — SEE TEMPLATE 4568 FOR ELECTRICAL RACEWAY DETAILS WHEN NEEDED.
- ⑤ — SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH.
- ④ — SEE MASTER SHEET No. 4019 FOR AREAS REQUIRING REINFORCEMENTS.
- ③ — SEE STRIKE TEMPLATE FOR MOUNTING LOCATION OF STRIKE.
FOR 881 MONITOR STRIKE SEE TEMPLATE 4386.
- ② — WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD.
- ① — TOLERANCE ON ALL DIMENSIONS $\pm 1/64$ ".

SARGENT Manufacturing Company 100 Sargent Drive New Haven, CT 06511	
DOOR MANUFACTURERS TEMPLATE 8504 RIM EXIT DEVICE WITH CYLINDER ONLY	RELEASE DATE 31 JAN 06
	TEMPLATE NO. 4307 G