

OUTSIDE LEVER HANDLE OR KNOB. INSERT MOUNTING POSTS THROUGH DOOR AND LOCK BODY ASSEMBLY THEN SECURE TO ADAPTER & PLATE ASSEMBLY USING (2) #8-32 SCREWS.

OUTSIDE ESCUTCHEON MOUNTING POST

O/S LOCK FRONT

OUTSIDE ESCUTCHEON

LEVER HANDLE OR KNOB MOUNTING POST

SPRING

SPINDLE

CL OF LOCK FRONT

INSIDE ESCUTCHEON. PLACE OVER ADAPTER & PLATE ASSEMBLY THEN FASTEN TO DOOR WITH TRIM SCREWS. (SEE DETAIL "S")

CL OF LOCK FRONT

#8-32UNC SCREW. TIGHTEN SECURELY TO LEVER HANDLE OR KNOB MOUNTING POST. (2 PLACES)

SPRING. INSERT INTO LEVER HANDLE OR KNOB. (BOTH SIDES)

SPINDLE. INSERT INTO LEVER HANDLE OR KNOB. (BOTH SIDES)

ADAPTER & PLATE ASSEMBLY

1 5/8" x 7 5/8" FOR LE1, KE1 AND LE3, KE3 DESIGNS.
2" x 8" FOR LW1, KW1 DESIGN.
2" x 7 7/8" FOR CE, TE DESIGN

1 51/64" REF. 6 7/8"

3 43/64"

2 3/4" REF. BACKSET

HANDLE SET SCREW. INSERT INTO INSIDE LEVER HANDLE OR KNOB AND TIGHTEN SECURELY TO ADAPTER.

CL OF LEVER HANDLE OR KNOB AND SPINDLES. 3/8" DIA. * CLEARANCE HOLE REQUIRED THRU DOOR. (2 PLACES)

OUTSIDE OF DOOR

INSIDE OF DOOR

EXPOSED SCREWS

TRIM SCREW. INSERT INTO INSIDE ESCUTCHEON AND TIGHTEN SECURELY TO OUTSIDE ESCUTCHEON MOUNTING POST. (2 PLACES)

DETAIL "S"

DOOR

INSIDE ESCUTCHEON

INSIDE LEVER HANDLE OR KNOB INSERT FULLY ONTO ADAPTER & PLATE ASSEMBLY AND SECURE WITH HANDLE SET SCREW.

③ FOR 9200, USED IN CONJUNCTION WITH TEMPLATE #4482 (LOCKBODY).

② * IMPORTANT: FOR TRIM ONE SIDE FUNCTIONS, INSIDE ESCUTCHEONS IS SURFACE APPLIED WITH (2) #8-32 COMB. SCREWS. (DO NOT APPLY TO 9200).

① FOR 7800/8200, USED IN CONJUNCTION WITH TEMPLATE #7057 (LOCKBODY).

SARGENT & COMPANY

NEW HAVEN, CONN. 06511

TEMPLATE: 7800, 8200 & 9200 MORTISE LOCK
LE1, LE3, LW1, CE AND TE
ESCUTCHEONS KE1, KE3 & KW1
(EXPOSED SCREWS)

RELEASE DATE

25 FEB 02

TEMPLT NO. 7052 E