

680F, 681F and 684F Exit Device


ACCENTRA

ASSA ABLOY


Trim

Installation Instructions


For use with 7100 Series Exit Device (Wood and Metal Doors)



680F
Offset Pull Trim
Handed - LHR Shown
(Field Reversible)



681F
Nightlatch Function
Offset Pull Trim
Handed - LHR Shown
(Field Reversible)



684F
Mortise Nightlatch Function
Offset Pull Trim
Handed - LHR Shown
(Field Reversible)

For Handing, see "Trim Assembly" on page 2.

⚠️ WARNING

This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

⚠️ WARNING

Attention Installer: Any retrofit or other field modification to a fire rated opening can potentially impact the fire rating of the opening, and ASSA ABLOY makes no representations or warranties concerning what such impact may be in any specific situation. When retrofitting any portion of an existing fire-rated opening, or specifying and installing a new fire-rated opening, please consult with a code specialist or local code official (Authority Having Jurisdiction) to ensure compliance with all applicable codes and ratings.

1-855-557-5078 Ext. 2 • www.accentra-assaabloy.com

80-8470-0680-000 04/24

Copyright © 2023,2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.



Experience a safer
and more open world

Trim Assembly**1. Check cylinder components.**

Note: Refer to ASSA ABLOY cylinder chart in catalog for collar sizing.

2. Assemble cylinder.


- Insert cylinder housing prongs into matching notches of escutcheon. Pass cylinder tailpiece thru cylinder collar (when required) and hole in cylinder housing.
- Fasten cylinder using (2) mounting screws. DO NOT OVERTIGHTEN SCREWS.

681F**Nightlatch Function
Offset Pull Trim****684F****Mortise Nightlatch Function
Offset Pull Trim**

680F, 681F and 684F Exit Device

Trim

Installation Instructions



ACCENTRA

ASSA ABLOY

TRIM	HOLES
680F	X
681F	A, B, X
684F	C, X
For Holes Marked X See Below	
METAL DOORS	
Inside Face: 5/16" (8) Dia.	
Outside Face: 1/2" (13) Dia.	
WOOD DOORS	
1/2" (13) Dia. Thru	


Dimensions given in Inches
(mm)

⚠ Caution: Office copiers and facsimile machines may change the size of a drawing and make the template inaccurate to use as a door marker. If this is not the original template packed with the trim, use only the holes on the door (do not use template as a door marker).


CUT LINE

Installation Instructions

1. Check box for contents. See page 2 for components.
2. After marking door inside face for device location (Device Instructions), transfer Vertical Reference Centerline from inside to outside door face. Follow steps a and b below.



a. MEASURE INSIDE LINE LOCATION.



b. TRANSFER DIMENSION TO OUTSIDE FACE.

3. Transfer Horizontal Reference Centerline from inside to outside door face.
4. Align trim template and tape to outside door face.

Figure 1

Device is bolted to trim using holes A (closest to door lock edge)





Figure 3

684F Mortise Cylinder Installation




1-855-557-5078 Ext. 2 • www.accentra-assaabloy.com

Copyright © 2023,2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

5. Spot holes and prepare door for trim.
6. Mount trim to door thru holes B. Fasten finger tight only with (2) screws and washers seating on door as shown in Figure 1.
7. Continue according to trim type:
 - **For 681F Nighthatch Trim:** Cut trim tailpiece as shown in Figure 2. Seat device so that the trim tailpiece penetrates cam slot as shown in Figure 1.
 - **For 684F Mortise Nighthatch Trim:** Insert and thread cylinder into Mortise Lock until seated within escutcheon recess with keyway positioned vertically and with plug in lower cylinder as shown in Figure 3. Tighten cylinder locking screw thru mortise lock front.
8. Continue as shown in device instructions.

Figure 2

681F Nightlatch Tailpiece Sizing



Note: Measure from device mounting surface (door face or shim surface)

Experience a safer
and more open world