



#### Frame Preparation

##### NOTES:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR active pair shown. Preparation is typical for both hands.
4. Minimum door stile width 4-1/2" (114).
5. Prepare mounting holes when installing the device.
6. Lock support by door manufacturer.
7. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components.
8. Holes for optional SNB: 9/32" (7.00) dia. inside door face; 3/8" (9.50) dia. outside door face

#### Door Preparation

9. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.
10. For outside trim preparation see appropriate trim template.
11. Unless otherwise specified, door preparation and dimensional tolerances must conform to ANSI A115.1.
12. Dimensions given about a centerline are symmetrical.
13. Latchbolt centerline is 23/32" (18.2) below & Auxbolt centerline is 3/16" (4.8) above the centerline of lockfront.
14. For electrical device suffixes "SAFE" or "SECURE" also see template 7477-0001.

**RESPONSIBILITY**  
 DOOR AND FRAME MANUFACTURERS ARE  
 RESPONSIBLE FOR PROVIDING ADEQUATE  
 CONSTRUCTION OR REINFORCEMENTS FOR  
 PROPER INSTALLATION OF HARDWARE SHOWN.  
 ALL ARCHITECTURAL BUILDERS HARDWARE MUST  
 BE INSTALLED ON PROPERLY REINFORCED  
 DOORS AND FRAMES, REGARDLESS OF TYPE,  
 MATERIAL, OR METHOD OF CONSTRUCTION.

**1530 and 1530F Mortise Exit Devices  
 with ANSI A115.1 Strike**  
 Application to Pair of Metal Doors without Mullion  
 1-855-557-5078 Ext. 2  
[www.accentra-assaabloy.com](http://www.accentra-assaabloy.com)

Experience a safer  
 and more open world

Copyright © 1999, 2023, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc.  
 All rights reserved. Reproduction in whole or in part without the express written  
 permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

**ACCENTRA**  
**ASSA ABLOY**