

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

2100 & 1800 Rim Panic Exit Devices with 757 Strike

Application for Wood or Composite Door and H.M. Frame or Mullion (Not for Fire Labeled Devices) 1-855-557-5078 Ext. 2 www.accentra-assaabloy.com

ACCENTRA ASSA ABLOY

SUPERSEDES

DO NOT SCALE DRAWING

Experience a safer and more open world Copyright © 2010, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

04/10 TEMPLATE NUMBER SHFFT 1 of 1 7421-1000

04/24