

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

2100F & 1800F Rim Fire Exit Devices With 757F Strike

Application for Fire Labeled Wood or Composite Door and H.M. Frame or Mullion 1-855-557-5078 Ext. 2 www.accentra-assaabloy.com

ACCENTRA ASSA ABLOY

Experience a safer and more open world Copyright © 2010, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES 04/10

DO NOT SCALE DRAWING TEMPLATE NUMBER SHFFT

7421-1002 1 of 1

04/24