

CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

Experience a safer and more open world Copyright © 2010, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

with 790 Floor Strike

1-855-557-5078 Ext. 2

www.accentra-assaabloy.com

ASSA ABLOY

SHEET

1 of 1

4/10

DO NOT SCALE DRAWING

DATE

04/24

SUPERSEDES

TEMPLATE NUMBER

7421-0010