



Notes:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. Minimum Stile Width: 2 (51).
4. Maximum door Width: 42 (1067)
5. Prepare mounting holes when installing the hardware.
6. For recommended door reinforcements see template 7400-0000.
Unreinforced doors require SNB option to mount the hardware
7. Holes for optional SNB: 9/32 (7.00) Dia. Inside door face;
3/8 (9.50) Dia. Outside door face.
8. Provide door stiffeners as needed to prevent door collapse due to installation with power tools, door use, or abuse.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

620DB & 720DB Dummy Push Bar
Application for Metal Door

1-855-557-5078 Ext. 2
www.accentra-assaabloy.com

ACCENTRA
ASSA ABLOY

Experience a safer
and more open world

Copyright © 1999, 2015, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES 7470-0720 01/24

DO NOT SCALE DRAWING

TEMPLATE NUMBER

7470-0720

SHEET

1 of 1

DATE

05/24